

ADXL288 and ADXL295 Evaluation Systems

FEATURES

Flexible inertial sensor evaluation platform
 Main board operates with interchangeable satellite boards
 or breakout boards
 Separates device under test (DUT) from controller for
 accurate environmental testing
 Facilitates dynamic testing
 Full speed data sampling @ 2 kHz
 Continuous stream to file data recording
 Standard USB cable for power and communications
 PC-based graphical user interface (GUI)
 Fast, easy installation

EVALUATION KIT CONTENTS

Inertial sensor evaluation board (ISEB)
 Breakout board ([ADXL288](#) or [ADXL295](#))
 Interconnect Board
 USB A to Mini-B cable
 18-inch, 20-pin ribbon cable
 18-inch, 10-pin cable
 CD with drivers and installers

GENERAL DESCRIPTION

The [ADXL288](#) and [ADXL295](#) inertial sensor evaluation system is an easy-to-use evaluation tool targeting bench or desktop characterization of Analog Devices, Inc., inertial sensor products. The system consists of the inertial sensor evaluation board (ISEB), or main board, and either a satellite board or breakout board for testing the Analog Devices inertial sensor component. Although the included test PCBs can vary, interoperability is maintained across all ISEB kits.

The ISEB connects directly to a PC via a USB cable, with the USB connection providing both power and communications to the board. The ISEB connects to a satellite board through an included ribbon cable. For evaluation systems where a breakout board is included, an additional 10-pin cable and interconnect board facilitate connection of the breakout board to the ISEB. This setup allows the inertial sensor component to be easily manipulated for testing or to be separately placed into an environmental chamber for temperature or humidity testing.

INERTIAL SENSOR EVALUATION SYSTEM



Figure 1.

11906-001

Separating the boards mitigates corruption of data due to the temperature and humidity effects of other components.

The ISEB is a universal main board and can be used with various satellites of Analog Devices inertial sensors, including analog and digital accelerometers and gyroscopes. The different products are evaluated by means of separate GUIs that are customized for performance and characterization measurements relevant to the inertial sensor being evaluated.

Refer to the Evaluation Kit Contents section for a complete listing of the hardware included in the EVAL-ADXL295Z-M kit. A CD is included with the necessary drivers and installers to use the system and to quickly begin evaluating the [ADXL288](#) or [ADXL295](#).

TABLE OF CONTENTS

Features	1	How to Use the Inertial Sensor Evaluation System GUI.....	9
Evaluation Kit Contents.....	1	Getting Started.....	9
Inertial Sensor Evaluation System.....	1	Configuration Tab (Phase 3).....	10
General Description	1	View/Record Data (Phase 4).....	12
Revision History	2	Arming Pin Functional Test (Phase 4)	13
Getting Started	3	Temperature Test Panel (Phase 4)	14
Installation Procedure.....	3	Troubleshooting Tips	15
Inertial Sensor Evaluation System Setup.....	3	Header Pinout	16
Evaluation Board Hardware	8	Related Links	16
Hardware Configuration	8		

REVISION HISTORY

3/14—Revision 0: Initial Version

GETTING STARTED

INSTALLATION PROCEDURE

The included CD contains all of the software necessary to install the complete inertial sensor evaluation system. Refer to the included ReadMe file for the proper installation procedure. Device drivers, LabVIEW® run-time environments, and the [ADXL288](#) and [ADXL295](#) evaluation GUI must all be installed. After the device drivers and run-time environments are installed, this process does not need to be repeated for any future ISEB evaluation kit purchase.

Each installation routine is described in this user guide and should be performed in the following order.

1. Download the **USB Drivers, LabVIEW Run Time Installation**, and **ADXL288 - ADXL295** folders to the PC hard drive. (See the Download Files section.)
2. Install the USB drivers for the ISEB. (See the ISEB Hardware Setup section.)
3. Install the included LabVIEW run-time environment. (See the Installing the LabVIEW Run Time Environment section.)
4. Install the [ADXL288](#) and [ADXL295](#) evaluation system GUI. (See the ADXL288 and ADXL295 Software Evaluation GUI section.)
5. Configure the ISEB hardware. (See the Hardware Configuration section.)
6. Launch the [ADXL288](#) and [ADXL295](#) evaluation system GUI and test devices. (See the How to Use the Inertial Sensor Evaluation System GUI section.)

This user guide provides all the details necessary to install and operate the [ADXL288](#) and [ADXL295](#) evaluation system.

INERTIAL SENSOR EVALUATION SYSTEM SETUP

Download Files

Before proceeding with the installation routine, download the **ADXL288 - ADXL295, USB Drivers**, and **LabVIEW Run Time Installation** folders (located on the included CD) to a local folder on the target PC. This can be completed as follows:

1. Browse to a destination directory on the host PC.
2. Right-click to select **New > Folder**.
3. Name this folder and copy the CD files into this new location.

ISEB Hardware Setup

Before connecting the ISEB hardware to the PC, drivers must be installed so that the PC properly recognizes the ISEB main board. The USB drivers for the ISEB are available in the **USB Drivers** folder.

Installing the USB Drivers for the ISEB

To install the USB drivers, take the following steps:

1. Execute the **ADI_ISEB_USB_Drivers.exe** file located in **USB Drivers**.
2. Follow the on-screen instructions to install the drivers.
3. Click **Continue Anyway** when prompted that the drivers are not tested.

Next, connect the ISEB main board to the computer via the included USB cable. If the previously installed drivers are not automatically associated with the device, select the drivers manually, as follows:

1. Connect the USB A to Mini-B cable to the PC and then to the ISEB. When the ISEB board is connected, the **Found New Hardware Wizard** window appears.
2. If prompted to install drivers, click **Install from a list or specific location (Advanced)** and click **Next** (see Figure 2).



Figure 2. Found New Hardware Prompt

3. Select **Don't search. I will choose the driver to install** and click **Next** (see Figure 3).




Figure 3. Selection of the Driver to Install

4. Select **ADI Inertial Sensor Evaluation System** from the model list and click **Next** to complete the process (see Figure 4).




Figure 4. Selection of the ADI Inertial Sensor Evaluation System Drivers

The ISEB should be detected automatically in the **Device Manager** as **ADI Inertial Sensor Evaluation System** under the **Ports (COM & LPT)** selection. It is recommended to open the **Device Manager** to verify hardware detection and to record the communication port associated with the ISEB for use in the GUI.

COM Port Verification

Installing different firmware revisions, as well as operating the **ADXL288** and **ADXL295** evaluation GUI, requires that the user know the COM port that is assigned to the ISEB main board. With the ISEB main board connected to the PC, perform the following steps to determine the assigned COM port number.

For Windows® Vista/7,

1. From the **Start** menu, right-click **Computer** and select **Properties**. The window shown in Figure 5 opens.
2. Underneath **Tasks**, select **Device Manager**. Windows Vista may request that the user allow access to this panel, and administrative privileges may also be required. The window shown in Figure 6 opens.
3. Expand the **Ports (COM & LPT)** folder. The **ADI Inertial Sensor Evaluation System** should be listed with an assigned COM port number in parenthesis.
4. Note the COM port number for future use.




Figure 5. Computer Properties




Figure 6. Device Manager Showing the COM Port Number

For Windows XP/2000,

1. From the **Start** menu, right-click **My Computer** and select **Properties**.
2. Click the **Hardware** tab of the **System Properties** window (see Figure 7).
3. Click **Device Manager** to look up the assigned COM port of the ISEB hardware.
The **Device Manager** window should look like the window shown in Figure 6.




Figure 7. System Properties

Installing Other ISEB Firmware Revisions

The ISEB evaluation system is designed to allow maximum flexibility for the user. Interchangeable satellite and breakout boards are designed to operate with the same ISEB main board. When transitioning between satellite/breakout boards, it may be necessary to install a different firmware revision onto the main board. A utility has been included to allow for quick and easy flashing of the appropriate firmware, and the latest firmware revisions are included on the installation CD, located in the **Firmware Utility** folder.

The **ADI_ISEB_FW_XL288_XL295.hex** file should already be installed on the ISEB main board. To flash the ISEB microcontroller with new firmware, follow these steps:

1. Ensure that the ISEB is connected to and detected by the PC. The COM port on which the device is recognized must also be known, as mentioned in the COM Port Verification section.
2. Run the **ARMWSD.exe** program located in the **Firmware Utility** folder; it displays information about the downloader, see Figure 8.




Figure 8. ISEB ARMWSD Firmware Downloader

3. Click **Browse** and select the firmware associated with the desired product. Each firmware file is named according to the products that it supports.
4. Click **Configure** to display the window shown in Figure 9.

Configure the downloader file for the **ADuC7026** microcontroller. The only option that may need adjusting is the COM port. The user can select the correct port from the **Serial Port** box on the **Comms** tab (see Figure 9).




Figure 9. Selecting the Correct COM Port for the Downloader

When the COM port is selected, click **OK** to accept the changes and go back to the ARMWSD window (see Figure 8). The downloader is now fully configured.

Follow these steps to flash the firmware:

1. Click **Start** in the ARMWSD box (see Figure 8) to initiate the flashing process.
2. Press the two buttons (shown in Figure 10) on the ISEB in the following order to flash the firmware:
 - a. Press and hold down **SW1**.
 - b. With **SW1** held down, press and release **SW2**.
 - c. Release **SW1**.
3. The download begins and is automatically verified by the downloader.




Figure 10. ISEB Switch Locations for Flashing the Microcontroller

4. If the downloading process fails, which is indicated in the **Monitor Status** window (see Figure 8), attempt the download again by repeating Step 1 through Step 3.
5. After the download has completed successfully, click **Run** (shown in Figure 8).

The **ADI_ISEB_FW_XL288_XL295.hex** firmware has been developed for specific operation with the **ADXL288** or **ADXL295** satellite board. To use the ISEB main board with any other satellite board, simply locate the other device's firmware on the included installation CD and flash it onto the ISEB main board. This allows operation with that device's evaluation GUI.

Installing the LabVIEW Run Time Environment

Located in the **LabVIEW Run Time Installation** folder on the CD is an executable file designed to install the LabVIEW environment packages required for operation of the various product GUIs. To begin the installation process, double-click the **LabVIEW Run Time Install.exe** file (see Figure 11). Follow the on-screen prompts to successfully install the necessary LabVIEW components.




Figure 11. LabVIEW Run Time Environments Installation

ADXL288 and ADXL295 Software Evaluation GUI

To run the software GUI installation, double-click the **setup.exe** file located in the **ADXL288 - ADXL295 > Software** folder on the included CD. The window shown in Figure 12 appears.

Complete the following steps to install the evaluation software:

1. Select the **Destination Directory** (see Figure 13). It is recommended to keep the default settings for these fields.
2. Click **Next**. The **License Agreement** window then appears/opens.
3. Read the **National Instruments Software License Agreement**. Choose **I accept the License Agreement(s)**, and then click **Next**. The installer then lists the required components to be installed on the PC (see Figure 14).
4. Click **Next** to start the installation.
5. Click **Finish** to complete the installation.




Figure 12. ADXL288 and ADXL295 Evaluation Software Installation Welcome




Figure 13. Destination Directory Selection




Figure 14. Start Installation (Listing Varies Based on PC Requirements)

EVALUATION BOARD HARDWARE

HARDWARE CONFIGURATION

Connect the [ADXL288](#) and [ADXL295](#) evaluation system as demonstrated in Figure 15. The USB A to Mini-B cable is used to connect the ISEB motherboard to a Windows®-based PC. The 20-pin ribbon cable connects the ISEB motherboard to the included interconnect board. The interconnect board takes the necessary I/Os from the 20-pin ribbon cable and passes a subset of them to the included [ADXL288](#) or [ADXL295](#) breakout board. All of the included cables are keyed such that improper connection of the boards is avoided.

To ensure that the [ADXL288](#) and [ADXL295](#) evaluation system is properly enabled, the following process is recommended:

1. Ensure that the [ADI_ISEB_FW_XL288_XL295.hex](#) firmware file has been previously loaded onto the ISEB motherboard.
This process should be completed without the [ADXL288](#) or [ADXL295](#) breakout board attached.
2. Connect the [ADXL288](#) or [ADXL295](#) breakout board to the adaptor board with the included 10-pin cable.
3. Connect the adaptor board to the ISEB motherboard with the included 20-pin ribbon cable.
4. Connect the ISEB main board to a Windows-based PC with the included USB A to Mini-B cable.
5. After observing the green LED on the ISEB motherboard turn on, launch the [ADXL288_ADXL295_Eval](#) GUI from the **Start** menu.




Figure 15. ISEB Kit Connections

11906-015

HOW TO USE THE INERTIAL SENSOR EVALUATION SYSTEM GUI

GETTING STARTED

As part of the installation routine, a **Start** menu item is created that launches the [ADXL288](#) and [ADXL295](#) Evaluation GUI. Click the executable, located at **Start > All Programs > Analog Devices – Inertial Sensor Eval > ADXL288 - ADXL295 Evaluation Software > ADXL288_ADXL295 Eval**.

When opened, you will see the window shown in Figure 16. All functionality is disabled until the correct device type and COM port selection is complete. As the SPI format is different for the [ADXL288](#) and [ADXL195/ADXL295](#) devices, it is important to

select the correct device type to ensure proper operation. To do so, use the following instructions:

1. From the drop-down menu, select the device type that corresponds to the DUT mounted on the breakout board.
2. Select the COM port assigned to the ISEB evaluation board. Refer to the COM Port Verification section for the procedure to verify the COM port assignment.
3. Ensure that a reasonable COM port value (<10) has been assigned to the ISEB hardware. The software does not interact properly with excessively high COM port values.




Figure 16. COM Port Selection

11908-016

CONFIGURATION TAB (PHASE 3)

When the [ADXL288](#) or [ADXL295](#) device is first powered on, it will not immediately proceed into run-time operation. The device proceeds through its start-up sequence, remaining in Phase 3 until the end of initialization command is provided by the master device.

During Phase 3, the following actions are available in the **Configure Device** tab:

- The arming thresholds can be set.
- The auto zero configuration can be adjusted.
- The electromechanical self test can be activated, such that the acceleration output delta can be measured.

Once the device enters Phase 4, these settings can no longer be configured. However, the device can be returned to Phase 3 at any time by issuing a soft reset command. All of this functionality is readily available through the [ADXL288](#) and [ADXL295](#) evaluation GUI.

Upon selecting the device type, the pop-up window will close, and you will be presented with the screen shown in Figure 17. An initial read of all device registers is performed at this point, populating the register memory map shown at the right side of the GUI window. The memory map should look similar to the contents presented in Figure 17; however, there will be noticeable differences due to device variations, such as different serial numbers or revision IDs. Memory Address 0x08 can be used to verify a correct read of the memory map. For a single-axis device ([ADXL195](#)), Register 0x08 reads 0x1C. For a dual-axis device ([ADXL288](#) and [ADXL295](#)), Register 0x08 reads 0x2C.




Figure 17. Configuration Panel Initial Conditions

Arming Threshold Configuration

All variants of the [ADXL288](#) and [ADXL295](#) devices allow you to configure the arming thresholds (see Figure 18). If, internal to the [ADXL288](#) or [ADXL295](#) device, an acceleration data point exceeds the specified arming threshold, the associated arming

pin (ARM_X or ARM_Y) will assert. For more information, refer to the [ADXL288](#) or [ADXL295](#) data sheet.

When viewing acceleration data in the **Configure Device** tab, if the ARM_X or ARM_Y pin is observed to assert either positively or negatively, the LED indicators will turn-on.




Figure 18. Arming Pin Configurations

Self Test Enable

Phase 3 represents the only opportunity for activating the electromechanical self test. Activating this feature induces an electrostatic force onto the mechanical structure, resulting in a dc deflection of the movable sense element. The offset delta, pre and post self test activation, indicates the success of the self test routine. To activate self test, check the appropriate box in the **Self Test Enable** control box (see Figure 19). This enables the device self test, and the memory map updates to reflect this status change. Then, press the **View XL/HF Data** button in the **XL/HF Channel Self Test Values and Auto Zero** control box.



Figure 19. Self Test Control




Figure 20. Acceleration Data with Self Test Off and On

Auto Zero

During Phase 3, the auto zero functionality can be switched between fast and slow auto zero (see Figure 21). This allows you to understand the differences between the two routines, and the speed with which they correct for offset. The auto zero functionality can also be disabled entirely.

To set the mode of auto zero, simply select either the **FAST** or **SLOW** option from the radio button menu, and press the **SET** button. The next time the **View XL/HF Data** button is pressed, the data presented will conform to the selected auto zero mode.

When the **End of Initialization** command is issued, and the device transitions to Phase 4, the auto zero mode will be automatically configured to slow auto zero. If auto zero was disabled during Phase 3, it will remain disabled during Phase 4.



Figure 21. Auto Zero Enable/Disable

View XL/HF Data

While Phase 3 is not the primary phase for viewing acceleration data, the **Configure Device** tab does allow limited capability in this regard. Press the **View XL/HF Data** button to see the HF channel and acceleration channel data output to their respective waveform graphs.

To properly view the device self test response, use the following method:

1. Press **View XL/HF Data**.
2. Press **Stop Data View**.
3. Enable either the XL channel or HF channel self test (they cannot be activated simultaneously).
4. Press **View XL/HF Data**.
5. Press **Stop Data View** to capture the self test delta in the waveform graph window.

This results in the behavior shown in Figure 22. The self test delta can now be measured and compared to the X, Y, or HF self test expected value. These values are stored in Register 0x0E, Register 0x0F, and Register 0x10 for the X, Y, and HF channels, respectively. For convenience, these values are also presented in the numeric indicator boxes in between the XL and HF channel waveform graphs.




Figure 22. Self Test Behavior

End Of Initialization

Once the desired settings have been configured, the end of initialization command can be issued to the device to lock in the chosen settings, and proceed to Phase 4. Press the **End of Initialization** button, and the GUI will transition the device into Phase 4 (see Figure 23). At this point, the functionality of the **View/Record Data**, **Arming Pin Functional Test**, and **Temperature Test** tabs will become available.




Figure 23. End Of Initialization

VIEW/RECORD DATA (PHASE 4)

The **View/Record Data** tab is one of the tabs for reading/recording data from the [ADXL288](#) or [ADXL295](#) device. While you can return to the **Configure Device** tab at any time to perform a read of the memory registers, you will not be able to alter any of the device settings unless you press the **RESET** button, found in the lower left corner of any of the Phase 4 tabs.

Once in Phase 4, the auto zero will be configured to slow mode (unless it was disabled), self test will be disabled, and the arming thresholds will be frozen based on their values during Phase 3. Before any action is taken, the evaluation GUI should resemble the image shown in Figure 24.




Figure 24. View/Record Data Panel

The drop-down menu located on the left side of the GUI is the primary method for controlling the data view and record operations. The options will change depending upon the device type which was initially selected ([ADXL288](#), [ADXL195](#), or [ADXL295](#)). The following four sections show all options.

View XL Channel Data

This option is presented for [ADXL288](#) devices. When selected, the XL channel data is collected and displayed on the waveform graph. The SPI message header bits are presented to the right of the waveform graph (see Figure 25). Lastly, a status register read is performed with every acceleration read, and the results are presented in the LED indicator array, at the left side of the GUI.




Figure 25. View XL Channel Data

View XL and HF Channel Data

This option is presented for [ADXL195](#) and [ADXL295](#) devices. The functionality is exactly the same as in the View XL Channel Data section; however, this option includes the HF channel data.

Record XL Channel Data

This option is presented for [ADXL288](#) devices. This option performs a stream to file of all data presented in the front panel. This includes the acceleration data, SPI message header bits, X and Y auto zero offset value, and the status register. Data is written to file continuously, until the **Stop Data View** button is pressed. As the data rate is approximately 2 kHz, be careful to limit the data record time, or the data file may become unmanageably large.

Record XL and HF Channel Data

This option is presented for the [ADXL195](#) or [ADXL295](#) device. All of the same information, as described in the Record XL Channel Data section, is streamed to a data file, with the addition of the HF channel and associated SPI message bits.

When selecting either of the record options shown in the Record XL Channel Data and Record XL and HF Channel Data sections, you will be presented with a file dialog, which allows you to create a new file, or overwrite an existing file. To ensure proper file format, the *.txt file extension should be written onto the file name manually (see Figure 26).




Figure 26. Create or Overwrite File Dialog

If you decide to cancel the data record at this point, the following message will be presented:




Figure 27. Record Data Cancel

Upon confirming the file dialog, the **View/Record Data** tab will revert to its initial conditions, and you can continue to use the GUI without interruption.

ARMING PIN FUNCTIONAL TEST (PHASE 4)

As mentioned previously, [ADXL288](#) and [ADXL295](#) devices have two separate arming pins which can be used to alert the master device when the acceleration data exceeds a specified threshold. The value of these thresholds can be set independently for each axis, as well as independently for positive and negative acceleration. Upon initial entry to the **Arming Pin Functional Test** tab, you should see the screen shown in Figure 28. XL channel data will be presented in the top graph, HF channel data presented in the middle graph, and the state of the arming pin(s) presented in the lower graph.




Figure 28. Arming Pin Functional Test Panel

If the arming thresholds are not configured, that is, set to 0 g, then the default value of the arming pins will be 0 V (GND). Once an arming threshold is set, the behavior of the arming pin will change, such that the nominal value is now $V_{DD}/2$. If the acceleration is measured to exceed the positive arming threshold, then the arming pin output changes from $V_{DD}/2$ to $0.95 \times V_{DD}$. If the negative arming threshold is exceeded, the arming pin output changes from $V_{DD}/2$ to $0.05 \times V_{DD}$. The arming pin does not latch for any longer than is required to analyze a subsequent acceleration data point (62.5 μ s).

When the **View All** button is pressed, the XL channel, HF channel, if appropriate, and arming pin outputs are plotted simultaneously. Figure 29 shows an example where the positive and negative arming thresholds have been set to a low value of 1 g. This allows the thresholds to be exceeded by a simple shake of the device, resulting in the arming pin to assert both positively and negatively, in line with the acceleration data.




Figure 29. Arming Pin Output

Recording data is functionally identical to the **View/Record Data** tab. Upon pressing the **Record All** button, a file dialog will be presented (see Figure 26), and if you decide to cancel this procedure, a confirmation message will be presented as shown in Figure 27. All data presented in the front tab (XL channel, HF channel, arming pin outputs, and the status register) will be streamed to a file at the same data rate which they are presented on the screen.

TEMPERATURE TEST PANEL (PHASE 4)

As part of most sensor evaluations, it is desired to know the offset drift characteristic over temperature. As this style testing typically takes an hour or more, the 2 kHz data rate of the other test tabs will aggregate too much data to be manageable by most software tools. The **Temperature Test** tab is designed to significantly reduce the bandwidth and data rate of the [ADXL288](#) or [ADXL295](#) device through oversampling and averaging. For this panel, a 2 kHz sample rate is used to retrieve data from the device; however, each data point placed on the graph is an average of 400 samples. This results in an output data rate of roughly 5 Hz.

Figure 30 shows the **Temperature Test** tab, as it is first presented. Both the XL channel and HF channel are represented on this tab. Additionally, the auto zero offset for each axis is presented. Therefore, even if the auto zero routine is enabled, you can still understand the performance of the offset by monitoring the auto zero offset value.

The status register is read with every XL channel and HF channel data read. To indicate whether a failure has occurred at any time over the course of sampling those 400 data points, the status register is continuously OR'd with every new data read. Therefore, although the status register is only updated at 5 Hz, it will indicate any and all errors which were observed over the entire 400 sample averaging period.




Figure 30. Temperature Test Panel

Again, data recording is functionally equivalent to the other test panels. Upon pressing the **Record All** button, a file dialog will be presented (see Figure 26), and if you decide to cancel this procedure a confirmation message will be presented as shown in Figure 27. All data presented in the front panel (XL channel, HF channel, auto zero values and the status register) will be streamed to a file at the same data rate which they are presented on the screen.

TROUBLESHOOTING TIPS

The following tips are helpful for ensuring proper operation of the ISEB evaluation system, as well as recovery from any potential software/hardware errors.

- Connect the ISEB to the PC in this order:
 1. Connect the satellite board to the main board (ribbon cable).
 2. Connect the main board to the PC (USB cable).
 3. Start the evaluation GUI on the PC by clicking: **Start > All Programs > Analog Devices – Inertial Sensor Eval > ADXL288 - ADXL295 Evaluation Software > ADXL288_ADXL295 Eval.**
- Make sure that the proper firmware is loaded onto the microcontroller (the software may appear to freeze if this step has not been completed). **ADI_ISEB_FW_XL288_XL295.hex** is required for proper operation of this evaluation system.
- Only press the reset button (SW2) when new firmware is being flashed onto the microcontroller. There is no other intended use for this button.
- Ensure that a low COM port number (<10) has been assigned to the ISEB. The software does not properly recognize excessively high COM port values.
- To properly reset the evaluation system, take the following steps:
 1. Exit the [ADXL288](#) and [ADXL295](#) evaluation software.
 2. Disconnect the ISEB (unplug the USB cable from the PC).
 3. Reconnect the ISEB.
 4. Restart the [ADXL288](#) and [ADXL295](#) evaluation software.

HEADER PINOUT




Figure 31. ISEB 20-Pin Header Pinout

RELATED LINKS

Resource	Description
ADXL288	Product Page, High Performance, Dual-Axis Digital Output Accelerometer
ADXL295	Product Page, Dual-Axis High Performance Accelerometer with Dual Spectrum Signal Processing
ADXL195	Product Page, Single-Axis High Performance Accelerometer with Dual Spectrum Signal Processing
ADuC7026	Product Page, Precision Analog Microcontroller, 12-Bit Analog I/O ARM7 TDMI MCU



ESD Caution

ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.