


Ballantine



**MODEL 6127A
PROGRAMMABLE
OSCILLOSCOPE
CALIBRATOR
VOL. 1**

INSTRUCTION MANUAL

MODEL 6127A PROGRAMMABLE OSCILLOSCOPE CALIBRATOR VOL. 1

Ballantine Laboratories, Inc. P.O. Box 97 Boonton, New Jersey 07005 U.S.A.
Telephone: 201-335-0900 TWX: 710-987-8380

WARRANTY

This Ballantine Laboratories, Inc. product is warranted against defects in materials and workmanship for a period of one year from the date of shipment, except for batteries, electron tubes, vacuum thermocouples, and certain other components, if any, listed in this manual. Ballantine Laboratories, Inc. will, at its option, repair or replace products which prove to be defective during the warranty period provided they are returned to Ballantine Laboratories, Inc. prepaid, and provided the proper preventive maintenance and calibration procedures as listed in this manual have been followed. Repairs necessitated by misuse of the product are not covered by this warranty. NO OTHER WARRANTIES ARE EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. BALLANTINE LABORATORIES, INC. IS NOT LIABLE FOR CONSEQUENTIAL DAMAGES.

CERTIFICATION

Ballantine Laboratories, Inc. certifies that this equipment meets all applicable Ballantine specifications at time of shipment from the factory as determined by thorough testing and inspection. Ballantine further certifies that its measurements are traceable to the United States National Bureau of Standards. All instruments used in calibrating Ballantine products are standardized by systematic reference to NBS-traceable standards as described in the validation procedures shown below.




TABLE OF CONTENTS

PARAGRAPH	PAGE	PARAGRAPH	PAGE
SECTION 1. GENERAL INFORMATION			
1-1.	1-1	3-20.	3-15
1-3.	1-1	3-22.	3-15
1-6.	1-1	3-24.	3-15
1-13.	1-3	3-25.	3-17
SECTION 2. PREPARATION FOR USE AND SHIPMENT			
2-1.	2-1	3-27.	3-20
2-3.	2-1	3-29.	3-20
2-5.	2-1	3-30.	3-20
2-7.	2-1	3-31.	3-21
2-10.	2-2	3-33.	3-22
2-13.	2-2	3-35.	3-22
2-18.	2-4	3-36.	3-22
2-20.	2-4	3-37.	3-25
2-22.	2-4	3-43.	3-26
SECTION 3. OPERATION			
3-1.	3-1	3-46.	3-27
3-3.	3-1	3-48.	3-27
3-5.	3-1	3-50.	3-28
3-8.	3-1	3-53.	3-30
3-9.	3-1	3-54.	3-30
3-10.	3-10	3-55.	3-32
3-11.	3-11	NOTE	
3-12.	3-11	The following sections and information is contained in Volume 2 of this Manual.	
3-13.	3-12	SECTION 4	4-1
3-14.	3-13	SECTION 5	5-1
3-15.	3-14	SECTION 6	6-1
3-17.	3-14		

LIST OF ILLUSTRATIONS
VOLUME I

NUMBER	PAGE	NUMBER	PAGE
1-1.	Model 6127A Programmable Oscilloscope Calibrator	1-0	
2-1.	Voltage Selection and Fused Receptacle	2-1	
2-2.	Portable Outline Dimensions	2-2	
2-3.	Rack Mount Outline Dimensions	2-3	
2-4.	Model 6127A Packing Diagram	2-5	
3-1.	Model 6127A Front Panel Controls, Indicators and Connectors	3-2	
3-2.	Model 61271A Connectors	3-7	
3-3.	Model 61272A Indicators & Connectors	3-7	
3-4.	Model 6127A Rear Panel Controls and Connectors	3-8	
3-5.	Volts/Div Measurement, Equipment Set-Up	3-9	
3-6.	Milliamperes/Div Mode, Equipment Set-Up	3-10	
3-7.	Time/Div, Fast Rise Pulse & Low Distortion Pulse Modes, Equipment Set-Up	3-12	
3-8.	Calibrator Mode, Equipment Set-Up	3-14	
3-9.	Typical GPIB System	3-16	
3-10.	Model 6127A Address Switch	3-17	
3-11.	General Talker/Listener Program for the 6127A	3-21	
3-12.	Volts/Div Mode, Equipment Set-Up	3-22	
3-13.	Volts/Div Display; 1 V, 5 Div	3-24	
3-14a.	Model 6127A/61271A 50 Ω Source/50 Ω Load Condition	3-26	
3-14b.	Model 6127A/61271A 50 Ω Source/High Impedance Load Condition	3-26	
3-15.	Volts/Div Display; 10 μ V, 5 Div	3-27	
3-16.	Time/Div Display, 1 ms Markers	3-27	
3-17.	Time/Div Display, 1 ns Markers	3-28	
3-18.	Time/Div Display, 500 ps Markers	3-28	
3-19.	Time/Div Mode, Test Set-Up	3-29	
3-20.	Fast Rise Pulse Display, 200 ps Rise Time	3-29	
3-21.	Fast Rise Pulse Checks, Equipment Set-Up	3-30	
3-22.	Amplitude Comparator Equipment Set-Up	3-31	

LIST OF TABLES
VOLUME I

NUMBER	PAGE	NUMBER	PAGE
2-1.	Safety Considerations	2-6	
3-1.	Model 6127A Front Panel Controls, Indicators and Connectors	3-3	
3-2.	Model 61271A Connectors	3-7	
3-3.	Model 61272A Indicators and Connectors	3-7	
3-4.	Model 6127A Rear Panel Controls and Connectors	3-8	
3-5.	6127A VOLTS/DIV Mode Valid Entries	3-9	
3-6.	6127A Milliamperes/Div Mode Valid Entries	3-11	
3-7.	Low Distortion Pulse Mode Valid Entries	3-13	
3-8.	6127A IEEE-488 Interface Connector (J1)	3-15	
3-9.	Address Switch Conversion Table	3-17	
3-10.	6127A Programming Information	3-18	
3-11.	Model 6127A Operating Hints	3-23	
3-12.	Model 6127A VOLTS/DIV Output Resistance and Loading Error.	3-25	
3-13.	Representative True Errors of UUT Internal Calibrator	3-33	




Figure 1-1. Model 6127A Programmable Oscilloscope Calibrator

SECTION 1
GENERAL INFORMATION

1-1. INTRODUCTION

1-2. The Ballantine Model 6127A Programmable Oscilloscope Calibrator is a compact Test Set intended for calibration and maintenance of oscilloscopes. It may be operated in both Manual mode (Local) or Programmable mode (Remote) being compatible with IEEE 488 Standard bus. The 6127A embodies the concept of a Modularly Equipped and Configured Calibrator/Analyzer (MECCA) and features a Touch-plate front panel. The Oscilloscope Calibrator provides the following functions:

Standard Amplitude - VOLTS/DIV

± dc and square wave to 220 volts

Standard Time - TIME/DIV

0.5 nsec to 5 sec

Standard Current - Milliampere/DIV

1 mA to 50 mA, dc and square wave

Standard Calibrator

Checks oscilloscope internal calibration signal

Low Distortion Pulse

1 V to 100 V peak-to-peak, unterminated

50 mV to 1 V peak-to-peak, terminated into 50 Ω

Fast Risetime Pulse

≤ 200 psec risetime

1-3. INSTRUMENT AND MANUAL IDENTIFICATION

1-4. The 6127A Instruction Manual contains information fully defining operation, theory, troubleshooting, maintenance and calibration. Complete schematics, replaceable parts lists and location of components are included in this manual.

1-5. The Ballantine Model 6127A has a serial number nameplate on the rear panel. The first three digits of the serial number identify the configuration. Any change of the units affecting configuration will result in a change in the configuration code listed on the serial number and the front page of this manual. Addendum sheets supplied with the manual will identify the changes.

1-6. ELECTRICAL SPECIFICATIONS

1-7. VOLTS/DIV

High Impedance Output (into 1 Megohm)

Range: 40 uV to 200 volts
in 1, 2, 5 sequence.

Low Impedance Output (into 50 ohms)

Range: 40 uV to 5 volts
in 1, 2, 5 sequence.

Amplitude Accuracy

± 0.25% of reading ±1 uV

Amplitude Deviation

Deviation range of ±9.9% with a resolution of 0.1% as displayed on digital meter.

Digital deviation meter provides resolution of 0.1%; Error indicated is Unit Under Test (UUT) voltage error.

Frequency

Square wave of 10 Hz, 100 Hz, 1 kHz and 10 kHz; Dc positive, Dc negative

Trigger Output

Slaved to selected frequency.
Modes: OFF, X1, ÷ 10, ÷ 100.

Amplitude is 1 volt into 50 ohms.

1-8. TIME/DIV

Output Markers

500 psecs to 5 sec in 1, 2, 5 sequence.

Marker Amplitude

≥ 1 volt peak into 50 ohms.

Accuracy

±0.1% of reading ±10 psec
(2 ns to 5 sec)

±0.1% of reading ±20 psec
(0.5 nsec 1 nsec)

Trigger Output

Slaved to marker outputs from 5 sec to 100 nsec and slaved to 100 nsec for faster markers.

Modes: OFF, X1, $\div 10$, $\div 100$.

Amplitude is 1 volt into 50 ohms.

Deviation

Stepped variable period deviation to $\pm 9.9\%$ for markers and triggers.

Digital deviation meter provides resolution of 0.1%; Error indicated is UUT (Unit Under Test) timing error.

Internal Time Base

An internal temperature compensated 10 MHz crystal oscillator provides long term stability to better than 1 part in 10^{-5} per month after 72 hours and temperature stability of better than 1 part in 10^{-5} from $+4^{\circ}\text{C}$ to $+40^{\circ}\text{C}$ after a 30 minute warmup.

External Time Base Input

10 MHz at 1 V to 3 V rms from 50 ohm source.

1-9. Milliamperes/DIV

Current Range

1 mA to 50 mA in 1, 2, 5 sequence.

Accuracy

$\pm 0.25\%$ of reading ± 2 μA

Frequency

$\pm\text{DC}$; Square wave of 10 Hz, 100 Hz, 1 kHz and 10 kHz.

Trigger Output

Slaved to selected frequency.
Modes: OFF, X1, $\div 10$, $\div 100$.

Amplitude is 1 volt into 50 ohms.

1-10. STANDARD CALIBRATOR

Amplitude Range

High Impedance: ± 40 μV to ± 200 V
in 1, 2, 5 sequence

Low Impedance (50 Ω): ± 40 μV to ± 5 V
in 1, 2, 5 sequence

Accuracy

$\pm 0.25\%$ of reading ± 1 μV

Comparison Mode

Compares output of VOLTS/DIV generator and calibrator of UUT. Switching is at 100 Hz rate or alternate on command.

Accuracy of 50 Ω Impedance

$\pm 1\%$

Frequency

1 kHz square wave

Trigger Output

Slaved to 1 kHz frequency.
Modes: OFF, X1, $\div 10$, $\div 100$.

1-11. LOW DISTORTION PULSE

Amplitude

Range: From 1 to 100 volts peak-to-peak in 1, 2, 5 sequence when unterminated and from 50 mV to 1 V peak-to-peak in 1, 2, 5 sequence when terminated in 50 ohms.

Output Impedance

50 ohms $\pm 1\%$ when in low impedance (terminated) mode.

Wave Shape

Square wave with 50% duty cycle. Leading edge aberrations within 2% of peak-to-peak amplitude. Droop and tilt within 1% of peak-to-peak amplitude.

Risetime

≤ 2 nsec

Polarity

Positive transition from negative voltage to ground.

Frequency

1 kHz to 100 kHz in 3 decade steps when unterminated and 10 Hz to 1 MHz in 6 decade steps in 50 ohm terminated mode.

Trigger Output

Slaved to frequency selected.
Modes: OFF, X1, $\div 10$, $\div 100$.

1-12. FAST RISETIME PULSE

Amplitude

1 V peak-to-peak (May be varied by $\pm 9.9\%$)

Risetime

≤ 200 psec into 50 ohms.

Wave Shape

Output is positive square wave with 50% duty cycle. Leading edge aberrations are less than 3% of amplitude not exceeding 5% of peak-to-peak.

Frequency

10 kHz and 100 kHz.

Tripper Output

Slaved to frequency selected.
Modes: OFF, X1, $\div 10$, $\div 100$.

1-13. GENERAL SPECIFICATIONS

Operation

Local and Remote with full compatibility to IEEE-488-1978 Interface Bus. Local operation through touch key panel.

Self Test

Instrument includes full self test capability for all digital command and latch circuits, key board touch switches, displays and indicators, analog controls of master clock, VCO, and deviation. Internal voltmeter may be used to measure deviation limits.

Bus Address

Selected by switch accessible on rear panel. Address setting may be displayed after self test cycle.

Ac Mains Voltage

100/120/220/240 Vac, $\pm 10\%$; 50 to 440 Hz single phase sinusoidal with one lead at ground potential.

Power

Approximately 80 watts.

Weight

15.2 Kg (33.5 lbs.) with covers, accessories and 61271A and 61272A.

Shipping Weight

17.7 Kg (39 lbs.)

Height

133 mm (5.22 inches)

Width

Bench Mount: 425 mm (16.75 inches)

Rack Mount: 482 mm (19 inches)

Depth

Overall (Unit Only): 484 mm (19.05 inches)

Overall with covers: 506 mm (19.95 inches)

Behind panel: 438 mm (17.25 inches)

Environmental

Altitude: Storage to 15 Km (50,000 feet)

Operating to 3 Km (10,000 feet)

Humidity: (Operating) 0 to 90% RH

Temperature Storage: -55°C to +75°C

Operating: 0°C to 50°C

Meets or exceeds MIL-T-28800C Type III Class 5, including shock, vibration, bench handling, EMI (RE-03 limits reduced 10 dB above 10 MHz) Reliability, and Maintainability.

1-14. Model 61271A

Model 61271A Fast Pulse/Time Calibrator/Amplitude Calibrator Accessory is supplied with the Model 6127A. It connects to the main Output Connector and is required for:

Volts/Div, Milliamperes/Div, Time/Div, Fast Rise Pulse, Low Distortion Pulse operation.

1-15. Model 61272A

Model 61272A Amplitude Comparator Accessory is supplied with the Model 6127A. It connects to the main Output Connector and is required for:

Calibrator operation.

1-16. ACCESSORIES AVAILABLE

<u>MODEL</u>	<u>DESCRIPTION</u>
10650A	Input Capacitance Standardizer
12249D	Cable, 50 ohm, 48 inches, BNC/BNC
12630A	50 ohm Termination, BNC/BNC
	Module Kit, Spare Parts for 6127A
	Recalibration Kit for 6127A

SECTION 2

PREPARATION FOR USE AND SHIPMENT

2-1. GENERAL

2-2. This section contains information and instructions necessary for the installation and reshipment of the Model 6127A Oscilloscope Calibrator. Details are provided for initial inspection, performance checks, power connections, grounding safety requirements, installation information and repacking instructions for storage or shipment.

2-3. UNPACKING AND INITIAL INSPECTION

2-4. Unpacking and initial inspection of the calibrator require only the normal precautions and procedures applicable to the handling of sensitive electronic equipment. The contents of all shipping containers should be checked for included accessories and certified against the packing slip to ascertain that the shipment is complete.

2-5. PERFORMANCE CHECKS

2-6. This instrument was carefully inspected for mechanical and electrical performance before shipment from the factory. It should be free of

physical defects and in acceptable operating condition upon receipt. Check the instrument for possible damage incurred while in transit. Complete the performance checks beginning with paragraph 5-3. If there is any indication of damage or improper operation, refer to the warranty included in this manual and notify Ballantine or your local Ballantine field representative.

2-7. POWER REQUIREMENTS

2-8. The instrument may be operated from an ac voltage source rated at 100, 120, 220 or 240 volts rms at 50 to 400 Hz. The orientation of the printed circuit board in the ac power connector on the rear panel of the instrument matches the instrument to the ac voltage source. See Figure 2-1.

CAUTION

Failure to orient the printed circuit board properly will damage the instrument and void the warranty.




Figure 2-1. Voltage Selection and Fused Receptacle

2-9. The instrument should be operated from a power source with its neutral at or near ground (earth) potential. The instrument is not intended for operation from two phases of a multiphase ac system or across the legs of a single-phase, three-wire ac power system. Crest factor (ratio of peak voltage to rms) should be typically within the range of 1.3 to 1.6 at $\pm 10\%$ of the nominal line voltage. Use a true rms responding voltmeter, such as the Ballantine Model 3620A, to measure the power line voltage.

2-10. GROUNDING REQUIREMENTS

2-11. To insure the safety of operating personnel, the U.S. Occupational Safety and Health Act (OSHA) and good engineering practice require that the instrument enclosure be "earth" grounded. All Ballantine instruments are provided with a three-conductor power cable assembly which, when plugged into an appropriate power receptacle, grounds the instrument. The offset pin on the male end of the power cable is the ground wire connection to the connector on the rear panel of the instrument. The Model 6127A is supplied with a shielded power mains cable. Always use this cable to minimize the radiated EMI.

2-12. To preserve the safety protection feature when operating the instrument from a two-contact

power outlet, use a three-prong to two-prong adapter and connect the green lead or terminal on the adapter to "earth" ground.

NOTE

In addition to the two methods of grounding stated, the instrument also incorporates a case ground lug on the rear panel.

2-13. INSTALLATION AND MOUNTING

2-14. GENERAL. The calibrator is fully solid state and dissipates minimal heat. No special cooling is required; however, the instrument should not be operated where the ambient temperature exceeds 40°C (104°F) or when condensation due to high humidity appears anywhere on the instrument.

2-15. PORTABLE. The calibrator is shipped with rubber bumper-feet and metal tilt-stand in place, ready for use as a bench instrument. Outline dimensions are shown in Figure 2-2. The instrument, as supplied, includes side carry handles.




Figure 2-2. Portable Outline Dimensions

2-16. RACK MOUNTING. The calibrator is readily adapted for installation in a standard 19-inch wide equipment rack by use of the rack adapter kit. Outline dimensions are shown in figure 2-3.

2-17. The following instructions detail the procedure for installing the Model 6127A in a rack mount configuration.

- a. Remove the Calibrator bottom dust cover as detailed in paragraph 5-19.
- b. Remove the two rear feet from the dust cover.
- c. Remove the two front feet and tilt bail stand from the dust cover.
- d. Re-assemble the bottom dust cover to the Calibrator.
- e. Unfasten the screws securing the front cover clip and feet (2) to the right side casting. Remove both the clip and feet and then re-install the screws.
- f. Unfasten the screws securing the rear cover clip and feet (2) to the right side casting. Remove both the clip and feet and then re-install the screws.

g. Remove the two No. 8 screws located on the right side casting near the front of the Calibrator. These empty threaded holes will be used in step (h).

h. Mount one of the angle brackets to the right front side of the Calibrator by fastening it with the new No. 8 screws supplied with the kit.

i. Unfasten the screws securing the front cover clip to the left side casting. Remove the clip and then re-install the screws.

j. Unfasten the screws securing the rear cover clip to the left side casting. Remove the clip and then re-install the screws.

k. Unfasten the screws securing the handle to the left side casting and remove the handle. Do not re-install these screws.

l. Remove the two No. 8 screws located on the left side casting near the front of the Calibrator.

m. Attach the other angle bracket to the left front side of the Calibrator by securing it with the new No. 8 screws supplied with the kit.

n. To attach the right chassis-slide assembly, first unlatch and separate the inner slide from the two outer slide sections.




Figure 2-3. Rack Mount Outline Dimensions

o. Orient the inner slide so that the scalloped corner faces the upper front corner of the Calibrator right side.

p. Fasten this inner slide to the right side of the Calibrator with the three No. 8 screws supplied. (There are three threaded holes provided on the right side of the Model 6127A.)

q. Install the outer right slide assembly inside the right wall of the equipment rack frame.

r. To attach the left chassis-slide assembly repeat steps (n) through (q) except orient the scalloped corner of the inner left slide so that it faces the upper front corner of the Calibrator left side.

s. Install the outer left slide assembly inside the left wall of the equipment rack frame.

t. Position the instrument in the equipment rack and attach in place. It will be necessary to trip the latches on both the right and left Calibrator slide members to permit inserting the instrument completely into the equipment rack.

2-18. SHORT TERM STORAGE

2-19. If the instrument is to be stored for a short period of time (less than three months), place cardboard over the panel and cover the instrument with a suitable protective covering, such as a plastic bag or strong, draft paper. Place power cable and other accessories with the instrument. Store the covered instrument in a clean, dry area that is not subject to extreme temperature variations or conditions which may cause moisture to condense on the instrument.

2-20. LONG TERM STORAGE OR REPACKAGING FOR SHIPMENT

2-21. If the instrument is to be stored for a period longer than three months, or if it is to be repackaged for shipment, as a general guide, repackage the instrument as described in the following procedure and shown in figure 2-4. Use either the original packing material, if available, or material similar to that specified. Proceed as follows:

a. Store the ac power cord in the rear cover and store the Model 61271A and 61272A Heads in the recesses provided for them in this front cover.

b. For long distance shipping only, use U.S. Government packaging method IIC and tape a two-unit bag of dissicant (MIL-D-3464) on the rear cover.

c. Enclose the instrument in a plastic bag and seal the bag.

d. Wrap the bagged instrument in a 1-inch thick, flexible, cellular plastic-film, cushioning material (PPP-B-795) and place in a barrier bag (MIL-B-131). Extract the air from the bag and then heat seal the bag.

e. Place the wrapped instrument into a fiberboard box (PPP-B-636) of a suitable size. Fill spaces with rubberized hair or cellular plastic cushioning material. Close the box in accordance with container specifications. Seal with sturdy, water-resistant tape or with metal straps.

f. Mark container "FRAGILE," "HANDLE WITH CARE" or similar precautionary notice. Affix shipping labels as required or mark in accordance with MIL-STD-129.

NOTE

If the instrument is to be returned to Ballantine Laboratories, Inc. for calibration or repair; attach a tag to the instrument identifying the problem, symptoms and service or repair desired. List the model and serial number of the instrument. Ship the instrument prepaid to Ballantine Laboratories, Inc., 90 Fanny Road, Boonton, NJ 07005, U.S.A. In any correspondence, identify the instrument by model number, serial number, work authorization order; and date and method of shipment.

2-22. SAFETY

2-23. Table 2-1 delineates the safety aspects of this instrument.




Figure 2-4. Model 6127A Packing Diagram

TABLE 2-1. SAFETY CONSIDERATIONS

SAFETY CONSIDERATIONS

GENERAL

This is a Safety Class 1 instrument. This instrument has been designed considering IEC Publication 348 and ANSCI C39.5, "Safety Requirements for Electronic Measuring Apparatus".

This manual contains information, cautions, and warnings which must be followed by the service person to ensure safe operation and to retain the instrument in safe condition.

WARNINGS

SAFETY

If this instrument is to be energized via an autotransformer for voltage reduction, make sure the common terminal is connected to the earthed pole of the power source.

BEFORE SWITCHING ON THIS INSTRUMENT, the protective earth terminals of this instrument must be connected to the protective conductor of the (mains) power cord. The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. The protective action must not be negated by the use of an extension cord (power cable) without a protective conductor (grounding).

Make sure that only fuses with the required rated current and of the specified type (normal blow, time delay, etc.) are used for replacement. The use of repaired fuses and the short-circuiting of fuse holders must be avoided.

Whenever it is likely that the protection offered by fuses has been impaired, the instrument must be made inoperative and be secured against any unintended operation.

GROUNDING

Any interruption of the protective (grounding) conductor (inside or outside the instrument) or disconnecting the protective earth terminal is likely to make this instrument dangerous. Intentional interruption is prohibited.

HIGH VOLTAGE

Warning - These servicing instructions are for use by qualified personnel only. To avoid dangerous electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.


CAUTIONS

LINE VOLTAGE SELECTION

BEFORE SWITCHING ON THIS INSTRUMENT, make sure the instrument is set to the voltage of the power source. Verify that the power transformer primary is matched to the available line voltage. Verify that the correct fuse is installed.

GROUNDING

BEFORE SWITCHING ON THIS INSTRUMENT, ensure that all devices connected to this instrument are connected to the protective (earth) ground. (Grounding one conductor of a two-conductor outlet is not sufficient.)

This symbol:  , which appears on the instrument means: Read the instruction manual before operating the instrument. If the instrument is operated without reading the instructions, it may not operate correctly.



ATTENTION



SECTION 3
OPERATION

3-1. INTRODUCTION

3-2. This section contains instructions and information required for the operation of the Model 6127A Programmable Oscilloscope Calibrator. Included are identification of controls, connectors and indicators as well as remote programming information.

3-3. POWER REQUIREMENTS

3-4. See paragraphs 2-7 through 2-9. For grounding and safety earth connections, see paragraphs 2-10 through 2-12. Always check rear panel voltage selector card in the power receptacle.

CAUTION

Failure to apply the correct ac mains power voltage will cause serious damage to the instrument and will void the warranty.

3-5. OPERATING INSTRUCTIONS
(LOCAL MODE)

3-6. In the LOC (Local) mode, the Model 6127A is operated manually by touching the appropriate "Touch-plate" controls on the front panel. The respective annunciator lamps illuminate for each touch-plate command.

3-7. Refer to Figure 3-1 and Table 3-1 for identification and explanation of the Model 6127A front panel controls, indicators and connectors. See Figure 3-2 and Table 3-2 for identification and explanation of the Model 61271A connectors and Figure 3-3 and Table 3-3 for the Model 61272A indicators and connectors. Refer to Figure 3-4 and Table 3-4 for identification and explanation of the Model 6127A rear panel controls and connectors.

NOTE

Additional operating information is provided, starting with paragraph 3-27. This includes: expanded operating instructions, helpful hints, and application information.

3-8. INITIAL TURN-ON. Push the POWER switch to the "in" position. Both the green POWER lamp and the red SELF TEST lamp will illuminate. The 6127A will then run rapidly through a series of "self tests". At the completion of these self tests, all segments of all displays will illuminate for about 10 seconds. If all of the checks are passed, the instrument will indicate this by displaying "prompt" lines in all of the displays and extinguish the SELF TEST lamp. If any of the "self test" checks fail, the Calibrator will indicate a failure by displaying one of the number codes listed in the following table in the AMPLITUDE/DIV display.

ate for about 10 seconds. If all of the checks are passed, the instrument will indicate this by displaying "prompt" lines in all of the displays and extinguish the SELF TEST lamp. If any of the "self test" checks fail, the Calibrator will indicate a failure by displaying one of the number codes listed in the following table in the AMPLITUDE/DIV display.

6127A SELF TEST ERROR CODES

CODE	ERROR MESSAGE
001	Fail -9.9% DEV volts
002	Fail +9.9% DEV volts
003	Fail 0% DEV volts
004	Fail -9.9% DEV time
005	Fail +9.9% DEV time
006	Fail 0% DEV time
007	Fail RAM test
008	Fail Keyboard test
090	Fail Phase lock loop malfunction
091	Fail DVM malfunction in first digit (MSD)
092	Fail DVM malfunction in second digit
093	Fail DVM malfunction in third digit
094	Fail DVM malfunction in last digit (LSD)

3-9. VOLTS/DIV Mode. To use the Model 6127A Calibrator in the VOLTS/DIV Mode, proceed as follows:

- a. Connect the equipment as shown in figure 3-5. (Refer also to Table 3-5.)
- b. Touch the VOLTS/DIV, MILLIAMPERES/DIV OUTPUT Mode key pad. "Prompt" lines will appear in the AMPLITUDE/DIV display.

NOTE

Initially both mode annunciators will illuminate.

c. Enter the desired AMPLITUDE/DIV number (Any number in a 1,2,5 sequence or multiple thereof is a valid entry) by touching, in sequence, the respective key pads; 1,2,5 or 0.

NOTE

If an invalid numerical entry is made subsequent to a valid one, the Calibrator will indicate an "invalid entry" by displaying the last valid number and momentarily illuminating the INVALID ENTRY lamp.

d. Select the desired AMPLITUDE/DIV terminator by touching the respective key pad; V, mV or μ V. At this time, the instrument will go into the VOLTS/DIV Mode and the MILLIAMPERES/DIV annunciator lamp will extinguish. The annunciator lamp adjacent to the VOLTS/DIV terminator selected will illuminate. (To change the entry, re-touch the VOLTS/DIV OUTPUT key pad. The "prompt" lines will re-appear; then enter the new value and terminator.)

e. Touch the DIVS key pad. "Prompt" lines will appear in the DIVISIONS display.

f. Enter the desired (multiplier) DIVISIONS value (1,2,3,4,5,6,8 or 10) by touching the respective key pads. (To change the entry, re-touch the DIVS key pad. The "prompt" lines will re-appear, then enter the new number.)

g. Touch the TIME/FREQ key pad. "Prompt" lines will appear in the TIME/DIV-FREQUENCY display.

h. Enter the desired frequency (DC, 10Hz, 100Hz, 1kHz or 10kHz) by touching the respective key pad. The display and annunciator will indicate the frequency chosen.

i. If DC is initially selected, it will be positive (POS). To change it to negative, touch the NEG key pad.

NOTE

To change back to positive dc, it will be necessary to first re-touch the TIME/FREQ key pad and then the 8/DC key pad.

j. If a trigger output is required for external triggering of the UUT, touch one of the TRIGGER key pads depending on the trigger frequency desired; X1, $\frac{1}{10}$ or $\frac{1}{100}$. The respective annunciator lamp will illuminate.

k. If the low source impedance output (50Ω) is desired, for VOLTS/DIV amplitude of five volts ($1V \times 5 \text{ DIVS}$) or less, touch the 50Ω load key pad.

l. Touch the STANDBY/OPERATE key pad to "output" the VOLTS/DIV signal to the UUT. The OPERATE annunciator will illuminate.

m. To activate % DEVIATION, touch the DEV key pad. The DEVIATION display will be 0.0 and neither the HI nor LO lamp will be lit initially.

NOTE

% DEVIATION cannot be activated in the STANDBY condition.

n. If the signal displayed on the oscilloscope does not agree with the Calibrator value, increment or decrement the % DEVIATION by touching the respective key pad until the displayed signal is coincident with the proper horizontal graticule line. The number indicated on the display represents the error of the UUT (oscilloscope). If the HI annunciator lamp illuminates, the calibration error of the UUT is high; if the LO annunciator lamp illuminates, the calibration error of the UUT is low.




Figure 3-1. Model 6127A Front Panel Controls, Indicators and Connectors

TABLE 3-1. MODEL 6127A FRONT PANEL CONTROLS,
INDICATORS AND CONNECTORS

INDEX NO.	CONTROL, INDICATOR OR CONNECTOR	REF. DESIG.	FUNCTION
1	POWER LAMP	A25-DS1	Illuminates when ac mains power is applied to instrument.
2	POWER Switch	A52-S1	Push-push switch that when pushed to the "in" position applies ac mains power to the instrument.
3	OUTPUT, LOW DISTORTION PULSE Key Pad	A25-DS2	When touched, puts the 6127A in the Low Distortion Pulse Mode. AMPLITUDE/DIV "prompt" lines will appear and the annunciator lamp will illuminate.
4	OUTPUT, VOLTS/DIV, MILLIAMPERES/DIV Key Pad	A25-DS3, DS4	When touched, puts the 6127A in either the VOLTS/DIV or MILLIAMPERES/DIV Mode; depending on the next instruction. Both annunciator lamps will initially illuminate and AMPLITUDE/DIV "prompt" lines will appear. The next instruction will determine which one remains illuminated.
5	OUTPUT, TIME/DIV Key Pad	A25-DS5	When touched, puts the 6127A in the TIME/DIV Mode. Annunciator lamp will illuminate but no "prompt" lines will appear until TIME/FREQ touch key is pressed.
6	OUTPUT, FAST RISE PULSE Key Pad	A25-DS6	When touched, puts the 6127A in the FAST RISE PULSE Mode. Annunciator lamp and AMPLITUDE/DIV "prompt" lines will illuminate.
7	OUTPUT, CALIBRATOR, Key Pad	A25-DS7	When touched, puts the 6127A in the CALIBRATOR Mode. AMPLITUDE/DIV "prompt" lines will appear and annunciator lamp will illuminate.
8	DIVS Key Pad	A25	When touched, sets up the 6127A for next instruction (a numerical entry of 1, 2, 3, 4, 5, 6, 8 or 10) and DIV "prompt" lines will appear. This applies to LOW DISTORTION PULSE, VOLTS/DIV, MILLIAMPERES/DIV and CALIBRATOR Modes.
9	TIME/FREQ Key Pad	A25	When touched, sets up the 6127A for next instruction (depending upon which mode has been selected) and TIME/FREQ "prompt" lines will appear. This will be either a numerical entry in a 1, 2, 5 sequence for TIME/DIV Mode; or in decade steps for LOW DISTORTION PULSE, VOLTS/DIV, and FAST RISE PULSE Modes (FREQUENCY).
10	DEV Key Pad	A25	When touched, sets up the 6127A for % DEVIATION, from calibrated time or amplitude, by up to $\pm 9.9\%$. Not valid for LOW DISTORTION PULSE Mode. Initially displays 0.0% DEVIATION. Can only be activated in OPERATE state.

TABLE 3-1. MODEL 6127A FRONT PANEL CONTROLS,
INDICATORS AND CONNECTORS (Continued)


INDEX NO.	CONTROL, INDICATOR OR CONNECTOR	REF. DESIG.	FUNCTION
11	CURRENT LOOP 	A25	Milliampere current output terminal when in MILLIAMPERES/DIV Mode.
12	STANDBY/OPERATE Key PAD	A25-DS8. DS9	Will change from STANDBY (Output off) to OPERATE (Output on) when touched, providing all instructions for a particular operating mode have been entered. Annunciator lamps indicate status (STANDBY or OPERATE). Whenever there is an OUTPUT Mode change, instrument reverts back to STANDBY.
13	Output Connector	A24-J4	Main output connector for all signals except current and trigger. Connects Model 61271A for LOW DISTORTION PULSE, VOLTS/DIV, TIME/DIV, FAST RISE PULSE operation. Connects Model 61272A for CALIBRATOR operation.
14	1/10Hz, 2/100Hz, 3/1kHz, 4/10kHz, 5/100kHz, 6/1MHz, 8/DC, 0 Key Pads	A25	When touched, enters a numerical value in a 1, 2, 5 sequence (TIME/DIV and AMPLITUDE/DIV) or a fixed frequency, including dc, in decade steps (FREQUENCY).
15	NEG/ps Key Pad	A25	Dual function key pad that when touched, changes dc voltage output polarity to minus (NEG) or sets the TIME/DIV value to picoseconds (ps) depending on prior instruction set. Respective annunciator lamp will illuminate.
16	UUT/CALIB - ALT MODE Key Pad	A25	Dual function key pad that when touched, changes the CALIBRATOR Mode from (initially) 100 Hz chopped mode to ALT MODE. Successive touches cause the signal to alternate between that from the UUT (Unit Under Test) and CALIB (6127A) signal. Used with Model 61272A connected. In ALT MODE, the lamp on the Model 61272A is illuminated.
17	50 Ω LOAD Key Pad	A25	When touched, changes the 6127A source impedance to 50 Ω if the instrument is in either the VOLTS/DIV or LOW DISTORTION PULSE Mode. Annunciator lamp will illuminate to indicate 50 Ω source impedance. When in CALIBRATOR Mode, a 50 Ω load is presented to the UUT calibrator.
18	OUTPUT BNC Connector	A24-J30	Output connector for trigger signal.
19	\div 100 Key Pad	A25-DS12	When touched, divides the frequency of the trigger signal by 100 and presents trigger signal at OUTPUT BNC connector. Annunciator lamp will illuminate.
20	\div 10 Key Pad	A25-DS11	When touched, divides the frequency of the trigger signal by 10 and presents trigger signal at OUTPUT BNC connector. Annunciator lamp will illuminate.

TABLE 3-1. MODEL 6127A FRONT PANEL CONTROLS,
INDICATORS AND CONNECTORS (Continued)

INDEX NO.	CONTROL, INDICATOR OR CONNECTOR	REF. DESIG.	FUNCTION
21	X1/OFF	A25-DS10	Dual function key pad that when touched for the first time; causes a trigger signal to be present at the OUTPUT BNC connector at X1 (Normal) frequency. The annunciator lamp will illuminate. When key pad is re-touched, trigger signal is turned OFF (not present at OUTPUT BNC connector).
22	CLEAR Key Pad	A25	When touched twice, resets Calibrator to "Power On" condition and performs "self-test" sequence.
23	mA/ns Key Pad	A25	Dual function key pad that when touched, puts the 6127A in the MILLIAMPERES/DIV Mode (providing the VOLTS/DIV, MILLIAMPERES/DIV OUTPUT Mode was previously selected) or sets the TIME/DIV to ns (nanoseconds) if the instrument is in the TIME/DIV Mode. Respective annunciator lamp will illuminate.
24	uV/us Key Pad	A25	Dual function key pad that when touched, sets the VOLTS/DIV value to uV (microvolts) if the instrument is in the VOLTS/DIV Mode or sets the TIME/DIV value to us (microseconds) if the instrument is in the TIME/DIV Mode. Respective annunciator lamp will illuminate.
25	LOC/REM Key Pad	A25-DS13	When touched, puts the 6127A into the Local (manual) mode of operation if the Local Lockout (LLO) has not been set from the bus. The annunciator lamp will illuminate. If the instrument is connected to a controller, Remote overrides Local and the Calibrator must be manually re-keyed from Remote back to Local.
26	HI/LO Annunciators	A23-DS19, DS20	Lamps that indicate whether the % DEVIATION of the UUT is HI (above standard value) or LO (below standard value).
27	DEVIATION Display	A23-DS29, DS30	Two digit display of % DEVIATION.
28	mV/ms Key Pad	A25	Dual function key pad that when touched, sets the VOLTS/DIV value to mV (millivolts) if the instrument is in the VOLTS/DIV Mode or sets the TIME/DIV value to ms (milliseconds) if the instrument is in the TIME/DIV Mode. Respective annunciator lamp will illuminate.
29	V/s Key Pad	A25	Dual function key pad that when touched, sets the VOLTS/DIV value to V (volts) if the instrument is in the VOLTS/DIV Mode or sets the TIME/DIV value to s (seconds) if the instrument is in the TIME/DIV Mode. Respective annunciator will illuminate.

TABLE 3-1. MODEL 6127A FRONT PANEL CONTROLS,
INDICATORS AND CONNECTORS (Continued)



INDEX NO.	CONTROL, INDICATOR OR CONNECTOR	REF. DESIG.	FUNCTION
30	DC, POS, NEG, 50 Ω Annunciators	A23-DS15, DS16,DS17, DS18	Lamps that indicate a state of AMPLITUDE/DIV voltage: DC POS or NEG and whether high or low source impedance has been selected.
31	Hz, kHz, MHz, ps Annunciators	A23-DS11, DS12,DS13, DS14	Lamps that indicate value of FREQUENCY being displayed: Hz, kHz, MHz or a range of TIME/DIV displayed: ps.
32	s, ms, us, ns Annunciators	A23-DS7,DS8, DS9,DS10	Lamps that indicate TIME/DIV range displayed: s, ms, us or ns.
33	TIME/DIV-FREQUENCY Display	A23-DS26, DS27,DS28	Three digit display of TIME/DIV when in TIME/DIV Mode or FREQUENCY when in any other mode.
34	 Key Pad	A25	If the instrument is in Deviation mode, momentary touching of this key pad decrements the % DEVIATION one step (0.1% decrease) for each time the pad is touched. Maintaining pressure on key pad causes % DEVIATION value to slew in 0.5% steps until pressure is released, to a maximum of +9.9%. (Decreases output voltage in VOLTS/DIV Mode and increases marker repetition rate in TIME/DIV Mode.)
35	 Key Pad	A25	If the instrument is in Deviation mode, momentary touching of this key pad increments the % DEVIATION one step (0.1% increase) for each time the pad is touched. Maintaining pressure on key pad causes % DEVIATION value to slew in 0.5% steps until pressure is released, to a maximum of -9.9%. (Increases output voltage in VOLTS/DIV Mode and decreases marker repetition rate in TIME/DIV Mode.)
36	DIVISIONS Display	A23-DS24, DS25	Two digit display of number that multiplies AMPLITUDE/DIV value when the instrument is in VOLTS/DIV, MILLIAMPERES/DIV, CALIBRATOR or LOW DISTORTION PULSE Mode.
37	V, mV, uV, mA Annunciators	A23-DS3,DS4 DS5,DS6	Lamps that indicate VOLTS/DIV range displayed: V, mV, uV; LOW DISTORTION PULSE range displayed: V, mV; or MILLIAMPERES/DIV displayed: mA.
38	AMPLITUDE/DIV Display	A23-DS21, DS22,DS23	Three digit display of VOLTS/DIV (not including multiplier) when in VOLTS/DIV, CALIBRATOR and LOW DISTORTION PULSE Modes; and MILLIAMPERES/DIV (not including multiplier) when in MILLIAMPERES/DIV Mode.
39	SELF TEST Annunciator	A23-DS1	Lamp that illuminates during the time that the 6127A is performing a self check (immediately following a "Power On" condition or double entry of CLEAR key pad.
40	INVALID ENTRY Annunciator	A23-DS2	Lamp that illuminates when an invalid Entry has been made.

TABLE 3-2. MODEL 61271A CONNECTORS

INDEX NO.	CONNECTOR	REF. DESIG.	FUNCTION
1	OUTPUT	A40-P1	Connects to Unit Under Test (UUT) vertical input and provides either Fast Rise Pulse, Time Markers or Amplitude signal; depending on Mode selected.
2		A40-P100A	Multipin connector that couples Model 61271A cable to Model 6127A Calibrator.




Figure 3-2. Model 61271A Connectors




Figure 3-3. Model 61272A Indicators & Connectors

TABLE 3-3. MODEL 61272A INDICATORS AND CONNECTORS

INDEX NO.	CONNECTORS AND INDICATORS	REF. DESIG.	FUNCTION
1	CHOPPED OUTPUT	A42-P1	Output signal from Model 61272A Amplitude Comparator. Initially is switched at 100 Hz rate (chopped) between UUT's calibrator output and that of the Model 6127A. Normally connects to UUT vertical input.
2		A42-P100B	Multipin connector that couples Model 61272A cable to Model 6127A Calibrator.
3	UUT SELECTED	A42-CR2	Lamp that illuminates when signal from UUT calibrator has been selected.
4	FROM UUT CALIBRATOR	A42-J1	Input connector for connection of UUT calibration signal to Model 61272A. When UUT is selected, this signal is connected to oscilloscope vertical input.




Figure 3-4. Model 6127A Rear Panel Controls and Connectors

TABLE 3-4. MODEL 6127A REAR PANEL CONTROLS AND CONNECTORS

INDEX NO.	CONTROL OR CONNECTOR	REF. DESIG.	FUNCTION
1	Ac Power Connector	A50-J1	Ac power input connector that incorporates an ac mains voltage selector printed circuit board (100, 120, 220 or 240 volts) and fuse.
2	ADDRESS	A50-S1-S8	Set the Model 6127A interface address. (Only the first five rocker switches are used.)
3	EXT CLOCK/IN 10 MHz CLOCK OUT	A27-S9	Slide switch that selects either external 10 MHz clock input or 10 MHz clock output.
4		A50-J30	BNC connector for applying external 10 MHz clock input or provides output from Model 6127A 10 MHz clock.
5	REMOTE CONTROL	A50-J2	24 pin connector that permits remote programming of Model 6127A via standard IEEE 488 Bus.




Figure 3-5. Volts/Div Measurement, Equipment Set-Up

TABLE 3-5. 6127A VOLTS/DIV MODE VALID ENTRIES

AMPLITUDE/DIV	DIVISIONS (HI Z)									DIVISIONS (50Ω)								
	1	2	3	4	5	6	8	10		1	2	3	4	5	6	8	10	
50 V					VALID ENTRY REGION					VALID ENTRY REGION								
20 V										VALID ENTRY REGION								
10 V										VALID ENTRY REGION								
5 V										VALID ENTRY REGION								
2 V										VALID ENTRY REGION								
1 V										VALID ENTRY REGION								
500mV										VALID ENTRY REGION								
200mV										VALID ENTRY REGION								
100mV										VALID ENTRY REGION								
50mV										VALID ENTRY REGION								
20mV										VALID ENTRY REGION								
10mV										VALID ENTRY REGION								
5mV										VALID ENTRY REGION								
2mV										VALID ENTRY REGION								
1mV										VALID ENTRY REGION								
500uV										VALID ENTRY REGION								
200uV										VALID ENTRY REGION								
100uV										VALID ENTRY REGION								
50uV										VALID ENTRY REGION								
20uV	VALID ENTRY REGION									VALID ENTRY REGION								
10uV	VALID ENTRY REGION									VALID ENTRY REGION								

3-10. MILLIAMPERES/DIV Mode. To use the Model 6127A Calibrator in the MILLIAMPERES/DIV Mode, proceed as follows:

a. Connect the equipment as shown in Figure 3-6. (Refer also to Table 3-6.)

b. Touch the VOLTS/DIV, MILLIAMPERES/DIV OUTPUT Mode key pad. "Prompt" lines will appear in the AMPLITUDE/DIV display.

NOTE

Initially both mode annunciators will illuminate unless instrument was previously in VOLTS/DIV Mode.

c. Enter the desired AMPLITUDE/DIV number (Any number in a 1,2,5 sequence or multiple thereof is a valid entry) by touching, in sequence, the respective key pads; 1,2,5 or 0 and press the mA key pad. At this time MILLIAMPERES/DIV will remain lit and VOLTS/DIV will extinguish. The mA annunciator will also illuminate. (To change the entry, re-touch the MILLIAMPERES/DIV OUTPUT key pad. The "Prompt" lines will re-appear; then enter the new value and terminator.)

NOTE

If an invalid entry is made subsequent to a valid one, the Calibrator will indicate an "invalid entry" by displaying the last valid number and momentarily illuminating the INVALID ENTRY lamp.

d. Touch the DIVS key pad. "Prompt" lines will appear in the DIVISIONS display.

e. Enter the desired (multiplier) DIVISIONS value (1,2,3,4,5,6,8 or 10) by touching the respective key pads. To change the entry, re-touch the DIVS key pad. "Prompt" lines will re-appear; then enter the new number.

f. Touch the TIME/FREQ key pad. "Prompt" lines will appear in the TIME/DIV-FREQUENCY display.

g. Enter the desired frequency (DC, 10Hz, 100Hz, 1kHz or 10kHz) by touching the respective key pad. The display and annunciator will indicate the frequency chosen.

h. When DC is initially selected, the current flow will be in the direction of the arrow. To reverse the direction of current flow, touch the NEG key pad.

NOTE

To change the flow of current back to the direction indicated by the arrow, it will be necessary to first re-touch the TIME/FREQ key pad and then the B/DC key pad.

i. If a trigger output is required for external triggering of the UUT, touch one of the TRIGGER key pads depending on the trigger frequency desired; X1, $\div 10$ or $\div 100$. The respective annunciator lamp will illuminate.




Figure 3-6. Milliamperes/Div Mode, Equipment Set-Up

TABLE 3-6. 6127A MILLIAMPERES/DIV MODE VALID ENTRIES

AMPLITUDE/DIV	DIVISIONS								
	1	2	3	4	5	6	8	10	
10mA						VALID ENTRY REGION			
5mA						VALID ENTRY REGION			
2mA						VALID ENTRY REGION			
1mA						VALID ENTRY REGION			

j. Touch the STANDBY/OPERATE key pad to "output" the MILLIAMPERES/DIV signal to the UUT. The OPERATE annunciator will illuminate.

k. To activate % DEVIATION, touch the DEV key pad. The DEVIATION display will be 0.0 and neither the HI nor LO lamp will be lit initially.

NOTE

% DEVIATION cannot be activated in the STANDBY condition.

l. If the current sensed by the UUT does not agree with the Calibrator value, increment or decrement the % DEVIATION by touching the respective key pad until the current value displayed on the display represents the error of the UUT. If the HI annunciator lamp illuminates, the calibration error of the UUT is high; if the LO annunciator lamp illuminates, the calibration error of the UUT is low.

3-11. TIME/DIV Mode. To use the Model 6127A Calibrator in the TIME/DIV Mode, proceed as follows:

- a. Connect the equipment as shown in Figure 3-7.
- b. Touch the TIME/DIV OUTPUT Mode key pad. The annunciator lamp will illuminate indicating that the Calibrator is in the TIME/DIV Mode.
- c. Touch the TIME/FREQ key pad. "Prompt" lines will appear in the TIME/DIV-FREQUENCY display.
- d. Enter the desired TIME/DIV number (Any number in a 1, 2, 5 sequence or multiple thereof is a valid entry) by touching, in sequence, the respective key pads; 1, 2, 5 or 0. (To change the entry, re-touch the TIME/DIV key pad. The "prompt" lines will re-appear; then enter the new value and terminator.)
- e. Select the desired TIME/DIV terminator by touching the respective key pad; s, ms, us, ns or ps. The annunciator lamp adjacent to the terminator selected will illuminate.

f. If a trigger output is required for external triggering of the UUT, touch one of the TRIGGER key pads. The annunciator lamp of the selected TRIGGER key pad will illuminate.

g. Touch the STANDBY/OPERATE key pad to "output" the TIME/DIV signal to the UUT. The OPERATE annunciator will illuminate.

h. To activate % DEVIATION, touch the DEV key pad. The DEVIATION display will be 0.0 and neither the HI nor LO lamp will be lit initially.

NOTE

% DEVIATION cannot be activated in the STANDBY condition.

i. If the time markers displayed on the oscilloscope do not agree with the Calibrator value, increment or decrement the % DEVIATION by touching the respective key pad until the displayed markers are coincident with the proper vertical graticule lines. If the HI annunciator illuminates, the calibration error of the UUT is high; if the LO annunciator illuminates, the error of the UUT is low.

3-12. FAST RISE PULSE Mode. To use the 6127A Calibrator in the FAST RISE PULSE Mode, proceed as follows:

- a. Connect the equipment as shown in Figure 3-7.
- b. Touch the FAST RISE PULSE Mode key pad. The annunciator for that mode will illuminate.
- c. Touch the TIME/FREQ key pad. "Prompt" lines will appear in the TIME/DIV-FREQUENCY display.
- d. Select a frequency of either 10 kHz or 100 kHz by touching the respective key pad. The display and annunciator will indicate the frequency chosen.
- e. If a trigger output is required for external triggering of the UUT, touch the desired TRIGGER key pad. The annunciator lamp of the selected key pad (X1, $\div 10$ or $\div 100$) will illuminate.




Figure 3-7. Time/Div, Fast Rise Pulse & Low Distortion Pulse Modes, Equipment Set-Up

f. Touch the STANDBY/OPERATE key pad to "output" the FAST RISE PULSE to the UUT. The OPERATE annunciator will illuminate.

NOTE

The amplitude of the FAST RISE PULSE may be varied by $\pm 9.9\%$ from the 1 volt peak-to-peak level. Refer to step g.

g. To vary the amplitude of the Fast Rise-time Pulse, first touch the DEV key pad. The % DEVIATION display will be 0.0. To increase the amplitude, up to a maximum of +9.9%, touch the increment (deviation) key pad. To decrease the amplitude, to a maximum of -9.9%, touch the decrement (deviation) key pad.

NOTE

% DEVIATION cannot be activated in the STANDBY condition.

3-13. LOW DISTORTION PULSE Mode. To use the 6127A Calibrator in the LOW DISTORTION PULSE Mode, proceed as follows:

a. Connect the equipment as shown in Figure 3-7. (Refer also to Table 3-7.)

b. Touch the LOW DISTORTION PULSE OUTPUT Mode key pad. The annunciator lamp will illuminate indicating that the Calibrator is in the Low

Distortion Pulse Mode and "prompt" lines will appear in the AMPLITUDE/DIV display.

c. Enter the desired AMPLITUDE/DIV number (Any number in a 1, 2, 5 sequence or multiple thereof is a valid entry) by touching, in sequence, the respective key pads; 1, 2, 5 or 0 and then select the desired terminator; V or mV. To change the entry, re-touch the LOW DISTORTION PULSE OUTPUT key pad.

NOTE

If the LOW DISTORTION PULSE output is terminated in 50 Ω, the selected AMPLITUDE/DIV voltage range is from 50 mV to 1 V peak-to-peak. If the output is unterminated, then the range is from 1 V to 100 V peak-to-peak. For "1" VOLTS/DIV and "1" DIV, 50 Ω source is selected by pressing 50 Ω LOAD touch key.

d. Touch the DIVS key pad. "Prompt" lines will appear in the DIVISIONS display.

e. Enter the desired (multiplier) DIVISIONS value (1,2,3,4,5,6,8 or 10) by touching the respective key pads. To change the entry, re-touch the DIVS key pad. The "Prompt" lines will re-appear, then enter the new number.

f. Touch the TIME/FREQ key pad. "Prompt" lines will appear in the TIME/DIV-FREQUENCY display.

TABLE 3-7. LOW DISTORTION PULSE MODE VALID ENTRIES

AMPLITUDE/DIV	DIVISIONS (HI Z)								DIVISIONS (50 Ω)							
	1	2	3	4	5	6	8	10	1	2	3	4	5	6	8	10
20 V																
10 V																
5 V	VALID ENTRY REGION															
1 V	VALID ENTRY REGION															
500mV																
200mV																
100mV									VALID ENTRY REGION							
50mV									VALID ENTRY REGION							

g. Enter the desired frequency (10Hz, 100Hz, 1kHz, 10kHz, 100kHz or 1 MHz) by touching the respective key pad. The display and annunciator will indicate the frequency chosen.

NOTE

If the LOW DISTORTION PULSE output is unterminated then the frequency range selection is restricted to 1 kHz, 10 kHz and 100 kHz.

h. If a trigger output is required for external triggering of the UUT, touch one of the TRIGGER key pads depending on the trigger frequency desired; X1, $\frac{1}{10}$ or $\frac{1}{100}$. The respective annunciator lamp will illuminate.

i. Touch the STANDBY/OPERATE key pad to "output" the LOW DISTORTION PULSE to the UUT. The OPERATE annunciator will illuminate.

NOTE

% DEVIATION function is not available in the LOW DISTORTION PULSE Mode.

3-14. CALIBRATOR Mode. To use the Model 6127A Calibrator in the CALIBRATOR Mode, proceed as follows:

a. Connect the equipment as shown in Figure 3-8.

b. Touch the CALIBRATOR OUTPUT Mode key pad. The VOLTS/DIV and CALIBRATOR annunciator lamps will illuminate and a TIME/DIV-FREQUENCY of 1 kHz will be displayed, indicating that the Calibrator is in the CALIBRATOR Mode. "Prompt" lines will appear in the AMPLITUDE/DIV display.

c. Enter the desired AMPLITUDE/DIV number and terminator (Any number in a 1, 2, 5 sequence or multiple thereof is a valid entry.) by

touching, in sequence, the respective key pads; 1, 2, 5 or 0. (To change the entry, re-touch the CALIBRATOR OUTPUT key pad. The "prompt" lines will re-appear, then enter the new value and terminator.)

d. Touch the DIVS key pad. The "prompt" lines will appear in the DIVISIONS display.

e. Enter the desired (multiplier) DIVISIONS value (1, 2, 3, 4, 5, 6, 8 or 10) by touching the respective key pads. (To change the entry, re-touch the DIVS key pad. The "prompt" lines will re-appear; then enter the new number.)

NOTE

The TIME/FREQ key pad is not used in the CALIBRATOR Mode. The frequency of the Calibrator signal is fixed at 1 kHz.

f. If a trigger output is required for external triggering of the UUT, touch one of the TRIGGER key pads. The annunciator lamp of the selected TRIGGER key pad will illuminate. The trigger is slaved to the 100 Hz chopped rate but disappears once the ALTERNATE Mode has been selected.

g. Touch the STANDBY/OPERATE key pad to the "output" the CALIBRATOR signal to the UUT. The OPERATE annunciator will illuminate.

NOTE

Until the UUT/CALIB key pad is touched, the signal appearing at the UUT vertical input is both the Model 6127A signal and the UUT calibrator signal; alternately present at a 100 Hz chopped rate.




Figure 3-8. Calibrator Mode, Equipment Set-Up

h. To put the CALIBRATOR into the ALT MODE, touch the UUT/CALIB key pad. The initial touch presents the Model 6127A Calibrator signal (CALIB) to the oscilloscope. The second time the UUT/CALIB key pad is touched, the signal present is the oscilloscope's own internal calibration signal (UUT). This will be indicated by the lamp on the Model 61272A Amplitude Comparator illuminating. Subsequent touches of the UUT/CALIB key pad "toggle" the signal from CALIB to UUT.

i. To change back to the automatic (chopped) mode, it will be necessary to re-touch the CALIBRATOR OUTPUT key pad and re-enter an AMPLITUDE/DIV value.

j. To activate % DEVIATION, touch the DEV key pad. The DEVIATION display will be 0.0 and neither the HI nor the LO lamp will be lit initially.

k. If the oscilloscope internal "calibration" signal does not agree with the Calibrator value, increment or decrement the % DEVIATION by touching the respective key pad until the signals coincide. The number indicated on the display represents the error of the UUT (oscilloscope). If the HI annunciator lamp illuminates, the calibration error of the UUT is high; if the LO annunciator lamp illuminates, the calibration error of the UUT is low.

3-15. REMOTE OPERATION

3-16. In the REM (Remote) Mode, the Model 6127A is remotely programmable by an IEEE Standard 488 Bus. In this mode, all of the front panel touch

controls are disabled except the LOC/REM key pad. The POWER switch also remains under manual control.

3-17. Programming

3-18. GENERAL. The Model 6127A is programmable in the REM (Remote) Mode through a digital interface that is specified and described in IEEE Standard 488-1978, "Standard Digital Interface for Programmable Instrumentation". This digital interface is referred to as General Purpose Interface Bus (GPIB) throughout this manual. Connector J1, located at the rear of the instrument, is a standard 24 pin connector that permits remote programming of the Model 6127A via the GPIB. Table 3-8 lists the pin assignments of J1.

3-19. The GPIB consists of 16 signal lines that are functionally divided into three component busses. They are: an eight-line data bus (ASCII), a three-line transfer control (handshake) bus and a five-line management bus. The following is a definition of these signals:

a. Data Bus Lines consist of eight bidirectional signal lines; DI01 through DI08 inclusive. Information in the form of data bytes (eight bits at a time) is transferred over this bus during a handshake sequence. These data bytes are sent and received in a byte-serial, bit-parallel fashion.

Table 3-8.
6127A IEEE-488 Interface Connector (J1)

PIN NO.	SIGNAL	PIN NO.	SIGNAL
1	D103	13	NDAC
2	D104	14	IFC
3	D101	15	SRQ
4	D102	16	REN
5	D108	17	NRFD
6	D107	18	DAV
7	D105	19	ATN
8	Ground	20	EOI
9	D106	21	Not used
10	Ground	22	Not used
11	Ground	23	Not used
12	Ground	24	Not used

b. Transfer Bus Everytime a data byte is transmitted over the data bus a "handshake" sequence is executed between the enabled talker and all enabled listeners. These signal lines are:

1. DAV (Data Valid) Indicates to acceptor that data is available when asserted low by the talker.

2. NRFD (Not Ready For Data) Device(s) not ready to accept data. When all asserted listeners for a particular data byte transfer release NRFD, the NRFD line becomes unasserted (high).

3. NDAC (Not Data Accepted) Indicates acceptance of all devices when NDAC line becomes unasserted (high).

c. Management Bus is a group of five signal lines used to control the operation of the GPIB and are defined as follows:

1. ATN (Attention) - When ATN (con-

1. ATN (Attention) - When ATN (controller generated) is asserted (high), data lines carry addresses or commands; when unasserted (low), they carry data (controller driven).

2. IFC (Interface Clear) - Puts talkers and listeners into their idle states; and places interface system in a known quiescent state.

3. SRQ (Service Request) - Used by a device to indicate a need for service and to request an interrupt of the current events sequence.

4. REN (Remote Enable) - Selects between two alternate sources of device programming data; front panel control or interface control (controller driven).

5. EOI (End Of Identify) - Used to indicate end of multiple byte transfer sequences or with ATN to perform a parallel polling.

3-20. TYPICAL GPIB SYSTEM

3-21. A typical GPIB system is shown in Figure 3-9. It includes a controller, the Model 6127A Oscilloscope Calibrator and the Unit Under Test (UUT). In this case; an oscilloscope.

3-22. Functions

3-23. The following are definitions of the functions performed by instruments connected to the GPIB.

a. CONTROLLER - Software controlled device that determines which instruments will talk and which will listen during any given time interval. May also designate itself as a talker or listener, as required by the program routine, or send special codes and commands (interface messages) to either selected or all instruments on GPIB.

b. TALKER/LISTENER - Instrument on GPIB that may be designated alternately by the controller as a talker (sends data) or listener (receives data) over the data bus.

c. TALKER - Instrument connected to GPIB that can be addressed by an interface message from the controller to send device dependent messages over the data line.

d. LISTENER - Instrument connected to GPIB that can be addressed by an interface message from the controller to receive device dependent messages over the data line.

3-24. Messages

a. INTERFACE MESSAGES - These messages perform some direct function (address or control) within the interface which may or may not affect the operation of the interconnected devices. These messages include:

- (1) Primary talk addresses
- (2) Primary listen addresses
- (3) Addressed commands
- (4) Universal commands

Interface messages are specified by the IEEE-488 Standards and are sent exclusively by a controller device. All such messages are transmitted with the ATN line asserted (in the true state).




Figure 3-9. Typical GPIB System




Figure 3-10. Model 6127A Address Switch

b. DEVICE DEPENDENT MESSAGES - These messages are specifically constructed to affect some action directly on the device that message is sent to. An example would be a string of characters sent to the 6127A to select the LOW DISTORTION PULSE Mode. Device dependent messages are defined by the instrument (in this case the 6127A) interface designer. Device dependent messages may be programming data sent to an instrument to set up a measurement, or it may be numerical data returning from the instrument that results from the measurement. All such messages are transmitted with the ATN line unasserted (in the false state).

3-25. Address Switch

3-26. The bank of eight rocker switches located at the rear of the Model 6127A (See Figure 3-10) is the bus address switch. The first five switches in the bank are used to set the address. To do this, pick an unused bus address between 0 and 30 decimal. Convert the address to binary (refer to table 3-9) and write it left to right, putting the Least Significant Bit (LSB) on the left. Set the five address switches, using a soft-pointed instrument such as a pencil, to the binary value. As an example, the address switch depicted in Figure 3-10 is set to an address of 09 decimal.

NOTE

The 6127A is used as both a listener and Talker. The last three switches of the Address Switch (6, 7, 8) should all be set to the OFF (high) position. This permits the controller program to decide when to make the 6127A a Listener or Talker.

Table 3-9. Address Switch Conversion Table

DECIMAL NUMBER	ADDRESS SWITCH					DECIMAL NUMBER	ADDRESS SWITCH				
	1	2	3	4	5		1	2	3	4	5
00	0	0	0	0	0	16	0	0	0	0	1
01	1	0	0	0	0	17	1	0	0	0	1
02	0	1	0	0	0	18	0	1	0	0	1
03	1	1	0	0	0	19	1	1	0	0	1
04	0	0	1	0	0	20	0	0	1	0	1
05	1	0	1	0	0	21	1	0	1	0	1
06	0	1	1	0	0	22	0	1	1	0	1
07	1	1	1	0	0	23	1	1	1	0	1
08	0	0	0	1	0	24	0	0	0	1	1
09	1	0	0	1	0	25	1	0	0	1	1
10	0	1	0	1	0	26	0	1	0	1	1
11	1	1	0	1	0	27	1	1	0	1	1
12	0	0	1	1	0	28	0	0	1	1	1
13	1	0	1	1	0	29	1	0	1	1	1
14	0	1	1	1	0	30	0	1	1	1	1
15	1	1	1	1	0						

TABLE 3-10. 6127A PROGRAMMING INFORMATION

COMMAND	DEFINITION
DT ON	Set up next command string and await group execute trigger
DT OFF	Execute command string immediately
MODE V	Selects STANDARD AMPLITUDE Mode
MODE MKRS	Selects STANDARD TIME Mode
MODE CUR	Selects STANDARD CURRENT Mode
MODE CAL	Selects STANDARD CALIBRATOR Mode
MODE EDGE	Selects LOW DISTORTION PULSE Mode
MODE FASTEDGE or FE	Selects FAST RISETIME PULSE Mode
F\$/D G\$H\$	<p>Selects Unit/Div Output</p> <p>Valid G\$ = Numeric value from 0.001 to 500 in a 1, 2, 5 sequence</p> <p>Valid H\$ = NS (nsec), US (usec), MS (msec), S (sec), UV (μV), V (volts), MA (mA)</p>
FREQ A\$	<p>Selects frequency for: STANDARD AMPLITUDE, STANDARD CURRENT, FAST RISETIME PULSE and LOW DISTORTION PULSE</p> <p>Valid A\$ = DC, 10Hz, 100Hz, 1kHz, 10kHz, 100kHz, 1MHz</p>
MULT I\$	<p>Selects Multiplier</p> <p>Valid I\$ = 1,2,3,4,5,6,8,10</p>
POS	Selects POSITIVE Voltage/Current
NEG	Selects NEGATIVE Voltage/Current
LDZ B\$	<p>Selects either high impedance (unterminated) or low impedance ($50\ \Omega$) output of STANDARD AMPLITUDE and STANDARD CALIBRATOR Modes</p> <p>Valid B\$ = HI or $50\ \Omega$</p>
TRIG C\$	<p>Selects Trigger Output Mode</p> <p>Valid C\$ = NORM ($\div 1$), X.1 ($\div 10$), X.01 ($\div 100$), OFF (Disable), ON (Return to last valid state)</p>
<p>NOTES: 1. All letters transmitted on bus are to be as upper case ASCII characters.</p> <p>2. Only the first two characters of each COMMAND word are required by the 6127A.</p>	

TABLE 3-10. 6127A PROGRAMMING INFORMATION Continued

COMMAND	DEFINITION
OUT D\$	<p>Controls OUTPUT Valid D\$ = OFF (Standby) or ON (Operate)</p>
LOOP E\$	<p>Controls CURRENT Loop Output Valid E\$ = On or Off</p>
VAR	<p>DEVIATION on [Valid in ON (Operate) state only]</p>
FXD	<p>DEVIATION off</p>
PCT J\$	<p>% DEVIATION (Valid only in VAR state) Valid J\$ = Numeric value from -9.9 to +9.9</p>
INC	<p>Increment DEVIATION one step (0.1% increase) (Valid only in VAR state)</p>
DEC	<p>Decrement DEVIATION one step (0.1% decrease) (Valid only in VAR state)</p>
CHOP Z\$	<p>Selects Mode when in STANDARD CALIBRATOR Mode Valid Z\$ = AUTO (100 Hz chopping rate), DUT (Device Under Test), CG (Calibrator)</p>
LLO	<p>Disables Local operation of front panel</p>
<p><u>CONTROLLER REQUESTING INFORMATION</u></p>	
ERR?	<p>Sets up 6127A (CG) to respond with a message in the form: ERR X\$,(CR) (LF-EOI) Where X\$, = Numeric error codes if no error pending X\$ should = 00</p>
PCT?	<p>Sets up 6127A (CG) to respond with a transmission of the Deviation data in the form: PCT Y\$,(CR) (LF-EOI) Where Y\$ = Numeric value between -9.9 and +9.9</p>
ID?	<p>Sets up the Model 6127A (CG) to respond in the form: BALLANTINE 6127A</p>

3-27. EXPANDED OPERATING INSTRUCTIONS

3-28. Output Heads. Two accessory output heads are provided with the Model 6127A Calibrator. These heads connect to the instrument at the front panel OUTPUT receptacle, A24-J100. Either of these accessories, when attached, connect directly to the Unit Under Test (UUT).

3-29. The Model 61271A Head is used for:

a. VOLTS/DIV

Provides accurate, positive-going square waves of 10 Hz, 100 Hz, 1 kHz, and 10 kHz as well as positive and negative dc. The amplitude of this signal may be varied from 40 μ V up to 200 V in a 1, 2, 5 sequence. See table 3-5 for valid entries. Amplitude deviation capability of up to $\pm 9.9\%$ (high or low in terms of UUT error) is also provided.

This output signal may be used to check an oscilloscope's amplitude accuracy, vertical input attenuator compensation, and low frequency compensation. Other applications are to check the response of both high and low pass filters and to check the accuracy of dc and true rms voltmeters. The VOLTS/DIV output signal drives into a high impedance (1 Megohm) for all voltage levels and into 50 ohms for voltage levels up to five volts.

b. TIME/DIV

Provides accurate time markers from five seconds to 0.5 nanoseconds (2 GHz) into a 50 ohm load, in a 1, 2, 5 sequence. Time deviation capability to $\pm 9.9\%$ (high or low in terms of UUT error) is also provided.

The timing markers are crystal controlled and may be used to calibrate the time base (including delayed time base) of oscilloscopes; and to verify the performance of frequency counters, spectrum analyzers and general timing circuits.

c. FAST RISE PULSE

Provides a clean, flat-topped, positive-going, fast-rise step from a negative base to ground with a repetition frequency of either 10 kHz or 100 kHz into a 50 ohm load.

The fast rise signal is nominally one volt peak-to-peak when terminated in a 50 ohm load. It may be varied in amplitude from 0.9 to 1.1 volts by activating % DEVIATION. When -9.9% Deviation is selected, the fast rise amplitude is about 0.9 volts and when +9.9% Deviation is selected, the fast rise amplitude is about 1.1 volts.

The 200 picosecond rise time is used for checking step response of oscilloscope amplifiers (as well as other amplifiers) and for verifying overshoot, ringing, and pulse shape of the oscilloscope display. It may also be used to trigger logic elements and to check their propagation and

delay times. Still other applications (made possible because the FAST RISE signal repetition rate is crystal controlled and very rich in harmonics) include comb markers to check sweep generators and a frequency standard for checking spectrum analyzers beyond 12 GHz.

d. LOW DISTORTION PULSE

Provides a clean, flat-topped, 100 nanosecond rise time squarewave, variable in amplitude from 1 volt to 100 volts, into a high impedance (1 M Ω shunted by less than 35 pF); and a 2 nanosecond rise time squarewave, variable from 50 millivolts to 1 volt, into 50 ohms. Repetition rates of 10 Hz, 100 Hz, 1 kHz, 10 kHz, 100 kHz and 1 MHz are selectable for the low impedance (50 Ω) output and 1 kHz, 10 kHz and 100 kHz for the high impedance output. No % Deviation in time or amplitude is provided for this mode.

The low distortion pulse may be used to check the frequency compensation of oscilloscope input attenuators and will find application wherever a clean, fast rise, squarewave is required.

3-30. MODEL 61272A HEAD (Amplitude Comparator)

Permits comparison of the Model 6127A VOLTS/DIV output to the internal calibrator signal available on most oscilloscopes. When initially activated, the two signals are alternately displayed at a 100 Hz chopped rate. The selected output from the 61272A is applied to the oscilloscope vertical input as shown in figure 3-22. The first time the UUT/CALIB key pad is touched, the output from the 61272A Head is the VOLTS/DIV signal from the Model 6127A. The second touch of the key pad changes the output to that of the oscilloscope (UUT) calibrator signal and is indicated by the lamp on the Model 61272A. Successive touches cause the output from the 61272A Head to alternate between the VOLTS/DIV signal and the UUT calibrator signal. To change operation back to the chopped mode, the CALIBRATOR OUTPUT key pad is pressed and then a new AMPLITUDE/DIV entry is made.

In the chopped mode, the 61272A serves as a high resolution coincidence detector. The % Deviation feature is activated and then varied to create a "nulled" display on the oscilloscope. This indicates that the oscilloscope (UUT) internal calibrator peak-to-peak amplitude is equal to the VOLTS/DIV output from the 6127A. By reading the 6127A % DEVIATION displayed and performing a simple mathematical compensation, the calibration error of the UUT calibrator may be determined. (See paragraph 3-55.)

NOTE

A 50 Ω load may be presented to the UUT internal calibrator by pressing the 50 Ω LOAD touch key on the Model 6127A Calibrator. The comparator oscilloscope still retains its normal 1 M Ω input impedance under this condition.

```

100  ON SRQ GOTO 900
110  PRINT "STANDARD AMPLITUDE MODE"
120  PRINT "VOLTS/DIV ?"
130  INPUT G$
140  PRINT "DIVISIONS ?"
150  INPUT I$
160  PRINT "FREQUENCY ?"
170  INPUT A$
180  J$ = "DT OFF; MODE V; V/D "+G$+"; MULT"+I$+"; FREQ "+A$+"; OUT ON"
190  PRINT @ 1, J$
200  PRINT J$
210  GOTO 110

900  Y% = SPL(1)! SERIAL POLL OF DEVICE NEEDED TO CLEAR SRQ
910  ! IF Y% = 64 THEN DEVICE POLLED HAS GENERATED SRQ
920  PRINT @1, "ERR ?"
930  PRINT "SRQ GENERATED ERROR REQUEST"
940  INPUT @1, X$
950  PRINT X$ + " ' FROM CG"
960  RESUME

```

Comments

```

100  Directs the controller if device (6127A) on bus requests service.
110  States that STANDARD AMPLITUDE mode has been selected.
120  Prompts user to select VOLTS/DIV value.
130  User inputs numeric value for VOLTS and terminator for DIV (UV, MV or V for
      STANDARD AMPLITUDE Mode).
140  Prompts user to select DIVISIONS (multiplier) value.
150  User inputs numeric value for DIVISIONS.
160  Prompts user to select FREQUENCY.
170  User inputs FREQUENCY value.
180  Defines string variable J$ for a typical command string to 6127A.
190  Outputs string variable J$ via GPIB to device 1 (6127A).
200  Prints variable string J$ for user.
900  SRQ subroutine.

```

NOTE: A semicolon is used as separator for each command variable of table 3-10.

Figure 3-11. General Talker/Listener program for the 6127A

3-31. Trigger Output. The 6127A TRIGGER OUTPUT BNC connector provides a squarewave output for externally triggering the oscilloscope under test. The choice of trigger outputs are:

OFF (no trigger output), X1 (the normal mode) or $\div 10$ and $\div 100$. The X1 trigger output is locked to the Time/Div markers or to the Volts/Div, Fast Rise Pulse, or Low Distortion pulse squarewave.

When $\div 10$ or $\div 100$ is selected, the trigger output squarewave repeats once for every ten or one-hundred transitions of the time marker or amplitude squarewave outputs. The frequency of the TRIGGER OUTPUT is limited to a maximum of 10 MHz (100 ns) and a minimum of 0.002 Hz (500 seconds). For time markers above 10 MHz, the trigger frequency remains at 10 MHz. For time marker and trigger coincidence always trigger on the negative going TRIGGER OUTPUT edge.

3-32. The TRIGGER OUTPUT BNC shell is connected to circuit ground (isolated from the enclosure of the Model 6127A) to minimize noise in the amplitude calibration signals. The difference in potential between the enclosure ground and the TRIGGER OUTPUT BNC connector ground never exceeds more than a few millivolts across the 50 ohm 1/2 W resistor connecting the BNC connector shell to the enclosure.

CAUTION

Never apply any voltage or current between the TRIGGER OUTPUT ground and the 6127A enclosure. The TRIGGER OUTPUT cable should always be terminated in 50Ω at the trigger input of the UUT.

3-33. Milliamperes/Div CURRENT LOOP. The Milliamperes/Div CURRENT LOOP provides for the calibration of clamp-on type ac and dc current probes. The output is a squarewave current that may be varied from 1 to 50 mA in a 1, 2, 5 sequence. A choice of frequencies of 10 Hz, 100 Hz, 1 kHz and

10 kHz are offered as well as positive direct current and negative direct current. The arrow above the CURRENT LOOP indicates the direction of current flow when DC POS is selected.

3-34. The Milliamperes/Div CURRENT LOOP may be used to verify the current amplitude calibration of both ac and dc current probes. Deviation capability of $\pm 9.9\%$ is provided for the current probe under test.

3-35. Operating Hints. Refer to table 3-11 for a list of helpful operating hints.

3-36. Verifying Amplitude Accuracy and Input Attenuator Compensation.

a. Select the VOLTS/DIV OUTPUT mode to provide squarewaves having extremely flat tops and bottoms, a precisely known peak-to-peak amplitude and a crystal controlled frequency. Attach the Model 61271A Accessory Head to connect the Calibrator signal to the oscilloscope amplifier (UUT). (Refer to figure 3-12 for test equipment set-up.)




Figure 3-12. Volts/Div Mode, Equipment Set-Up

TABLE 3-11. MODEL 6127A OPERATING HINTS

HINT	REASON
<p>1. Always connect the UUT and 6127A Calibrator to adjacent power mains receptacles on the same branch line.</p>	<p>To minimize any potential (noise) between the 6127A and the UUT when using low level calibrating signals and when checking wide bandwidth scope amplifiers.</p>
<p>2. Always set the 6127A STANDBY/OPERATE to OPERATE after changing operating modes.</p>	<p>Because STANDBY mode disconnects the 6127A OUTPUT signal as a safety precaution to protect the operator. OPERATE connects the OUTPUT signal to the UUT. % DEVIATION may only be called for in the OPERATE mode.</p>
<p>3. Always select a 6127A TRIGGER OUTPUT when externally triggering the UUT.</p>	<p>The 6127A TRIGGER OUTPUT initializes to OFF and the UUT will not have a display unless a 6127A trigger is requested.</p>
<p>4. Always use a 10 kHz to 30 kHz high frequency cut-off filter in the UUT when using 6127A VOLTS/DIV amplitude levels below 10 mV.</p>	<p>This minimizes base line noise and permits viewing the cleanest calibrating signal in the 40 microvolt to 10 millivolt range.</p>
<p>5. Use a 50 ohm feed thru termination between the input BNC of high impedance (1 megohm) scopes and the Model 6127A OUTPUT connector when selecting:</p> <p style="padding-left: 40px;">TIME/DIV FAST RISE PULSE LOW DISTORTION (below 1 Volt 50Ω is automatically selected)</p>	<p>Because use of a 50Ω load is required to preserve wave shapes in these modes.</p>
<p>6. When checking a UUT having a 50 ohm input impedance, select 50Ω LOAD on the 6127A in:</p> <p style="padding-left: 40px;">VOLTS/DIV LOW DISTORTION PULSE</p>	<p>Because then the Model 6127A will automatically set proper voltage levels for 50 ohm inputs.</p>
<p>7. Don't be surprised when you make a selection if the previous selection is displayed.</p>	<p>The 6127A intelligently returns to the <u>last</u> valid entry made if you enter an <u>invalid</u> request.</p>
<p>8. If the Model 6127A reacts strangely, with blinking indicators or invalid indications, simply turn the POWER off for 10 seconds and then turn it back on.</p>	<p>The Model 6127A microprocessor lost program control. Turning the POWER off for ten seconds resets the 6127A digital logic and properly re-starts the Calibrator, beginning with a Self Test.</p>
<p>9. Press the CLEAR key pad twice to reset the digital control circuits and initiate the Self Test sequence.</p>	<p>Use if Model 6127A appears to lose program control or use to clear the calibrator setting by calling for the Self Test.</p>
<p>10. When using the TIME/DIV mode, avoid the base line prior to the first pulse by selecting negative slope, external triggering on the UUT.</p>	<p>Because the Time Markers are coincident with the faster (negative going) edge of the TRIGGER OUT square wave.</p>
<p>11. When externally triggering a UUT from the 6127A TRIGGER OUTPUT always select negative triggering slope on the UUT.</p>	<p>The negative edge of the 6127A TRIGGER OUTPUT squarewave is time coincident with the TIME/DIV markers and the VOLTS/DIV calibrating squarewave.</p>

b. Set the Model 6127A controls as follows:

OUTPUT Mode	VOLTS/DIV
AMPLITUDE/DIV	Same as the UUT Volts/Div range to be checked
DIVS	5
TIME/DIV-FREQUENCY	1 kHz
DEV	OFF
STANDBY/OPERATE	OPERATE

c. Set the oscilloscope (UUT) controls as follows:

Volts/Div	1
Input Coupling	DC
Trigger Source	Internal, + Slope
Trigger Coupling	AC
Time/Div	0.5 milliseconds

d. Observe that the UUT displays a square-wave signal of approximately 5 divisions peak-to-peak. The signal should have flat tops and sharp corners to verify proper oscilloscope vertical amplifier alignment. (See figure 3-13.)

NOTE

It is desirable to maintain a constant input capacitance, on all UUT ranges tested, by inserting an Input Capacitance Standardizer (such as the Ballantine Model 10650A) between the UUT input and the 61271A output. Constant input capacitance on all ranges is required on a scope to assure proper frequency compensation of scope probes when Volts/Div ranges are switched. Most scopes provide capacitance trimming to standardize input capacitance between ranges.

e. If an Input Capacitance Standardizer is used, it will be necessary to change the DIVS value to 10 to maintain the same display of 5 divisions on the UUT as the Capacitance Standardizer attenuates the signal by a factor of 2:1. Adjust the Input Capacitance Standardizer compensation, using an insulated alignment tool, until a flat topped squarewave with sharp corners is displayed on the UUT. Do not readjust the standardizer when switching Volts/Div ranges on the oscilloscope.

f. Select % DEVIATION on the 6127A by pressing the DEV key pad and observe that 0.0% is indicated by the DEVIATION display.

g. Position the bottom of the displayed squarewave on the next lower horizontal graticule line of the UUT.




Figure 3-13. Volts/Div Display; 1 V, 5 Div

h. Increment the % DEVIATION by pressing the Δ key pad (this will cause the amplitude of the squarewave to increase) or decrement by pressing the ∇ key pad (this will cause the squarewave amplitude to decrease). By incrementing or decrementing, adjust the squarewave amplitude until it is exactly 5 divisions peak-to-peak as indicated by the UUT. Read the % DEVIATION displayed on the Model 6127A. It is the amplitude range calibration error of the UUT.

NOTE

If it was necessary to increment the % DEVIATION to obtain a display of exactly 5 divisions, the Calibrator will indicate a LO % DEVIATION reading. This means the UUT has low sensitivity. A HI % DEVIATION reading (the result of decrementing) means the UUT has high sensitivity.

i. If the % DEVIATION reading exceeds the allowable calibration error of the UUT, note the reading and recalibrate the oscilloscope.

j. Check each Volt/Div range of the UUT. Set the Model 6127A Calibrator Volt/Div to match the UUT. Check all ranges for amplitude and flatness of waveshape. For dual trace oscilloscopes repeat the procedure for the second channel.

k. If the % DEVIATION reading exceeds the accuracy limits of the UUT or waveshape aberration errors occur, the UUT will require maintenance and recalibration of vertical amplifier sensitivity, attenuator frequency compensation and/or input capacitance adjustment (if using an Input Capacitance Standardizer).

3-37. Possible Errors When Using VOLTS/DIV Mode.

3-38. LOADING ERRORS (HI Z LOAD). The VOLTS/DIV OUTPUT amplitude accuracy is specified into 10 Megohms. Because the output impedance of the 6127A VOLTS/DIV attenuator is very low, the errors caused by loads of less than 100 kΩ are small. Changing the DIVISIONS multiplier does not change the output impedance or the loading errors. Refer to table 3-12 for a summary of these loading errors. The 1 megohm input impedance found on most oscilloscope vertical amplifiers causes negligible loading errors and the 0.25% calibration accuracy of the Model 6127A is maintained. However, even

severe loading errors may be corrected by applying the following formula:

1. Determine the load resistance. (R_L).
2. Find the 6127A output resistance (R_S) on that VOLTS/DIV range by referring to table 3-12.
3. Calculate the loading error (E_L), in percent, by:

$$E_L = \frac{R_S}{R_S + R_L} \times 100$$

TABLE 3-12.
MODEL 6127A VOLTS/DIV OUTPUT RESISTANCE AND LOADING ERROR

VOLTS/DIV	6127A OUTPUT RESISTANCE IN OHMS (R_S)	% LOADING ERROR				
		1 MΩ LOAD	10 MΩ LOAD			
20 V	220	- .020	0			
10 V	2.72 k	- .270	- .025			
5 V	2.09 k	- .207	- .019			
2 V	1.12 k	- .110	- .090			
1 V	695	- .068	- .005			
.5 V	↑	↑	↑			
.2 V						
.1 V						
50 mV						
20 mV						
10 mV						
5 mV						
2 mV				51.6	NEGLIGIBLE	NEGLIGIBLE
1 mV				↓	↓	↓
.5 mV						
.2 mV						
.1 mV						
50 μV						
20 μV						
10 μV						

3-39. **LOADING ERRORS (50Ω LOAD).** When the 50 Ω LOAD touch key is pressed, the 6127A presents a 50 Ω source impedance to the load. For this condition, the amplitude accuracy specification of the 6127A is only valid when a precise 50 ohm load is used. Deviation of the 50 ohm load from nominal will cause calibration errors. Refer to figure 3-14a. When the 50 Ω LOAD mode is selected, but a high load impedance is used, then the VOLTS/DIV OUTPUT amplitude will be approximately twice the value displayed by the 6127A Calibrator. Refer to figure 3-14b.

3-40. **DC OFFSET ERRORS.** For VOLTS/DIV OUTPUT amplitudes above 50 mV, the 6127A output attenuator resistors must dissipate sufficient power to heat the precision resistors. Although ultra-stable precision resistors are used, the offset errors caused by self heating may be noticeable when either DC POS or DC NEG is selected. In these modes, the attenuator resistors dissipate twice the power they would for any of the squarewave modes. Thermo-electric potentials are generated as a result of the attenuator heating and these, in turn, cause offsets of a few microvolts on the lower level ranges of VOLTS/DIV OUTPUT.

3-41. Always allow a few minutes waiting period when selecting low VOLTS/DIV OUTPUT amplitudes (below 50 mV) after having used the higher output amplitudes. This assures temperature equalization

in the precision attenuators and relays and minimizes thermo-electric offset potentials in low level VOLTS/DIV OUTPUT signals.

3-42. Do not use the GND position of the oscilloscope (UUT) input coupling switch or short the input terminals of the voltmeter (UUT) to establish a zero voltage reference. Instead, select the Model 6127A STANDBY mode. This eliminates the effect of most of the thermo-electric offset potentials in the Calibrator. The voltage offset sensed by the UUT when the Model 6127A is in the STANDBY mode is the minimum error voltage of the total calibration system. This voltage should be measured whenever using low dc mode amplitude levels (below 50 mV) of VOLTS/DIV OUTPUT and the correction applied to the calibration measurement. Thermo-electric potentials are offset voltages from reference zero and do not affect the basic accuracy of squarewave amplitude calibration.

3-43. Ground Current Errors

3-44. Always ground the Model 6127A Calibrator, the Bus Controller and the UUT to earth ground. Use adjacent power mains receptacles on the same power outlet branch to avoid potentials between the various earth grounds and between power line low and earth ground. This is especially important for minimizing noise interference when using low amplitude levels of the VOLTS/DIV OUTPUT.




Figure 3-14a. 50Ω Source/50Ω Load Condition




Figure 3-14b. 50Ω Source/High Impedance Load Condition

3-45. The VOLTS/DIV circuitry floats within the 6127A and is grounded only at the 61271A Head OUTPUT BNC. Always connect the 61271A Head directly to the UUT input and not through additional connecting cables. This avoids circulating ground loop noise problems between the 6127A/61271A output and the UUT input. When using VOLTS/DIV OUTPUT signals below 100 mV and the calibration of the UUT is suspect or displays either digital noise or amplitude distortion at power mains frequency, carefully check all of the instruments for power mains circuit leakage problems. If the instruments are found safe, it is recommended that one or more of these instruments be temporarily isolated from the power mains earth ground. Well shielded isolation transformers may also be used to connect each of the instruments separately to the power mains. These measures will reduce or eliminate circulating ground currents and thus reduce the noise content of low level VOLTS/DIV calibration signals. See figure 3-15 for a typical 10 microvolt, 5 div, 1 kHz VOLTS/DIV signal displayed with dc to 30 kHz bandwidth.

WARNING

Disconnecting earth grounds may result in a personnel safety hazard. Use extreme caution to avoid shock. One instrument should remain grounded at all times. If in doubt, measure the potential between the enclosures of all instruments in the test set-up using a high impedance voltmeter. Always restore earth ground connections to all instruments once low amplitude VOLTS/DIV calibration is completed.




Figure 3-15. Volts/Div Display; 10 uV, 5 Div

3-46. Warmup Errors.

3-47. The Model 6127A is fully operational within one minute after the power has been turned on. The amplitude calibration drift during the first 20 minutes of operation in a laboratory environment, where the ambient is held constant, is less than ± 0.2 percent.

3-48. Verifying Oscilloscope Time Base Accuracy

a. Select the TIME/DIV OUTPUT mode to provide time markers, having well defined peaks (figure 3-16) for periods slower than 10 nanoseconds and sinewaves for 1 and 0.5 nano-seconds (figure 3-17 and 3-18). All timing signals are locked to the 6127A precision crystal controlled clock. Attach the Model 6127A Accessory Head to connect the Calibrator signal to the oscilloscope (UUT). Refer to figure 3-19 for test equipment set-up.




Figure 3-16. Time/Div Display, 1 ms Markers

b. Set the Model 6127A controls as follows:

OUTPUT Mode	TIME/DIV
TIME/FREQ	Same as the UUT Time/Div range to be checked
DEV	Off
TRIGGER	\div 10
STANDBY/OPERATE	OPERATE

c. Set the oscilloscope (UUT) controls as follows:

Volts/Div	0.2 V
Input Coupling	DC
Trigger Source	External, - Slope
Trigger Coupling	AC
Time/Div	To UUT range that is to be checked, (Rotate the Time/Div Variable control to the CALIBRATE position.)

d. Adjust the oscilloscope trigger controls to obtain a stable display. Observe that the peak-to-peak amplitude of the time markers is about 5 divisions.

NOTE

Use triggered sweep synchronization for all Time/Div settings of the UUT to avoid unstable triggering and to optimize left hand time marker alignment with the vertical graticule line.

e. Adjust the oscilloscope horizontal position control to place the second marker pulse on the second vertical graticule line.

f. Select %DEVIATION on the 6127A by pressing the DEV key pad and observe that 0.0% is indicated by the DEVIATION display.

g. Increment the % DEVIATION by pressing the Δ key pad (this will cause the distance between the time markers to increase) or decrement by pressing the ∇ key pad (this will cause the distance to decrease). By incrementing or decrementing, adjust the time markers so that they are coincident with the vertical graticule lines. (See figure 3-16.) The second and tenth time marks should exactly align with the vertical graticule lines. Read the % DEVIATION displayed on the Model 6127A. It is the time base range calibration error of the UUT.

NOTE

If it was necessary to increment the % DEVIATION to align the time markers, the Calibrator will indicate a LO % DEVIATION reading. This means the UUT time base calibration is slow. A HI % DEVIATION reading (the result of decrementing) means the UUT calibration is fast.




Figure 3-17. Time/Div Display, 1 ns Markers

h. If the % DEVIATION reading exceeds the allowable time base calibration error of the UUT, note the reading and any obvious sweep non-linearity before recalibrating the oscilloscope.




Figure 3-18. Time/Div Display, 500 ps Markers

i. Check each Time/Div range of the UUT. Set the Model 6127A Calibrator TIME/DIV to match that of the UUT.

NOTE

When using the higher TIME/DIV ranges of the 6127A, oscilloscopes with insufficient bandwidth will show a decrease in vertical sensitivity and some on-screen distortion. In this case, it will be necessary to switch to a more sensitive Volts/Div range of the UUT.

3-49. To calibrate fast sweeps of oscilloscopes having low bandwidths, do not select the same TIME/DIV setting on the Model 6127A as the range being checked on the UUT. Instead, select a 6127A TIME/DIV range that is ten times slower than that of the oscilloscope. This will produce two markers on the UUT display, one at the left vertical graticule line and one at the right; still adequate for time base calibration. For example: to calibrate a 1 ns/div sweep range on an oscilloscope having only a 150 MHz bandwidth, select the 10 ns TIME/DIV range of the 6127A Calibrator. The oscilloscope vertical amplifier is then required to pass only the 100 MHz content of the 10 ns time markers and will readily display them for full graticule time base accuracy verification.

3-50. Fast Rise Pulse Measurements. The Model 6127A provides a fast rise time signal from a generator located within the Model 61271A Head. The FAST RISE PULSE OUTPUT features a clean 200 ps rise time pulse that is ideal for checking high frequency alignment of both real time and sampling oscilloscopes. (See figure 3-20.) It permits verification of scope bandwidth by relating the risetime to frequency through use of the following formula:

$$\text{Bandwidth (MHz)} = \frac{350}{\text{Risetime (nanoseconds)}}$$




Figure 3-19. Time/Div Mode, Test Set-Up




Figure 3-20. Fast Rise Pulse Display,
200 ps Rise Time

3-51. To check the risetime of an oscilloscope proceed as follows:

a. Connect the Model 6127A Head to the input of the UUT vertical amplifier. (Refer to

figure 3-21 for test equipment set-up.) If the UUT does not have a $50\ \Omega$ input, use a feed-thru termination.

NOTE

It is recommended that the risetime of a real time oscilloscope be measured with the scope vertical input attenuator set to maximum sensitivity. The Model 6127A Fast Rise Pulse delivers 1 Volt peak-to-peak into $50\ \Omega$ and requires a $50\ \Omega$ attenuator between the 61271A OUTPUT connector and the UUT. Use an attenuator that connects directly, without cables. For example: 30 dB of attenuation will be required to display the fast rise pulse on the UUT with the scope Volt/Div set to 5 mV. With this amount of attenuation, the amplitude of the displayed signal will be about 6 divisions high.

b. Trigger the oscilloscope internally (or externally using the 6127A TRIGGER OUTPUT signal terminated in $50\ \Omega$ at the external trigger input of the UUT). Obtain a stable rise time display with the oscilloscope set to its highest sweep speed.




Figure 3-21. Fast Rise Pulse Checks, Equipment Set-Up

c. Activate the DEVIATION controls by pressing the DEV touch key. By either incrementing (Δ) or decrementing (∇) Deviation, the amplitude of the Fast Rise Pulse may be adjusted to exactly 6 divisions peak-to-peak (0% and 100% horizontal reference lines) on the oscilloscope graticule.

NOTE

Before measuring the displayed risetime of the oscilloscope vertical amplifier, the time base accuracy of the oscilloscope should be checked in the graticule area to be used. For best accuracy of the risetime measurement, check at the fastest magnified sweep speed and position the risetime pulse so that it starts at least 10 percent from the beginning of the sweep. This assures that it is in the linear and best calibrated portion of the sweep.

d. Measure the time required for the pulse to rise from the 10% to the 90% level. This is the displayed risetime.

3-52. The 200 picosecond risetime of the 6127A Fast Rise Pulse checks the performance of oscilloscopes having bandwidths exceeding 1 GHz. For a 300 MHz oscilloscope with a 1.2 ns risetime ampli-

fier, the 200 picosecond Fast Rise Pulse will increase the displayed risetime by only 1%. For slower oscilloscopes, the displayed risetime may be taken as the true risetime of the UUT amplifier. For oscilloscopes having faster risetimes, the true risetime of the UUT amplifier may be calculated from the following formula:

$$\text{True Risetime} = \sqrt{\text{Displayed Risetime}^2 - \text{Input Risetime}^2}$$

Where: Input Risetime (of 61271A) = 0.2 ns.

3-53. Oscilloscope (UUT) Calibrator Amplitude Accuracy Check

3-54. Chopped Mode. To verify the amplitude accuracy of the oscilloscope's own internal amplitude calibrator, attach the Model 61272A Head to the Model 6127A and proceed as follows:

a. Connect the FROM UUT CALIBRATOR BNC of the Model 61272A Comparator to the oscilloscope (UUT) internal amplitude calibrator, using a short length of coaxial cable. (See figure 3-22.) If the UUT internal calibrator has a range of voltages, start with the highest one first.




Figure 3-22. Amplitude Comparator Equipment Set-Up

b. Connect the 61272A CHOPPED OUTPUT BNC to the vertical input of the UUT (or other scope having a $1\text{ M}\Omega$ input impedance). This will serve as the comparator/coincidence detector.

c. Set the Model 6127A controls as follows:

OUTPUT Mode	CALIBRATOR
-------------	------------

(Note that both the CALIBRATOR and VOLTS/-DIV annunciators light, the TIME/DIV-FREQUENCY display is 1 kHz and the AMPLITUDE/DIV displays prompt lines.)

d. Set the oscilloscope (UUT) controls as follows:

Volts/Div	One-tenth amplitude of UUT internal calibrator
Input Coupling	DC
Trigger	(EXT) Free running or Auto, (No Sync)
Time/Div	50 μs

NOTE

If the oscilloscope (UUT) calibrator output amplitude is 50 volts or lower, select the appropriate VOLTS/DIV value and a DIVS (multiplier) value of 1. If the UUT calibrator output amplitude is above 50 volts, select a VOLTS/DIV value of 1/10 the amplitude of the UUT calibrator and then use a DIVS value of 10.

e. Press the STANDBY/OPERATE touch key to put the Model 6127A in the OPERATE mode.

f. Observe the oscilloscope display. It will be a wide band having a single base line along the bottom edge of the sweep and; either a double line (out of calibration) or single line (within calibration) along the top edge.

NOTE

If the oscilloscope (UUT) display is chopped or torn, select a different TIME/DIV frequency on the UUT.

g. Press the DEV key pad to activate % DEVIATION.

h. If necessary, press either the Δ (increment) or ∇ (decrement) key pad until the top edge of the displayed sweep is a single thin line (similar to the bottom edge). This indicates that the peak-to-peak amplitude of the Model 6127A Calibrator and the Oscilloscope (UUT) internal voltage calibrator are identical.

i. If increased resolution of the coincidence (top) line of the sweep is desired, increase the UUT VOLTS/DIV sensitivity.

j. Observe the % DEVIATION displayed on the Model 6127A. This is the calibration error of the UUT internal calibrator.

3-55. Alternate Mode. Follow the same procedure outlined in the previous paragraph up to step f, and then proceed as follows:

a. Press the UUT/CALIB key pad.

NOTE

Pressing this key pad changes the 61272A transfer switch from automatic to manual. Subsequent touches will cause the 61272A transfer switch to alternate between the Model 6127A output and the UUT internal calibrator output. A red lamp on the Model 61272A will illuminate each time transfer is made to the UUT output.

b. Press the DEV key pad to activate % DEVIATION.

c. Press either the Δ (increment) or ∇ (decrement) key pads until the amplitude of the 6127A Calibrator is identical to that of the UUT internal calibrator, as observed on the oscilloscope.

d. Observe the % DEVIATION displayed on the Model 6127A. This is not the calibration error of the UUT internal calibrator. (See Table 3-13.) To determine the calibration error, apply the following formula:

$$\text{True UUT Error} = \frac{-X}{1 + X}$$

$$\text{Where: } X = \frac{\text{Displayed \% DEVIATION}}{100}$$

Example (1):

If the displayed % DEVIATION is 5.0% HI, then:

$$X = \frac{+ 5.0}{100} = + 0.05$$

and

$$\text{True UUT Error} = \frac{- 0.05}{1.05} = - 0.0476$$

or

-4.76%

Example (2):

If the displayed % DEVIATION is 3.5% LO, then:

$$X = \frac{-3.5}{100} = - 0.035$$

and

$$\text{True UUT Error} = \frac{-(-0.035)}{1+(-0.035)} = \frac{0.035}{0.965} = 0.0362$$

or

+3.62%

3-56. With the 61272A Comparator Head attached, the Model 6127A has the capability of presenting a 50 Ω load to the UUT for signals having an amplitude of 5 volts or less. If the source impedance of the UUT internal calibrator is 50 ohms, press the 50 Ω LOAD touch key on the Model 6127A. This will cause the 61272A Comparator Head to terminate the UUT output in a 50 ohm load, indicated by the 50 Ω annunciator on the 6127A lighting.

3-57. The Model 6127A will not permit selection of amplitudes greater than 5 volts in the CALIBRATOR mode with 50 Ω LOAD selected. However, the 50 ohm load resistance for the calibrator under test in the Model 61272A is not protected from voltage in excess of 5 volts or any voltage that would cause more than 1/2 watt to be dissipated in the 61272A 50 ohm load. When signal inputs to the Model 61272A Comparator BNC input exceed either 5 volts or 1/2 watt, do not select the 50 Ω LOAD mode.

WARNING

The maximum power capability of the source connected to the Model 61272A Comparator UUT input port BNC must be limited to a 1/2 watt when using the 50 Ω LOAD mode. Input power must not exceed 10 watts peak under any operating condition.

Table 3-13. Representative True Errors of UUT Internal Calibrator

% DEVIATION DISPLAY OF MODEL 6127A	TRUE ERROR OF UUT INTERNAL CALIBRATOR
1.0% HI	-0.99%
1.0% LO	+1.01%
2.0% HI	-1.96%
2.0% LO	+2.04%
3.0% HI	-2.91%
3.0% LO	+3.09%
4.0% HI	-3.85%
4.0% LO	+4.17%
5.0% HI	-4.76%
5.0% LO	+5.26%
9.9% HI	-9.00%
9.9% LO	+10.99%



ADDENDUM

TO INSTRUCTION MANUAL:

MODEL No. 6127A

Units thru Serial Prefix 021

INSTRUCTION MANUAL

Page 3-1. Add the following NOTE at the end of paragraph 3-8.

NOTE

To check the setting of the Calibrator's IEEE-488 bus address selector switch A50-S1/58 wait for the prompt lines to appear in every display window and press the CLEAR touch key. The two digits of bus address to which the 6127A is set, will appear in the DEVIATION display window. Be sure the 6127A bus address matches the command program from the bus controller. Refer to paragraph 3-25 for bus address switch setting. The bus address display capability is active only after a SELF TEST cycle.

Page 3-23. Add the following to table 3-11.

TABLE 3-11. MODEL 6127A OPERATING HINTS--(Cont'd)

12. Unit self test checks okay after SELF TEST cycle, but will not respond to the bus controller.

6127A bus address may not match controller program. Determine controller program address requirement for the 6127A. Then SELF TEST again and wait for all prompt lines to appear. Press CLEAR touch key and observe 6127A bus address display in DEVIATION window. If 6127A and controller bus address do not coincide, reset 6127A address.

13. When using the VOLTS/DIV and LOW DISTORTION PULSE modes at low amplitudes below 500 mV, always select reduced bandwidth below 20 MHz on the scope under test.

This minimized noise and permits viewing the cleanest calibrating signal in the 5 millivolt to 500 millivolt amplitude range.

ref:



ADDENDUM

TO INSTRUCTION MANUAL:

MODEL No. 6127A

INSTRUCTION MANUAL (VOLUME 1)
APPLIES TO ALL UNITS.
(90-10267-5A #2)

Page 1-1. Paragraph 1-8. Marker Amplitude change to read:

Markers to 2 ns/DIV	≥ 1 volt peak into 50 ohms
1 ns/DIV	≥ 350 mV peak to peak into 50 ohms
500 ps/DIV	≥ 100 mV peak to peak into 50 ohms

Page 3-13. Delete TABLE 3-7 and replace with following.

TABLE 3-7. LOW DISTORTION PULSE MODE VALID ENTRIES

AMPLITUDE/DIV	DIVISIONS (HI Z)								DIVISIONS (50 Ω)							
	1	2	3	4	5	6	8	10	1	2	3	4	5	6	8	10
50 V																
20 V																
10 V																
5 V																
1 V																
500mV																
200mV																
100mV																
50mV																

VALID ENTRY REGION

Page 3-17. TABLE 3-9. Delete line 00.

Delete and Add as follows:

TABLE 3-10. 6127A PROGRAMMING INFORMATION

COMMAND		DEFINITION
TYPE	MNEMONIC	
State	DT ON	Set up next command string and await group execute trigger
	DT OFF	Execute command string immediately
	LLO	Disables local operation of front panel
	GTL	Enables local operation of front panel
Mode	MODE V	Selects STANDARD AMPLITUDE Mode
	MODE MK	Selects STANDARD TIME Mode
	MODE CU	Selects STANDARD CURRENT Mode
	MODE CA	Selects STANDARD CALIBRATOR Mode
	MODE ED	Selects LOW DISTORTION PULSE Mode
	MODE FA or FE	Selects FAST RISETIME PULSE Mode
	F\$/D G\$H\$	Selects Unit/Div Output Valid G\$ = Numeric value from 0.001 to 500 in a 1, 2, 5 sequence Valid H\$ = NS (nsec), US (usec), MS (msec), S (sec), UV (uV), V (volts), MA (mA) Valid F\$ = U (Remain in present Mode) S (Standard Time Mode) V (Standard Amplitude Mode) A (Standard Current Mode)
Modifier	FR A\$	Selects frequency for: STANDARD AMPLITUDE, STANDARD CURRENT, FAST RISETIME PULSE and LOW DISTORTION PULSE Valid A\$ = DC, 10HZ, 100HZ, 1KHZ, 10KHZ, 100KHZ, 1MHZ
	MU I\$	Selects Multiplier Valid I\$ = 1,2,3,4,5,6,8,10
	PO	Selects POSITIVE Voltage/Current
	NE	Selects NEGATIVE Voltage/Current
	LD B\$	Selects either high impedance (unterminated) or low impedance (50 ohms) output of STANDARD AMPLITUDE and STANDARD CALIBRATOR Modes Valid B\$ = HI or 50 Ohms
	TR C\$	Selects Trigger Output Mode Valid C\$ = NORM ($\div 1$), X.1 ($\div 10$), X.01 ($\div 100$), OFF (Disable), ON (Return to last valid state)

TABLE 3-10. 6127A PROGRAMMING INFORMATION - Cont'd

COMMAND		DEFINITION
TYPE	MNEMONIC	
Modifier (Cont'd)	OU D\$	Controls OUTPUT Valid D\$ = OFF (Standby) or ON (Operate)
	LO E\$	Controls CURRENT Loop Output Valid E\$ = ON or OFF
Special	VA	DEVIATION on [Valid in ON (Operate) condition only]
	FX	DEVIATION off
	PC J\$	% DEVIATION (Valid only in VA state) Valid J\$ = Numeric value from -9.9 to +9.9
	IN	Increment DEVIATION one step (0.1% increase) (Valid only in VA state)
	DE	Decrement DEVIATION one step (0.1% decrease) (Valid only in VA state)
	CH Z\$	Selects Mode when in STANDARD CALIBRATOR Mode Valid Z\$ = AUTO (100 Hz chopping rate), DUT (Device Under Test), CG (Calibrator)
<u>CONTROLLER REQUESTING INFORMATION</u>		
	ERR?	Sets up 6127A (CG) to respond with a message in the form: ERR X\$, (CR) (LF-EOI) Where X\$, = Numeric error codes if no error pending X\$ should = 00
	PCT?	Sets up 6127A (CG) to responds with a transmission of the Deviation data in the form: PCT Y\$, (CR) (LF-EOI) Where Y\$ = Numeric value between n -9.9 and +9.9
	ID?	Sets up the Model 6127A (CG) to respond in the form: BALLANTINE 6127A

- NOTES: 1. All letters transmitted on bus are to be as upper case ASCII characters.
2. Only the first two characters of each COMMAND word are required by the 6127A.

6127A IEEE SRQ ERROR CODES

SERIAL POLL HEXADECIMAL CODE	ERR? RESPONSE DECIMAL CODE	ERROR MESSAGE
--	00	No Error
43	03	IEEE Output Buffer Not Accepted
44	04	IEEE Buffer OVERFLOW
50	10	Alternate Command Not Legal in the present Mode
51	11	Deviation Command Not Ok
52	12	No Mode Selected
53	13	Multiplier Command Not Ok
54	14	Frequency Command Not OK
55	15	Multiplier Command Not OK
57	17	Amplitude Command Not Correct
58	18	No Space in String
60	20	Illegal Command in String
61	21	Amplitude Setting Out of Range
62	22	Terminator Not OK
63	23	Deviation Not on during Inc, Dec, or PCT Command
64	24	Illegal Trigger Setting
66	26	Time Terminator Command Not OK in this Mode
67	27	Get Not Legal due to DT OFF Command

NOTE

To obtain the error code, a serial poll sequence must be initiated. The byte received in the serial poll sequence is the error code.

Delete and Add as follows:

There are five command types that can be sent across the bus to the 6127A. These are defined in the following table.

TYPE	STRING EXAMPLE	WHEN USED
State	DT OFF DT ON LLO GTL	Prior to selecting an output mode. Required only once if not to be changed.
Mode	MODE V;V/D 1MV MODE CU;A/D 5MA MODE MK;S/D 2MS MODE FE MODE ED;V/D 5V MODE CAL;V/D 2V	Anytime a change of mode is selected this entire string must be sent as a group.
Modifier	FREQ 10KHZ MULT 4 LDZ HI TRIG X1 OUT ON LOOP OFF U/D 1V	May be sent any time after Mode Select while in Standby or Operate state. Some commands apply only to particular Modes.
Special	VAR FXD PCT -8.8 INC CHOP AUTO	These commands may only be used while the 6127A is in the Operate state.

The following examples are typical strings to select and output signals for each mode of operation.

STANDARD AMPLITUDE:	3 mV @ 1 kHz & Operate into High Z MO V;V/D 1MV;MU 3;FR 1KHZ;OU ON
STANDARD CURRENT:	10 mA @ 10 kHz & Operate MO CU;A/D 5MA;MU 2;FR 10KHZ;LO ON
STANDARD TIME:	10 uS time marks MO MK;S/D 10US;OU ON
STANDARD CALIBRATION:	4 mV @ 100 Hz & Operate Chopped @ 100 Hz MO CA;V/D 1V;MU 4;FR 100HZ;OU ON
FAST RISETIME PULSE:	1 V into 50 ohms @ 100 kHz & Operate MO FE;FR 100KHZ;OU ON
LOW DISTORTION PULSE:	30 mV @ 1 MHz & Operate into 50 ohm load MO ED;V/D 10MV;MU 3;FR 1MHZ;OU ON

NOTE

All SPACES indicated in strings and command mnemonics are part of the program and MUST be included.

Paragraph 3-52 change as follows:

$$\text{True Risetime} = \sqrt{\left(\text{Displayed Risetime}\right)^2 + \left(\text{Input Rise-time}\right)^2}$$



ADDENDUM

TO INSTRUCTION MANUAL:

MODEL No. 6127A

INSTRUCTION MANUAL (Volume 1)
Applies to all units.
(90-10267-5A #3)

Page 1-1. Paragraph 1-8. TIME/DIV

CHANGE TO READ: ACCURACY

$\pm 0.005\%$ of reading ± 10 psec
(2 ns to 5 sec)

$\pm 0.005\%$ of reading ± 20 psec
(0.5 ns to 1 ns)

Page 1-4. Paragraph 1-16. ACCESSORIES AVAILABLE

ADD: Model 61273A


Noise filter, wideband; BNC to BNC accessory for attenuating wideband noise when using the 61271A Pulse Head to perform low level amplitude calibration.

Page 3-1. Paragraph 3-7.

ADD: Refer to figure 3-22 for operation of the "Key Pad" switches located on the front panel.

Page 3-33/3-34. Figure 3-22. Operating the Key Pad Switches

ADD: Figure 3-22. Key Pad Switch Operation (See Attached)



USE PAD OF INDEX FINGER OR THUMB TO DEPRESS PADS OF
TOUCH PANEL SWITCHES

Figure 3-22. Key Pad Switch Operation



Ballantine Laboratories, Inc.

ADDENDUM

TO INSTRUCTION MANUAL:

MODEL No. 6127A

INSTRUCTION MANUAL (VOLUME 1)
APPLIES TO UNITS WITH SERIAL
PREFIX 053- AND BELOW.
(90-10267-5A #4)

Page 3-17. Paragraph 3-26

ADD THE FOLLOWING: For instruments with Serial Prefix 053- and below the IEEE-488 Bus Address Switch should only be changed when POWER is OFF, or prior to a CLEAR/CLEAR command.

ref: AUGUST 1983 (90-10267-5A #4)



Ballantine Laboratories, Inc.

PO. Box 97, Boonton, New Jersey 07005, U.S.A.

Telephone: 201-335-0900, TWX: 710-987-8380