

HP 3852A Data Acquisition/Control Unit

HP 44789A RS-232/422 Serial Interface Accessory Configuration and Programming Manual


This is the HP 44789A RS-232/422 Serial Interface Accessory Configuration and Programming Manual. Insert this manual and tab page into the Plug-In Accessories Configuration and Programming Manuals Binder supplied with your HP 3852A Data Acquisition/Control Unit.



44789-90002

Copyright Hewlett-Packard Company, 1990

Manual Part Number: 44789-90002
Microfiche Part Number: 44789-99002



Printed: July 1990 Edition 2
Printed in U.S.A. E0790

0
P
0
0
0
0
0
0
C
A
E
E
C
L
L
L
L
L
L
E

HP 3852A Data Acquisition/Control Unit

HP 44789A RS-232/422 Serial Interface Accessory Configuration and Programming Manual



Copyright Hewlett-Packard Company, 1990

Manual Part Number: 44789-90002
Microfiche Part Number: 44789-99002

Printed: July 1990 Edition 2
Printed in U.S.A. E0790

CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by that organization's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard product is warranted against defects in materials and workmanship for a period of one year from date of shipment. Duration and conditions of warranty for this product may be superceded when the product is integrated into (becomes a part of) other HP products. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Hewlett-Packard (HP). Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with a product will execute its programming instructions when properly installed on that product. HP does not warrant that the operation of the product, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied products or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

The design and implementation of any circuit on this product is the sole responsibility of the Buyer. HP does not warrant the Buyer's circuitry or malfunctions of HP products that result from the Buyer's circuitry. In addition, HP does not warrant any damage that occurs as a result of the Buyer's circuit or any defects that result from Buyer-supplied products.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

NOTICE

The information contained in this document is subject to change without notice. HEWLETT-PACKARD (HP) MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. HP shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company. HP assumes no responsibility for the use or reliability of its software on equipment that is not furnished by HP.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subdivision (b)(3)(ii) of the Rights in Technical Data and Computer Software clause at 52.227-7013. Hewlett-Packard Company; 3000 Hanover Street; Palo Alto, California 94304

Herstellerbescheinigung

Hiermit wird bescheinigt, dass dieses Gerät/System HP 44789A in Übereinstimmung mit den Bestimmungen von Postverfügung 1046/84 funktionsfähig ist. Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes/Systems angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt.

Zusatzinformation für Mess- und Testgeräte:

Werden Mess- und Testgeräte mit ungeschirmten Kabeln und/oder in offenen Messaufbauten verwendet, so ist vom Betreiber sicherzustellen, dass die Funk-Entstörbestimmungen unter Betriebsbedingungen an seiner Grundstücksgrenze eingehalten werden.

Manufacturer's Declaration

This is to certify that the equipment HP 44789A meets the radio frequency interference requirements of Directive FTZ 1046/84. The German Bundespost has been notified that this equipment was put into circulation and has been granted the right to check the product type for compliance with these requirements.

Additional Information for Test and Measurement Equipment:

If test and measurement equipment is operated with unshielded cables and/or used for measurements on open set-ups, the user has to assure that under operating conditions the Radio Interference Limits are still met at the border of the user's premises.

Printing History

The Printing History shown below lists all Editions and Updates of this manual and the printing date(s). The first printing of the manual is Edition 1. The Edition number increments by 1 whenever the manual is revised. Updates, which are issued between Editions, contain replacement pages to correct the current Edition of the manual. Updates are numbered sequentially starting with Update 1. When a new Edition is created, it contains all the Update information for the previous Edition. Each new Edition or Update also includes a revised copy of this printing history page. Many product updates or revisions do not require manual changes and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one-to-one correspondence between product updates and manual updates.

Edition 1 (Part Number 44789-90001) September 1989

Edition 2 (Part Number 44789-90002) July 1990

Trademark Information

GW-BASIC® is a U.S. registered trademark of Microsoft Corporation.

Smartmodem™ is a trademark of Hayes Microcomputer Products, Inc

Micropatch™ is a trademark of DATATRAN Corporation.


Safety Symbols



Instruction manual symbol affixed to product. Indicates that the user must refer to the manual for specific Warning or Caution information to avoid personal injury or damage to the product.



Indicates the field wiring terminal that must be connected to earth ground before operating the equipment—protects against electrical shock in case of fault.



Frame or chassis ground terminal—typically connects to the equipment's metal frame.



Alternating current (AC).



Direct current (DC).



Indicates hazardous voltages.

WARNING

Calls attention to a procedure, practice, or condition that could possibly cause bodily injury or death.

CAUTION

Calls attention to a procedure, practice, or condition that could possibly cause damage to equipment or permanent loss of data.

WARNINGS

The following general safety precautions must be observed during all phases of operation, service, and repair of this product. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the product. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

Ground the equipment: For Safety Class 1 equipment (equipment having a protective earth terminal), an uninterruptible safety earth ground must be provided from the mains power source to the product input wiring terminals or supplied power cable.

DO NOT operate the product in an explosive atmosphere or in the presence of flammable gases or fumes.

For continued protection against fire, replace the line fuse(s) only with fuse(s) of the same voltage and current rating and type. **DO NOT** use repaired fuses or short-circuited fuseholders.

Keep away from live circuits: Operating personnel must not remove equipment covers or shields. Procedures involving the removal of covers or shields are for use by service-trained personnel only. Under certain conditions, dangerous voltages may exist even with the equipment switched off. To avoid dangerous electrical shock, **DO NOT** perform procedures involving cover or shield removal unless you are qualified to do so.

DO NOT operate damaged equipment: Whenever it is possible that the safety protection features built into this product have been impaired, either through physical damage, excessive moisture, or any other reason, **REMOVE POWER** and do not use the product until safe operation can be verified by service-trained personnel. If necessary, return the product to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DO NOT service or adjust alone: Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT substitute parts or modify equipment: Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the product. Return the product to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

Contents

Introduction

Manual Contents	1-1
The RS-232C Interface Standard	1-1
The RS-422 Standard	1-2
HP 44789A Accessory Description	1-3

Installing the HP 44789A

Introduction	2-1
Installation	2-1
Cables	2-2
Sample Programs	2-4
HP 44789A Test Program	2-5
HP Vectra PC or PC/XT/AT Program	2-5
HP 9000 Series 200/300 using the Built-in Serial Port	2-5
HP 9000 Series 200/300 with the HP 98628A Datacomm Interface	2-7
Reconfiguring the RS-232C Port	2-9
Using the RS-422 Port	2-10

Using the HP 44789A

Introduction	3-1
Programming the HP 44789A	3-1
Default Settings	3-1
Setting up SERIAL, MODE and PROTOCOL	3-2
Programming the HP 3852 through the HP 44789A	3-3
Using a Terminal	3-3
Using the HP Vectra PC or PC/XT/AT	3-3
Using a Modem	3-3
Using the HP 9000 Series 200/300 Computers	3-4
Using the HP 44789A for Printers or other Slave Devices	3-4
Command Summary	3-5
Common Commands	3-5
ID?	3-5
RST	3-5
TEST	3-5
USE	3-5
Configuration Commands	3-6
DTR	3-6
ENABLE/DISABLE RCVR	3-6
ENABLE/DISABLE XMIT	3-6
INBUF	3-6
INTR	3-7
MODE	3-7
NPER	3-8
OUTBUF	3-8
PROTOCOL	3-9
RTS	3-9
STORE CONF	3-10

THRESH	3-10
Programming Commands	3-10
CLRIN/CLROUT	3-10
BREAK	3-10
DEST IS	3-10
ENABLE/DISABLE SRQ BREAK	3-10
ENABLE/DISABLE DCL BREAK	3-10
ENABLE/DISABLE INTR	3-10
ENTER	3-11
INTR?	3-11
ON INTR	3-11
OUTPUT	3-11
READ	3-11
SERIAL	3-12
TIMEOUT	3-12
WRITE	3-12
XRDGS	3-12
Additional Programming Commands	3-13
Multi-tasking Commands	3-13
Data Flow Control Diagrams	3-13
PROTOCOL NONE	3-13
PROTOCOL XON/XOFF	3-14
PROTOCOL CTRL (Hardware)	3-14
PROTOCOL BOTH	3-15
Troubleshooting RS-232C Connections	3-15
Using the READ Command	3-16
Signal Levels and Logic States	3-16

Command Summary Quick Reference A1

1

Introduction



Introduction

Manual Contents

This Configuration and Programming Manual contains three chapters, an index and Appendix A. The contents of the chapters are the following:

Chapter 1 - Introduction summarizes the contents of the manual, gives a brief description of the RS-232C and RS-422 standards, and provides an overview of the HP 44789A RS-232C/RS-422 Serial Interface Accessory.

Chapter 2 - Installing the HP 44789A shows how to install the HP 44789A in the HP 3852 mainframe. A section on cables is included. Chapter 2 also contains sample programs for various configurations to ensure that a data link is established. The final section describes non-standard RS-232C configurations.

Chapter 3 - Using the HP 44789A provides the command set for the HP 44789A. Chapter 3 also provides data flow control diagrams which show the handshaking decision tree for the different PROTOCOLs. The final section is a troubleshooting guide for RS-232C interfaces.

Appendix A is a Command Summary quick reference.

The RS-232C Interface Standard

The RS-232C interface is a standard from the Electronic Industry Association (EIA) titled "Interface Between Data Terminal Equipment (DTE) and Data Communications Equipment (DCE) Employing Serial Binary Data Interchange". Briefly, the RS-232C provides a system whereby computers (DTEs) can communicate with other computers as well as modems, printers and other peripherals (DCEs).

The EIA RS-232C standard sets guidelines for the following four elements:

Electrical Signal Characteristics describes the electrical signals and levels which are allowed or required.

Interface Mechanical Characteristics (Connectors) describes the physical connection. The most common used connector is the DB-25 connector.

Functional Description of Interchange Circuits names and describes the electrical signal functions, as well as specifying which pin these functions will be on. There are 21 of these assigned pins, although most RS-232C implementations only use eight of them. The HP 44789A RS-232C interface uses up to 10 of these pins, depending on the application.

Standard Interfaces for Selected Communication System Configurations describes some common modem-to-terminal connections.

Any two devices which are "RS-232C compatible" should connect together and operate without any modifications. Unfortunately, the standard was designed specifically to connect terminals with modems, so using RS-232C to connect any other peripheral is in itself a deviation from the original purpose. The problem is further compounded because different manufacturers interpret the functions of the handshake lines differently. Fortunately there are many de facto standards for the RS-232C. The HP 44789A implements most of these de facto standards. If you are trying to connect any device other than those specifically listed in this manual, you may have to refer to Chapter 3, Troubleshooting RS-232C Connections. The Troubleshooting section also contains information on signal levels and the corresponding logic states. Table 1-1 shows the most commonly used pins in an RS-232C connection.

Table 1-1. RS-232C Standard

Pin	Input/Output	Description
2 TxD	O	Transmitted Data
3 RxD	I	Received Data
4 RTS	O	Request To Send
5 CTS	I	Clear To Send
6 DSR	I	Data Set Ready
7		Common
8 CD	I	Data Carrier Detect
20 DTR	O	Data Terminal Ready

The RS-422 Standard

The RS-422 interface uses two separate wires for each data signal. Each bit is defined according to the voltage difference between the two lines, rather than between a single line and ground. This minimizes the problems associated with varying ground potentials. This also means that any transmission-induced voltages affect both lines equally, so that the relative difference between the two lines is unchanged. This technique is called balanced transmission.

The major advantages of RS-422 connections are higher data rates and much longer transmission distances. There are no control lines for RS-422 interfaces, so therefore there is no hardware handshaking. Table 1-2 shows the RS-422 pin assignments. Some manufacturers reverse the logic state, and + and - are reversed. For those situations, you will have to use a cable which reverses pin 1 with pin 2 and pin 3 with pin 4.

Table 1-2. RS-422 Pin Assignments

Pin	Input/Output	Description
1	O	Transmitted Data -
2	O	Transmitted Data +
3	I	Received Data -
4	I	Received Data +
5		Ground

HP 44789A Accessory Description

The HP 44789A RS-232C/RS-422 Serial Interface Accessory allows the HP 3852 to communicate with a host computer, peripherals, or other instrumentation. It can be configured to operate a slave device or for full-duplex (two way data transfer) communication. The HP 44789A can also be configured to work with 9600 baud modems which use RTS as a reverse Clear To Send. The HP 44789A can serve as a programming port for the HP 3852. The HP 44789A can only be used with HP 3852 ROM set version 4.0 or later. To determine the ROM set on your HP 3852, use the IDN? command.

You can install multiple HP 44789A modules in your mainframe to allow serial communication with many devices; however, only one HP 44789A can serve as a programming port for the HP 3852. You can use the HP-IB and the HP 44789A as programming ports at the same time. This allows both a local host computer and a remote computer to send commands and receive data.

The HP 44789A allows both software and hardware handshaking to control the flow of data through the RS-232C port. Standard cables and connectors can be ordered from HP Direct Marketing (1-800-538-8787) for most applications. In addition, you can jumper the pin-outs on the RS-232C interface for non-standard connections. There is a constant high pin and a constant low pin which can be used to assert or deassert lines on a custom cable.

The 25 pin RS-232C connector and the 9 pin RS-422 connector are in logical parallel. It is not possible to communicate through both connectors at the same time. The RS-422 interface does not use hardware handshaking, so PROTOCOL must be set to NONE or XON; see Chapter 3. Table 1-3 lists the features of the HP 44789A.

Table 1-3. HP 44789A Features

One port	Operating either as an RS-232C interface through the 25 pin connector or an isolated RS-422 interface through the 9 pin connector.
Baud rate	Software selectable 300 baud to 19.2 Kbaud.
Parity	Software selectable (even, odd, none).
Byte length	Software selectable (7 or 8 bits).
Handshaking	XON/XOFF and Hardware (CTRL).
Buffering	Up to eight Kbytes on both input and output.
Interrupt	Buffer conditions, transmission errors, timing and/or user selected character.
EEPROM	Storage of selected settings. Settings stored in HP 44789A EEPROM (Electrically Erasable Program- mable Read Only Memory) are used at power on/reset.

Figure 1-1 shows a typical installation of the HP 44789A. The remote computer system can be used for monitoring or programming the HP 3852.




Figure 1-1. Typical Installation

2

Installing the HP 44789A




Installing the HP 44789A

Introduction

This chapter shows how to install the HP 44789A in the cardcage, and describes the cables which connect the RS-232C interface to the peripherals. Sample programs are provided so that you can verify the handshaking and data flow are working properly. The next section shows how to reconfigure the pins on the RS-232C connector for non-standard RS-232C interfaces. The final section describes how to use the RS-422 port.

Installation

Figure 2-1 shows how to install the HP 44789A module into the HP 3852 cardcage.



Installing the Accessory

1. Line up the ridges on the top and bottom rails of the accessory with the slot guides to the left of the slot number on the mainframe.
2. Slide the accessory in to the slot and press firmly to lock the accessory in the slot. You will hear a click when the accessory locks.




Figure 2-1. Installing the HP 44789A

Cables

To connect a peripheral device to the HP 44789A, you must have the proper cable. In addition to having connectors of the proper gender (male or female) on both ends of the cable, the internal wiring of the cable must be correct. For example, when the HP 44789A is connected to a modem (DTE to DCE), pin 2 is wired to pin 2 and pin 3 is wired to pin 3, whereas when the HP 44789A is connected to a PC (DTE to DTE) then pin 2 is wired to pin 3 and pin 3 is wired to pin 2. In most cases, if the gender of the connectors is correct for the desired connection then the wiring is also correct. If you are not certain you have the proper cable and problems occur, consider the cable as a possible source of the trouble.

The RS-232C port on the HP 44789A is almost identical to the DTE RS-232C port on a PC/XT/AT. If you are connecting a printer or other slave device, the same cable which is recommended for connecting it to a PC should work with the HP 44789A. You can also connect devices which use the 9 pin (DB9) connector if you use the proper 25 pin to 9 pin cable.

Table 2-1 lists cables, adapters and a reference book on RS-232C communications. If you do not have the necessary items available, you may purchase them from HP Direct Marketing (1-800-538-8787).

Table 2-1. RS-232C Products

Product	Description	Order Number
HP 98628 Cable	Modem (U.S.) 50M - 25M pin	13222N
HP Vectra PC HP 44789A Cable	Printer 25M - 25M pin	13242G
HP Vectra PC HP 44789A Cable	9FM - 25M pin	24542G
HP 9000 Series 200/300 HP 44789A Cable	Printer 25M-25M pin	13242G
	Micropatch Wiring Adapter (Male-Male)	92204J
	Micropatch Wiring Adapter (Male-Female)	92204K
	Micropatch Wiring Adapter (FM-FM)	92204L
Book	The RS-232C Solution ¹	92234X

¹ Joe Campbell, The RS-232C Solution (SYBEX, Inc. 1984)

Table 2-2 shows the connector pin description for connecting a HP Vectra PC to the HP 44789A using a 13242G cable or a 24542G cable. Figure 2-3 shows the connector pin description for connecting a Hayes Smartmodem™ to the HP 44789A using a 13242N cable.

Table 2-2. Connector Pin Description – HP Vectra PC and HP 44789A

HP 44789A Name Pin		Signal Description	PC/XT/AT Direction	Name	9 pin DB 9	25pin DB 25
TXD	2	data from HP 3852 to PC	→	RXD	2	3
RXD	3	data from PC to HP 3852	←	TXD	3	2
DTR	20	Data Terminal Ready	→	CTS	8	5
CTS	5	Clear To Send	←	DTR	4	20
RTS	4	Request To Send	→	DCD	1	8
DCD	8	Data Carrier Detect	←	RTS	7	4
GND	7	signal ground	NA	GND	5	7
RI	22	Ring Indicator	←	RI	9	22
DSR	6	Data Set Ready	←	DSR	6	6

**Table 2-3. Connector Pin Description
Hayes Smartmodem™ and HP 44789A**

HP 44789A Name Pin		Signal Description	Direction	Hayes Modem Name Pin
GND	1	Chassis ground	NA	GND 1
TXD	2	data from HP 3852	→	TXD 2
RXD	3	data from modem to HP 3852	←	RXD 3
DTR	20	Data Terminal Ready	→	DTR 20
CTS	5	Clear To Send	←	CTS 5
DCD	8	Data Carrier Detect	←	DCD 8
GND	7	signal ground	NA	NA GND
RI	22	Ring Indicator (can interrupt HP 3852 on edge)	←	RI 22
DSR	6	Data Set Ready	←	DSR 6
RTS	5	Request To Send	→	RTS 5

Sample Programs

The following sample programs verify that the HP 44789A is properly installed, and that your computer is communicating through the HP 44789A. The first program is a simple test program for the HP 44789A. The second program is for an HP Vectra PC or other PC/XT/AT equipped with a serial data communications port. The third is for an HP 9000 Series 200/300 computer using the built-in RS-232C interface. The fourth program is for an HP 9000 Series 200/300 computer equipped with an HP 98628 Datacomm interface.

Before running the sample programs, you must verify that the MODE and PROTOCOL are the same for both the HP 44789A and the computer you want to connect. MODE sets the baud rate, parity, number of data bits and number of stop bits. PROTOCOL sets the handshaking for the control lines. The factory default settings for MODE and PROTOCOL are:

MODE 300 baud, no parity, 7 data bits, 2 stop bits

PROTOCOL NONE (Sends whenever bytes are in the output buffer.
No overflow protection on the input buffer.)

These default settings are almost identical to those on most PC/XT/AT computers. To determine the settings on your computer, refer to the RS-232C Serial Interface section in your computer manual. If you have previously stored different MODE and PROTOCOL settings in the HP 44789A EEPROM, use the MODE, PROTOCOL and STORE CONF commands in Chapter 3 to reconfigure the settings.

HP 44789A Test Program

This program tests the HP 44789A. The HP 3852 transmits the data through pin 2 (TxD) on the RS-232C port, and receives it through pin 3 (RxD). The HP 3852 monitor then displays the data.

Connect pins 2 and 3 on the HP 44789A RS-232C connector. You can use any small wire to connect these pins on the connector panel of the HP 44789A. Enter the instructions from the HP 3852 front panel.

```
SERIAL IS NONE
RST                                ! Reset the card
PROTOCOL NONE USE 400             ! The HP 44789A in slot 4
INTEGER I                          ! Declare integer variable
OUTPUT 400 123                     ! Output a number to slot 400
ENTER 400 I                         ! Enter data to variable I
DISP I                             ! Display variable I (123)
```

HP Vectra PC or PC/XT/AT Program

The following GWBASIC® program for the HP Vectra PC or a PC/XT/AT computer uses the internal HP 3852 clock to return the number of seconds past midnight. Enter the following commands on the HP 3852 front panel before running the program.

```
SERIAL IS USE <chan >            ! Sets HP 3852 for serial
                                   communication through HP
                                   44789A in designated slot
RST                                ! Reset HP 3852 with stored
                                   configuration
```

When the HP 3852 is set up for serial communication, enter the following program in the PC:

```
10 OPEN "COM1:300,N,7,2" AS #1
20 PRINT #1,"TIME;"
30 INPUT #1,T
40 PRINT "HP 3852 SECONDS PAST MIDNIGHT ";T;" SECONDS"
50 END
```

HP 9000 Series 200/300 using the Built-in Serial Port

To use the HP 9000 Series 200/300 built-in serial port you must use the PACE option under the MODE command. PACE inserts delays between the data bytes coming from the HP 3852A so that the input buffer in the Series 200/300 does not overflow. This allows the Series 200/300 sufficient time to remove a byte of data from the serial interface and/or change handshake lines before the next byte is sent.

GW-BASIC is U.S. registered trademark of Microsoft Corporation.

Enter the following commands from the front panel of the HP 3852 before running the program.

```
USE 400                ! HP 44789A is in slot 4
RTS ON                 ! Required for Series 200/300
DTR IN                 ! Control input to the HP 3852
MODE 19200 NONE 7 2 .001 ! Baud 19200 no parity 7 data
                        bits 2 stop bits PACE 1 sec
PROTOCOL CTRL 10 15   ! Hardware handshaking,
                        buffer limits 10 and 15
STORE CONF             ! Store in EEPROM
SERIAL IS USE 400     ! Sets HP 3852 for serial
                        communication through HP
                        44789A in designated slot
RST                    ! Reset the HP 3852 with stored
                        configuration
```

The following program is for the HP 9000 Series 200/300. It prints seconds after midnight and the Julian date and time from the HP 3852 real time clock. If an error occurs, the program prints the type of error detected.

```
10                     ! Program for HP 9000 Series
                        200/300 with built-in serial port
20 CONTROL 9,3;19200   ! Set baud rate
30 CONTROL 9,4;32 + 0 + 4 + 2 70 ! Set up data frame format
40 ON ERROR GOTO Error ! Set up error checking
50 OUTPUT 9;"SET TIME 0;SUB A; TIME;TIMEDATE;SUBEND" ! A
                        subroutine to reset clock and
                        output data
60 WHILE 1             ! Set up endless loop
70 OUTPUT 9;"CALL A"
80 ENTER 9;A
90 ENTER 9;B
100 PRINT A,B
110 END WHILE
120 GOTO End
130 ERROR:              ! If ERROR then display cause
140 STATUS 9,10;ERR
150 IF BIT (ERR,1) THEN PRINT "OVERRUN"
160 IF BIT (ERR,2) THEN PRINT "PARITY"
170 IF BIT (ERR,4) THEN PRINT "BREAK"
180 IF BIT (ERR,3) THEN PRINT "FRAMING"
190 END:
200 END
```

HP 9000 Series 200/300 with the HP 98628A Datacomm Interface

The following program sets up the HP 9000 series 200/300 computer for communication with the HP 3852 through the HP 98628 Datacomm interface. The program first checks to see if there is data in the queue. Then it checks to see if there have been any errors since power on or reset. If there are no errors the program will print out the HP 3852 model number, the HP 3852 ROM revision number, and the HP 44789A slot number. There is more information on communications settings in the datacomm section of your HP 9000 Series 200/300 "BASIC Interfacing Techniques" manual.

Enter the following command from the front panel of the HP 3852.

SERIAL IS USE 400	<i>! Prepares HP 3852 for serial communication through the designated channel</i>
RST	<i>! Reset HP 3852 with stored configuration</i>

Enter the following program in the HP 9000 Series 200/300.

10 CONTROL 20,0;1	<i>! Reset HP 98628 serial card</i>
20 CONTROL 20,3;13	<i>! Set serial card for asynchronous communication</i>
30 CONTROL 20,14;3	<i>! Set control block mask for EOL and Prompt</i>
40 CONTROL 20,15;0	<i>! No modem line connection notification</i>
50 CONTROL 20,16;0	<i>! Disable connection timeout</i>
60 CONTROL 20,17;0	<i>! Disable no activity timeout</i>
70 CONTROL 20,18;0	<i>! Disable lost carrier timeout</i>
80 CONTROL 20,19;0	<i>! Disable transmit timeout limit</i>
90 CONTROL 20,20;7	<i>! Set transmission speed to 300 baud</i>
100 CONTROL 20,21;7	<i>! Set receive speed to 300 baud</i>
110 CONTROL 20,22;0	<i>! Protocol handshake disabled</i>
120 CONTROL 20,23;0	<i>! Hardware handshake off</i>
130 CONTROL 20,24;66	<i>! Remove protocol characters except EOL. Change errors to underscores</i>
140 CONTROL 20,26;17	<i>! Reset protocol handshake. Default DC1</i>
150 CONTROL 20,27;19	<i>! Reset protocol handshake. Default DC3</i>
160 CONTROL 20,28;2,13,10	<i>! Set EOL to 2 characters CR,LF</i>
170 CONTROL 20,31;1,17	<i>! Set prompt sequence to 1 character DC1</i>
180 CONTROL 20,34;2	<i>! Set data length to 7 bits per character</i>
190 CONTROL 20,35;2	<i>! Set stop bits = 2</i>
200 CONTROL 20,36;0	<i>! Set parity = none</i>
210 CONTROL 20,37;0	<i>! Reset inter-character time gap. Default = 0</i>
220 CONTROL 20,39;4	<i>! Set break time. Default = 4</i>

```

230                                     ! All instructions to this point
                                     ! are to prepare the HP 98628
                                     ! for protocol none 7 data bits no
                                     ! parity and 2 stop bits.

240                                     !
250                                     ! The following routine checks
                                     ! serial communications.
                                     ! Variable A is status (either 1, 2,
                                     ! or 3). Variable B holds the
                                     ! number of errors received since
                                     ! power on or reset. A value of 0
                                     ! means no errors.

260                                     !
270 OUTPUT 20;"VREAD 1"
280 FOR I = 1 TO 30
290 STATUS 20,5;A
300 STATUS 20,25;B
310 PRINT I,A,B
320 WAIT .1
330 NEXT I
340 ENTER 20;A$
350 DISP A$
360 OUTPUT 20;"IDN?"                                     ! Returns HP 3852 model
                                                         ! number, ROM revision, and
                                                         ! slot number

370 ENTER 20;A$
380 ENTER 20;X$
390 ENTER 20;Y$
400 ENTER 20;Z$
410 DISP A$,X$,Y$,Z$
420 END

```



Reconfiguring the RS-232C Port

You can change the pin out on the RS-232C port to work with any peripheral which uses an unusual or non-standard implementation of the RS-232C standard. Signals from the HP 44789A (RTS, CTS, etc.) can be routed to another pin. A pin can be connected to a pin, which effectively jumpers the RS-232C port on the peripheral. You can connect a constant high or a constant low to a pin to assert or deassert a line on a custom cable. Table 2-4 lists the HP 44789A RS-232C pin assignments.

Table 2-4. RS-232C Pin Assignments

Pin	I/O	Circuit
1	NA	Protective Ground
2	O	Transmitted Data
3	I	Received Data
4	O	Request To Send
5	I	Clear To Send
6	I	Data Set Ready
7	NA	Logic Ground
8	I	Carrier Detect
18	NA	RS-232C low (-12 V)
20	O	Data Terminal Ready
22	I	Ring Indicator
25	NA	RS-232C high (+12 V)

To change the pin out, first cut the jumper, bend the end up, and then wire-wrap to the desired pin. See Figure 2-2. It may be simpler to use a Micropatch™ wiring adapter, listed in Table 2-1.



38521P/44789 F. 2. 2

Figure 2-2. RS-232C Jumpers

Using the RS-422 Port

The 9 pin connector on the HP 44789A is for RS-422 communication. The data lines on the RS-422 port and the RS-232C port are in logical parallel, so you can not use both ports at the same time. Also, RS-422 communication does not use control lines, so you must set **PROTOCOL** to **NONE** or **XON**. Enter the following commands through the front panel of the HP 3852.

```
USE 400 ! HP 44789A is in slot 4
MODE <baud>, <parity>, <data bits>, <stop bits> ! Ensure these values are the same as the peripheral's RS-422 values

PROTOCOL NONE or XON ! See Chapter 3
STORE CONF ! Store configuration in EEPROM

SERIAL IS USE 400 ! Identify the channel that is the serial port

RST ! Resets the HP 3852 with stored values
```

The HP 3852 is now ready to communicate through the RS-422 port on the HP 44789A. Table 2-5 shows the RS-422 pin assignment.

Table 2-5. RS-422 Pin Assignments

Pin	Input/Output	Circuit
1	O	Transmitted Data -
2	O	Transmitted Data +
3	I	Received Data -
4	I	Received Data +
5		Ground

A common error in RS-422 cables is reversed + and - leads. If the peripheral you are connecting uses reverse polarity logic states, or the cable is for reverse logic but the peripheral is normal logic, you will have to reverse the leads. Change the lead for pin 1 with pin 2, and the lead for pin 3 with pin 4.

3

Using the HP 44789A

6
7
8



Using the HP 44789A

Introduction

This chapter begins with a description on how to program the HP 44789A. The default settings are listed next, followed by a section on setting SERIAL, MODE and PROTOCOL for the desired application. Next are sample programs which show how to use various types of computers to program the HP 3852 through the HP 44789A interface. The following section describes the commands, and the last section is a troubleshooting guide for RS-232C interfaces.

Programming the HP 44789A

There are four types of commands for the HP 44789A: Common Commands, Configuration Commands, Programming Commands and Multitasking Commands. Common Commands are not card specific. They can reset, test, select, or identify any card in the system. Configuration Commands set the data rate, data format, pacing protocol, and buffer size. Programming Commands concern data handling by the sender or receiver. Multi-tasking Commands are HP 3852 commands which can be used if the HP 44789A is used as a programming port for the HP 3852.

Program the HP 44789A the same as you would any other card in the HP 3852. Specify the slot number, then enter the commands. When you initially set up any of the Configuration Commands, use the STORE CONF to save the configuration in EEPROM. That way, if the HP 3852 should lose power or be reset the HP 44789A will be properly configured.

You can program the HP 44789A directly from a computer which is communicating through the HP 44789A with one exception. To change MODE and PROTOCOL you must first put the commands in a subroutine, then call the subroutine. Otherwise, as soon as the HP 44789A receives the MODE command it changes the settings and breaks the communication link. After you call the subroutine you must then change the settings on the computer to match the new settings before you can reestablish the communication link.

Default Settings

Table 3-1 shows the factory-set default settings for the HP 44789A. Once you use the STORE CONF command, the settings stored in EEPROM will be used at power on or reset. If you should lose the contents of EEPROM the HP 44789A will revert to the default settings at power on or reset.

Table 3-1. Default Settings

MODE	300 Baud, NO Parity, 7 Data Bits, 2 Stop Bits
PROTOCOL	NONE
INBUF	1024 Bytes
OUTBUF	1024 Bytes
RTS	ON
DTR	ON
THRESH IN	512 Bytes
THRESH OUT	512 Bytes
NPER	4 Character periods
ENABLE	XMIT
ENABLE	RCVR
INTR	0

Setting up SERIAL, MODE and PROTOCOL

To establish a communication link between the HP 3852 and a peripheral, you must designate where the link is located (SERIAL), what the data frames will look like (MODE), and how the data flow will be controlled (PROTOCOL). SERIAL is stored in non-volatile RAM in the mainframe and will be used at all subsequent resets or power-ons. MODE and PROTOCOL are stored in the HP 44789A EEPROM with the STORE CONF command.

MODE and PROTOCOL are set up at reset or power-on with the values stored in EEPROM. If there are no values in EEPROM, the default settings in Table 3-1 are used. These values must be the same as those used by the peripheral.

Programming the HP 3852 through the HP 44789A

You can use any terminal or computer with an RS-232C or an RS-422 interface to program the HP 3852 through the HP 44789A. Once you have established the communication link and designated a specific HP 44789A as a programming port, any programs or commands entered through that port go directly to the HP 3852.

Using a Terminal

A terminal or computer running terminal-emulation software acts as a remote extension of the keyboard for the HP 3852. Characters which are typed on the keyboard are accepted by the HP 3852. If those characters form programs or commands, those programs or commands are executed. BACKSPACE and RECALL are not implemented. Also, error messages are not automatically returned to the terminal. If you do not get a response from the HP 3852, then enter the error query command, ERRSTR?. The HP 3852 will send the contents of the error storage to the terminal.

Using the HP Vectra PC or PC/XT/AT

You can use the HP Vectra PC or any PC/XT/AT compatible to program the HP 3852 through the HP 44789A. The sample program in Chapter 2 shows how to establish the communication link. Use any BASIC that runs on a PC/XT/AT. The following program is written in GWBASIC®.

```
10 OPEN "COM1:300,N,7,2" AS #1      ! Sets the MODE for PC
20 PRINT #1,"ID? 400;"            ! Queries slot 4 for ID
30 INPUT #1,A$                    ! Returns slot ID
40 PRINT "HP";A$                  ! Displays HP 44789A ID on
                                   CRT
50 END
```

Using a Modem

A modem allows you to communicate over long distances, generally with a telephone connection. Using a modem with a terminal or a computer with communication software is very similar to operating with a direct connection. The only difference is dialing and hanging up. Your modem manual will have information on how this is done.

The following program for the HP Vectra PC demonstrates the overhead required for a modem. Ensure that the MODE and PROTOCOL settings are equivalent for the computer, modem and HP 44789A. The print statement in line 50 is not required for operation, it is there for information only.

```
10 OPEN "COM2:1200,N,7,2" AS #1    ! Set COM parameters and
                                   open buffer
20 PRINT #1, "ATDT 123-4567"       ! Dial phone number
30 WHILE EOF (1):WEND              ! Wait till something is in the
                                   buffer
40 SOUND 32565,30:SOUND 32565,1    ! Insert delay approx 1.5
                                   seconds
50 PRINT LOC(1):ON ERROR GOTO 30   ! Print bytes in buffer: clear
                                   error
60 A$ = INPUT$ (LOC(1),#1)         ! Define A$ and set pointer
70 IF INSTR (A$, "CONNECT") = 0 THEN 30 ! Identify feedback from
                                   modem
```

```

80 PRINT "CARRIER DETECTED"
90 PRINT #1,"RST;"           ! Reset HP 3852
100 SOUND 32565,30:SOUND 32565,1 ! Insert delay approx 1.5
                               seconds
110 PRINT #1, "ID? 400;"     ! Request ID of card in slot 4 of
                               HP 3852
120 INPUT #1,A$             ! Return response from line 110
130 PRINT "  HP ";A$        ! Print ID appended to HP
140 PRINT #1, "~ ~ ~ + + ~ ~ ~ATH0"! Get modems' attention and
                               hang up phone
150 END

```

Using the HP 9000 Series 200/300 Computers

The HP 9000 Series 200/300 built-in serial interface requires the use of the PACE option under MODE. The HP 98628A Datacomm interface provides full handshaking and communication without the need for the PACE option. The built-in serial interface requires eight lines of code to set up the HP 3852 and two lines of code to set up the Series 200/300. The HP 98628A Datacomm interface requires approximately 20 lines of code for the Series 200/300. The factory default settings for the HP 44789A are correct for communicating with the HP 98628A. You must specify SERIAL IS USE <chan> on the HP 3852.

HP-IB programs will work with the HP 98628A if you change the interface select code and address from 7XX (HP-IB) to 20 (Datacomm card). For more information see the datacomm section in the HP 9000 Series 200/300 "Basic Interfacing Techniques" manual.

The set-up codes for the built-in serial interface and the HP 98628A Datacomm card are listed in Chapter 2. The following program shows how to send commands using the HP 98628A Datacomm card.

```

10                               ! Datacomm setup, requires 20
                               to 25 lines of code, see Chapter
                               2.
450                             ! Datacomm card setup
                               complete.
460                             !
470 OUTPUT 20;"ADDR?"         ! Requests HP-IB address
480 ENTER 20;"A"              ! Return address to computer
490 DISP A                    ! Display address on CRT
500 END

```

Using the HP 44789A for Printers or other Slave Devices

You can use the HP 44789A to operate any device which has an RS-232C or RS-422 interface. The RS-232C interface on the HP 44789A is almost identical to that on a PC/XT/AT. You can use the same cable for the HP 44789A that is recommended for a PC. If the printer uses a non-standard implementation of the RS-232C interface, you may have to jumper the pins and/or use software handshaking. Refer to the Control Lines section in the printer manual.

Command Summary

The following is a summary description of the HP 44789A commands. The list is organized alphabetically in four functional groups: COMMON COMMANDS, CONFIGURATION COMMANDS, PROGRAMMING COMMANDS, and MULTITASKING COMMANDS.

Common Commands

Common Commands refer to the physical HP 44789A card and its location in the HP 3852 cardcage.

ID? Returns the accessory number (44789A).

Syntax: ID? <slot>

RST Resets the HP 44789A to its power-on state. All configuration settings are restored from EEPROM (MODE, PROTOCOL, INBUF, OUTBUF, RTS, DTR, THRESH, NPER, ENABLE/DISABLE XMIT/RCVR, and INTR), interrupts are disabled, and input and output buffers are cleared. When the HP 44789A is reset the HP 3852 waits until the card has passed its self-test or 2 seconds, whichever occurs first. If a timeout occurs then a self-test error is declared. In some cases the HP 44789A may still be used, but with risk. When the HP 44789A is an HP 3852 controller I/O, the RST <slot> command is not allowed if <slot> is the location of the HP 44789A.

If an EEPROM checksum error occurs, code E will be written to the HP 3852 display and the error buffer. Error messages stored in the error buffer may be recalled with the ERRSTR? command. If code E is detected it means the default values will be used. Set up the configuration and store it with the STORE CONF command.

Syntax: RST <slot>

TEST Initiates a pass/fail self-test of the accessory. It tests the backplane, interface registers, and microprocessor ROM/RAM/EEPROM, but not the RS-232C and RS-422 transceivers. Programmed state is preserved, but data received over the serial interface during the test is lost and/or causes an overrun error. If an error is noted then a failed self-test error is logged in the error buffer and on the HP 3852 display. You may view error messages from a remote location with the ERRSTR? command.

Syntax: TEST <slot>

USE Specifies the default USE channel for subsequent commands. The valid channel format is Extender, Slot number, Channel number, (ESCC). Refer to your HP 3852 "Configuration and Programming Manual" for more information.

Syntax: USE <chan>

Configuration Commands

Configuration commands refer to the identification and control of data passing through the interface.

DTR Determines the function or state of the DTR line. DTR may be forced to either OFF or ON. It may be configured as the standard Data Terminal Ready (DTR OUT). It may also be used as an input-buffer-available flag for use with many HP products (DTR IN).

DTR state stored in the EEPROM is used at reset or power-on. If the EEPROM contents are lost, DTR ON is the default.

Syntax: DTR [{OFF|ON|OUT|IN}] [USE <chan>]

ENABLE/DISABLE RCVR Enables or disables the reception of data. Upon execution of ENABLE RCVR the input UART is cleared and prepared to receive serial data.

At reset or power-on, the state stored in the EEPROM is used. If the EEPROM contents are lost, ENABLE RCVR is the default.

Syntax: ENABLE RCVR [USE <chan>]
DISABLE RCVR [USE <chan>]

ENABLE/DISABLE XMIT Enables or disables the transmission of data from the output buffer. Up to four bytes may be sent after the DISABLE XMIT command is issued. This number depends on the baud rate and the current state of the bytes being output.

ENABLE/DISABLE XMIT state stored in the EEPROM is used at reset or power-on. If the EEPROM contents are lost, ENABLE XMIT is the default.

Syntax: ENABLE XMIT [USE <chan>]
DISABLE XMIT [USE <chan>]

INBUF INBUF <bytes> with SERIAL or USE <chan> sets the size of the input buffer. Changing the input buffer size clears the input buffer and any pending interrupts. If the currently set PROTOCOL THRESH thresholds are greater than the new input buffer size, the lower and upper limits are set to 25% and 75% of the new buffer size. If the currently set input buffer THRESH threshold is greater than the new input buffer size, the threshold is set to 50% of the new buffer size. INBUF <bytes> with no USE <chan> defaults to the HP-IB input buffer size command.

The maximum INBUF size is eight Kbytes. The available sizes are 256, 512, 1024, 2048, 4096 and 80192. Input buffer size stored in the EEPROM is used at reset or power-on. If the EEPROM contents are lost, default INBUF 1024 is set.

Syntax: INBUF <bytes> [{HPIB|SERIAL|USE <chan>}]

INTR Sets the mask for the ENABLE/DISABLE INTR command. The *<mask>* is the sum of all the decimal values for the selected mask. A "1" in a bit enables that bit; a "0" disables it. All of the bits in the selected mask must be enabled before ENABLE INTR will generate an interrupt. You may also set a character to test all input bytes against.

Syntax: INTR *<mask>* [*<character>*] [USE *<chan>*]

Table 3-1. Bit Definition

Decimal Value	Bit	Definition
1	0	Input buffer not empty
2	1	Input buffer (THRESH IN) threshold reached
4	2	Input buffer full
8	3	Break received
16	4	Input NPER expired
32	5	Output buffer empty
64	6	Output buffer (THRESH OUT) threshold reached
128	7	Output buffer full
256	8	Input buffer overflow
512	9	Parity error detected
1024	10	Framing error
2048	11	Receiver overrun
4096	12	Carrier detect changed state
8192	13	Ring indicator changed state
16384	14	Character match detect
	15	-undefined-

MODE Selects the baud rate, parity, number of bits/character and stop bits.

Available baud rates: 300, 600, 1200, 4800, 9600, 19200

Note that 110 baud is not supported. Baud rate values within the range but not listed are rounded up to the next higher rate. Changing the MODE of the HP 44789A during transmission may cause an error.

Available data lengths are either 7 or 8 bits. The number of stop bits may be either 1 or 2. The UART (universal asynchronous receiver transmitter) limitations prevent the use of some combinations of parity, character bits and stop bits. Table 3-2 shows allowable parity and stop bit combinations.

Available parity types are:

NONE	no parity
IGNORE	parity bit is one for output, ignored on input
ZERO	parity bit is always zero
ONE	parity bit is always one
EVEN	even parity
ODD	odd parity

Table 3-2. Parity and Stop Bit Combinations

Parity	Data Bits	Stop Bits	
		1	2
NONE	7		ok
NONE	8	ok	ok
Parity	8	ok	
other	7	ok	ok

The PACE option inserts delay between the data frames in the sender. Use PACE when the input buffer of a serial port is small and can easily overflow. The *<period>* is from .001 to 60 seconds. See Figure 3-1.




Figure 3-1. PACE

Syntax: **MODE** *<baud>*, *<parity>*, *<data bits>*, *<stop bits>* [,PACE *<period>*],[USE *<chan>*]

NPER

Sets the Number of input character PERiods that must pass with no input received before an Input Buffer Timer interrupt will be generated. The valid range of *<periods>* is 1 to 65535. At reset or power-on, the value stored in the EEPROM is used. If the EEPROM contents are lost, NPER 4 is the default.

Syntax: **NPER** *<periods>* [USE *<chan>*]

OUTBUF

OUTBUF *<bytes>* with no USE *<chan>* defaults to the HP-IB output buffer size command. OUTBUF *<bytes>* with SERIAL or USE *<chan>* sets the size of the output buffer. Changing the output buffer size will clear the output buffer. If the currently set output buffer THRESH threshold is greater than the new output buffer size, the threshold is set to 50% of the new buffer size.

Eight Kbytes is the maximum OUTBUF size. The available sizes are 256, 512, 1024, 2048, 4096 and 8192. Output buffer size stored in the EEPROM is used at reset and power-on. OUTBUF default size is 1024 bytes.

Syntax: **OUTBUF** *<bytes>* [{HPIB|SERIAL|USE *<chan>* }]

PROTOCOL	Selects the protocol used to prevent buffer overflows, on both input and output of the serial interface. Available protocols are:
NONE	No protocol used. Sends whenever bytes are in the output buffer. Too much input will overflow the input buffer.
CTRL	DSR and CTS must be ON to send a character. If RTS IN is set then RTS is set OFF if the input buffer exceeds the upper threshold. RTS is set ON when the lower threshold is reached. If DTR IN is set then DTR is set OFF if the input buffer exceeds the upper threshold and ON when the lower threshold is reached.
XON/XOFF	XOFF received will halt output until XON is received. XOFF is sent if the input buffer upper threshold is exceeded. XON is sent when the lower threshold is reached.
BOTH	Combines CTRL and XON/XOFF modes.

Note

To use the RS-422 interface or an RS-232C three-wire connection (Common, TXD, RXD), set PROTOCOL to NONE or XON/XOFF. Otherwise, no output will occur since the unconnected state of DSR and CTS is off.

When PROTOCOL CTRL, XON/XOFF, or BOTH is selected, the lower and upper input buffer thresholds must be specified. These thresholds determine when the control lines are enabled or disabled. When the input buffer upper threshold is reached, THRESH turns RTS OFF (RTS IN), DTR OFF (DTR IN), and/or sends XOFF. This tells the sending device to stop sending data. As the HP 3852 removes bytes from the input buffer the lower threshold limit is reached. This turns RTS ON (RTS IN), DTR ON (DTR IN) and/or sends XON, enabling the sending device to start transmitting data again.

The lower limit must be greater than or equal to zero and less than or equal to the upper limit. The upper limit must be greater than or equal to the lower limit and less than or equal to the input buffer size. Values stored in the EEPROM are used at reset or power-on. PROTOCOL NONE is the default value.

Syntax: PROTOCOL {NONE|{CTRL|XON/XOFF|BOTH},
 <lower limit>, <upper limit> } [USE <chan>]

RTS Determines the function or state of the RTS line. RTS may be set to either OFF or ON. It may be configured as the standard Request To Send (RTS OUT). It is also used as an input-buffer-available flag for use with many 9600 baud modems (RTS IN). RTS mode stored in the EEPROM is used at reset or power-on. If the EEPROM contents are lost, RTS OUT is the default.

Syntax: RTS [{OFF|ON|OUT|IN}] [USE <chan>]

STORE CONF Stores the currently programmed state into the EEPROM. At power-on or reset the conditions stored in the EEPROM will be set. STORE CONF requires about 1.5 seconds to run.

Syntax: STORE CONF [USE *<chan>*]

THRESH Controls when bits 1 and 6 in the interrupt status are set (see INTR *<mask>* command). For input, the interrupt is asserted whenever the number of bytes in the input buffer is greater than or equal to the threshold. For output, the interrupt is asserted whenever the number of bytes in the output buffer is less than or equal to the threshold.

Thresholds stored in the EEPROM are used at reset or power-on. If the EEPROM contents are lost, THRESH IN 512 and THRESH OUT 512 are the defaults.

Syntax: THRESH {IN|OUT} *<bytes>* [USE *<chan>*]

Programming Commands Programming commands concern what the sender or receiver do with the data. They also allow you to control the flow of data with other programs.

CLRIN/CLROUT Clears the input or output buffer of the specified destination. HP-IB is the default destination (for backward compatibility). SERIAL specifies the currently selected SERIAL IS slot.

Syntax: CLRIN [{HPIB|SERIAL|USE *<chan>*}]
CLROUT [{HPIB|SERIAL|USE *<chan>*}]

BREAK BREAK ON sends a continuous break until BREAK OFF. BREAK ONCE sends a single break character immediately after any byte already being transmitted is sent. This break is sent regardless of the protocol state, the associated lines, and XOFFs.

Syntax: BREAK {OFF|ON|ONCE} [USE *<chan>*]

DEST IS Enables the output of a command to be directed to a desired destination.

Syntax: DEST IS {SERIAL|HPIB} [USE *<chan>*]

ENABLE/DISABLE SRQ BREAK Enables/disables the sending of a break to the host computer to indicate SRQ. This command affects only the serial programming port.

Syntax: ENABLE SRQ BREAK
DISABLE SRQ BREAK

ENABLE/DISABLE DCL BREAK Enables/disables the reception of a break from the host computer to indicate Device CLear. This command affects only the serial programming port.

Syntax: ENABLE DCL BREAK
DISABLE DCL BREAK

ENABLE/DISABLE INTR

Enables/disables the interrupts selected by the INTR command. All interrupt conditions except input/output buffer full/empty and thresholds reached are cleared.

Syntax: ENABLE INTR [USE *<chan >*]
DISABLE INTR [USE *<chan >*]

ENTER

Takes input data from a device or file and assigns the values to variables. Numeric characters, decimal point, +, -, e and E are valid characters for ENTER. For further information on ENTER, see your HP 3852 Mainframe "Command Reference Manual".

Syntax: ENTER *<path or chan >* *<list >*

INTR?

If *<chan >* is present, returns a 16-bit word indicating the state of all 15 of the interrupting conditions for the channel. This word is bit mapped the same as the INTR mask. INTR? clears the interrupt status for the serial card. Level-sensitive conditions will be set again when the card polls its internal status. Edge conditions (break received, character matched, error detected) will not be set unless the condition occurs again. If *<chan >* is omitted, the mainframe INTR? command is executed, returning the last channel to interrupt.

The HP 3852 BINAND and BINOR commands can be used with INTR? to check the state of individual bits.

Syntax: INTR? [*<chan >*]

ON INTR

Specifies a subroutine to be executed or run upon an interrupt from the specified channel (for information on subroutines see the HP 3852 Mainframe "Command Reference Manual").

Syntax: ON INTR [USE *<chan >*] {CALL *<sub >* |RUN *<sub >*, *<task >* }

OUTPUT

Outputs data to a specified destination. Destination can be an I/O path name or a device selector. For further information on OUTPUT, see your HP 3852 Mainframe "Command Reference Manual".

Syntax: OUTPUT *<path or chan >* *<list >*

READ All of the connector lines are read and returned as a bit-mapped integer (the decimal sum of the bits set to "1"; a "1" means "set" or "on", a "0" means "off"). Table 3-3 shows the decimal bit values.

Table 3-3. Decimal Bit Values

Bit	Decimal Value	Line
0	1	DSR
1	2	DTR
2	4	CTS
3	8	RTS
4	16	DCD
5	32	RI
6	64	TXD
7	128	RXD

Syntax: READ <chan>

SERIAL SERIAL OFF/ON eliminates wait time for certain commands sent to some multiplexer and switching accessories (see SERIAL command in the HP 3852 Mainframe "Command Reference Manual").

SERIAL IS USE <chan> selects the serial channel that will be used as a programming port after the next reset or power-on. SERIAL IS NONE deselects any serial channel. Only one serial channel may be selected at any time. Channel selected is stored in mainframe non-volatile RAM. It will be used for all succeeding resets or power-on.

Selecting a serial channel will leave the mainframe with approximately 1250 fewer bytes of available memory.

Syntax: SERIAL [OFF|ON|IS {NONE|USE<chan>}]

TIMEOUT Timeout is the amount of time the HP 44789A will wait between receiving characters before declaring a timeout error. The HP 3852 timeout period is used. The allowable timeout periods are .001 sec to infinity. A 0 represents infinity. For further information see your HP 3852 Mainframe "Command Reference Manual".

Syntax: TIMEOUT <time>

WRITE Allows you to send decimal equivalent of a desired ASCII bit pattern. The allowable range is 0 to 255. You can send the characters as a data list or an array. The WRITE command does not affect the index of an array. WRITE requires 300 μ sec overhead plus 80 μ sec per byte. Timeout used is the present overall system timeout. Timeouts which are an integer number allow the fastest WRITE. The following two examples WRITE decimal 75 (ASCII K).

WRITE 2300 75

! "K" sent to slot 23


```

INTEGER I(8)
MAT I = (75)
WRITE 2300 I                               ! "KKKKKKKKKK" sent to slot
                                             23

```

Syntax: WRITE <slot> [data list | array]

XRDGS Allows you to transfer bytes from the HP 44789A into an array. The index of the array is automatically increased by the number of elements transferred.

The <number of bytes> determines how many bytes are sent. You can choose a positive integer, a negative integer or 0. A positive integer transfers that number of bytes. A negative integer transfers as many bytes as are found in the HP 44789A, up to the absolute value of the integer. A 0 transfers all the bytes in the HP 44789A. The default value is 1.

If the array is not large enough for all of the bytes, an error is declared and no bytes are transferred. The best way to transfer an unknown number of bytes is to use a negative integer whose absolute value is less than the number of empty spaces in the array. XRDGS requires 700 μ sec overhead plus 180 μ sec per

bytes. Timeout used is the present overall system timeout. Timeouts which are integer numbers allow the fastest XRDGS. The following examples show how to use XRDGS.

```

INTEGER I(199)
XRDGS 2300 0 INTO I                         ! Transfers all bytes into I. If
                                             there are more than 200, an
                                             error is declared.

INTEGER I(8)
XRDGS 2300 -9 INTO I                        ! Transfers up to 9 bytes into I

```

Syntax: XRDGS <slot> [number of bytes] INTO

Additional Programming Commands

There are six HP 3852 programming commands which affect the HP 44789A. These are: ASSIGN, ENTER, OUTPUT, PRINTER IS, PRINT and TIMEOUT. For a complete description of these commands, see your HP 3852 Mainframe "Command Reference Manual".

Multi-tasking Commands

There are four HP 3852 multi-tasking commands which affect the HP 44789A. These commands are ABORT SERIAL, PAUSE SERIAL, PROBE and SIGNAL SERIAL. For a complete description of these commands, see your HP 3852 Mainframe "Command Reference Manual".

Data Flow Control Diagrams

PROTOCOL commands determine which series of events will enable or disable data transmission. These sequences are called data flow control loops. Each PROTOCOL parameter has a different data flow control loop. These loops monitor input buffers, output buffers and control lines. Some PROTOCOL commands override control lines to enable or disable transmission.

There are four data flow control diagrams, one for each PROTOCOL parameter. The diagrams describe the continuous decision process which takes place every 0.5 milliseconds.

PROTOCOL NONE

This is the simplest control loop. There are no thresholds to compare the input data buffer count to and likewise there are no responses. SERIAL IS USE *<chan>* establishes a continuous communication link.




Figure 3-2. PROTOCOL NONE Flow Diagram

PROTOCOL BOTH

When both XON/XOFF and CTRL protocols are used together, the two protocols are combined. When XON or XOFF needs to be sent to the other unit, the hardware protocol must be completed before XON or XOFF is sent. It is easiest to think of the XON or XOFF as being pushed into the front of the output buffer and, when allowed by the hardware handshake, they are sent out. DISABLE XMIT cannot stop an XON or XOFF from being sent.




Figure 3-5. PROTOCOL BOTH Flow Diagram

Troubleshooting RS-232C Connections

There are four components of an RS-232C communication link through the HP 44789A Serial Interface Accessory. An error in any one of them will break the communication link. These four components, and the associated critical parameters, are:

HP 3852 (SERIAL IS USE *<chan>*)

HP 44789A (MODE, PROTOCOL)

Cable (Pins wired to proper pins)

Peripheral (*<baud>* *<parity>* *<data bits>* *<stop bits>* *<protocol>*)

If you are using one of the peripherals mentioned in this manual, and have verified the above four components, the communication link should work. If it does not, then one of the components is most likely defective. Change the components one at a time until you get the system to work. This will help you isolate the defective component. If you are using a peripheral other than those listed in this manual, see the following section.

Using the READ Command

The READ command returns a bit-mapped decimal value which reflects the state of the pins. You can use this command to determine which pins are asserted or deasserted. If you are trying to connect a terminal or computer, set PROTOCOL to NONE and transmit the command BEEP; from the terminal to the HP 3852. You should hear a beep. If you do not hear a beep, then one by one set the control lines to ON and transmit BEEP;. There are four control lines, so there are 16 possible combinations. Use the READ command between each change of settings to determine if the new settings cause the terminal to assert or deassert a line. You can also use the INTR? command to determine changes.

When you get a character to transmit, you know which control lines the terminal needs to transmit. You then need to find out which control lines it uses to receive and to signal that the buffer is full. One by one set the control lines to ON and transmit a character from the HP 3852. Use the READ command to find the state of the bits when the peripheral is receiving data. Then use the WRITE command to send a large array which should overflow the input buffer on the peripheral. Use the READ command again to determine which line the peripheral sets for input buffer full. The WRITE command will also verify full handshaking capability.

Once you have determined the necessary handshake for the peripheral, you can jumper the RS-232C port, use a Micropatch wiring adapter (see table 1-1), make a custom cable or use software handshaking.

If you still cannot get your peripheral to work, check to see if TxD and RxD are on the proper pins. The peripheral may also be using pins other than those supported by the HP 44789A. In that case you will need a breakout box. The book listed in Table 1-1 is an excellent reference for troubleshooting non-standard RS-232C interfaces.

Signal Levels and Logic States

Signal level refers to the magnitude and polarity of a signal on a line. Logic state refers to whether a given signal represents a 0 or 1 for data lines and asserted/enabled or deasserted/ disabled for control lines. Data lines and control lines do not use the same convention.

For an RS-232C data line, a logic 0 is represented by a voltage between +5 and +15 volts for output and between +3 and +15 volts on input. A logic 1 is represented by a voltage between -5 and -15 volts for output and between -3 and -15 volts for input. Voltages outside of those limits represent undefined logic states.

For RS-232C control lines, an assert/enable is represented by a voltage between +5 and +15 volts for output and between +3 and +15 volts on input. A deassert/disable is represented by a voltage between -5 and -15 volts for output and between -3 and -15 volts for input. Voltages outside of those limits represent undefined logic states.

Appendix A



Command Summary Quick Reference

Common Commands:

ID? *<slot>*
 RST *<slot>*
 TEST *<slot>*
 USE *<chan>*

Configuration Commands:

DTR [{OFF|ON|OUT|IN}] [USE *<chan>*]
 DISABLE RCVR [USE *<chan>*]
 DISABLE XMIT [USE *<chan>*]
 ENABLE RCVR [USE *<chan>*]
 ENABLE XMIT [USE *<chan>*]
 INBUF *<bytes>* [{HPIB|SERIAL|USE *<chan>*}]
 INTR *<mask>* [*<character>*] [USE *<chan>*]
 MODE *<baud>*, *<parity>*, *<data bits>*, *<stop bits>*, [PACE
<Period>] [USE *<chan>*]
 NPER *<periods>* [USE *<chan>*]
 OUTBUF *<bytes>* [{HPIB|SERIAL|USE *<chan>*}]
 PROTOCOL [NONE|{CTRL|XON|BOTH}], *<llimit>*, *<ulimit>*
 [USE *<chan>*]
 RTS [{OFF|ON|OUT|IN}] [USE *<chan>*]
 STORE CONF [USE *<chan>*]
 THRESH {IN|OUT} *<bytes>* [USE *<chan>*]

Programming Commands:

BREAK {OFF|ON|ONCE} [USE *<chan>*]
 CLRIN/CLROUT [{HPIB|SERIAL|USE *<chan>*}]
 DEST IS {SERIAL|HP-IB} [USE *<chan>*]
 DISABLE DCL BREAK
 DISABLE INTR [USE *<chan>*]
 DISABLE SRQ BREAK
 ENABLE DCL BREAK
 ENABLE INTR [USE *<chan>*]
 ENABLE SRQ BREAK
 INTR? [*<chan>*]
 ON INTR [USE *<chan>*] {CALL *<sub>* | RUN *<sub>*, *<task>* }
 READ *<chan>*
 SERIAL [OFF|ON|IS {NONE|USE *<chan>*}]
 WRITE *<slot>* [data list | array]
 XRDGS *<slot>* [number of bytes] INTO

Information on the following commands is in the HP 3852 mainframe
 programing Command Reference manual.

ASSIGN *<path>* TO {*<chan>* |*}
 ENTER *<path or chan>* *<list>*
 OUTPUT *<path or chan>* *<list>*
 PRINTER IS *<chan>*

PRINT <list>
TIMEOUT <time>

**Multitasking
Commands:**

Multi-tasking Commands are HP 3852 mainframe commands which also apply to the HP 44789A. For further information, see your HP 3852 manual.

ABORT SERIAL
PAUSE SERIAL
PROBE
SIGNAL SERIAL

Index



Index

A

Accessory Description, 1-3

B

BINAND, 3-11

BINOR, 3-11

Bit Definitions

Interrupt Mask, 3-7

Bit Values

Control Lines, 3-11

BOTH

Protocol, 3-9, 3-15

BREAK, 3-10

Buffers, 3-9

C

Cables, 2-2, 3-15

CLRIN/CLROUT, 3-10

Command Summary, 3-5

Commands

Common, A-1

Configuration, A-1

Multitasking, A-2

Programming, A-1

Common Commands, A-1

ID?, 3-5

RST, 3-5

TEST, 3-5

USE, 3-5

Communication Link, 3-2, 3-15

Configuration Commands, A-1

DTR, 3-6

ENABLE/DISABLE XMIT, 3-6

ENABLE/DISABLE RCVR, 3-6

INBUF, 3-6

INTR, 3-7

MODE, 3-7

NPER, 3-8

OUTBUF, 3-8

PROTOCOL, 3-9

RTS, 3-9

STORE CONF, 3-10

THRESH, 3-10

Connectors, 2-2

CTRL

Protocol, 3-9

D

Data Flow Control Diagrams, 3-13

Datacomm Interface, 2-7

DCL BREAK, 3-10

Default Values, 3-1 - 3-2

DEST IS, 3-10

DTR, 3-6

E

EEPROM, 2-4

ENABLE/DISABLE DCL BREAK, 3-10

ENABLE/DISABLE INTR, 3-10

ENABLE/DISABLE RCVR, 3-6

ENABLE/DISABLE SRQ BREAK, 3-10

ENABLE/DISABLE XMIT, 3-6

ENTER, 3-11

F

Features, 1-3

H

Handshaking, 3-13

HARDWARE

Protocol, 3-14

HP 3852 Multi-tasking Commands, 3-13

HP 3852 Programming Command, 3-13

HP 44789A

Programming, 3-1

Test Program, 2-5

HP 9000 Series 200/300 Built-in Serial Port, 2-5

HP 9000 Series 200/300 Computers, 3-4

HP 9000 Series 200/300 HP 98628A Datacomm Interface, 2-7

HP Vectra PC, 3-3

HP Vectra PC PC/XT/AT Program, 2-5

I

ID?, 3-5

INBUF, 3-6

Installation, 2-1

Interrupts, 3-11

INTR, 3-7, 3-11

J

Jumpers, 2-9

L

Logic State, 3-16

M

MODE, 2-4, 3-2, 3-7, 3-15
Modem, 3-3
Multi-tasking Commands, 3-13
Multitasking Commands, A-2

N

NONE
Protocol, 3-9, 3-13
NPER, 3-8

O

ON INTR, 3-11
OUTBUF, 3-8
OUTPUT, 3-11

P

PACE, 3-8
Parity, 3-8
PC/XT/AT, 3-3
Printers, 2-2, 3-16
Programming Commands, 3-10, A-1
BREAK, 3-10
CLRIN/CLROUT, 3-10
DEST IS, 3-10
ENABLE/DISABLE DCL BREAK, 3-10
ENABLE/DISABLE INTR, 3-10
ENABLE/DISABLE SRQ BREAK, 3-10
HP 3852, 3-13
ON INTR, 3-11
READ, 3-12
SERIAL, 3-12
WRITE, 3-12
XRDGS, 3-12
Programming the HP 3852, 3-3
Programming the HP 44789A, 3-1
PROTOCOL, 2-4, 3-2, 3-9
Protocol BOTH, 3-15
Protocol CTRL, 3-14
Protocol NONE, 3-13
Protocol XON/XOFF, 3-14

R

READ, 3-11, 3-16
Reconfiguring RS-232C Port, 2-9
RS-232C Pin Assignment, 2-9
RS-232C Standard, 1-1 - 1-2
RS-422 Operation, 2-10, 3-9
RS-422 Pin Assignment, 1-2, 2-10
RS-422 Standard, 1-2
RST, 3-5
RTS, 3-9

S

Sample Programs, 2-4
SERIAL, 3-2, 3-12, 3-15
Signal Level, 3-16
Slave Devices, 3-4, 3-16
SRQ BREAK, 3-10
Stop Bits, 3-8
STORE CONF, 3-10

T

Terminal, 3-3
TEST, 3-5
Test Program
HP 44789A, 2-5
HP 9000 Series 200/300, 2-7
HP Vectra PC PC/XT/AT, 2-5
THRESH, 3-10
Troubleshooting, 3-15

U

USE, 3-5

W

WRITE, 3-12

X

XON/XOFF
Protocol, 3-9, 3-14
XRDGS, 3-12

HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices

NORTH/CENTRAL AFRICA

Hewlett-Packard S A
7, rue du Bois-du-Lan
CH-1217 MEYRIN 1, Switzerland
Tel: (022) 83 12 12
Telex: 27835 hmea
Cable: HEWPACKSA Geneva

ASIA

Hewlett-Packard Asia Ltd
47/F, 26 Harbour Rd.,
Wanchai, HONG KONG
G P O Box 863, Hong Kong
Tel: 5-8330833
Telex: 76793 HPA HX
Cable: HPASIAL TD

EASTERN EUROPE

Hewlett-Packard Ges m b h
Liebigasse 1
P O Box 72
A-1222 VIENNA, Austria
Tel: (222) 2500-0
Telex: 13 4425 HEPA A

NORTHERN EUROPE

Hewlett-Packard S A
V. D. Hooplaan 241
P O Box 999
NL-1183 AG AMSTELVEEN
The Netherlands
Tel: 20 547999
Telex: 18 919 hpnr

SOUTH EAST EUROPE

Hewlett-Packard S A
World Trade Center
110 Avenue Louis Casai
1215 Cointrin, GENEVA, Switzerland
Tel: (022) 98 96 51
Telex: 27225 hpser

EASTERN USA

Hewlett-Packard Co
4 Choke Cherry Road
ROCKVILLE, MD 20850
Tel: (301) 948-6370

MIDWESTERN USA

Hewlett-Packard Co
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800

SOUTHERN USA

Hewlett-Packard Co
2000 South Park Place
ATLANTA, GA 30339
Tel: (404) 955-1500

WESTERN USA

Hewlett-Packard Co
5161 Lankershim Blvd
NORTH HOLLYWOOD, CA 91601
Tel: (818) 505-5600

MEDITERRANEAN AND MIDDLE EAST

Hewlett-Packard S A
Mediterranean and Middle East
Operations
Atrina Centre
32 Kilissias Ave
Paradissos-Amarousion, ATHENS
Greece
Tel: 682 88 11
Telex: 21-6588 HPAT GR
Cable: HEWPACKSA Athens

OTHER INTERNATIONAL AREAS

Hewlett-Packard Co
Intercontinental Headquarters
3495 Deer Creek Road
PALO ALTO, CA 94304
Tel: (415) 857-1501
Telex: 034-8300
Cable: HEWPACK

ARGENTINA

Hewlett-Packard Argentina S A
Montaneses 2140/50
1428 BUENOS AIRES
Tel: 781-4059/69
Cable: HEWPACKARG

AUSTRALIA

Hewlett-Packard Australia Ltd
31-41 Joseph Street
P O Box 221
BLACKBURN, Victoria 3130
Tel: 895-2895
Telex: 31-024
Cable: HEWPAARD Melbourne

Hewlett-Packard Australia Ltd

17-23 Talavera Road
P O Box 308
NORTH RYDE, N S W 2113
Tel: 888-4444
Telex: 21561
Cable: HEWPAARD Sydney

AUSTRIA

Hewlett-Packard Ges.m.b.h
Liebigasse 1
P O Box 72
A-1222 VIENNA
Tel: (0222) 2500-0
Telex: 134425 HEPA A

BELGIUM

Hewlett-Packard Belgium S A /N V
Blvd de la Woluwe, 100
Woluwe-la
B-1200 BRUSSELS
Tel: (02) 762-32-00
Telex: 23-494 paloben bru

BRAZIL

Hewlett-Packard do Brasil
I e C Ltda
Alameda Rio Negro, 750
ALPHAVILLE
06400 Barueri SP
Tel: (011) 421.1311
Telex: (011) 33872 HPBR-BR
Cable: HEWPACK Sao Paulo

Hewlett-Packard do Brasil
I e C Ltda
Praia de Botafogo 228
6º Andar-conj 614

Edificio Argentina - Aia A
22250 RIO DE JANEIRO, RJ
Tel: (021) 552-6422
Telex: 21905 HPBR-BR
Cable: HEWPACK Rio de Janeiro

CANADA

Hewlett-Packard (Canada) Ltd
11120-178th Street
EDMONTON, Alberta T5S 1P2
Tel: (403) 486-6666

Hewlett-Packard (Canada) Ltd
17500 Trans Canada Highway
South Service Road
KIRKLAND, Quebec H9J 2X8
Tel: (514) 697-4232
Telex: 058-21521

Hewlett-Packard (Canada) Ltd
6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
Tel: (416) 678-9430
Telex: 069-8644

Hewlett-Packard (Canada) Ltd
2670 Queensview Dr
OTTAWA, Ontario K2B 8K1
Tel: (613) 820-6483

CHINA, People's Republic of

China Hewlett-Packard Co., Ltd.
P.O. Box 9610, Beijing
4th Floor, 2nd Watch Factory Main Bldg
Shuang Yu Shou, Bei San Huan Road
Hai Dian District
BEIJING
Tel: 28-0567
Telex: 22601 CTSHP CN
Cable: 1920 Beijing

DENMARK

Hewlett-Packard A/S
Kongevejen 25
DK-3460 BIRKERÖD
Tel: (02) 81-66-40
Telex: 37409 hpas dk

FINLAND

Hewlett-Packard Oy
Pilsankalliontie 17
02200 ESPOO
Tel: 00358-0-88721
Telex: 121563 HEWPA SF

FRANCE

Hewlett-Packard France
Chemin des Mouilles
Boite Postale 162
69131 ECULLY Cedex (Lyon)
Tel: (78) 133-81-25
Telex: 310617F

Hewlett-Packard France

Parc d'activités du Bois Briard
Avenue du Lac
91040 EVRY Cedex
Tel: (60) 77-83-83
Telex: 692315F

Hewlett-Packard France
Zone Industrielle de Courtaboeuf
Avenue des Tropiques
91947 LES ULIS Cedex (Orsay)
Tel: (69) 07-78-25
Telex: 600048F

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH
Vertriebszentrum Mitte
Hewlett-Packard-Strasse
D-6380 BAD HOMBURG
Tel: (06172) 400-0
Telex: 410 844 hpbhg

Hewlett-Packard GmbH
Vertriebszentrum Südwest
Schickardstrasse 2
D-7030 BÖBLINGEN
Tel: (07031) 645-0
Telex: 7265 743 hep

Hewlett-Packard GmbH
Vertriebszentrum Süd
Eschenstrasse 5
D-8028 TAUFKIRCHEN
Tel: (089) 61 20 7-0
Telex: 0524985

GREECE

Hewlett-Packard A.E.
178, Kifissias Avenue
6th Floor
Halandri-ATHENS
Greece
Tel: 6471543, 6471673, 6472971
Telex: 221 286 HPHLGR

HONG KONG

Hewlett-Packard Hong Kong, Ltd
G P O Box 795
5th Floor, Sun Hung Kai Centre
30 Harbour Road
HONG KONG
Tel: 5-8323211
Telex: 66678 HEWPA HX
Cable: HEWPACK HONG KONG

ICELAND

Hewlett-Packard Iceland
Hoefdabakka 9
110 REYKJAVIK
Tel: (1) 67 1000

INDIA

Blue Star Ltd.
13 Community Center
New Friends Colony
NEW DELHI 110 065
Tel: 633182, 636674
Telex: 031-61120
Cable: BLUEFROST

INDONESIA

BERCA Indonesia P T
P.O. Box 2497/Jkt
Antara Bldg., 11th Floor
Jl. Medan Merdeka Selatan 17
JAKARTA-PUSAT
Tel: 343989
Telex: 46748 BERSAL IA

IRELAND

Hewlett-Packard Ireland Ltd
82/83 Lower Leeson Street
DUBLIN 2
Tel: 0001 608800
Telex: 30439

ISRAEL

Computation and Measurement
Systems (CMS) Ltd.
11 Masad Street
67060
TEL-AVIV
Tel: 388 388
Telex: 33569 Motil IL

ITALY

Hewlett-Packard Italiana S.p.A
Via G. di Vittorio 9
I-20063 CERNUSCO SUL
NAVIGLIO
(Milano)
Tel: (02) 923691
Telex: 334632

Hewlett-Packard Italiana S.p.A.
Viale C. Pavese 340
I-00144 ROMA EUR
Tel: (06) 54831
Telex: 610514

JAPAN

Yokogawa-Hewlett-Packard Ltd
Chuo Bldg.
4-20 Nishinakajima, 5 Chome
Yodogawa-ku
OSAKA, 532
Tel: (06) 304-6021
Telex: YHPOSA 523-3624
Yokogawa-Hewlett-Packard Ltd.
28-21 Takaido-Higashi, 3 Chome
Suginami-ku TOKYO 168
Tel: (03) 331-6111
Telex: 232-2024 YHPTOK

Yokogawa-Hewlett-Packard Ltd
Yasuda Seimei Nishiguchi Bldg
30-4 Tsuruya-cho, 3 Chome
Kanagawa-ku YOKOHAMA 221
Tel: (045) 312-1252

**SALES & SUPPORT OFFICES**

Arranged alphabetically by country

KOREA

Samsung Hewlett-Packard Co Ltd
Dongbang Yeouuido Building
12-16th Floors
36-1 Yeouuido-Dong
Youngdeungpo-Ku
SEOUL
Tel: 784-4666, 784-2666
Telex: 25166 SAMSAN K

MALAYSIA

Hewlett-Packard Sales (Malaysia)
Sdn Bhd
9th Floor
Chung Khlaw Bank Building
46, Jalan Raja Laut
50350 KUALA LUMPUR
Tel: 2986555
Telex: 31011 HPSM MA

MEXICO

Hewlett-Packard de Mexico,
S.A. de C.V.
Monte Pelvoux No. 111
Lomas de Chapultepec
11000 **MEXICO, D.F.**
Tel: 5-40-62-28, 72-86, 50-25
Telex: 17-74-507 HEWPACK MEX

NETHERLANDS

Hewlett-Packard Nederland B.V.
Startbaan 16
NL-1187 XR **AMSTELVEEN**
P.O. Box 667
NL-1180 AR **AMSTELVEEN**
Tel: (020) 547-6911
Telex: 13 216 HEPA NL

NORWAY

Hewlett-Packard Norge A/S
Osterdalen 16-18
P.O. Box 34
N-1345 **ØESTERAAS**
Tel: 0047 7/24 60 90
Telex: 76621 hpnas n

PUERTO RICO

Hewlett-Packard Puerto Rico
101 Muñoz Rivera Av
Esu. Calle Ochoa
HATO REY, Puerto Rico 00918
Tel: (809) 754-7800

SAUDI ARABIA

Modern Electronics Establishment
Hewlett-Packard Division
P.O. Box 1228
Redec Plaza, 6th Floor
JEDDAH
Tel: 644 96 28
Telex: 4027 12 FARNAS SJ
Cable: ELECTA JEDDAH

SINGAPORE

Hewlett-Packard Singapore (Sales)
Pte. Ltd.
#08-00 Incape House
450-2 Alexandra Road
Alexandra P.O. Box 58
SINGAPORE, 9115
Tel: 4731788
Telex: 34209 HPSGSO RS
Cable: HEWPACK, Singapore

SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd.
9 Eastern Service Road
Eastgate Ext. 3
SANDTON 2144
Tel: 802-5111, 802-5125
Telex: 4-20877 SA
Cable: HEWPACK Johannesburg

SPAIN

Hewlett-Packard Española, S.A.
Ctra. de la Coruña, Km. 16, 400
Las Rozas
E-MADRID
Tel: (1) 637.00.11
Telex: 23515 HPE

SWEDEN

Hewlett-Packard Sverige AB
Skalholtsgatan 9, Kista
Box 19
S-16393 **SPÅNGA**
Tel: (08) 750-2000
Telex: (854) 17886
Telefax: (08) 7527781

SWITZERLAND

Hewlett-Packard (Schweiz) AG
7, rue du Bois-du-Lan
Case postale 365
CH-1217 **MEYRIN 1**
Tel: (0041) 22-83-11-11
Telex: 27333 HPAG CH

TAIWAN

Hewlett-Packard Taiwan Ltd.
8th Floor, Hewlett-Packard Building
337 Fu Hsing North Road
TAIPEI
Tel: (02) 712-0404
Telex: 24439 HEWPACK
Cable: HEWPACK Taipei

TURKEY

Teknim Company Ltd
Iran Caddesi No. 7
Karaklidere
ANKARA
Tel: 275800
Telex: 42155 TKNM TR

UNITED KINGDOM**ENGLAND**

Hewlett-Packard Ltd.
Heathside Park Road
Cheadle Heath
STOCKPORT
Cheshire
SK3 0RB
Tel: 061-428-0828
Telex: 668068

Hewlett-Packard Ltd.
King Street Lane
Winnerah, **WOKINGHAM**
Berkshire RG11 5AR
Tel: 0734 784774
Telex: 847178

SCOTLAND

Hewlett-Packard Ltd.
SOUTH QUEENSFERRY
West Lothian, EH30 9TG
Tel: 031 331 1188
Telex: 72682

UNITED STATES**Alabama**

Hewlett-Packard Co.
420 Wynn Drive
HUNTSVILLE, AL 35805
Tel: (205) 830-2000

Arizona

Hewlett-Packard Co.
8080 Pointe Parkway West
PHOENIX, AZ 85044
Tel: (602) 273-8000

California

Hewlett-Packard Co.
1421 S. Manhattan Av.
FULLERTON, CA 92631
Tel: (714) 999-6700

Hewlett-Packard Co
5651 West Manchester Ave.
LOS ANGELES, CA 90045
Tel: (213) 337-8000
Telex: 910-325-6608

Hewlett-Packard Co.
9606 Aero Drive
SAN DIEGO, CA 92123
Tel: (619) 279-3200

Hewlett-Packard Co.
3003 Scott Boulevard
SANTA CLARA, CA 95054
Tel: (408) 988-7000
Telex: 910-338-0586

Colorado

Hewlett-Packard Co
24 Inverness Place, East
ENGLEWOOD, CO 80112
Tel: (303) 649-5000

Connecticut

Hewlett-Packard Co.
47 Barnes Industrial Road South
WALLINGFORD, CT 06492
Tel: (203) 265-7801

Florida

Hewlett-Packard Co
2901 N.W. 62nd Street
FORT LAUDERDALE, FL 33309
Tel: (305) 973-2600

Hewlett-Packard Co.
6177 Lake Ellenor Drive
ORLANDO, FL 32809
Tel: (305) 859-2900

Georgia

Hewlett-Packard Co.
2000 South Park Place
ATLANTA, GA 30339
Tel: (404) 955-1500
Telex: 810-766-4890

Illinois

Hewlett-Packard Co
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800
Telex: 910-687-1066

Indiana

Hewlett-Packard Co
11911 N. Meridian St.
CARMEL, IN 46032
Tel: (317) 844-4100

Louisiana

Hewlett-Packard Co
160 James Drive East
ST. ROSE, LA 70087
P.O. Box 1449
KENNER, LA 70063
Tel: (504) 467-4100

Maryland

Hewlett-Packard Co
3701 Koppers Street
BALTIMORE, MD 21227
Tel: (301) 644-5800
Telex: 710-862-1943

Hewlett-Packard Co
2 Choke Cherry Road
ROCKVILLE, MD 20850
Tel: (301) 948-6370

Massachusetts

Hewlett-Packard Co
1775 Minuteman Road
ANDOVER, MA 01810
Tel: (617) 682-1500

Michigan

Hewlett-Packard Co.
39550 Orchard Hill Place Drive
NOVI, MI 48050
Tel: (313) 349-9200

Minnesota

Hewlett-Packard Co.
2025 W. Larpenteur Ave.
ST. PAUL, MN 55113
Tel: (612) 644-1100

Missouri

Hewlett-Packard Co.
1001 E. 101st Terrace Suite 120
KANSAS CITY, MO 64131-3368
Tel: (816) 941-0411

Hewlett-Packard Co
13001 Hollenberg Drive
BRIDGETON, MO 63044
Tel: (314) 344-5100

New Jersey

Hewlett-Packard Co.
120 W. Century Road
PARAMUS, NJ 07653
Tel: (201) 265-5000

New Mexico

Hewlett-Packard Co.
7801 Jefferson N.E.
ALBUQUERQUE, NM 87109
Tel: (505) 823-6100

New York

Hewlett-Packard Co
9600 Main Street
CLARENCE, NY 14031
Tel: (716) 759-8621

Hewlett-Packard Co.
7641 Henry Clay Blvd
LIVERPOOL, NY 13088
Tel: (315) 451-1820

Hewlett-Packard Co.
3 Crossways Park West
WOODBURY, NY 11797
Tel: (516) 682-7800

North Carolina

Hewlett-Packard Co
5605 Roanne Way
GREENSBORO, NC 27420
Tel: (919) 852-1800

Ohio

Hewlett-Packard Co
15885 Sprague Road
CLEVELAND, OH 44136
Tel: (216) 243-7300

Hewlett-Packard Co
9080 Springboro Pike
MIAMISBURG, OH 45342
Tel: (513) 433-2223

Hewlett-Packard Co
675 Brooksedge Blvd
WESTERVILLE, OH 43081
Tel: (614) 891-3344

Oklahoma

Hewlett-Packard Co
3525 N.W. 56th St
Suite C-100
OKLAHOMA CITY, OK 73112
Tel: (405) 946-9499

Oregon

Hewlett-Packard Co
9255 S.W. Pioneer Court
WILSONVILLE, OR 97070
Tel: (503) 682-8000

Pennsylvania

Hewlett-Packard Co.
111 Zeta Drive
PITTSBURGH, PA 15238
Tel: (412) 782-0400

Hewlett-Packard Co
2750 Monroe Boulevard
VALLEY FORGE, PA 19482
Tel: (215) 666-9000

Texas

Hewlett-Packard Co.
1826-P Kramer Lane
AUSTIN, TX 78758
Tel: (816) 941-0411

Hewlett-Packard Co.
10535 Harwin Drive
HOUSTON, TX 77036
Tel: (713) 776-6400

Hewlett-Packard Co
930 E. Campbell Rd
RICHARDSON, TX 75081
Tel: (214) 231-6101

Hewlett-Packard Co.
1020 Central Parkway South
SAN ANTONIO, TX 78232
Tel: (512) 494-9336

Utah

Hewlett-Packard Co
3530 W. 2100 South St
SALT LAKE CITY, UT 84119
Tel: (801) 974-1700

Virginia

Hewlett-Packard Co.
4305 Cox Road
GLEN ALLEN, VA 23060
Tel: (804) 747-7750

Washington

Hewlett-Packard Co.
15815 S.E. 37th Street
BELLEVUE, WA 98006
Tel: (206) 643-4000

Wisconsin

Hewlett-Packard Co.
275 N. Corporate Dr
BROOKFIELD, WI 53005
Tel: (414) 794-8800

VENEZUELA

Hewlett-Packard de Venezuela C A
3A Transversal Los Ruices Norte
Edificio Segre 2 & 3
Apartado 50933
CARACAS 1050
Tel: (582) 239-4133
Telex: 251046 HEWPACK

YUGOSLAVIA

Do Hermes
General Zdanova 4
YU-11000 BEOGRAD
Tel: (011) 342 641
Telex: 11433