


# HP E1420B

## QUICK REFERENCE GUIDE



Provides the following:

- START-UP/VERIFICATION
- PARAMETER TYPES
- ERROR MESSAGES AND CODES
- INITIALIZATION DEFAULTS
- COMMON COMMAND SUMMARY
- SCPI COMMAND SUMMARY

 HEWLETT  
PACKARD

HP PART NUMBER: E1420-90022



## ***HP E1420B SCPI Command Summary***

:(ROOT)	KEYWORD/SYNTAX	PARAMETER FORM	CHANNEL NUMBER
<b>ARM Subsystem</b>	<b>ABORT[1 2 3]</b> <b>ARM</b> [:SEQUence[1]:STATe] :SEQUence2:STOP [:LAYer[1]] [:IMMediate] :LEVel :LEVel? :SLOPe :SLOPe? :SOURce :SOURce?	<value MINimum MAXimum DEFault> [<MINimum MAXimum DEFault>] <POSitive NEGative> <EXTernal IMMediate BUS  HOLD TTLTrig<n>> n= 0-7	1,2,3
<b>CONFigure Subsystem</b>	<b>CONFigure[1 2 3]</b> [:VOLTage] :AC :DC :FREQuency :RATio :FTIME -or- :FALL :TIME :MAXimum :MINimum :NWIDth :PERiod :PWIDth :RTIME -or- :RISE :TIME :TINTerval :TOTalize CONFigure[1 2 3]?	[<expected value>[,<resolution>]] [<expected value>[,<resolution>]] [<expected value>[,<resolution>]] [<expected value>[,<resolution>]] [<lower reference>,<upper reference> [,<expected value>[,<resolution>]]]] [<expected value>[,<resolution>]] [<expected value>[,<resolution>]] [<reference>,<expected value> [,<resolution>]]] [<expected value>[,<resolution>]] [<reference>,<expected value> [,<resolution>]]] [<lower reference>,<upper reference> [,<expected value>[,<resolution>]]]] [<expected value>[,resolution>]] [<expected value>[,resolution>]]	1,2 1,2 1,2,3 1,2,3 1 1,2 1,2 1,2,3 1,2 1 1,2 1 1



## **DIAGnistics Subsystem**

**DIAGnistics**  
:CALibrate  
  
:OFFSet?  
:FULLscale?  
:ASSEMBly  
[:ALL]?  
:A1?  
:A2?  
:BLOCK  
[:ALL]?  
:CALRam?  
:ROM?  
:RAM?  
:COUNTchain  
[:ALL]?  
:CONNECTor?  
:INTerpolat?  
:DINTerpolat?  
:MRC?  
:TIMEbase?  
:READ  
:INT?  
:MRC?  
:UFail[?]   
  
:<BOTH>  
:<BOTH>

<STS|SPS|STL|SPL|STAR|STOP|CAL|ALL>  
<EREG|TREG|ALL>  
<OFF|0|ON|1>

1,2,3

## **FETCh Subsystem**

**FETCh[1|2|3]**  
[:<function>?]

## **INITiate Subsystem**

**INITiate[1|2|3]**  
[:IMMediate]  
:CONTinuous  
:CONTinuous?

<OFF|0|ON|1>

## **INPut Subsystem**

**INPut[1|2]**  
:ATTenuation  
:ATTenuation?  
:COUPling  
:COUPling?  
:IMPedance  
:IMPedance?  
:ROUTE  
:ROUTE?  
  
:<value|MINimum|MAXimum|DEFault>  
:[<MINimum|MAXimum|DEFault>]  
<AC|DC>  
  
:<value|MINimum|MAXimum|DEFault>  
:[<MINimum|MAXimum|DEFault>]  
<COMMON|SEParate>

1,2  
1,2  
1,2  
1,2  
1,2  
1,2  
1,2  
1,2



**MEASure  
Subsystem****MEASure[1|2|3]**

<b>[:VOLTage]</b>		
:AC?	[<expected value>[,<resolution>]]	1,2
:DC?	[<expected value>[,<resolution>]]	1,2
:FREQuency?	[<expected value>[,<resolution>]]	1,2,3
:RATio?	[<expected value>[,<resolution>]]	1,2,3
:FTIMe?		
-or-		
:FALL		
:TIME?	[<lower reference>[,<upper reference> ,<expected value>[,<resolution>]]]]	1
:MAXimum?	[<expected value>[,<resolution>]]	1,2
:MINimum?	[<expected value>[,<resolution>]]	1,2
:NWIDth?	[<reference>[,<expected value> ,<resolution>]]]	1,2
:PERiod?	[<expected value>[,<resolution>]]	1,2,3
:PWIDth?	[<reference>[,<expected value> ,<resolution>]]]	1,2
:RTIMe?		
-or-		
:RISE		
:TIME?	[<lower reference>[,<upper reference> ,<expected value>[,<resolution>]]]]	1
:TINTerval?	[<expected value>[,<resolution>]]	1

*Option 040, Shared Memory (Refer to the E1420B User's Manual, E1420-90014)***MEMory  
Subsystem****OUTPut  
Subsystem****OUTPut**

:TTLTrg<n> N= 0-7		
[:STATe]	<OFF 0 ON 1>	Backplane Trigger Lines
[:STATe]?		
:ROSCillator		
[:STATe]	<OFF 0 ON 1>	Int/Ext Reference
[:STATe]?		

**READ  
Subsystem****READ[1|2|3]**

[:<function>]?]		1,2,3
-----------------	--	-------



## SENSe Subsystem

[SENSe[1 2 3]]		
:AVERage	<OFF 0 ON 1>	
[:STATe]		
[:STATe]?		
:COUNT?		
:EVENT		
:LEVel		
[:ABSolute]	<value MINimum MAXimum DEFault>	
[:ABSolute]?	[<MINimum MAXimum DEFault>]	
:AUTO	<OFF 0 ON 1 ONCE>	
:AUTO?		
:RELative		
:RELative?		
:SLOPe		
:SLOPe?		
:HYSTeresis		
:HYSTeresis?		
:FREQuency		
:APERture	<value MINimum MAXimum DEFault>	1,2,3
:APERture?	[<MINimum MAXimum DEFault>]	1,2,3
:RANGE		1
[:UPPer]	<value MINimum MAXimum DEFault>	
[:UPPer]?	[<MINimum MAXimum DEFault>]	
:AUTO	<OFF 0 ON 1>	
:AUTO?		
:FUNCTION		
"[VOLTage:]AC"		1,2
"[VOLTage:]DC"		1,2
"[VOLTage:]FREQuency"		1,2,3
"[VOLTage:]FREQuency:RATio"		1,2,3
"[VOLTage:]FTIMe"		1
"[VOLTage:]FALL:TIME"		1
"[VOLTage:]MAXimum"		1,2
"[VOLTage:]MINimum"		1,2
"[VOLTage:]NWIDth"		1,2
"[VOLTage:]PERiod"		1,2,3
"[VOLTage:]PWIDth"		1,2
"[VOLTage:]RTIMe"		1
"[VOLTage:]RISE:TIME"		1
"[VOLTage:]TINTerval"		1,2
"[VOLTage:]TOTalize"		1,2
		1,2,3
:FUNCTION?		
:PERiod		
[:APERture]	<value MINimum MAXimum DEFault>	1,2,3
[:APERture]?	[<MINimum MAXimum DEFault>]	1,2,3
:RATio		
[:APERture]	<value MINimum MAXimum DEFault>	1,2,3
[:APERture]?	[<MINimum MAXimum DEFault>]	1,2,3
:ROSCillator		
:SOURce	<INTERNAL EXTERNAL CLK10>	Int/Ext Reference
:SOURce?		
:TINTerval		
:DELAY		
[:STATe]	<OFF 0 ON 1>	
[:STATe]?		
:TIME		
:TIME?		
:TOTalize		
:GATE		
[:STATe]	<OFF 0 ON 1>	
[:STATe]?		
:POLarity		
:POLarity?		
:SOURce?		



**STATus  
Subsystem**

**STATus**  
:OPERation  
:CONDition?  
:ENABLE <value>|<non-decimal numeric>  
  
:ENABLE?  
[:EVENT]?  
:QUEStionable  
:CONDition?  
:ENABLE <value>|<non-decimal numeric>  
  
:ENABLE?  
[:EVENT]?  
:PRESet

**SYSTem  
Subsystem**

**SYSTem**  
:ERRor?  
:PIMacro <string>  
:VERSion? <string>

— See other side for IEEE 488.2 Common Commands (available at any time). —



H

P

E

1

4

2

0

## ***Start-Up/Verification***

Verify the counter with the following procedures:

1. Power-up the controller if this is separate from the VXIbus mainframe.
2. Power-up the VXIbus mainframe and verify Slot 0 functionality. (If present, the Slot 0 module must be correctly set-up, functional, and pass its own self-test.)
3. Observe that the "Failed" LED on the HP E1420B is lit, then extinguishes after a few seconds indicating successful completion of Self-test. The counter is now in the power-on state and is ready for use.

## ***In Case Of Difficulty***

If the counter fails to successfully complete Self-test, doublecheck the following items:

- System controller present and operational (passes own self-test),
- Slot 0 module present and operational (passes own self-test),
- VXIbus C sized cardcage present and operational (cooling and power supplies OK),
- HP-IB connection between controller and VXIbus cardcage present and operational,
- HP E1420B front-panel Access LED is lit momentarily to indicate correct Bus addressing of the E1420B Universal Counter.
- HP E1420B present and operational (passes own self-test and reports results back to Slot 0 module/systems controller),
- Syntactically correct Common/SCPI command messages sent to HP E1420B via BASIC over the HP-IB and VXIbus interface.
- Correct use of the particular instrument control language to transfer commands from the controller to the HP E1420B counter. (Refer to pg. 3-2/4 of the HP E1420B User's Manual for more information.)
- Verify that the signal inputs to the counter's front-panel BNC connectors are present and that a 10-MHz reference timebase signal is connected to the Int/Ext Reference BNC.
- Ensure that the programmed SCPI commands are in fact triggering counter measurements as input signal events occur indicated by associated Input BNC trigger LEDs.



# B

## **HP E1420B Parameter Types**

<b>TYPE</b>	<b>EXPLANATIONS AND EXAMPLES</b>
Numeric:	Accepts all commonly used decimal representations of numbers including optional signs, decimal points, and scientific notation: 123, 123E2, -123, -1.23E2, .123, 1.23E-2, 1.23000E-01. Special cases include MIN, MAX, and DEF. MIN selects minimum value available, MAX selects maximum value available, and DEF selects the default or reset value. Queries on MIN, MAX, or DEF results in an associated numeric value. All decimal types also accept MIN, MAX, or DEF, and can be queried with them to produce a numeric value.
Boolean:	Represents a single binary condition that is either true or false: 1 or ON, 0 or OFF.
Discrete:	Selects from a finite number of values. These parameters use mnemonics to represent each valid setting. An example is the ARM:SOURce <source> command where source can be BUS, TTLTrg<n>, Hold, IMMEDIATE, or EXTERNAL.



TT



# HP E1420B Error Messages and Codes

CODE	MESSAGE	CAUSE
-100	Command error	Unrecognized character in specified parameter
-101	Invalid character	Command missing space/comma between parameters
-102	Syntax error	Command parameter separately by space not comma
-103	Invalid separator	Wrong data type specified in parameter
-104	Data type error	Group Execute Trigger was received
-105	GET not allowed	Parameter specified in parameterless command
-108	Parameter not allow	Parameter missing in entered command
-109	Missing parameter	Header contains more than 12 characters
-112	Program mnemonic too long	Command header incorrectly specified
-113	Undefined header	Entered character for numeric data is incorrect
-121	Invalid character in number	Exponent larger than 32000
-123	Numeric overflow	More than 256 digits specified
-124	Too many digits	Number specified for parameter not letter
-128	Numeric data not allowed	Parameter suffix incorrectly specified, (e.g. 50 M instead of 50 MHz)
-131	Invalid suffix	Parameter suffix specified when not allowed
-138	Suffix not allowed	Parameter type specified not allowed (e.g. data "MEAS:FREQ HIGH" instead of "MEAS:FREQ MAX")
-141	Invalid character data	Character data element has more than 12 characters
-144	Character data too long	Entered character data not recognized by counter
-148	Character data not allowed	Entered string data contained a non-specific error
-150	String data error	Entered string data syntax invalid
-151	Invalid string data	String data encountered but not allowed
-158	String data not allowed	Entered block data contained a non-specific error
-160	Block data error	Entered block data syntax invalid
-161	Invalid block data	Block data encountered but not allowed
-168	Block data not allowed	Entered expression contained a non-specific error
-170	Expression error	Entered block data syntax invalid
-171	Invalid expression	Expression data encountered but not allowed
-178	Expression data not allowed	Entered macro command or parameter contained a non-specific error
-180	Macro error	Macro parameter placeholder encountered outside a macro definition
-181	Invalid outside macro definition	Program message sent with *DMC is syntactically invalid
-183	Invalid inside macro definition	Requested measurement is not available
-200	Execution error	Command not executeable while device in local
-201	Invalid while in local	Appropriate channel was not set up for the requested measurement
-204	Channel not configured for measurement	External arm source inconsistent for start and stop within the same program message
-205	Arming configuration conflict	Executed FETCh? without initiating measurement for new configuration
-206	Measurement has not been initiated	Totalize on channel 2 (totalize on 1 or totalize 2 by 1)
-207	Invalid totalize	Calculated parameter outside allowed range
-208	Value out of range	Entered parameter(s) outside of range - data truncated at limit
-209	Data clipped to limit	ARM:IMMEDIATE set without being INITIALIZED
-212	ARM ignored	Another measurement already in progress
-213	INIT ignored	Attempted FECh? while arming was in HOLD or BUS mode
-215	Arm deadlock	Requested configuration conflicts with one or more current setting(s)
-221	Settings Conflict	Specified parameter value too large/small
-222	Data out of range	Excess data for memory/device-specific process requirements
-223	Too much data	Specific numeric value not allowed
-224	Illegal parameter value	New measurement started but not completed since last access
-230	Data corrupt or stale	Measurement accuracy is suspect
-231	Data questionable	Execution error due to hardware fault
-240	Hardware error	Option 010 or 030 not installed
-241	Hardware missing	Non-specific execution related macro error
-270	Macro error	Illegal macro syntax entered
-271	Macro syntax error	Macro execution error due to macro definition error
-272	Macro execution	Entered macro label not accepted by device
-273	Illegal macro label	Macro definition contains improperly used macro parameter
-274	Macro parameter error	Device found macro recursive
-276	Macro recursion error	Macro label already defined
-277	Macro redefinition not allowed	Allotted VXIbus shared memory space is full
-301	Exceeded shared memory	Non-specific system error has occurred
-310	System error	Specific hardware failed
-331	Selftest failed; EPROM checksum failure	Specified hardware failed
-332	Selftest failed; RAM failure	Specified hardware failed
-333	Selftest failed; Clock 10 failed	Specified hardware failed
-334	Selftest failed; Front-end failed	Specified hardware failed
-335	Selftest failed; Calibration RAM failure	Specified hardware failed
-350	Too many errors	The error queue is full - more than 30 errors have occurred
-400	Query error	Data not read from output buffer before another command was executed
-410	Query interrupted	Command generating data unable to complete due to configuration error
-420	Query unterminated	Command cannot complete output due to controller request for input
-430	Query deadlock	





## HP E1420B Initialization State

SUBSYSTEM	COMMAND/ PARAMETER	STATE	COMMAND	DESCRIPTION
INPUT	ATTenuation	x1	*CLS	Clears the Status Byte Register, Standard Event Status Register, and error queue.
	COUPling	dc	*DMC	Assigns a sequence of program elements to a Macro label.
	IMPedance	50Ω	*EMC	Enables/disables the execution of macros.
	ROUTe	SEParate	*EMC?	Returns the current enable/disable status of a macro.
ARM	EXTernal:LEVel	1.6V (TTL)	*ESE	Enable events in Standard Event Status Register to be reported.
	STARt:SLOPe	NEGative	*ESE?	Returns the sum of all enabled bits in the Standard Events Status Register.
	STARt:SOURce	IMMEDIATE	*GMC?	Returns the current definition of a macro.
	STOP:SLOPe	NEGative	*IDN?	Returns identification string.
SENSe (also, CONFigure and MEASure)	STOP:SOURce	IMMEDIATE	*LMC?	Returns the labels of all currently defined macros.
	APERture	100 ms	*OPC	Sets bit 0 in the Standard Event Status Register after all pending operations complete.
	Auto Trigger State	OFF	*OPC?	Returns ASCII "1" after all pending operations complete.
	AVERage:STATe	OFF	*PMC	Purges all currently defined macros.
	TINT:DELay:STATe	OFF	*RCL	Recalls configuration previously stored via the *SAV command.
	TINT:DELay:TIME	100 ms	*RST	Resets the counter to a known power-on/reset status.
	EVENT:LEVel (Trigger level)	0 volts	*SAV	Saves the current counter module configuration.
	EVENT:SLOPe	POSitive	*SRE	Enable Status Register bits to assert SRQ.
	FUNCTion	FREQuency	*SRE?	Returns sum of enabled status register bits.
	HYSTeresis	"DEF"	*STB?	Returns sum of all bits set in Status Byte Register.
OUTPut	Input Channel	1	*TRG	Triggers the counter.
	CH1 Prescaling	OFF	*TST?	Executes the counter's internal self-test.
	RANGe:AUTO	OFF	*WAI	Causes the counter to wait until all previous commands or queries complete.
	RELative (trigger level)	50%		
	ROSCillator:SOURce	CLK10		
	TOTalize:GATE:POLarity	NORMAL		
	TOTalize:GATE:STATe	OFF		

