



3900 Series Digital Radio Test Set Maintenance Manual

Issue-7

EXPORT CONTROL WARNING: This document contains controlled technical data under the jurisdiction of the Export Administration Regulations (EAR), 15 CFR 730-774. It cannot be transferred to any foreign third party without the specific prior approval of the U.S. Department of Commerce Bureau of Industry and Security (BIS). Violations of these regulations are punishable by fine, imprisonment, or both.

3900 Series

Digital Radio Test Set

Maintenance Manual

PUBLISHED BY
Aeroflex

COPYRIGHT © Aeroflex 2015

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior permission of the publisher.

Re-Issued	Jan 2010
Issue-2	Mar 2010
Issue-3	Jan 2011
Issue-4	Oct 2011
Issue-5	Sep 2013
Issue-6	Jan 2014
Issue-7	Feb 2015

10200 West York/Wichita, Kansas 67215 U.S.A./ (316) 522-4981/FAX (316) 524-2623

Subject to Export Control, see Cover Page for details.

WARNING:

HIGH VOLTAGE EQUIPMENT

THIS EQUIPMENT CONTAINS CERTAIN CIRCUITS AND/OR COMPONENTS OF EXTREMELY HIGH VOLTAGE POTENTIALS, CAPABLE OF CAUSING SERIOUS BODILY INJURY OR DEATH. WHEN PERFORMING ANY OF THE PROCEDURES CONTAINED IN THIS MANUAL, HEED ALL APPLICABLE SAFETY PRECAUTIONS.

SAFETY FIRST: TO ALL SERVICE PERSONNEL

REFER ALL SERVICING OF UNIT TO QUALIFIED TECHNICAL PERSONNEL.

CASE, COVER OR PANEL REMOVAL






Removing protective covers, casings or panels from this unit exposes the technician to electrical hazards that can result in electrical shock or equipment damage.

SAFETY IDENTIFICATION IN TECHNICAL MANUAL

This manual uses the following terms to draw attention to possible safety hazards that may exist when operating or servicing this equipment.

CAUTION	IDENTIFIES CONDITIONS OR ACTIVITIES THAT, IF IGNORED, CAN RESULT IN EQUIPMENT OR PROPERTY DAMAGE, E.G., FIRE.
WARNING	IDENTIFIES CONDITIONS OR ACTIVITIES THAT, IF IGNORED, CAN RESULT IN PERSONAL INJURY OR DEATH.

SAFETY SYMBOLS IN MANUALS AND ON UNITS

	CAUTION: Refer to accompanying documents. (This symbol refers to specific CAUTIONS represented on the unit and clarified in the text.)
	Indicates a Toxic hazard.
	Indicates item is static sensitive.
	AC TERMINAL: Terminal that may supply or be supplied with AC or alternating voltage.
	DANGEROUS VOLTAGE: Indicates electrical shock hazard due to high voltage levels.

EQUIPMENT GROUNDING PRECAUTION

WARNING	IMPROPER GROUNDING OF EQUIPMENT CAN RESULT IN ELECTRICAL SHOCK.
----------------	--

USE OF PROBES

Refer to products specifications for the maximum voltage, current and power ratings of any connector on the unit before connecting it with a probe from a terminal device. Be sure the terminal device performs within these specifications before using it for measurement, to prevent electrical shock or damage to the equipment.

POWER CORDS

Power cords must not be frayed or broken nor expose bare wiring when operating this equipment.

WARNINGS

USE RECOMMENDED FUSES ONLY

Use only fuses specifically recommended for the equipment at the specified current and voltage ratings. Refer to product specifications for fuse requirements and specifications..

CAUTION

INTEGRATED CIRCUITS AND SOLID STATE DEVICES SUCH AS MOS FETS, ESPECIALLY CMOS TYPES, ARE SUSCEPTIBLE TO DAMAGE BY ELECTROSTATIC DISCHARGES RECEIVED FROM IMPROPER HANDLING, THE USE OF UNGROUNDED TOOLS AND IMPROPER STORAGE AND PACKAGING. ANY MAINTENANCE TO THIS UNIT MUST BE PERFORMED TAKING THE FOLLOWING PRECAUTIONS:

BEFORE USE IN A CIRCUIT, KEEP ALL LEADS SHORTED TOGETHER, EITHER BY THE USE OF VENDOR SUPPLIED SHORTING SPRINGS OR BY INSERTING LEADS INTO A CONDUCTIVE MATERIAL.

WHEN REMOVING DEVICES FROM THEIR CONTAINERS, GROUND THE HAND BEING USED WITH A CONDUCTIVE WRISTBAND.

TIPS OF SOLDERING IRONS AND/OR ANY TOOLS USED MUST BE GROUNDED.

DEVICES MUST NEVER BE INSERTED INTO NOR REMOVED FROM CIRCUITS WITH POWER ON.

PC BOARDS, WHEN TAKEN OUT OF THE SET, MUST BE LAID ON A GROUNDED CONDUCTIVE MAT OR STORED IN A CONDUCTIVE STORAGE BAD. REMOVE ANY BUILT-IN POWER SOURCE, SUCH AS A BATTERY, BEFORE LAYING PC BOARDS ON A CONDUCTIVE MAT OR STORING IN A CONDUCTIVE BAG.

PC BOARDS, IF BEING SHIPPED TO THE FACTORY FOR REPAIR, MUST BE PACKAGES IN A CONDUCTIVE BAG AND PLACED IN A WELL-CUSHIONED SHIPPING CONTAINER.



CAUTION



THIS EQUIPMENT CONTAINS PARTS
SENSITIVE TO DAMAGE
BY ELECTROSTATIC DISCHARGE (ESD).

CAUTION

SIGNAL GENERATORS CAN BE A SOURCE OF ELECTROMAGNETIC INTERFERENCE (EMI) TO COMMUNICATION RECEIVERS. SOME TRANSMITTED SIGNALS CAN CAUSE DISRUPTION AND INTERFERENCE TO COMMUNICATION SERVICE OUT TO A DISTANCE OF SEVERAL MILES. USER OF THIS EQUIPMENT SHOULD SCRUTINIZE ANY OPERATION THAT RESULTS IN RADIATION OF A SIGNAL (DIRECTLY OR INDIRECTLY) AND SHOULD TAKE NECESSARY PRECAUTIONS TO AVOID POTENTIAL COMMUNICATION INTERFERENCE PROBLEMS.

KEEP ALL VENT OPENINGS CLEAR AND UNOBSTRUCTED FOR PROPER EQUIPMENT COOLING AND CONTINUED RELIABILITY. DO NOT OPERATE EQUIPMENT IN THE VERTICAL POSITION ON PLUSH CARPET OR UPHOLSTERY TO AVOID IMPAIRING THE AIR EXHAUST. WHEN OPERATING THE TEST SET IN THE NORMAL HORIZONTAL OR TILT BAIL POSITION, MAINTAIN AT LEAST 1.6 INCHES (4 CENTIMETERS) OF CLEARANCE BETWEEN THE EQUIPMENT REAR EXHAUST FAN SCREEN AND OBJECTS OR WALLS.

Subject to Export Control, see Cover Page for details.

Preface

SCOPE

This manual contains instructions for the maintenance of the 3900 Series Digital Radio Test Set. Aeroflex recommends that the technician performing these procedures be familiar with this manual before attempting to perform any maintenance action on the Test Set. The information in this manual enables servicing technicians to:

- Service, test or replace any major assembly within the Test Set.
- Maintain operating conditions of the Test Set to the expected performance standards.
- Understand principles of operation, relating to the overall operation of the unit as well as functional operation within the major assemblies.

NOMENCLATURE

The 3901, 3902, 3920 and 3920B Digital Radio Test Set is the official nomenclature for the test sets currently included in the 3900 Digital Radio Test Set Series. In this manual, 3900, unit or Test Set, refers to the 3901, 3902, 3920 and 3920B Digital Radio Test Sets unless otherwise indicated.

ORGANIZATION

The 3900 Series Digital Radio Test Set Maintenance Manual is composed of the following sections:

Chapter 1 - Introduction

Contains general Test Set information.

Chapter 2 - Theory of Operation

Describes system level and module (assembly) level functionality of the 3900.

Chapter 3 - Troubleshooting

Describes system level and assembly troubleshooting procedures.

Chapter 4 - Verification/Calibration Procedures

Provides step by step procedures for verifying and calibrating the 3900.

Chapter 5 - Replacement Procedures

Provides step by step instructions on removing and installing replaceable Test Set assemblies.

Chapter 6 - Assemblies and Interconnect Diagrams

Provides interconnect and assembly diagrams for the 3901, 3902, 3920 and 3920B.

Chapter 7 - Parts List

Provides parts lists for ordering accessories and replaceable parts for the 3900.

THIS PAGE INTENTIONALLY LEFT BLANK.

Table of Contents

General Information 1 - 1

1.1 . . . General Information	1 - 1
1.1.1 Scope	1 - 1
1.1.2 Nomenclature Cross Reference List	1 - 1
1.2 . . . Equipment Description and Data	1 - 1
1.2.1 Equipment Characteristics, Capabilities and Features	1 - 1
1.2.2 Equipment Data	1 - 1
1.2.3 Safety, Care and Handling	1 - 1
1.3 . . . Service Upon Receipt of Material	1 - 2
1.3.1 Unpacking	1 - 2
1.3.2 Checking Unpacked Equipment	1 - 3
1.4 . . . General Conditions of Use	1 - 3
1.4.1 Case, Cover or Panel Removal	1 - 4
1.4.2 Precautions	1 - 4

Theory of Operation 2 - 1

2.1 . . . General Information	2 - 1
2.2 . . . Principles of Operation	2 - 1
2.2.1 General Operational Description	2 - 1
2.2.2 General Functional Description	2 - 1
2.3 . . . Receive System Overview	2 - 2
2.4 . . . Generate System Overview	2 - 3
2.5 . . . Module Overview	2 - 29
2.5.1 Backplane PCB Assembly (44A1A1A1)	2 - 29
2.5.2 Rear Panel Audio Assembly	2 - 30
2.5.3 CPU Adapter PCB Assembly (44A1A1A5)	2 - 30
2.5.4 Power Supply Assembly (44A1A1A6)	2 - 31
2.5.5 Power Term(ination) Assembly (44A1A1A7)	2 - 31
2.5.6 Digital Multimeter (DMM) Assembly (44A1A1A9 3920 only)	2 - 32
2.5.7 DISK I/O PCB Assembly (44A1A1A9)	2 - 33
2.5.8 Attenuator Assembly (44A1A3)	2 - 34
2.5.9 Generator Assembly (44A1A4)	2 - 34
2.5.10 Generator Assembly (44A1A4)	2 - 35
2.5.11 IF/Video PCB Assembly (44A1A5)	2 - 37
2.5.12 Receiver Assembly (44A1A7)	2 - 37
2.5.13 CAI PCB Assembly (44A1A8)	2 - 38
2.5.14 DAM (Data Acquisition Module) Carrier PCB Assembly (44A1A10)	2 - 38

Troubleshooting Procedures 3 - 1

- 3.1 . . . General 3 - 1
 - 3.1.1 . . . Symptom Troubleshooting Procedures 3 - 1
 - 3.1.2 . . . Assembly Troubleshooting Procedures 3 - 1
- 3.2 . . . Troubleshooting Guidelines 3 - 2
 - 3.2.1 . . . Precautions 3 - 2
- 3.3 . . . Required Equipment 3 - 3
- 3.4 . . . Preventive Maintenance Procedures 3 - 3
 - 3.4.1 . . . External Cleaning 3 - 3
 - 3.4.2 . . . Internal Cleaning 3 - 3
 - 3.4.3 . . . Visual Inspection 3 - 4
- 3.5 . . . Assembly Cables and Connectors 3 - 5
 - 3.5.1 . . . 390x and 3920 Cables and Connectors 3 - 5
 - 3.5.2 . . . 3920B Cables and Connectors 3 - 6
- 3.6 . . . Symptom Troubleshooting Procedures 3 - 7
 - 3.6.1 . . . Preliminary Procedure 3 - 7
- 3.7 . . . Assembly Troubleshooting Procedures 3 - 21
 - 3.7.1 . . . Preliminary Procedures 3 - 21
 - 3.7.2 . . . Verify DAM Carrier PCB Assy Operation 3 - 21
 - 3.7.3 . . . Verify Generator Assy Operation. 3 - 22
 - 3.7.4 . . . Verify Attenuator/Power Term Assy Operation. 3 - 23
 - 3.7.5 . . . Verify Power Term Assy Receive operation. 3 - 23
 - 3.7.6 . . . Verify Receiver Assy Operation. 3 - 24
 - 3.7.7 . . . Verify IF/Video PCB Assy operation. 3 - 25

Verification/Calibration Procedures 4 - 1

4.1 . . . General Information 4 - 1

4.2 . . . Verification Schedule 4 - 1

4.3 . . . Calibration Schedule 4 - 1

4.4 . . . Follow-up Procedures 4 - 1

4.5 . . . Controls and Connectors 4 - 1

4.6 . . . Test Records 4 - 1

4.7 . . . Disassembly Requirements 4 - 2

4.8 . . . Precautions 4 - 2

 4.8.1 . . . Safety 4 - 2

 4.8.2 . . . ESD 4 - 2

4.9 . . . Required Equipment 4 - 2

4.10 . . . Special Notes/Instructions 4 - 2

4.11 . . . Saving Calibration Files 4 - 3

4.12 . . . Restoring Calibration Files 4 - 3

4.13 . . . Test Set Verification 4 - 4

 4.13.1 . . . Accessing Procedures 4 - 4

 4.13.2 . . . Verification Types 4 - 4

 4.13.3 . . . Verification Procedures 4 - 5

4.14 . . . Verification Data Sheet 4 - 38

4.15 . . . Calibration Procedures 4 - 48

 4.15.1 . . . Accessing Calibration System 4 - 48

 4.15.2 . . . Calibration Tile Layout 4 - 48

 4.15.3 . . . Selecting Calibration Procedure 4 - 49

 4.15.4 . . . Soft Keys 4 - 49

 4.15.5 . . . Zero/Calibrate Message 4 - 50

 4.15.6 . . . Time to Complete 4 - 51

4.16 . . . RF Generator Calibration 4 - 52

 4.16.1 . . . PA Detector Calibration 4 - 52

 4.16.2 . . . Attenuator Response Calibration 4 - 53

 4.16.3 . . . GEN Port Freq Response Calibration 4 - 54

 4.16.4 . . . T/R Port Freq Response Calibration 4 - 55

Verification/Calibration Procedures (cont)

4.17 . . Receiver Calibration	4 - 56
4.17.1 . . . Splitter Calibration	4 - 56
4.17.2 . . . IF Gain Calibration	4 - 58
4.17.3 . . . IF AMP Calibration	4 - 60
4.17.4 . . . ANT Port AMP Gain Calibration	4 - 62
4.17.5 . . . ANT Port 0-30 dB Calibration	4 - 63
4.17.6 . . . ANT Port Linearity Calibration	4 - 64
4.17.7 . . . Port Delta Calibration	4 - 65
4.17.8 . . . T/R Port 0-40 dB Calibration	4 - 66
4.17.9 . . . T/R Port Linearity Calibration	4 - 67
4.17.10 . . YIG Sweep Calibration	4 - 68
4.17.11 . . Function Generator Calibration	4 - 69
4.17.12 . . Scope DC Calibration	4 - 70
4.17.13 . . Scope AC Calibration	4 - 71
4.17.14 . . TCXO Adjustment Calibration	4 - 73
4.18 . . Calibration Data Sheet	4 - 74
4.19 . . Calibration Kit Contents	4 - 76

Remove/Install Procedures 5 - 1

5.1 . . . General 5 - 1

5.2 . . . Safety Precautions 5 - 1

5.3 . . . ESD Precautions 5 - 1

5.4 . . . Tool Requirements 5 - 2

5.5 . . . Preliminary Procedures 5 - 2

5.6 . . . Remove/Install Procedures 5 - 3

 5.6.1 Common Procedures 5 - 3

 5.6.2 3901/3902 Procedures 5 - 3

 5.6.3 3920/3920B Procedures 5 - 3

5.7 . . . Common Procedures 5 - 4

 5.7.1 Case Assembly 5 - 4

 5.7.2 Handle Assembly 5 - 8

 5.7.3 Attenuator Assembly 5 - 10

 5.7.4 DAM Carrier PCB Assembly 5 - 12

 5.7.5 CAI PCB Assembly 5 - 14

 5.7.6 CPU Adapter PCB Assembly 5 - 16

 5.7.7 CPU Adapter PCB Assembly Battery 5 - 20

 5.7.8 Rear Panel Assembly 5 - 21

 5.7.9 Rear Panel PCB Assembly 5 - 28

 5.7.10 Rear Panel Audio I/O PCB Assembly 5 - 29

 5.7.11 Fan Assembly 5 - 31

 5.7.12 Power Supply Assembly 5 - 33

 5.7.13 Speaker Wire Harness Assembly 5 - 37

 5.7.14 LCD Assembly 5 - 38

 5.7.15 LCD Lens 5 - 41

 5.7.16 Front Panel PCB Assembly 5 - 44

 5.7.17 Keypad Assembly 5 - 48

 5.7.18 Inverter Supply PCB Assembly 5 - 49

 5.7.19 LED Backlight Driver 5 - 52

 5.7.20 Power Termination Assembly 5 - 55

 5.7.21 Backplane PCB Assembly 5 - 59

5.8 . . . 3901/3902 Procedures 5 - 63

 5.8.1 Generator Assembly 3901/3902 5 - 63

 5.8.2 Receiver Assembly 3901/3902 5 - 67

 5.8.3 IF/Video PCB Assembly 3901/3902 5 - 72

 5.8.4 Disk I/O PCB Assembly 3901/3902 5 - 74

 5.8.5 Front Panel Assembly 3901/3902 5 - 76

 5.8.6 Front Panel Digital Interface PCB Assembly 3901/3902 5 - 80

 5.8.7 Floppy Drive Assembly 3901/3902 5 - 84

Remove/Install Procedures (cont)

5.9 . . . 3920/3920B Procedures	5 - 86
5.9.1 Generator Assembly 3920/3920B	5 - 86
5.9.2 Receiver Assembly 3920/3920B	5 - 91
5.9.3 IF/Video PCB Assembly 3920/3920B	5 - 95
5.9.4 Disk I/O PCB Assembly 3920/3920B	5 - 98
5.9.5 Front Panel Assembly 3920/3920B	5 - 100
5.9.6 Front Panel Digital Interface PCB Assembly 3920/3920B	5 - 104
5.9.7 DMM Assembly (3920 Optional Hardware)	5 - 107
5.9.8 USB Cable (3920 Front Panel)	5 - 109

Interconnect and Assembly Diagrams 6 - 1

6.1 . . . General	6 - 1
6.2 . . . 3901/3902 Composite Assembly	6 - 3
6.3 . . . 3901/3902 Composite Assy Interconnect Diagram	6 - 4
6.4 . . . 3901/3902 Chassis Assy	6 - 5
6.5 . . . 3920/3920B Composite Assembly	6 - 6
6.6 . . . 3920 Composite Assy Interconnect Diagram	6 - 7
6.7 . . . 3920B Composite Assy Interconnect Diagram	6 - 8
6.8 . . . 3920/3920B Chassis Assy	6 - 9
6.9 . . . Front Panel Cables	6 - 10
6.10 . . . Assembly and Cable Locations	6 - 11
6.11 . . . Front Panel Assembly	6 - 13

Parts List 7 - 1

7.1 . . . General 7 - 1

7.2 . . . 3901/3902 Assemblies/Subassemblies 7 - 2

 7.2.1 3901/3902 Composite Assembly 7 - 2

 7.2.2 3901/3902 Chassis Assy 7 - 3

 7.2.3 Front Panel Assy (3901/3902) 7 - 4

 7.2.4 Rear Panel Assy 7 - 4

 7.2.5 CPU Adapter Battery 7 - 4

7.3 . . . 3920/3920B Assemblies/Subassemblies 7 - 5

 7.3.1 3920 Composite Assembly 7 - 5

 7.3.2 3920B Composite Assembly 7 - 6

 7.3.3 3920/3920B Chassis Assy 7 - 7

 7.3.4 Front Panel Assy (3920/3920B) 7 - 8

 7.3.5 Rear Panel Assy 7 - 8

 7.3.6 CPU Adapter Battery 7 - 8

 7.3.7 DMM Fuse 7 - 8

7.4 . . . Replacement Parts Pictures 7 - 9

 7.4.1 Composite Assembly Replacement Parts 7 - 9

 7.4.2 Chassis Assembly Replacement Parts 7 - 10

 7.4.3 Front Panel Replacement Parts 7 - 13

 7.4.4 Miscellaneous Parts 7 - 14

7.5 . . . Accessories 7 - 15

 7.5.1 Standard Accessories 7 - 15

 7.5.2 Optional Accessories 7 - 16

I/O Connectors and Pin-Out Tables A - 1

A.1 . . . Connector Functions A - 1

A.2 . . . MIC/ACC Connector Pin-Out Table A - 2

A.3 . . . GPIB Connector Pin-Out Table A - 3

A.4 . . . Serial Connector Pin-Out Table A - 4

A.5 . . . Parallel Connector Pin-Out Table A - 5

A.6 . . . VGA Monitor Output Connector Pin-Out Table A - 5

A.7 . . . Ethernet and USB Connectors Pin-Out Table A - 6

A.8 . . . PS/2 Interface Connectors Pin-Out Table A - 7

A.9 . . . Test Connector Pin-Out Table A - 7

3900 Platform SpecificationsB - 1

B.1 . . . RF Signal Generator B - 1

 B.1.1 . . . Frequency B - 1

 B.1.2 . . . Output Level B - 1

 B.1.3 . . . Spectral Purity B - 2

 B.1.4 . . . Modulation B - 3

B.2 . . . RF Receiver B - 6

 B.2.1 . . . Demodulation Selections B - 6

 B.2.2 . . . Frequency Range (Usable from 100 kHz) B - 6

 B.2.3 . . . Sensitivity B - 6

 B.2.4 . . . Selectivity B - 6

 B.2.5 . . . Demod Output Level B - 6

B.3 . . . RF Receive Measurements B - 7

 B.3.1 . . . AM Meter B - 7

 B.3.2 . . . FM Deviation Meter B - 8

 B.3.3 . . . RF Counter B - 8

 B.3.4 . . . RF Error Meter B - 9

 B.3.5 . . . Demodulation B - 9

 B.3.6 . . . RF Power Meter (Broad band) B - 10

 B.3.7 . . . RF Power Meter (In Band) B - 10

B.4 . . . Audio Function Generator(s) B - 11

 B.4.1 . . . Waveshape B - 11

 B.4.2 . . . Frequency B - 11

 B.4.3 . . . Level (Sine) B - 11

 B.4.4 . . . Impedance B - 11

 B.4.5 . . . Spectral Purity B - 11

B.5 . . . Audio & Modulation Measurements B - 12

 B.5.1 . . . AF Counter B - 12

 B.5.2 . . . AF Level Meter B - 13

 B.5.3 . . . SINAD Meter B - 14

 B.5.4 . . . Distortion Meter B - 15

 B.5.5 . . . Hum and Noise B - 16

 B.5.6 . . . Signal to Noise Ratio B - 17

 B.5.7 . . . Audio Filters (Characteristic Response) B - 18

B.6 . . . Channel Analyzer B - 19

 B.6.1 . . . Frequency B - 19

 B.6.2 . . . Span B - 19

 B.6.3 . . . Level B - 19

 B.6.4 . . . Resolution Bandwidth B - 19

 B.6.5 . . . Sweep B - 19

3900 Platform Specifications (cont)

B.7 . . . RF Spectrum Analyzer	B - 20
B.7.1 Frequency	B - 20
B.7.2 Span	B - 20
B.7.3 Display Accuracy	B - 20
B.7.4 Markers	B - 20
B.7.5 Level	B - 21
B.7.6 Resolution Bandwidth	B - 22
B.7.7 Video Bandwidth	B - 22
B.7.8 Sweep	B - 22
B.7.9 Function/Feature	B - 23
B.8 . . . Tracking Generator (Option)	B - 23
B.8.1 Tracking Generator Output	B - 23
B.8.2 Span and Sweep Time	B - 23
B.8.3 Tracking Generator Controls	B - 23
B.9 . . . Oscilloscope	B - 24
B.9.1 Display	B - 24
B.9.2 Vertical	B - 24
B.9.3 Horizontal	B - 25
B.9.4 Trigger	B - 25
B.10 . . Frequency Standard I/O	B - 26
B.10.1 . . . Internal Frequency Standard Output (OCXO)	B - 26
B.10.2 . . . External Frequency Input	B - 26
B.11 . . Audio Spectrum Analyzer (Option)	B - 27
B.11.1 . . . Frequency Range	B - 27
B.11.2 . . . Resolution	B - 27
B.11.3 . . . Accuracy	B - 27
B.11.4 . . . Span	B - 27
B.11.5 . . . Level	B - 27
B.11.6 . . . Markers	B - 27
B.12 . . Digital Multimeter (3920 Only)	B - 28
B.12.1 . . . AC/DC Voltmeter	B - 28
B.12.2 . . . AC/DC AM Meter	B - 28
B.12.3 . . . Ohm Meter	B - 28
B.12.4 . . . External Shunt (Optional Accessory)	B - 29

3900 Platform Specifications (cont)

B.13 . . . Input/Output Connectors	B - 30
B.13.1 . . . ANT (RF Input)	B - 30
B.13.2 . . . T/R (RF Input/Output)	B - 30
B.13.3 . . . GEN (RF Output)	B - 31
B.13.4 . . . GPIB	B - 31
B.13.5 . . . Ethernet	B - 31
B.13.6 . . . RS-232	B - 31
B.13.7 . . . Video	B - 32
B.13.8 . . . IF Output	B - 32
B.13.9 . . . MIC/Accessory	B - 32
B.13.10 . . . Parallel Port	B - 32
B.13.11 . . . USB	B - 32
B.13.12 . . . PS/2 Interfaces (3901/3902 only)	B - 33
B.13.13 . . . Test Port	B - 33
B.13.14 . . . Auxiliary IF Input	B - 33
B.14 . . . Environmental	B - 34
B.14.1 . . . Operating Temperature	B - 34
B.14.2 . . . Warm-up Time	B - 34
B.14.3 . . . Storage Temperature	B - 34
B.14.4 . . . Relative Humidity	B - 34
B.14.5 . . . Altitude	B - 34
B.14.6 . . . Shock and Vibrations	B - 34
B.14.7 . . . Use	B - 34
B.14.8 . . . EMC	B - 34
B.14.9 . . . Reliability	B - 34
B.15 . . . Safety Standards	B - 34
B.16 . . . Dimensions and Weight	B - 34
B.17 . . . AC Power Requirements	B - 35
B.17.1 . . . Voltage	B - 35
B.17.2 . . . Power Consumption	B - 35
B.17.3 . . . Mains Supply Voltage Fluctuations	B - 35
B.17.4 . . . Fuse Requirements	B - 35
B.18 . . . General Features	B - 35
B.18.1 . . . LCD Display	B - 35
B.18.2 . . . Disk Storage (3901/3902 only)	B - 35

Controls and ConnectorsC - 1

C.1 . . . Front Panel Controls and Connectors C - 1

 C.1.1 . . . Soft Keys (1) C - 1

 C.1.2 . . . HELP Key (2) C - 1

 C.1.3 . . . RETURN Key (3) C - 2

 C.1.4 . . . TEST (4) C - 2

 C.1.5 . . . CONFIG (5) C - 2

 C.1.6 . . . UTILS (6) C - 2

 C.1.7 . . . TAB Key (7) C - 2

 C.1.8 . . . SELECT Key (8) C - 2

 C.1.9 . . . CANCEL Key (9) C - 2

 C.1.10 . . . Cursor Keys (10) C - 2

 C.1.11 . . . ENTER Key (11) C - 2

 C.1.12 . . . Data Input and Entry Keys (12) C - 2

 C.1.13 . . . Backspace Key (13) C - 2

 C.1.14 . . . Rotary Control Knob (14) C - 2

 C.1.15 . . . ASSIGN Key (15) C - 2

 C.1.16 . . . Display HOLD Key (16) C - 2

 C.1.17 . . . Power Supply On/Standby Key (17) C - 3

 C.1.18 . . . 3.5 inch Floppy Disk Drive (18) (3901/3902) C - 3

 C.1.19 . . . Digital Multimeter (DMM) (18) (3920) C - 3

 C.1.20 . . . RF Input and Output Connectors C - 3

C.2 . . . Rear Panel Controls and Connectors C - 5

 C.2.1 . . . AC Power Connector (30) C - 5

 C.2.2 . . . AC Power Fuse (31) C - 5

 C.2.3 . . . AC Power Switch (32) C - 5

 C.2.4 . . . Rear Cooling Outlets (33) C - 5

 C.2.5 . . . IF Output Signal Connector (34) C - 5

 C.2.6 . . . Ext Ref I/O External Interface (35) C - 5

 C.2.7 . . . Audio Input Connector (36) C - 5

 C.2.8 . . . External Trigger Signal Input Connector (37) C - 6

 C.2.9 . . . Audio Output Connector (38) C - 6

 C.2.10 . . . Synchronization Signal Input/Output Connector (39) C - 6

 C.2.11 . . . Auxiliary IF Input Connector (LVDS) (40) C - 6

 C.2.12 . . . GPIB/IEEE-488 Interface Connection (41) C - 6

 C.2.13 . . . Standard USB Client Connector (42) C - 6

 C.2.14 . . . PS/2 Mouse Interface Connector (43) C - 6

 C.2.15 . . . Keyboard Interface Connector (44) C - 6

 C.2.16 . . . USB X2 Connector (45) C - 6

 C.2.17 . . . Ethernet Connector (46) C - 6

 C.2.18 . . . VGA Monitor Output Connector (47) C - 6

 C.2.19 . . . RS-232 Serial Connector (48) C - 6

 C.2.20 . . . Parallel Printer Output Connector (49) C - 6

Shipping Test SetD - 1

 D.1 . . . Repacking for Shipping D - 1

 D.1.1 . . . Return Authorization D - 1

 D.2 . . . Tagging Test Sets D - 1

 D.3 . . . Shipping Containers D - 1

 D.4 . . . Freight Costs D - 1

 D.5 . . . Repacking Procedure D - 2

Calibration/Verification EquipmentE - 1

 E.1 . . . Calibration Equipment E - 1

 E.2 . . . Verification Equipment E - 1

Ethernet Crossover CableF - 1

Fuse Replacement Instructions G - 1

AbbreviationsH - 1

List of Figures

FIGURE	PAGE
Fig. 2-1	3901/3902 System Interconnect Diagram 2-5
Fig. 2-2	3920 System Interconnect Diagram 2-12
Fig. 2-3	3920B System Interconnect Diagram 2-19
Fig. 2-4	Backplane PCB Assembly Interconnect Diagram 2-26
Fig. 2-5	Backplane PCB Assembly Connector Locations 2-27
Fig. 2-6	Power Supply Assembly Interface Diagram 2-31
Fig. 2-7	Disk I/O PCB Assembly Interconnect Diagram 2-33
Fig. 2-8	DAM Carrier Red LED Status Indicator 2-38
Fig. 2-9	Carrier - Vocoder Tabs 2-39
Fig. 2-10	Carrier Green LED Status Indicators 2-39
Fig. 2-11	Gaussian Filter Selected 2-40
Fig. 2-12	Gaussian plus 200 kHz Ceramic Filters Selected 2-40
Fig. 2-13	Dithering LED Status Indicator 2-40
Fig. 2-14	Power Termination Assembly Interconnect Diagram 2-42
Fig. 2-15	Digital Multimeter Block Diagram 2-44
Fig. 2-16	CAI PCB Assembly Block Diagram 2-45
Fig. 2-17	DAM Carrier PCB Assembly Interconnect Diagram 2-50
Fig. 3-1	3900 Assembly Connections 3-5
Fig. 3-2	3900 Assembly Cables 3-5
Fig. 3-3	3920B Assembly Connections 3-6
Fig. 3-4	3920B Assembly Cables 3-6
Fig. 3-5	3900 Mouse and Keyboard Connectors 3-17
Fig. 4-1	System Error - No USB Device Connected 4-3
Fig. 4-2	Select Frequency Reference Tile 4-5
Fig. 4-3	Calibration Menu Layout 4-48
Fig. 4-4	Zero/Calibrate Status Message 4-50
Fig. 4-5	PA Detector Calibration Setup 4-52
Fig. 4-6	PA Detector Signal Trace 4-52
Fig. 4-7	Attenuator Response Calibration Setup 4-53
Fig. 4-8	Attenuator Response Signal Trace 4-53
Fig. 4-9	GEN Port Calibration Setup 4-54
Fig. 4-10	GEN Port Signal Trace 4-54
Fig. 4-11	T/R Port Calibration Setup 4-55
Fig. 4-12	T/R Port Signal Trace 4-55
Fig. 4-13	Splitter Calibration Setup (ANT Port) 4-56
Fig. 4-14	Splitter Calibration Setup (REF Port) 4-56
Fig. 4-15	Splitter Calibration Complete 4-57

List of Figures

FIGURE	PAGE
Fig. 4-16 IF Gain Calibration Setup	4-58
Fig. 4-17 IF Gain Channel Cal Signal Trace	4-58
Fig. 4-18 IF Gain Main Cal Signal Trace	4-59
Fig. 4-19 IF AMP Calibration Setup	4-60
Fig. 4-20 IF AMP Channel Cal Signal Trace	4-60
Fig. 4-21 IF AMP Main Cal Signal Trace	4-61
Fig. 4-22 ANT Port Amp Gain Calibration Setup	4-62
Fig. 4-23 ANT Port Amp Gain Signal Trace	4-62
Fig. 4-24 ANT Port 0-30 dB Calibration Setup	4-63
Fig. 4-25 ANT Port 0-30 dB Signal Traces	4-63
Fig. 4-26 ANT Port Linearity Calibration Setup	4-64
Fig. 4-27 ANT Port Linearity Signal Trace	4-64
Fig. 4-28 Port Delta Calibration Setup	4-65
Fig. 4-29 Port Delta Calibration Complete	4-65
Fig. 4-30 T/R Port 0-40 dB Calibration Setup	4-66
Fig. 4-31 T/R Port 0-40 dB Signal Trace	4-66
Fig. 4-32 T/R Port Linearity Calibration Setup	4-67
Fig. 4-33 T/R Port Linearity Signal Trace	4-67
Fig. 4-34 YIG Sweep Calibration Complete	4-68
Fig. 4-35 Function Generator Calibration Setup	4-69
Fig. 4-36 Function Generator Calibration Complete	4-69
Fig. 4-37 Scope DC Calibration Complete	4-70
Fig. 4-38 Scope AC Calibration Setup	4-71
Fig. 4-39 Scope AC Calibration Complete	4-72
Fig. 4-40 TCXO Adjust Calibration Setup	4-73
Fig. 4-41 TCXO Adjust Calibration Complete	4-73
Fig. 6-1 3901 (24711) and 3902 (24710) Composite Assembly	6-3
Fig. 6-2 3901/3902 Composite Assy Interconnect Diagram	6-4
Fig. 6-3 3901/3902 (64400) Chassis Assy	6-5
Fig. 6-4 3920 (72412) / 3920B (91164) Composite Assembly	6-6
Fig. 6-5 3920 Composite Assy Interconnect Diagram	6-7
Fig. 6-6 3920B Composite Assy Interconnect Diagram	6-8
Fig. 6-7 3920/3920B (64417) Chassis Assy	6-9
Fig. 6-8 3901/3902 Front Panel Cables	6-10
Fig. 6-9 3920/3920B Front Panel Cables	6-10
Fig. 6-10 3901/3902/3920 Assembly Locations	6-11
Fig. 6-11 3920B Assembly Locations	6-11
Fig. 6-12 3901/3902/3920 Cable Locations	6-11
Fig. 6-13 3920B Cable Locations	6-11

List of Figures

FIGURE	PAGE
Fig. 6-14 Rear Panel Cables	6-12
Fig. 6-15 Power Term Cables	6-12
Fig. 6-16 Front Panel Assembly	6-13
Fig. 6-17 Front Panel Assembly (64418-C0/D0)	6-13
Fig. 6-18 Backplane PCB Assy Connectors (65654)	6-14
Fig. A-1 Microphone and Accessory Connector	A-2
Fig. A-2 GPIB Connector Pin Locations	A-3
Fig. A-3 Serial Connector Pin Locations	A-4
Fig. A-4 Null Modem Connections	A-4
Fig. A-5 Parallel Connector Pin Locations	A-5
Fig. A-6 Ethernet and USB Connectors	A-6
Fig. A-7 PS/2 Interfaces	A-7
Fig. A-8 Test Connector	A-7
Fig. C-1 3901/3902 Front Panel Controls and Connectors	C-1
Fig. C-2 3920/3920B Front Panel Controls and Connectors	C-1
Fig. C-3 Rear Panel Controls and Connectors	C-5

List of Figures

FIGURE

PAGE

THIS PAGE INTENTIONALLY LEFT BLANK.

List of Tables

Power Meter Level Settings - Generator Output Power	4-7
Test Set Generator Frequencies - Generator Level Flatness	4-8
Power Meter Settings - Generator T/R Power Level Accuracy	4-9
Test Set Generator Frequencies - Generator T/R Power Level Flatness	4-10
RF Generator Settings - Inband Power Meter Accuracy	4-12
RF Generator Frequencies - Analyzer Level Accuracy	4-13
FM Modulation Rates - Generator FM Modulation Rate	4-18
Test Set Audio Function Generator Settings - Scope Amplitude Accuracy	4-28
IEEE 488.2 Addresses	4-48
Calibration Time Chart	4-51
MIC/ACC Connector Pin-Out Table	A-2
GPIB Connector Pin-Out Table	A-3
Serial Connector Pin-Out Table	A-4
VGA Monitor Output Connector Pin-Out Table	A-5
Ethernet Connector Pin-Out Table	A-6
USB Connector Pin-Out Table	A-6
PS/2 Interface Connector Pin-Out Table	A-7
Test Connector Pin-Out Table	A-7

THIS PAGE INTENTIONALLY LEFT BLANK.

Chapter 1 - General Information

1.1 GENERAL INFORMATION

The 3900 Digital Radio Test Set platform integrates several test instruments into a single user-friendly instrument that offers the interconnectivity normally expected from a personal computer.

The digital test platform, created with modular design, is simple to support and upgrade. The 3900 provides comprehensive transmitter and receiver testing, while the full-range spectrum analyzer and measurement Meters Tiles allow base site component testing to be performed. The dual channel oscilloscope and internal DEMOD scope provide comprehensive viewing of signals.

The 3920 has been designed to allow for an optional factory upgrade that extends the unit's frequency range value from 1.05 GHz to 2.71 GHz. The 3901 does not have this design capability.

1.1.1 Scope

Type of Manual	Maintenance Manual
Equipment Name and Model Number	3901, 3902, 3920 or 3920B Digital Radio Test Set
Equipment Use	General purpose Communications Service Monitor for testing radios and related equipment.

1.1.2 Nomenclature Cross Reference List

Common Name	3900, Test Set or Unit
Official Nomenclature	3901, 3902, 3920 or 3920B Digital Radio Test Set

1.2 EQUIPMENT DESCRIPTION AND DATA



1.2.1 Equipment Characteristics, Capabilities and Features

Refer to 3900 Series Operation Manual for this information.

1.2.2 Equipment Data

Refer to 3900 Series Operation Manual for this information.

1.2.3 Safety, Care and Handling

Observe all WARNINGS, CAUTIONS and NOTES in this manual. This equipment can be extremely dangerous if these instructions are not followed.

1.3 SERVICE UPON RECEIPT OF MATERIAL

1.3.1 Unpacking

Special design packing material inside this shipping container provides maximum protection for the 3900 Radio Test Set. Avoid damaging the shipping container and packaging material when unpacking equipment; if necessary the shipping container and packaging material can be reused to ship the Test Set.

CAUTION

To prevent personal injury or damage to Test Set, Aeroflex recommends two people unpack the Test Set.


Use the following steps to unpack the 3900:

STEP	PROCEDURE	STEP	PROCEDURE
------	-----------	------	-----------

1. Cut and remove sealing tape on top of the shipping container. Open shipping container.



2. Grasp the 3900 firmly while restraining the shipping container. Lift the equipment and packing material vertically out of the shipping container.
3. Place Test Set and packing material on a flat, clean and dry surface.
4. Remove Accessory Box from foam inserts.



5. Remove foam inserts from the Test Set.
6. Store packing materials (foam inserts and cardboard insert) inside shipping container. Store shipping container and materials for possible future use.

1.3.2 Checking Unpacked Equipment

Inspect equipment for possible damage incurred during shipment. If Test Set has been damaged, report the damage to Aeroflex Customer Service.

Review packing slip to verify shipment is complete. Packing slip identifies the standard items as well as purchased options. Report all discrepancies to Aeroflex.

Contact:

Aeroflex

Customer Service Dept.
10200 West York Street
Wichita, Kansas 67215

Telephone: 800-835-2350

FAX: 316-524-2623

email: americas.service@aeroflex.com



1.3.2.A Standard Items

Description	Part Number	QTY
Ship Unit	Refer to Packing List	1
3900 Series Operation Manual (CD-ROM)	6047	1
3900 Series Getting Started Manual	6050	1
Kit, STD Cords/Accessory	63938	1

1.4 GENERAL CONDITIONS OF USE

This product is designed and tested to comply with the requirements of IEC/EN61010-1 'Safety requirements for electrical equipment for measurement, control and laboratory use' for Class I portable equipment and is for use in a pollution degree 2 environment. The equipment is designed to operate from installation supply Category II.

Equipment should be protected from liquids such as spills, leaks, etc. and precipitation such as rain, snow, etc. When moving the equipment from a cold to hot environment, allow the temperature of the equipment to stabilize before it is connected to the supply to avoid condensation forming. Only operate Test Set within specified environmental conditions (refer to Appendix B, Platform Specifications).

This product is not approved for use in hazardous atmospheres or medical applications. If the equipment is to be used in a safety-related application, such as avionics or military applications, the suitability of the product must be assessed and approved for use by a competent person.

Refer all servicing of unit to Qualified Technical Personnel. This unit contains no operator serviceable parts.

1.4.1 Case, Cover or Panel Removal

Opening the Case Assembly exposes the operator to electrical hazards that may result in electrical shock or equipment damage. Do not operate this Test Set with the Case Assembly open.

1.4.2 Precautions

1.4.2.A Safety

This manual uses the following terms to draw attention to possible safety hazards that may exist when operating or servicing this equipment.

CAUTION IDENTIFIES CONDITIONS OR ACTIVITIES THAT, IF IGNORED, CAN RESULT IN EQUIPMENT OR PROPERTY DAMAGE, E.G., FIRE.

WARNING IDENTIFIES CONDITIONS OR ACTIVITIES THAT, IF IGNORED, CAN RESULT IN PERSONAL INJURY OR DEATH.



Static Sensitive Components



CAUTION THIS EQUIPMENT CONTAINS COMPONENTS SENSITIVE TO DAMAGE BY ELECTROSTATIC DISCHARGE (ESD). ALL PERSONNEL PERFORMING MAINTENANCE OR CALIBRATION PROCEDURES SHOULD HAVE KNOWLEDGE OF ACCEPTED ESD PRACTICES AND/OR BE ESD CERTIFIED.

NOTE To comply with EMC requirements, double shielded cables should be used for making connections to all input and output connectors.

Chapter 2 - Theory of Operation

2.1 GENERAL INFORMATION

The 3900 Series Digital Radio Test platform integrates several radio-testing instruments into a single instrument that offers the inter connectivity normally expected from a personal computer. The 3900 test platform is a modular design that is simple to support and upgrade. The System Overview and Module Overview sections describe how the Test Set operates.

2.2 PRINCIPLES OF OPERATION

2.2.1 General Operational Description

Refer to the 3900 Series Operation Manual for general Test Set information.

2.2.2 General Functional Description

Refer to Test Set System Interconnect Diagrams ([Fig. 2-1](#), [Fig. 2-2](#) and [Fig. 2-3](#)) for the relationship of all 3900 assemblies. Table below lists assemblies alphabetically.

Description	Reference Designator	Page
Attenuator Assembly	44A1A3	2 - 34
Backplane PCB Assembly	44A1A1A1	2 - 29
CAI PCB Assembly	44A1A8	2 - 38
CPU Adapter PCB Assembly	44A1A1A5	2 - 30
DAM Carrier PCB Assembly	44A1A10	2 - 38
Digital Multimeter (DMM) Assembly	--	2 - 32
Disk I/O PCB Assembly	44A1A1A9	2 - 33
Front Panel Analog PCB Assembly	44A1A1A4A5	2 - 30
Front Panel Digital PCB Assembly	44A1A1A2	2 - 30
Generator Assembly	44A1A4	2 - 34
IF/Video PCB Assembly	44A1A5	2 - 37
Power Supply Assembly	44A1A1A6	2 - 31
Power Term(ination) Assembly	44A1A1A7	2 - 31
Rear Panel Audio I/O PCB Assembly	44A1A1A10	2 - 30
Rear Panel PCB Assembly	44A1A1A3	2 - 30
Receiver Assembly	44A1A7	2 - 37

2.3 RECEIVE SYSTEM OVERVIEW

The Test Sets in the 3900 Series are capable of receiving modulated or un-modulated signals over a range of 1 MHz to 2.7 GHz depending on the model and options installed in the unit. Low power signals (<-10 dBm) are received through the Power Term Assembly at the ANT Connector. High power signals (>-10 to +50 dBm) are received through the Power Term Assembly at the T/R Connector. A diode detector serves to measure RF power applied to the T/R Connector. The ANT Connector and GEN Connector are protected from high power levels by a limiter circuit. Refer to section 2.4, [Generate System Overview](#), for more details on the GEN Connector. The RF signal is routed to the Receiver Assembly.

The Receiver Assembly has selectable attenuators and provides the system with reference signals of 10, 40, 80 and 400 MHz. An External 10 MHz reference I/O is routed from the Receiver Assembly to the Rear Panel Assembly. The Receiver Assembly converts the incoming signal to a 210.7 MHz IF (intermediate frequency) and starts signal conditioning. The 210.7 MHz IF signal is then passed to the IF/Video PCB Assembly.

The IF/Video PCB Assembly has selectable 10.7 MHz IF filtering of 30 kHz, 300 kHz and 6 MHz. The CAI (Common Air Interface) PCB Assembly and IF/Video PCB Assembly work together to provide the AGC (Automatic Gain Control) for the Receiver Assembly. The CAI PCB Assembly sends data to the IF/Video PCB Assembly to increase or decrease the gain automatically, providing the correct level to the CAI PCB Assembly. The IF/Video PCB Assembly also selects and controls the Analyzer resolution bandwidth filters. When the Spectrum Analyzer is selected, all combinations of IF filtering are used to provide a fully functional Spectrum Analyzer. Other functions of the IF/Video PCB Assembly are to provide the following:

- 10.7 MHz IF output to the Rear Panel Assembly;
- Video output to the Rear Panel Assembly;
- IF Count to the DAM Carrier PCB Assembly.

The DAM Carrier PCB Assembly converts the 10.7 MHz IF signal to a digital signal, which is then sent to the CAI PCB Assembly.

The CAI PCB Assembly receives the 10.7 MHz digital signal and digitally performs the demodulation process. During the demodulation process, the signal is measured for correct power strength. If the incoming power is incorrect, data is provided back to the IF/Video PCB Assembly for AGC control as described in the section above regarding the IF/Video PCB Assembly. The CAI PCB Assembly provides digitally demodulated signals to the system for meter functions such as: Receiver Level Meter, Deviation Meter Demod Output, Internal Demod Scope, Speaker, etc. Other CAI PCB Assembly functions are discussed in the Generate System Overview.

2.4 GENERATE SYSTEM OVERVIEW

The Generate System path begins in the CAI PCB Assembly. The CAI PCB Assembly generates a digitally modulated 11.4 MHz IF signal and passes the modulated signal to the DAM Carrier PCB Assembly. The DAM Carrier PCB Assembly converts the 11.4 MHz IF Signal from a digital signal to an analog signal. The 11.4 MHz Analog signal is then routed to the Generator Assembly. The Modulation sources are the MIC and Audio connectors.

The Generator Assembly is designed to convert the 11.4 MHz IF analog signal to the desired output frequency between the 1 MHz to 2.7 GHz range, based on the unit's frequency range. The variable attenuator in the Generator Assembly provides 9.9 dB attenuation in 0.1 dB steps between the 10 dB steps of the Attenuator Assembly. The signal is amplified to a level high enough to overcome the losses of the Attenuator Assembly and Power Term Assembly and to meet the specified maximum output power level. The desired RF signal is then routed from the Generator Assembly to the Attenuator Assembly.

The Attenuator Assembly consists of six relay-attenuator sections and a driver board. The relay-attenuator section consists of one 10 dB relay-attenuator, one 5 dB relay-attenuator and four 20 dB relay-attenuators, for a total attenuation of 95 dB. From the Attenuator Assembly the RF signal is routed to the Power Term Assembly.

The Power Term Assembly routes the RF signal out the GEN Connector or the T/R Connector. The GEN Connector provides a maximum output signal of +10 dBm. The T/R Connector provides a maximum output signal of -30 dBm over the 1 MHz to 2.7 GHz range.

NOTE	The 3901 and 3920 frequency range is 1 MHz to 1.05 GHz. The 3902 and 3920 with frequency extension option has a frequency range of 1 MHz to 2.7 GHz. Refer to Appendix B, Platform Specifications for complete product specifications.
-------------	--

THIS PAGE INTENTIONALLY LEFT BLANK.




Fig. 2-1 3901/3902 System Interconnect Diagram
0000-4440-100-E (Sheet 1 of 7)




Fig. 2-1 3901/3902 System Interconnect Diagram
0000-4440-100-E (Sheet 2 of 7)




Fig. 2-1 3901/3902 System Interconnect Diagram
 0000-4440-100-E (Sheet 3 of 7)




Fig. 2-1 3901/3902 System Interconnect Diagram
 0000-4440-100-E (Sheet 4 of 7)




Fig. 2-1 3901/3902 System Interconnect Diagram
 0000-4440-100-E (Sheet 5 of 7)




Fig. 2-1 3901/3902 System Interconnect Diagram
0000-4440-100-E (Sheet 6 of 7)

Theory of Operation




Fig. 2-1 3901/3902 System Interconnect Diagram
0000-4440-100-E (Sheet 7 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 1 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 2 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 3 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 4 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 5 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 6 of 7)




Fig. 2-2 3920 System Interconnect Diagram
10000012508 (Sheet 7 of 7)




Fig. 2-3 3920B System Interconnect Diagram
1000026951 (Sheet 1 of 7)




Fig. 2-3 3920B System Interconnect Diagram
10000026951 (Sheet 2 of 7)




Fig. 2-3 3920B System Interconnect Diagram
10000026951 (Sheet 3 of 7)




Fig. 2-3 3920B System Interconnect Diagram
10000026951 (Sheet 4 of 7)

Data Acquisition Module





Fig. 2-3 3920B System Interconnect Diagram
1000026951 (Sheet 5 of 7)



CPU Adpater Board

Fig. 2-3 3920B System Interconnect Diagram
10000026951 (Sheet 6 of 7)




Fig. 2-3 3920B System Interconnect Diagram
10000026951 (Sheet 7 of 7)





Fig. 2-4 Backplane PCB Assembly Interconnect Diagram
0000-4430-600-D



*J18 Applies to 3920 only and is a USB connection.

*J15 Applies to 3901/3902 only.

Fig. 2-5 Backplane PCB Assembly Connector Locations

THIS PAGE INTENTIONALLY LEFT BLANK.

2.5 MODULE OVERVIEW

This section describes the various assemblies and connectors utilized in the 3900.

2.5.1 Backplane PCB Assembly (44A1A1A1)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#) and [Fig. 2-3](#).

The Backplane PCB Assembly routes electrical signals between the various system assemblies. The Backplane PCB Assembly utilizes the following connectors for routing signals:

- 32-Pin Connector provides connection to Power Term Assembly (J4).
- 10 Pin Header provides ribbon cable connection to Front Panel Keypad Assembly (J16).
- 10 Pin Header provides ribbon cable connection to Attenuator Assembly (J5).
- 24 Pin Header provides ribbon cable connection to GPIB Connector (J9).
- 44 Pin Header (J8) and 34 Pin Header (J13) provide connections to Front Panel Digital Interface PCB Assembly.
- 20 Pin DIN Connector for Rear Panel PCB Assembly (J6).
- 24 Pin DIN Connector for Power Supply Assembly (J12).
- 48 Pin DIN Connectors for:
 - Disk I/O PCB Assembly (J7).
 - IF/Video PCB Assembly (J1) (Slot 3).
 - Generator Assembly (J3) (Slot 5).
 - Receiver Assembly (J2) (Slot 4).
 - Five 154 Pin DIN Connectors (J22, J23, J24, J25 and J26) for CPU Adapter Assembly (Slot 0).
 - One 175 Pin PCI Connector (J28) and four 154 Pin Keyed Connectors (J29, J30, J31 and J32) for the CAI PCB Assembly (Slot 1).
 - One 175 Pin PCI Connector (J33) and four 154 Pin Keyed Connectors (J27, J34, J35 and J36) for the Data Acquisition Module (DAM) (Slot 2).
 - 68 PIN Auxiliary IF Input (J10).
 - 25F/9M/15 HDF DSUB Connector for Video, Printer and RS-232 connections (J14).
 - 6 PIN Dual PS/2 Connector for Keyboard (J15).
 - 4 PIN USB Connector for USB connection (J20).
 - 18 PIN 2XUSB Connector for Ethernet and USB device connections (J19).
 - 4 PIN USB Connector for Front Panel USB connection (J18).

The Backplane PCB Assembly layout utilizes RF techniques on all signals >33 MHz and on all low level signals.

2.5.1.A Front Panel Analog PCB Assembly (44A1A1A4A5)

2.5.1.B Front Panel Digital Interface PCB Assembly (44A1A1A2)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The Front Panel Audio Assembly consists of the Front Panel Digital Interface PCB Assembly and the Front Panel Analog PCB Assembly. The Front Panel Audio Assembly includes standard audio Input/Output connectors and controls, as well as a 6-channel audio function generator and a dual-channel 40 msp digital Oscilloscope.

The Front Panel Analog PCB Assembly converts analog audio signals received from the Audio Input Connector to digital signals. The Front Panel Digital Interface PCB Assembly contains a Digital to Analog Converter (DAC) which converts the system's digital signals to analog audio signals which are then sent to the Front Panel Audio Output Connector.

Signal Tone filtering, in addition to the balanced or unbalanced switching, are also performed by the Front Panel Audio PCB Assembly. The Front Panel Audio PCB Assembly output signals are the audio function generator signals and the demodulated audio signal (Demod). Audio Input signals to the Front Panel Audio PCB Assembly are the Microphone, Channel 1 and 2 Scope inputs and Audio 1 and 2 connectors.

The Front Panel Audio PCB Assembly generates a digitally controlled output voltage for the Test Connector and routes input/output signals to/from the Test Connector.

2.5.2 Rear Panel Audio Assembly

2.5.2.A Rear Panel PCB Assembly (44A1A1A3)

2.5.2.B Rear Panel Audio I/O PCB Assembly (44A1A1A10)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The Rear Panel Audio Assembly consists of the Rear Panel PCB Assembly and the Rear Panel Audio I/O PCB Assembly. The Rear Panel PCB Assembly includes standard Input/Output connectors as well as Ethernet, Video, Printer, RS-232, keyboard, and USB Mouse connectors. The Rear Panel Audio I/O PCB Assembly includes standard audio Input/Output connectors.

2.5.3 CPU Adapter PCB Assembly (44A1A1A5)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The CPU Adapter Assembly provides a mechanism by which all CPU generated signals are distributed through the Backplane PCB Assembly to other system assemblies. The CPU Adapter Assembly is comprised of five Compact PCI connectors placed end-to-end along the CPU Adapter PCB Assembly. The CPU Adapter Assembly contains a 32 bit PCI bus which operates at 33 MHz, running a Pentium ETX form factor which offers internal RAM. The single board computer is mounted to the CPU Adapter PCB Assembly, which interfaces with other PCB Assemblies via the Backplane PCB Assembly.

NOTE	3901's with SN 298001115 and lower and 3902's with SN 297001117 and lower contain a CPU Adapter PCB Assembly that contains a 266 MHz processor. Units containing a 266 MHz processor can be returned to the factory for an optional hardware upgrade to the 733 MHz processor. Check the UTILS, Operational Status Tile for unit processor speed.
-------------	---

2.5.4 Power Supply Assembly (44A1A1A6)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#) and [Fig. 2-6](#).

AC power for the Power Supply Assembly is provided by an IEC universal 3-prong power entry module with an integrated power switch, fuses and EMI filter.

The Power Supply Assembly is responsible for generating all internal voltages required to operate the 3900. The voltages generated by the Power Supply Assembly and distributed through the Backplane PCB Assembly are:

- Filtered +5 V Digital and Analog
- Filtered +15 V
- Filtered -15 V
- +5.1 V Auxiliary
- +3.3 V Enable
- OS Active (Override from main CPU)




Fig. 2-6 Power Supply Assembly Interface Diagram

2.5.5 Power Term(ination) Assembly (44A1A1A7)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#) and [Fig. 2-14](#).

The Power Term Assembly provides the focal point through which RF signals pass between the UUT and the Test Set. There are three RF user interface connectors (on the front of the unit) (ANT IN, GEN OUT, T/R) and two internal coaxial cable connections (Receiver and Generator Assembly). The Power Term Assembly consists of the following PCB Assemblies: GEN and ANT Connector Power Buffers, RF Power and Controller and Tx/Rx Step Attenuators for input power and generator level control. The assembly housing provides circuit isolation, as well as heat sink cooling for the high power RF input. The cooling fan is turned on and off by the processor control based on the temperature of the Power Term Assembly.

2.5.6 Digital Multimeter (DMM) Assembly (44A1A1A9 3920 only)

Refer to Fig. 2-1 or Fig. 2-2 and Fig. 2-15.

The Digital Multimeter is hardware/software feature that is available on the 3920.

The Digital Multimeter is a self contained, electrically isolated, digital module capable of operating at temperatures of -20C to +70C. The Digital Multimeter measures AC and DC voltage, current and resistance within $\pm 5\%$ full scale of the selected range. The Digital Multimeter measures up to 400 Volts AC or DC, 3 Amps of current and 40 M Ω of resistance.

The Digital Multimeter is designed around a self contained, Integrated Circuit (IC) that is controlled by an on-board host microprocessor (uP). The Digital Multimeter's uP is responsible for transferring digitized measurement data from the Digital Multimeter IC to the 3900, for processing all commands sent to the Digital Multimeter module from the 3900 and for retaining calibration values for each function and range on the Digital Multimeter's flash memory.

All AC and DC voltage measurements must be adjusted to avoid damaging the input to the Digital Multimeter IC. The 3900's host processor performs the auto-ranging function using a resistive voltage divider network with various branches that are switched in or out by the Digital Multimeter IC according to the overflow data.

The Digital Multimeter also contains AC compensation capacitors that flatten out the AC voltage response of the meter over the range of 0 to ~ 20 KHz. The precision values of the AC compensation capacitors are critical to the proper operation of the AC voltage function over the entire frequency bandwidth.

The internal voltages for the Digital Multimeter module are received from a +5 V input from the Test Set via an isolated 5 Volt DC to DC converter whose output is also 5 volts DC and post regulated via a linear regulator IC. The output from the DC to DC Converter is split into separate +2.5 and -2.5 Volt supplies for the associated analog circuitry.

The Digital Multimeter +5 V input supply and the 2-wire serial data port circuits that run between the Test Set and Digital Multimeter module are both electrically isolated within the Digital Multimeter module to prevent damage and personal injury which may occur when inappropriately high voltages are applied to the input terminals.

The AC Voltage function of the Digital Multimeter module is a true RMS reading achieved by using an RMS voltage converter IC. When AC Voltage measurements are being performed, the voltage is automatically routed through the RMS converter IC, then back into the Digital Multimeter IC for conversion. Streaming results and measurement data are then passed to the Test Set via the internal uP over a 2-wire serial link.

The AC and DC Current metering capability of the Digital Multimeter module is protected from overload by a fuse located on the front of the module. The fuse is rated at 3 amps maximum for a period of ten seconds. The voltage and resistance input terminals are internally protected from the application of excessive voltages by a gas discharge tube across the inputs.

2.5.7 DISK I/O PCB Assembly (44A1A1A9)

Refer to Fig. 2-1 or Fig. 2-2 and Fig. 2-7.

CPU Input/Output signals are routed to the Disk I/O PCB Assembly plug-in slot through the Backplane PCB Assembly. Signals for the floppy disk drive (3901/3902) are routed directly to a 26-pin flex cable header, providing a connection to a 3.5" half-height floppy disk drive. The 3920 has a serial port for DMM interconnect that is routed from the CPU to the Disk I/O PCB Assembly for DMM operation. The OCXO oscillator is located on the Disk I/O PCB Assembly, providing a stable and accurate 10 MHz reference frequency for the system. The Digital to Analog Converter (DAC) on the Disk I/O PCB Assembly provides voltage tuning for the OCXO. A serial EEPROM stores the factory calibrated tuning voltage for the oscillator. A dual Digital to Analog Converter (DAC) drives the speaker amplifier after it is filtered by a 4.6 kHz filter.




Fig. 2-7 Disk I/O PCB Assembly Interconnect Diagram
0000-4430-200-B1

2.5.8 Attenuator Assembly (44A1A3)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The attenuator consists of six relay-attenuator sections and a driver board. The relay-attenuator section consists of one 10 dB relay-attenuator, one 5 dB relay-attenuator and four 20 dB five relay-attenuators; for a total attenuation of 95 dB. The driver board contains a serial to parallel converter and six transistor driver stages which drive the attenuator relays with the required current. The module uses 5 V for the supply and relay drives.

Each stage is accurate (± 0.5 dB) to its rated value. The attenuator has a frequency response flatness (slope) from 0 to 2.7 GHz of < 3 dB. This slope remains constant (± 0.5 dB) with different stages of attenuation on or off. This error is removed when the 3900 is calibrated.

2.5.9 Generator Assembly (44A1A4)

Section 2.5.9 applies to the 3901, 3902 and 3920 models. Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The CAI PCB Assembly provides 11.4 MHz IF to the Generator Assembly for frequency conversion to the desired output frequency. The Generator Assembly provides 0.1 dB increments between the 10 dB steps of the step attenuator attached to the top of the Generator Assembly. The Generator Assembly consists of the RF/Microwave PCB Assembly and Synthesizer/Control PCB Assembly. The lower frequency functions reside on the Synthesizer/Control PCB Assembly, while the higher frequency functions reside on the RF/Microwave PCB Assembly.

2.5.9.A RF/Microwave PCB Assembly

The RF/Microwave PCB Assembly is designed to convert an 11.4 MHz IF input to any frequency between 1 MHz to 2.7 GHz. The 11.4 MHz IF signal is converted to three increasingly higher IF frequencies: 91.4, 611.4 and 3411.4 MHz respectively. At each IF, a considerable amount of filtering is performed in order to remove the images resulting from the previous up-conversion. Finally, the 3411.4 MHz signal is down-converted to the desired frequency. The signal is then leveled and amplified up to a level high enough to overcome the losses of the step attenuator and Power Term and still meet the specified maximum output power level.

2.5.9.B Synthesizer/Control PCB Assembly

The Synthesizer/Control PCB Assembly consists of three major loops: DDS, main and comb driver. This structure locks a YIG oscillator by mixing the output with that of the comb frequency coming from the clean loop. The comb moves in approximately 0.4 MHz steps providing a coarse tune. The DDS, which is tunable in extremely fine steps, drives the main loop, giving the Synthesizer/Control PCB Assembly sub-hertz resolution. The comb driver has two loops that generate an exceptionally clean signal that is multiplied up to the YIG frequency. The step loop provides all of the step size for the comb driver and is followed by the clean loop which tracks the step loop changes. The frequencies of 80 and 400 MHz that exist in the Receiver Assembly are reused to generate the LOs used for the up-converter block. This is what determines the choice of IF frequencies. In order to convert 11.4 to 91.4 MHz, 11.4 MHz is mixed with 80 MHz and the sum product taken. The 520 MHz LO needed for the 611.4 MHz IF is generated by dividing 400 MHz by two. This 200 MHz signal is mixed with the 80 MHz in a mixer that has poor third order LO performance. The 3rd LO minus the IF produces 600 MHz. Subtract 80 MHz for a sum of 520 MHz. Finally, the 2800 MHz LO needed to convert 611.4 to 3411.4 MHz is generated by multiplying 400 MHz by seven.

2.5.10 Generator Assembly (44A1A4)

Section 2.5.10 applies to the 3920B model. Refer to [Fig. 2-1](#) or [Fig. 2-3](#).

The CAI PCB Assembly provides 10.8 MHz IF to the Generator Assembly for frequency conversion to the desired output frequency. The Generator Assembly provides 0.1 dB increments between the 10 dB steps of the step attenuator attached to the top of the Generator Assembly. The Generator Assembly consists of the RF/Microwave PCB Assembly and Synthesizer/Control PCB Assembly. The lower frequency functions are performed by the Synthesizer/Control PCB Assembly, while the higher frequency functions are performed by the RF/Microwave PCB Assembly.

2.5.10.A RF/Microwave PCB Assembly

The RF/Microwave PCB Assembly is designed to convert a 10.8 MHz IF input to any frequency between 1 MHz to 2.7 GHz. The frequency conversion is handled in a banded approach. The Low Band range is 10 MHz to 1000 MHz; the High Band range is >1.0 GHz to 2.7 GHz. The 10.8 MHz IF signal is mixed with an 80 MHz LO signal from the Receiver Assembly to create a 90.8 MHz IF signal. This 90.8 MHz signal is then mixed with a 1309.2 MHz fixed LO which is received from the Synthesizer PCB to create a 1400 MHz IF signal. Low Band frequency conversion mixes the 1400 MHz IF signal with the Low Band 1st LO (1400 – 2400 MHz) to down convert the 1400 MHz IF signal to the desired output frequency. High Band frequency conversion mixes the 1400 MHz IF signal with a 2 GHz Fixed LO to create a 3400 MHz IF signal. The 3400 MHz IF signal is then down converted to the desired output frequency by mixing it with the High Band 1st LO (4400 – 6000 MHz).

When the system Tracking Generator is enabled the 2 GHz LO is adjusted to 2010.7 MHz and mixed with the 1400 MHz IF signal to form a 3410.7 IF signal. In order for the Receiver and Generator to track in frequency the 1st LO from the Receiver is used by the Generator to generate the output frequency.

Filtering is performed at each IF to remove the images resulting from the up-conversion process. In order to meet the specified maximum output power level the signal is leveled and amplified to a level high enough to overcome the losses of the step attenuator and Power Term.

2.5.10.B Synthesizer/Control PCB Assembly\

The Synthesizer/Control PCB Assembly consists of:

- A CPLD which interfaces with the system backplane to provide control functions for the module.
- Switching and linear voltage regulators to supply both the Synthesizer and Microwave PCB with the desired operating voltages.
- Automatic Level Control (ALC) circuitry used by the Microwave PCB to level the output signal.
- 7 Phase Locked Loops (PLL's) which generate the variable and fixed LO signals used on the Microwave PCB.

The 80 MHz LO signal from the Receiver module is amplified and filtered then sent to the Microwave PCB. This 80 MHz signal is also used as the reference to phase lock a 100 MHz OCXO with the system.

The 100 MHz OCXO provides an extremely low phase noise reference for the other PLL's. A fractional PLL referenced to the 100 MHz OCXO is used to generate the fixed 1309.2 MHz LO. An integer PLL uses the low phase noise OCXO as reference to generate a 2 GHz LO. When the system Tracking Generator is enabled the 2 GHz PLL is reconfigured to fractional mode to create a 2010.7 MHz LO signal.

Both the Low Band (1400 to 2400 MHz) and High Band (4400 to 6000 MHz) 1st LO signals are generated using fractional PLL circuits. In order to control the fractional spurs associated with fractional PLL's separate integer PLL's are used to generate the variable reference frequencies used by the Fractional PLL's to create the LO signal.

2.5.11 IF/Video PCB Assembly (44A1A5)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The IF/Video PCB Assembly conditions incoming signals from the Receive IF Assembly for the CAI PCB Assembly and provides a squared IF signal to the CAI PCB Assembly for frequency counter circuitry. The IF/Video PCB Assembly provides the analyzer gain adjustment when adjusting the Reference level dBm on the Spectrum Analyzer, and acts as the receiver Automatic Gain Control (AGC) when in the Receiver mode. As well as providing a digitized logarithmic representation of the incoming signal amplitude for both the “channel” and “widescan” analyzer modes, the IF/Video PCB Assembly also provides a buffered 10.7 MHz IF signal to the rear of the 3900 and a temperature sensor for sensing the internal ambient unit temperature.

2.5.11.A IF/Video - 10.7 MHz IF Filters

The 10.7 MHz IF path provides gain adjustment and hardware bandwidth restriction of the signal being received from the Receive IF Assembly. This signal is used by the CAI PCB Assembly to perform all signal processing, decoding and metering functions. The 10.7 MHz filter bandwidth selections include: 6 MHz, 300 kHz and 30 kHz.

2.5.11.B IF/Video - 5.3 MHz IF Filters “Channel” IF

The Spectrum Analyzer 5.3 MHz IF functions to provide a fixed frequency down-conversion of the CAI 10.7 MHz IF signal for the Channel Analyzer screens. The 5.3 MHz filter bandwidth selections include 60 kHz, 3 kHz and 300 Hz.

2.5.12 Receiver Assembly (44A1A7)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#).

The Receiver Assembly is a self contained wideband triple conversion receiver designed to convert incoming frequencies (9 kHz to 2.7 GHz) to a 10.7 MHz IF Output frequency. The module consists of the Receiver PCB Assembly and Synthesizer PCB Assembly.

2.5.12.A Receiver PCB Assembly

The Receiver PCB Assembly converts incoming frequencies (9 kHz to 2.7 GHz) to a 10.7 MHz IF Output frequency. The Receiver PCB Assembly provides all the necessary LO's for the conversion to 10.7 MHz IF. The 10.7 MHz IF is routed to the IF/Video PCB Assembly for additional filtering and signal conditioning.

2.5.12.B Synthesizer PCB Assembly

The Synthesizer PCB Assembly consists of three major loops: the DDS, main, and comb driver. This structure locks a YIG oscillator by mixing its output with that of the comb frequency coming from the clean loop. The comb itself moves in approximately 0.4 MHz steps providing a coarse tune. The DDS, which is tunable in extremely fine steps, drives the main loop giving the synthesizer its sub-hertz resolution. The comb driver has two loops that generate an exceptionally clean signal that is multiplied up to the YIG frequency. The step loop provides the step size for the comb driver and is followed by the clean loop which tracks the step loop changes. The synthesizer/control board provides an 80 and 400 MHz reference for the Generator Module.

2.5.13 CAI PCB Assembly (44A1A8)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#) and [Fig. 2-16](#).

The CAI (Common Air Interface) PCB Assembly contains three DSP's, a protocol processor and a digital up/down converter chipset. The main responsibility of the CAI PCB Assembly is to provide the interface between the IF and the host CPU.

- Digitally perform modulation and demodulation of IF signal using an up/down converter chipset and DSP.
- Perform parametric measurements from the digital data that is generated by the up/down converter chipset.
- Generate digital outputs.
- Controlled by the host CPU over the PCI bus in which part of the address decoding has been performed external to the CAI PCB Assembly.

2.5.14 DAM (Data Acquisition Module) Carrier PCB Assembly (44A1A10)

Refer to [Fig. 2-1](#) or [Fig. 2-2](#) and [Fig. 2-17](#).

The DAM Carrier provides a digitizing sub system for the IF signal path. The output of the AD6644 64.8 MHz digitizer is converted to 16 pairs of LVDS (Low Voltage Differential) for transmission to the Backplane PCB Assembly. The data is reconstructed at the FPGA on the CAI module using a LVDS receiver IC.

The DAM Carrier contains three RF signal paths that are utilized by the analog to digital digitizer. One of the RF signal paths is the bypass mode, which does not contain bandwidth filtering. The total delay of this RF signal path is 12.5 ns. The second RF signal path is the 10.7 MHz Gaussian filter. This RF signal path contains a -3 dB bandwidth of 1.4 MHz, with a typical delay of 780 to 810 μ s. The third RF signal path contains a 200 kHz ceramic filter in series with the Gaussian filter output. The two filters on this RF signal path create a combined delay of approximately 5 μ s.

The AD6644's 64.8 MHz Encode/Decode clock is phase locked to the 40 MHz reference routed from the Receiver module to the Backplane PCB Assembly, then to the Xilinx XC9572 CPLD. The CPLD uses the 40 MHz reference to derive the onboard 10 MHz PLL clock. The 64.8 MHz TCXO is a voltage controlled oscillator. The input control voltage for the TCXO is driven by the LMX2301TM Phase Lock Loop IC. Once the microcontroller has programmed the PLL registers, the LMX2301TM IC phase locks the TCXO to the 10 MHz reference. A red LED indicates whether or not phase lock has been established. When the red LED is OFF a phase locked condition has been achieved. If the LED is ON phase lock has not been achieved. Refer to [Fig. 2-8](#) for red LED location.




Fig. 2-8 DAM Carrier Red LED Status Indicator

An ATMEL microcontroller (ATMEGA8515) is used as the on board intelligent controller. The microcontroller uses a SPI (Serial Port Interface) to perform setups, filter selection, and dithering control. The microcontroller uses a 4 MHz clock, which is also derived from the 40 MHz reference.

The DAM Carrier contains a separate digital to analog converter that generates an RF Output signal in the range of 10 to 13 MHz, with a maximum output level of -6 dBm. The output signal is derived from another set of LVDS signals received from the FPGA on the CAI module. These LVDS signals drive a LVDS receiver, which converts the LVDS data into TTL compatible outputs that are used to drive the Digital to Analog Converter (DAC).

The DAM Carrier PCB Assembly has three slots available for vocoder functions. Each slot has ten bits of digital I/O connected to the CAI module. There are +5 V, +15 V, -15 V and +3.3 V power lines available for the satellite PCBs.

Vocoders are factory installed on all 3920's and have been installed on 3901 and 3902's with serial numbers ending in 1288 or higher. DAM Carrier PCB Assemblies containing Vocoders have visible white tabs on the back of the assembly (refer to Fig. 2-9). The Vocoder Option (390XOPT216) also appears in the option list on the Utility License Tile when the Vocoder hardware has been installed in a unit.




Fig. 2-9 Carrier - Vocoder Tabs

The DAM Carrier module has three green LEDs that indicate micro status (Fig. 2-10). The first two LEDs indicate filter status. When Wideband filtering is selected both of these LEDs are OFF. When Gaussian filtering is selected the first LED is ON and the second LED is OFF (Fig. 2-11). When the first and second LED are ON, GAUSSIAN plus 200 kHz Ceramic filters are selected (refer to Fig. 2-12). The third LED indicates a heartbeat and shows whether or not dithering is enabled (Fig. 2-13). A slow moderate blinking LED indicates NO DITHERING, while a fast blinking LED indicates dithering is enabled. LED blink speed indicates how much dithering is actually being applied.




Fig. 2-10 Carrier Green LED Status Indicators



Fig. 2-11 Gaussian Filter Selected



Fig. 2-12 Gaussian plus 200 kHz Ceramic Filters Selected



Fig. 2-13 Dithering LED Status Indicator

THIS PAGE INTENTIONALLY LEFT BLANK.




Fig. 2-14 Power Termination Assembly Interconnect Diagram
0000-4431-900-C (Sheet 1 of 2)




Fig. 2-14 Power Termination Assembly Interconnect Diagram
0000-4431-900-C (Sheet 2 of 2)




Fig. 2-15 Digital Multimeter Block Diagram
0000-4435-100-C1




Fig. 2-16 CAI PCB Assembly Block Diagram
 0000-4431-200-E (Sheet 1 of 5)




Fig. 2-16 CAI PCB Assembly Block Diagram
0000-4431-200-E (Sheet 2 of 5)




Fig. 2-16 CAI PCB Assembly Block Diagram
0000-4431-200-E (Sheet 3 of 5)




Fig. 2-16 CAI PCB Assembly Block Diagram
0000-4431-200-E (Sheet 4 of 5)




Fig. 2-16 CAI PCB Assembly Block Diagram
0000-4431-200-E (Sheet 5 of 5)




Fig. 2-17 DAM Carrier PCB Assembly Interconnect Diagram
0000-4433-200-E

THIS PAGE INTENTIONALLY LEFT BLANK.

Chapter 3 - Troubleshooting Procedures

3.1 GENERAL

Troubleshooting is divided into Symptom Troubleshooting Procedures and Assembly Troubleshooting Procedures.

3.1.1 Symptom Troubleshooting Procedures

The Symptom Troubleshooting Procedures identifies common malfunctions which may occur during Test Set operation. When numerous tests/inspections are indicated, perform tests/inspections and corrective actions in order listed.

NOTE	<p>Voltage readings reference analog ground unless otherwise specified. Refer to Chapter 6, Interconnect and Assembly Diagrams, for assembly drawings and interconnect diagrams.</p> <p>This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, the troubleshooting technique (the formulation of a logical approach to locating the source of trouble) is left to the technician's discretion.</p>
-------------	--

3.1.2 Assembly Troubleshooting Procedures

Assembly Troubleshooting Procedures are intended to determine whether or not an assembly is functioning properly; these procedures do not determine if an assembly is operating within specified parameters. Perform Test Set Verification Procedures (refer to Chapter 4, Verification and Calibration Procedures) to determine if an assembly is operating within specified parameters.

3.2 TROUBLESHOOTING GUIDELINES

The following is a list of guidelines to be used when troubleshooting the Test Set.

- Refer to Chapter 2, Theory of Operation for System Interconnect Diagram.
- Refer to the 3900 Series Operation Manual for proper use of the Test Set.
- Many Test Set problems are caused by cable corrosion. Sometimes removing and reseating an affected cable corrects the malfunction. Cleaning connectors and/or switch contacts with alcohol repairs many types of digital and analog circuit malfunctions.
- The following inspection procedures are used to locate obvious Test Set malfunctions :
- Inspect all external surfaces of Test Set for physical damage, breakage, loose or dirty contacts and missing components.

NOTE

Do not disconnect or remove any board assemblies in the Test Set unless the unit is removed from AC Power source. Some assemblies contain devices that can be damaged if the assembly is removed when power is on. Several components can be damaged by Electrostatic Discharge. Use conductive foam and grounding straps when servicing is required around sensitive components.

- Inspect assemblies for discoloration, cracks, breaks and warping.
- Inspect visible printed circuit boards for burnt or loose components, discoloration, cracks, breaks and warping.
- Inspect all chassis-mounted components for looseness, breakage, loose contacts or conductors.
- Inspect Test Set for disconnected, broken, cut, loose or frayed cables or wires.

3.2.1 Precautions

3.2.1.A Safety

WARNING

REMOVE ALL JEWELRY OR OTHER COSMETIC APPAREL BEFORE PERFORMING ANY TROUBLESHOOTING PROCEDURES INVOLVING LIVE CIRCUITS.

WHEN WORKING WITH LIVE CIRCUITS OF HIGH POTENTIAL, KEEP ONE HAND IN POCKET OR BEHIND BACK TO AVOID SERIOUS SHOCK HAZARD.

USE ONLY INSULATED TOOLS WHEN WORKING WITH LIVE CIRCUITS.

FOR ADDED INSULATION, PLACE RUBBER BENCH MAT UNDERNEATH ALL POWERED BENCH EQUIPMENT, AS WELL AS A RUBBER MAT UNDERNEATH TECHNICIAN'S CHAIR.

HEED ALL WARNING AND CAUTIONS CONCERNING MAXIMUM VOLTAGES AND POWER INPUTS.


3.2.1.B EMC and Safety Compliance

All assemblies, cables, connectors, plastic fasteners, gaskets, fingerstock and miscellaneous hardware within Test Set are configured to satisfy safety and EMC compliance standards.

CAUTION

UPON COMPLETION OF ANY MAINTENANCE ACTION; ALL ASSEMBLIES, CABLE, CONNECTORS, PLASTIC FASTENERS, GASKETS, FINGERSTOCK AND MISCELLANEOUS HARDWARE MUST BE CONFIGURED AS INSTALLED AT THE FACTORY.

3.2.1.C ESD



CAUTION TEST SET COMPONENTS CONTAIN PARTS SENSITIVE TO DAMAGE BY ELECTROSTATIC DISCHARGE (ESD). ALL PERSONNEL PERFORMING TROUBLESHOOTING PROCEDURES SHOULD HAVE KNOWLEDGE OF ACCEPTED ESD PRACTICES AND/OR BE ESD CERTIFIED.

3.3 REQUIRED EQUIPMENT

The following equipment is required to perform 3900 Troubleshooting Procedures:

- Spectrum Analyzer
- SSMB to BNC Coaxial Cable
- SMA to BNC Coaxial Cable
- Male to Male SSMB Connector

3.4 PREVENTIVE MAINTENANCE PROCEDURES

Contains routine maintenance instructions for cleaning and inspecting the Test Set.

CAUTION DISCONNECT TEST SET FROM AC POWER SUPPLY TO AVOID POSSIBLE INJURY TO PERSONNEL AND DAMAGE TO ELECTRONIC CIRCUITS.

3.4.1 External Cleaning

STEP	PROCEDURE
1.	Clean front panel and display face with soft lint-free cloth. If dirt is difficult to remove, dampen cloth with water and mild liquid detergent.
2.	Remove grease, fungus and ground-in dirt from surfaces with soft lint-free cloth dampened (not soaked) with isopropyl alcohol.
3.	Remove dust and dirt from connectors with soft-bristled brush.
4.	Cover connectors, not in use, with suitable dust cover to prevent tarnishing of connector contacts.
5.	Clean cables with soft lint-free cloth.
6.	Paint exposed metal surface to avoid corrosion.

3.4.2 Internal Cleaning

Remove dust with hand-controlled dry air jet of 15 psi (1.054 kg/cm) and wipe internal chassis parts and frame with soft lint-free cloth moistened with isopropyl alcohol.



CAUTION TO AVOID POSSIBLE DAMAGE, DO NOT NEEDLESSLY DISCONNECT CONNECTORS FROM ASSEMBLIES OR REMOVE ASSEMBLIES FROM TEST SET.

Do not open assemblies for purpose of cleaning and inspection.

3.4.3 Visual Inspection

Inspect Chassis for:

- Tightness of sub-assemblies and chassis mounted connectors.
- Corrosion or damage to metal surfaces.

Inspect Connectors for:

- Loose or broken parts, cracked insulation and bad contacts.

Inspect Circuit Boards for:

- Corrosion or damage to connectors.
- Damage to visible mounted components including crystals and ICs.
- Freedom from foreign material.

Inspect Wiring for:

- Broken or loose ends and connections.
- Proper dress relative to other chassis parts.
- Verify wrapped wiring is tight.

3.5 ASSEMBLY CABLES AND CONNECTORS

3.5.1 390x and 3920 Cables and Connectors

Fig. 3-1 and Fig. 3-2 identify coaxial cables and connection points referenced in this section.




Fig. 3-1 3900 Assembly Connections




Fig. 3-2 3900 Assembly Cables

3.5.2 3920B Cables and Connectors

Fig. 3-3 and Fig. 3-4 identify coaxial cables and connection points referenced in this section.




Fig. 3-3 3920B Assembly Connections




Fig. 3-4 3920B Assembly Cables

3.6 SYMPTOM TROUBLESHOOTING PROCEDURES

3.6.1 Preliminary Procedure

Reboot Test Set prior to performing any Troubleshooting Procedure. If the problem persists after rebooting Test Set, proceed to Troubleshooting Procedure.

Symptom Index		Page
1.	Front Panel ON/Standby LED does not illuminate.	3 - 8
2.	Test Set does not load system at power up.	3 - 8
3.	No GENERATE output.	3 - 9
4.	No RECEIVE signal.	3 - 10
5.	Receive message "Receive Synthesizers are Unlocked" or "Reference is Unlocked."	3 - 10
6.	No Audio measurements.	3 - 11
7.	Apparent low sensitivity and/or degraded receive performance.	3 - 12
8.	Scope display is frozen and trace does not update.	3 - 13
9.	Scope trace is not triggering properly.	3 - 14
10.	No modulation - CW output only.	3 - 15
11.	Software Upgrade failed.	3 - 15
12.	Option Installation failed.	3 - 16
13.	License Installation failed.	3 - 16
14.	Test Set does not recognize PS/2 Mouse.	3 - 17
15.	USB Mouse unresponsive.	3 - 17
16.	USB Keyboard unresponsive	3 - 17
17.	PS/2 Keyboard unresponsive	3 - 17
18.	Front Panel USB Connector unresponsive.	3 - 18
19.	Test Set does not maintain correct time or receive message "Check Date and Time settings", "Press <F1> to resume. <F2> to Setup" when unit is powered on.	3 - 19
20.	Test Set does not power down to Standby Mode when On/Standby Key is pressed.	3 - 19
21.	Receive "Receiver YIG Calibration Failed" message during boot-up procedure.	3 - 19
22.	Receive "Generator YIG Calibration Failed" message during boot-up procedure.	3 - 20
23.	Receive "Generator and Receiver YIG Calibration Failed" message during boot-up procedure.	3 - 20

NOTE

The Symptom Index lists common malfunctions found during normal operation or maintenance of Test Set. The tests/inspections and corrective actions should be performed in the order listed.


MALFUNCTION		
TEST OR INSPECTION		
CORRECTIVE ACTION		
1.	Front Panel ON/Standby LED does not illuminate.	
	Step 1	<ul style="list-style-type: none"> Is Test Set connected to live AC Power Supply? <ul style="list-style-type: none"> If NO, connect Test Set to live AC Power Supply. If YES, proceed to next step.
	Step 2	<ul style="list-style-type: none"> Is Test Set AC Power Switch in ON position? <ul style="list-style-type: none"> If NO, turn AC Power Switch to ON. If YES, proceed to next step.
	Step 3	<ul style="list-style-type: none"> Is fuse at AC Power Switch functional? <ul style="list-style-type: none"> If NO, replace fuse. If YES, probable cause of error is Power Supply Assy. Refer to Chapter 5 for Power Supply Assy Remove/Install Procedures or contact Aeroflex Customer Service.
2.	Test Set does not load system at power up.	
	Step 1	<ul style="list-style-type: none"> Perform Reboot to Factory Defaults Procedure. If problem persists after corrective action is taken proceed to next step.
	Step 2	<ul style="list-style-type: none"> Is Test Set operating within specified temperature range (0° to 50° C)? <ul style="list-style-type: none"> If NO, move Test Set to suitable working environment and allow unit to reach proper operating temperature. If YES, proceed to next step.
	Step 3	<ul style="list-style-type: none"> Is Floppy Disk Drive empty? <ul style="list-style-type: none"> If NO, remove floppy disk from Floppy Disk Drive and restart Test Set. If YES, proceed to next step.
	Step 4	<ul style="list-style-type: none"> Have USB device(s) been removed from USB Connectors? <ul style="list-style-type: none"> If NO, remove USB device(s) and restart Test Set. If YES, proceed to next step.
	Step 5	<ul style="list-style-type: none"> Is License file valid (check status on UTILS, License Tile)? <ul style="list-style-type: none"> If NO, install valid License file. If YES, proceed to next step or contact Aeroflex Customer Service.
The following steps are for Qualified Service Personnel Only!		
	Step 6	<ul style="list-style-type: none"> Does Start-up Screen list all licensed systems for Test Set? <ul style="list-style-type: none"> If YES, proceed to next step. If NO, does Operational Status Tile show valid Receive, Generator and IF temperatures? <ul style="list-style-type: none"> If NO, contact Aeroflex Customer Service for "One-Wire" debug. If YES, record Test Set Serial Number and UID from Utility License Tile and contact Aeroflex Customer Service to request a new License File.
	Step 7	<ul style="list-style-type: none"> If able to access files, save customer generated files and calibration files on a USB device or floppy disk. Refer to Chapter 4 for Save and Recall Calibration Files procedures.
	Step 8	<ul style="list-style-type: none"> Scrape and reload software and reinstall valid license file. If problem persists, contact Aeroflex Customer Service.


MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
3.	No GENERATE output at GEN or T/R connector.	
Step 1	<ul style="list-style-type: none"> • Is correct Output connector selected (GEN or T/R). <ul style="list-style-type: none"> • If NO, select correct Output connector. • If YES, proceed to next step. 	
Step 2	<ul style="list-style-type: none"> • Is RF Gen Soft Key set to ON? <ul style="list-style-type: none"> • If NO, turn RF Generator ON. • If YES, proceed to next step. 	
Step 3	<ul style="list-style-type: none"> • Is RF Generator frequency set to desired frequency? <ul style="list-style-type: none"> • If NO, set RF Generator frequency to desired frequency. • If YES, proceed to next step. 	
Step 4	<ul style="list-style-type: none"> • Is RF Generator level set to desired setting? <ul style="list-style-type: none"> • If NO, set RF Generator level to desired setting. • If YES, proceed to next step. 	
Step 5	<ul style="list-style-type: none"> • The Port Overload Protection may have been triggered. Reset Port Overload Protection (UTILS, Hardware Settings, Operational Status Tile). If problem persists, proceed to next step or contact Aeroflex Customer Service. 	
The following steps are for Qualified Service Personnel Only!		
Step 6	<ul style="list-style-type: none"> • Verify DAM Carrier Assy operation (3.7.2 Verify DAM Carrier PCB Assy Operation). 	
Step 7	<ul style="list-style-type: none"> • Verify Generator Assy operation (3.7.3 Verify Generator Assy Operation). 	
Step 8	<ul style="list-style-type: none"> • Verify Attenuator/Power Term Assy operation (3.7.4 Verify Attenuator/Power Term Assy Operation). 	

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
4. No RECEIVE Signal at ANT or T/R connector.		
Step 1	<ul style="list-style-type: none"> • Is cable properly connected to desired RF Receive Input connector (ANT or T/R)? <ul style="list-style-type: none"> • If NO, connect cable to desired Input Connector. • If YES, proceed to next step. 	
Step 2	<ul style="list-style-type: none"> • Is correct RF Receive Input Connector selected (ANT or T/R)? <ul style="list-style-type: none"> • If NO, select correct Input Connector. • If YES, proceed to next step. 	
Step 3	<ul style="list-style-type: none"> • Is IF Bandwidth set appropriately for input signal type? <ul style="list-style-type: none"> • If NO, adjust IF Bandwidth to value appropriate for input signal. • If YES, proceed to next step. 	
Step 4	<ul style="list-style-type: none"> • Is desired AGC mode of operation (Manual or Auto) selected? <ul style="list-style-type: none"> • If NO, select desired AGC mode. • If YES, proceed to next step. 	
NOTE	AGC mode of operation is system dependent and not available with all Test Set systems.	
Step 5	<ul style="list-style-type: none"> • Is desired Pre-AMP setting (ON or OFF) selected? <ul style="list-style-type: none"> • If NO, select desired Pre-AMP setting. • If YES, proceed to next step. 	
Step 6	<ul style="list-style-type: none"> • The Port Overload Protection may have been triggered. Reset Port Overload Protection (UTILS, Hardware Settings, Operational Status Tile). If problem persists, proceed to next step or contact Aeroflex Customer Service. 	
The following steps are for Qualified Service Personnel Only!		
Step 7	<ul style="list-style-type: none"> • Verify Power Term Assy Receive operation (3.7.4 Verify Attenuator/Power Term Assy Operation.). 	
Step 8	<ul style="list-style-type: none"> • Verify Receiver Assy operation (3.7.6 Verify Receiver Assy Operation.). 	
Step 9	<ul style="list-style-type: none"> • Verify IF/Video PCB Assy operation (3.7.7 Verify IF/Video PCB Assy operation.). 	
5. Receive message “Receive Synthesizers are Unlocked” or “Reference is Unlocked.”		
NOTE	When Test Set is configured to utilize an external reference signal, an external reference signal must be provided.	
Step 1	<ul style="list-style-type: none"> • Is Test Set operating within specified temperature range (0° to 50° C)? <ul style="list-style-type: none"> • If NO, move Test Set to suitable working environment and allow unit to reach proper operating temperature. • If YES, proceed to next step. 	
Step 2	<ul style="list-style-type: none"> • Is INT/EXT frequency reference set EXT (External) (UTILS, Hardware Settings, Frequency Reference)? <ul style="list-style-type: none"> • If NO, probable cause of error is Disk I/O PCB Assy. Refer to Chapter 5 for Disk I/O PCB Assy Remove/Install Procedures or contact Aeroflex Customer Service. • If YES, proceed to next step. 	

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
	Step 3	<ul style="list-style-type: none"> • Is a valid reference frequency connected to the EXT I/O Connector? <ul style="list-style-type: none"> • If NO, provide a valid reference frequency to EXT I/O Connector or switch to INT (Internal). • If YES, probable cause of error is Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures or contact Aeroflex Customer Service.
6. No Audio measurements.		
	Step 1	<ul style="list-style-type: none"> • Is Source field on Analyzer Tile set to correct port? <ul style="list-style-type: none"> • If NO, select correct port. • If YES, proceed to next step.
	Step 2	<ul style="list-style-type: none"> • Is Impedance field on Analyzer Tile set to expected received value? <ul style="list-style-type: none"> • If NO, adjust Impedance setting. • If YES, proceed to next step.
	Step 3	<ul style="list-style-type: none"> • Is Filter field on Analyzer Tile set appropriately for frequency content of received signal? <ul style="list-style-type: none"> • If NO, change filter selection to one appropriate for frequency content of received signal. • If YES, proceed to next step.
	Step 4	<ul style="list-style-type: none"> • Is provided signal level within Test Set specifications? <ul style="list-style-type: none"> • If NO, adjust signal level. • If YES, proceed to next step.
	Step 5	<ul style="list-style-type: none"> • Is desired Noise Meter (SINAD or Distortion) selected? <ul style="list-style-type: none"> • If NO, select desired Noise Meter. • If YES, probable cause of error is FP Digital Interface PCB Assy, Front Panel Assy or coaxial cable(s). Refer to Chapter 5 for FP Digital Interface PCB Assy Remove/Install Procedures or contact Aeroflex Customer Service.


MALFUNCTION		
TEST OR INSPECTION		
CORRECTIVE ACTION		
7.	Apparent low sensitivity and/or degraded receive performance.	
Step 1	<ul style="list-style-type: none"> • Is signal generator output routed to T/R port? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, there may be an interfering signal. Perform one of the following: <ul style="list-style-type: none"> • Turn off signal generator; • Change generate frequency to a frequency outside of the receive bandwidth; • Change selected port to GEN output port. 	
Step 2	<ul style="list-style-type: none"> • Is IF Bandwidth set to an appropriate setting for current operating conditions? <ul style="list-style-type: none"> • If NO, adjust IF Bandwidth to a setting appropriate for operating conditions. • If YES, proceed to next step. 	
Step 3	<ul style="list-style-type: none"> • Is Test Set operating with an antenna? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, there may be an interfering signal causing interference. Remove interfering signal (Spectrum Analyzer can be used to locate unknown signals). 	
Step 4	<ul style="list-style-type: none"> • Is a strong signal being received? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, verify Pre-Amp is set to OFF (CONFIG, Ports, Pre-AMP)? 	
Step 5	<ul style="list-style-type: none"> • The Port Overload Protection may have been triggered. Reset Port Overload Protection (UTILS, Hardware Settings, Operational Status Tile). If problem persists, proceed to next step 	
The following steps are for Qualified Service Personnel Only!		
Step 6	<ul style="list-style-type: none"> • Verify Power Term Assy Receive operation (3.7.4 Verify Attenuator/Power Term Assy Operation.). 	
Step 7	<ul style="list-style-type: none"> • Verify Receiver Assy operation (3.7.6 Verify Receiver Assy Operation.). 	
Step 8	<ul style="list-style-type: none"> • Verify IF/Video PCB Assy operation (3.7.7 Verify IF/Video PCB Assy operation.). 	


MALFUNCTION	
TEST OR INSPECTION	
CORRECTIVE ACTION	
8.	Scope trace is frozen and does not update.
Step 1	<ul style="list-style-type: none"> Is cable properly connected to selected Scope input (CH1 or CH2)? <ul style="list-style-type: none"> If NO, properly connect cable to selected Scope input. If YES, proceed to next step.
Step 2	<ul style="list-style-type: none"> Is desired trigger source selected (Trace A or B)? <ul style="list-style-type: none"> If NO, select desired trigger source. If YES, proceed to next step.
Step 3	<ul style="list-style-type: none"> Is NORMAL Trigger mode selected? <ul style="list-style-type: none"> If NO, proceed to next step. If YES, verify Level setting is appropriate for signal type.
Step 4	<ul style="list-style-type: none"> Is REPEAT trace selected? <ul style="list-style-type: none"> If NO, select REPEAT to enable continuous trace. If YES, proceed to next step or contact Aeroflex Customer Service.
The following steps are for Qualified Service Personnel Only!	
Step 5	<ul style="list-style-type: none"> Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 6	<ul style="list-style-type: none"> Remove Front Panel Assy. Refer to Chapter 5 for Front Panel Assy Remove/Install Procedures.
Step 7	<ul style="list-style-type: none"> Inspect cables that connect Front Panel Assy to Front Panel Audio PCB Assy. Are cables properly connected?
	
	<ul style="list-style-type: none"> If NO, properly connect cables that connect Front Panel Assy to Front Panel Audio PCB Assy. If cables are properly connected, probable cause of error is Front Panel Assy, Front Panel Digital PCB Assy, CAI PCB Assy or coaxial cable(s). Refer to Chapter 5 for Remove/Install Procedures or contact Aeroflex Customer Service.

MALFUNCTION	
TEST OR INSPECTION	
CORRECTIVE ACTION	
9.	Scope trace is not triggering properly.
Step 1	<ul style="list-style-type: none"> Is desired trigger source selected (Trace A or B)? <ul style="list-style-type: none"> If NO, select desired trigger source. If YES, proceed to next step.
Step 2	<ul style="list-style-type: none"> Is NORMAL Trigger mode selected? <ul style="list-style-type: none"> If NO, proceed to next step. If YES, verify Level setting is appropriate for signal type.
Step 3	<ul style="list-style-type: none"> Is REPEAT trace selected? <ul style="list-style-type: none"> If NO, select REPEAT to enable continuous trace. If YES, proceed to next step.
Step 4	<ul style="list-style-type: none"> Is Filter setting appropriate for signal type being measured? <ul style="list-style-type: none"> If NO, change filter type to one appropriate for signal type. If YES, proceed to next step or contact Aeroflex Customer Service.
The following steps are for Qualified Service Personnel Only!	
Step 5	<ul style="list-style-type: none"> Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 6	<ul style="list-style-type: none"> Remove Front Panel Assy. Refer to Chapter 5 for Front Panel Assy Remove/Install Procedures.
Step 7	<ul style="list-style-type: none"> Inspect cables that connect Front Panel Assy to Front Panel Audio PCB Assy. Are cables properly connected?
	
	<ul style="list-style-type: none"> If NO, properly connect cables that connect Front Panel Assy to Front Panel Audio PCB Assy. If YES, probable cause of error is Front Panel Assy, Front Panel Digital PCB Assy, CAI PCB Assy or coaxial cable(s). Refer to Chapter 5 for assembly Remove/Install Procedures or contact Aeroflex Customer Service.

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
10.	No modulation - CW Output only.	
	Step 1	<ul style="list-style-type: none"> • Is correct modulation type selected? <ul style="list-style-type: none"> • If NO, select correct modulation type. • If YES, proceed to next step.
	Step 2	<ul style="list-style-type: none"> • Are modulators turned ON? <ul style="list-style-type: none"> • If NO, turn modulators ON. • If YES, proceed to next step.
	Step 3	<ul style="list-style-type: none"> • Are modulator(s) set to desired settings? <ul style="list-style-type: none"> • If NO, adjust modulator settings. • If YES, proceed to next step.
	Step 4	<ul style="list-style-type: none"> • Is External modulation set to Aud1, Aud2 or Balanced? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, verify a modulation source is connected to selected source.
	Step 5	<ul style="list-style-type: none"> • Is External modulation set to MIC? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, verify MIC Phantom Power is set to desired setting.
The following steps are for Qualified Service Personnel Only!		
	Step 6	<ul style="list-style-type: none"> • Remove Case Assy. Refer to Chapter 5 for Remove/Install Procedures.
	Step 7	<ul style="list-style-type: none"> • Are cables are properly connected to CAI PCB Assy? <ul style="list-style-type: none"> • If NO, properly connect cables to CAI PCB Assy. • If YES, probable cause of error is CAI PCB Assy or coaxial cable(s). Refer to Chapter 5 for CAI PCB Assy Remove/ Install Procedures or contact Aeroflex Customer Service.
11.	Software Upgrade failed.	
	Step 1	<ul style="list-style-type: none"> • Verify Test Set recognizes USB device (Troubleshooting Procedure for Unresponsive USB Device).
	Step 2	<ul style="list-style-type: none"> • Was Restore to Factory Defaults procedure completed before performing software upgrade? <ul style="list-style-type: none"> • If NO, contact Aeroflex Customer Service. • If YES, proceed to next step.
	Step 3	<ul style="list-style-type: none"> • Does Test Set contains software version prior to V1.1? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, contact Aeroflex Customer Service.
	Step 4	<ul style="list-style-type: none"> • When performing Software Upgrade, was software upgrade file placed in correct folder hierarchy (\Aeroflex\3900)? <ul style="list-style-type: none"> • If NO, place software upgrade file in correct folder hierarchy (\Aeroflex\3900) and repeat Software Upgrade procedure. • If YES, proceed to next step.
	Step 5	<ul style="list-style-type: none"> • Was license installed prior to software upgrade? <ul style="list-style-type: none"> • If NO, install license and repeat Software Upgrade procedure. • If YES, contact Aeroflex Customer Service.

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
12.	Option installation failed.	
Step 1	<ul style="list-style-type: none"> • Is license valid? <ul style="list-style-type: none"> • If NO, contact Aeroflex Customer Service. • If YES, proceed to next step. 	
Step 2	<ul style="list-style-type: none"> • Was valid license installed in Test Set with serial number for which it was purchased? <ul style="list-style-type: none"> • If NO, install license in Test Set with serial number for which it was purchased. • If YES, contact Aeroflex Customer Service. 	
13.	License installation failed.	
Step 1	<ul style="list-style-type: none"> • Verify Test Set recognizes USB device (Troubleshooting Procedure for Unresponsive USB Device). 	
Step 2	<ul style="list-style-type: none"> • Was license installed in Test Set with same serial number for which it was purchased? <ul style="list-style-type: none"> • If NO, install license in Test Set with serial number for which it was purchased. • If YES, proceed to next step. 	
Step 3	<ul style="list-style-type: none"> • Has license expired? <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, contact Aeroflex Customer Service. 	
Step 4	<ul style="list-style-type: none"> • Does Test Set contains software prior to V1.1 release. <ul style="list-style-type: none"> • If NO, proceed to next step. • If YES, contact Aeroflex Customer Service. 	
Step 5	<ul style="list-style-type: none"> • When installing license, was license file in correct folder hierarchy (\Aeroflex\3900)? <ul style="list-style-type: none"> • If NO, place license file in correct folder hierarchy (\Aeroflex\3900) and repeat License Installation procedure. • If YES, contact Aeroflex Customer Service. 	

MALFUNCTION		TEST OR INSPECTION	CORRECTIVE ACTION
		<p style="text-align: center;">PS/2 Mouse Interface Connector</p>  <p style="text-align: center;">Fig. 3-5 3900 Mouse and Keyboard Connectors</p> <p style="text-align: center;">Refer to Fig. 3-5 for connector identification for the following steps.</p>	
14.	Test Set does not recognize PS/2 mouse.		
	Test Set does not support PS/2 mouse. Use USB mouse with USB Connector.		
15.	USB Mouse unresponsive.		
	<ul style="list-style-type: none"> • Is USB mouse connected to USB Connector? <ul style="list-style-type: none"> • If NO, connect USB mouse to USB Connector. • If YES, disconnect, then reconnect, USB mouse from USB Connector. If problem persists after corrective action is performed, contact Aeroflex Customer Service. 		
16.	USB Keyboard unresponsive.		
	<ul style="list-style-type: none"> • Is USB Keyboard connected to USB Connector? <ul style="list-style-type: none"> • If NO, connect USB mouse to USB Connector. • If YES, disconnect, then reconnect, USB Keyboard from USB Connector. If problem persists after corrective action is performed, contact Aeroflex Customer Service. 		
17.	PS/2 Keyboard unresponsive.		
	<ul style="list-style-type: none"> • Is PS/2 Keyboard connected to Keyboard Interface Connector? <ul style="list-style-type: none"> • If NO, connect PS/2 Keyboard to Keyboard Interface Connector. • If YES, disconnect, then reconnect, PS/2 Keyboard from Keyboard Interface Connector. If problem persists after corrective action is performed, contact Aeroflex Customer Service. 		

MALFUNCTION		
TEST OR INSPECTION		
CORRECTIVE ACTION		
18.	Front Panel USB Connector unresponsive.	
Step 1	<ul style="list-style-type: none"> Are you using recommended USB device, Aeroflex PN 67325? <ul style="list-style-type: none"> If NO, use recommended USB device, Aeroflex PN 67325. If YES, proceed to next step. 	
Step 2	<ul style="list-style-type: none"> Does USB device (Aeroflex PN 67325) function when used with a device other than the Test Set? <ul style="list-style-type: none"> If NO, probable cause of error is USB device. If YES, proceed to next step. 	
Step 3	<ul style="list-style-type: none"> Is USB device securely connected to Front Panel USB Connector? <ul style="list-style-type: none"> If NO, securely connect USB device to Front Panel USB Connector. If YES, disconnect, then reconnect, USB device Front Panel USB Connector. If problem persists after corrective action is performed, proceed to next step or contact Aeroflex Customer Service. 	
<p>The following steps are for Qualified Service Personnel Only! These steps require use of recommended USB device, Aeroflex PN 67325.</p>		
Step 4	<ul style="list-style-type: none"> Remove Power Supply Assy. Refer to Chapter 5 for Remove/Install Procedures. 	
Step 5	<ul style="list-style-type: none"> Disconnect USB Cable from Backplane Assy USB Connector. 	
Step 6	<ul style="list-style-type: none"> Connect USB device to Backplane Assy USB Connector. 	
Step 7	<ul style="list-style-type: none"> Reinstall Power Supply with USB device still connected to Backplane PCB Assy. 	
Step 8	<ul style="list-style-type: none"> Power on Test Set. Is USB device accessible/responsive using Store/Recall Utilities function? <ul style="list-style-type: none"> If NO, remove USB device from Backplane Assy USB Connector, reconnect USB Cable, reinstall Power Supply Assy and proceed to next step. If YES, probable cause of error is USB Cable. Refer to Chapter 5 for USB Cable Remove/Install Procedure or contact Aeroflex Customer Service. 	
Step 9	<ul style="list-style-type: none"> Connect USB device to CPU Adapter Assy USB connector. 	
Step 10	<ul style="list-style-type: none"> Is USB device responsive? <ul style="list-style-type: none"> If NO, probable cause of error is CPU Adapter PCB Assy. Refer to Chapter 5 for CPU Adapter Assy Remove/Install Procedures or contact Aeroflex Customer Service. If YES, probable cause of error is Backplane Assy USB Connector. Refer to Chapter 5 for Backplane Assy Remove/Install Procedures or contact Aeroflex Customer Service. 	

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
19.	Test Set does not maintain correct time or receive message “Check Date and Time settings”, “Press <F1> to resume. <F2> to Setup” when unit is powered on.	
The following steps are for Qualified Service Personnel Only!		
	Step 1	<ul style="list-style-type: none"> • Replace CPU Adapter PCB Assy Battery. Refer to Chapter 5 for CPU Adapter PCB Assy Battery Remove/Install Procedures.
	Step 2	<ul style="list-style-type: none"> • Program Test Set Date and Time on the Time Date Utility Tile.
	Step 3	<ul style="list-style-type: none"> • If problem persists after corrective action is performed, contact Aeroflex Customer Service.
20.	Test Set does not power down to Standby Mode when On/Standby Key is pressed.	
	Step 1	<ul style="list-style-type: none"> • Switch Rear Panel AC Power Supply Switch to OFF position.
	Step 2	<ul style="list-style-type: none"> • After Test Set completely powers down, return AC Power Supply Switch to ON position.
	Step 3	<ul style="list-style-type: none"> • Press On/Standby Key to power on Test Set.
	Step 4	<ul style="list-style-type: none"> • Does Test Set reboot to operational state? <ul style="list-style-type: none"> • If NO, contact Aeroflex Customer Service. • If YES, proceed to next step.
	Step 5	<ul style="list-style-type: none"> • Press On/Standby Key to initiate power down sequence.
	Step 6	<ul style="list-style-type: none"> • At power down prompt, select YES.
	Step 7	<ul style="list-style-type: none"> • Did Test Set initiate power down sequence? <ul style="list-style-type: none"> • If NO, probable cause of error is Keypad Assy. Refer to Chapter 5 for Keypad Assy Remove/Install Procedure or contact Aeroflex Customer Service. • If YES, proceed to next step.
	Step 8	<ul style="list-style-type: none"> • Did Test Set initiate power down sequence, stopping with a black display containing a line of command code? <ul style="list-style-type: none"> • If YES, probable cause of error is Power Supply Assy. Refer to Chapter 5 for Power Supply Assy Remove/Install Procedure or contact Aeroflex Customer Service.
21.	Receive “Receiver YIG Calibration Failed” message during boot-up procedure.	
The following steps are for Qualified Service Personnel Only!		
	Step 1	<ul style="list-style-type: none"> • Power down and reboot Test Set. Does error message re-occur during boot-up procedure? <ul style="list-style-type: none"> • If YES, probable cause of failure is Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedure or contact Aeroflex Customer Service. • If NO, verify all coaxial cables are securely attached to assemblies. Refer to Chapter 5, Remove/Install Procedures for connector locations.
	Step 2	<ul style="list-style-type: none"> • Does problem persist after replacing Receiver Assy? <ul style="list-style-type: none"> • If YES, probable cause of failure is DAM Carrier PCB Assy. Refer to Chapter 5 for DAM Carrier PCB Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 3	<ul style="list-style-type: none"> • Does problem persist after DAM Carrier PCB Assy is replaced? <ul style="list-style-type: none"> • If YES, contact Aeroflex Customer Service.

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION		
22.	Receive “Generator YIG Calibration Failed” message during boot-up procedure.	
The following steps are for Qualified Service Personnel Only! The following steps apply to the 3901, 3902 and 3920.		
	Step 1	<ul style="list-style-type: none"> • Power down and reboot Test Set. Does error message re-occur during boot-up procedure? <ul style="list-style-type: none"> • If NO, verify all coaxial cables are securely attached to assemblies. Refer to Chapter 5, Remove/Install Procedures. • If YES, probable cause of failure is Generator Assy. Refer to Chapter 5 for Generator Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 2	<ul style="list-style-type: none"> • Does problem persist after replacing Generator Assy? <ul style="list-style-type: none"> • If YES, probable cause of failure is Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 3	<ul style="list-style-type: none"> • Does problem persist after replacing Receiver Assy? <ul style="list-style-type: none"> • If YES, probable cause of failure is DAM Carrier PCB Assy. Refer to Chapter 5 for DAM Carrier PCB Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 4	<ul style="list-style-type: none"> • Does problem persist after DAM Carrier PCB Assy is replaced? <ul style="list-style-type: none"> • If YES, contact Aeroflex Customer Service.
23.	Receive “Generator and Receiver YIG Calibration Failed” message during boot-up procedure.	
The following steps are for Qualified Service Personnel Only! The following steps apply to the 3901, 3902 and 3920.		
	Step 1	<ul style="list-style-type: none"> • Power down and reboot Test Set. Does error message re-occur during boot-up procedure? <ul style="list-style-type: none"> • If NO, verify all coaxial cables are securely attached to assemblies. Refer to Chapter 5, Remove/Install Procedures. • If YES, probable cause of failure is Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 2	<ul style="list-style-type: none"> • Does problem persist after replacing Receiver Assy? <ul style="list-style-type: none"> • If YES, probable cause of failure is DAM Carrier PCB Assy. Refer to Chapter 5 for DAM Carrier PCB Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 3	<ul style="list-style-type: none"> • Does problem persist after DAM Carrier PCB Assy is replaced? <ul style="list-style-type: none"> • If YES, probable cause of failure is Generator Assy. Refer to Chapter 5 for Generator Assy Remove/Install Procedure or contact Aeroflex Customer Service.
	Step 4	<ul style="list-style-type: none"> • Does problem persist after Generator Assy is replaced? <ul style="list-style-type: none"> • If YES, contact Aeroflex Customer Service.

3.7 ASSEMBLY TROUBLESHOOTING PROCEDURES

Assembly Troubleshooting Procedures require Test Set disassembly and should only be performed by a qualified service technician. Refer to [Fig. 3-1](#) and [Fig. 3-2](#) for assembly connectors and coaxial cable locations.

NOTE	Assembly Troubleshooting Procedures are intended to determine whether or not an assembly is functioning properly; these procedures do not determine if an assembly is operating within specified parameters. Perform Test Set Verification Procedures (refer to Chapter 4, Verification/Calibration Procedures) to determine if an assembly is operating within specified parameters.
-------------	---

3.7.1 Preliminary Procedures

Complete section [3.6, Symptom Troubleshooting Procedures](#) prior to performing Assembly Troubleshooting Procedures.

3.7.2 Verify DAM Carrier PCB Assy Operation

TEST OR INSPECTION CORRECTIVE ACTION	
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect W2 from A10J1.
Step 4	Use SSMB to BNC Coaxial Cable to connect Spectrum Analyzer to A10J1.
Step 5	Use Spectrum Analyzer to search for a signal at 11.4 MHz (for 3920B search for signal at 10.8 MHz). <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, probable cause of error is DAM Carrier PCB Assy or CAI PCB Assy. Refer to Chapter 5 for DAM Carrier PCB Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, proceed to 3.7.3 Verify Generator Assy Operation.

3.7.3 Verify Generator Assy Operation.

TEST OR INSPECTION CORRECTIVE ACTION	
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect W7 from A7J3.
Step 4	Use SSMB to BNC Coaxial Cable to connect Spectrum Analyzer to A7J3.
Step 5	Use Spectrum Analyzer to search for a signal at 80 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, probable cause of error is the Receiver Assy, replace Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W7 to A7J3. <ul style="list-style-type: none"> • 3901/3902/3920 proceed to next step. • 3920B proceed to Step 12.
Step 6	Disconnect W6 from A7J7.
Step 7	Use SSMB to BNC Coaxial Cable to connect Spectrum Analyzer to A7J7.
Step 8	Use Spectrum Analyzer to search for a signal at 400 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, probable cause of error is the Receiver Assy, replace Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W6 to A7J7. Proceed to next step.
Step 9	Disconnect W3 from A4J5.
Step 10	Use SSMB to BNC Coaxial Cable to connect Spectrum Analyzer to A4J5.
Step 11	Use Spectrum Analyzer to search for a signal at 200 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Generator Assy. Refer to Chapter 5 for Generator Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W3 to A4J5. Proceed to next step.
Step 12	Disconnect W9 from A4J1 and A3J2.
Step 13	Use SMA to BNC Coaxial Cable to connect Spectrum Analyzer to A4J1.
Step 14	Use Spectrum Analyzer to search for a signal at set RF Generator frequency. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, probable cause of error is the Generator Assy. replace Generator Assy. Refer to Chapter 5 for Generator Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W9 to A4J1. Proceed to 3.7.4 Verify Attenuator/Power Term Assy Operation.

3.7.4 Verify Attenuator/Power Term Assy Operation.

TEST OR INSPECTION CORRECTIVE ACTION	
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect A1W6 from connector A3J1.
Step 4	Use SMA to BNC Coaxial Cable to connect Spectrum Analyzer to A3J1.
Step 5	Use Spectrum Analyzer to search for a signal at the set RF Generator frequency. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Attenuator Assy. Refer to Chapter 5 for Attenuator Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect A1W6 to A3J1 and replace Power Term Assy. Refer to Chapter 5 for Power Term Assy Remove/Install Procedures.

3.7.5 Verify Power Term Assy Receive operation.

TEST OR INSPECTION CORRECTIVE ACTION	
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect A1W7 from A7J1.
Step 4	Use Male to Male SSMB Connector and SSMB to BNC coaxial cable to connect Spectrum Analyzer to end of A1W7.
Step 5	Use Spectrum Analyzer to search for signal at expected frequency. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Power Term Assy. Refer to Chapter 5 for Power Term Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect A1W7 to A7J1. Proceed to 3.7.6 Verify Receiver Assy Operation.

3.7.6 Verify Receiver Assy Operation.

TEST OR INSPECTION	CORRECTIVE ACTION
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect W6 from A7J7.
Step 4	Use SSMB to BNC coaxial cable to connect Spectrum Analyzer to A7J7.
Step 5	Use Spectrum Analyzer to search for a signal at 400 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W6 to A7J7 and proceed to next step.
Step 6	Disconnect W7 from A7J3.
Step 7	Use SSMB to BNC coaxial cable to connect Spectrum Analyzer to A7J3.
Step 8	Use Spectrum Analyzer to search for a signal at 80 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W7 to A7J3 and proceed to next step.
Step 9	Disconnect W3 from A7J5.
Step 10	Use SSMB to BNC coaxial cable to connect Spectrum Analyzer to A4J5.
Step 11	Use Spectrum Analyzer to search for a signal at 200 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace Generator Assy. Refer to Chapter 5 for Generator Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W3 to A4J5 and proceed to next step.
Step 12	Disconnect W4 from A7J8.
Step 13	Use SSMB to BNC coaxial cable to connect Spectrum Analyzer to A7J8.
Step 14	Use Spectrum Analyzer to search for a signal at 210.7 MHz. <ul style="list-style-type: none"> • SIGNAL on Spectrum Analyzer, replace Receiver Assy. Refer to Chapter 5 for Receiver Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, reconnect W4 to A7J8. Proceed to 3.7.7 Verify IF/Video PCB Assy operation.

3.7.7 Verify IF/Video PCB Assy operation.

TEST OR INSPECTION CORRECTIVE ACTION	
Step 1	Remove Case Assy. Refer to Chapter 5 for Case Assy Remove/Install Procedures.
Step 2	Inspect all coaxial cables to ensure they are properly connected to assemblies. If coaxial cables are properly connected to all assemblies, proceed to next step.
Step 3	Disconnect W5 from A5J5.
Step 4	Use SSMB to BNC coaxial cable to connect Spectrum Analyzer to A5J5.
Step 5	Use Spectrum Analyzer to search for a signal at 10.7 MHz. <ul style="list-style-type: none"> • NO SIGNAL on Spectrum Analyzer, replace IF/Video PCB Assy. Refer to Chapter 5 for IF/Video PCB Assy Remove/Install Procedures. • SIGNAL on Spectrum Analyzer, probable cause of error is DAM Carrier PCB Assy, CAI PCB Assy or coaxial cable(s). Refer to Chapter 5 for Remove/Install Procedures or contact Aeroflex Customer Service.

THIS PAGE INTENTIONALLY LEFT BLANK.

Chapter 4 - Verification/Calibration Procedures

4.1 GENERAL INFORMATION

This chapter provides step-by-step instructions for performing Test Set Verification and Calibration Procedures. Calibration files are included when the Calibration Software Option (390XOPT040) is installed in the Test Set. Software version 1.7.3 includes Verification Setup Files as a standard software item; units containing earlier software versions must download the Verification Setup Files from the 3900 Maintenance Manual CD.

Refer to the 3900 Series Operation CD for information on using the File Management Utility function to transfer Verification Setup Files to the Test Set.

4.2 VERIFICATION SCHEDULE

Verification Procedures should be performed following completion of any Remove/Install Procedure.

4.3 CALIBRATION SCHEDULE

The Calibration Procedure should be performed as a result of one or more of the following conditions:

- The Test Set fails to meet the performance specifications as determined by Verification Procedures.
- The recommended 12 month calibration interval is due.
- The CPU Adapter PCB Assy has been repaired or replaced.

4.4 FOLLOW-UP PROCEDURES

Aeroflex recommends that the Test Set's internal Calibration Files be saved to a USB device after Calibration is complete. Refer to section 4.11, [Saving Calibration Files](#).

4.5 CONTROLS AND CONNECTORS

Refer to Appendix A for the location of controls and connectors specified in the Verification and Calibration Procedures.

4.6 TEST RECORDS

Make copies of the Verification and Calibration Data Sheets to record and verify results obtained while performing these Calibration Procedures.

Electronic Data Sheets are available by clicking the links below. Adobe Reader allows the user to complete the form electronically and print the results. Electronic copies of completed data sheets can only be saved when using Adobe Acrobat.

- [Verification Data Sheet](#)
- [Calibration Data Sheet](#)

4.7 DISASSEMBLY REQUIREMENTS

None.

4.8 PRECAUTIONS

4.8.1 Safety

Use extreme caution when working with “live” circuits. Observe the following precautions when performing the Verification and Calibration Procedures:

WARNING

Heed all warnings and cautions concerning maximum voltages and power inputs.

4.8.2 ESD



CAUTION

Only perform Calibration Procedures in an ESD Environment. All personnel performing Calibration Procedures should have knowledge of accepted ESD practices and/or be ESD certified.

4.9 REQUIRED EQUIPMENT

Refer to Appendix E for list of equipment required to perform Verification and Calibration Procedures.

4.10 SPECIAL NOTES/INSTRUCTIONS

- Allow the Test Set to warm up for a minimum of 45 minutes prior to beginning Verification and Calibration Procedures.
- When 10 dB pads are included in the Calibration setup use one 10 dB pad only at Power Sensor head connections, and the other 10 dB pad only at ANT connections to obtain consistent readings.
- The Calibration System is designed to skip unnecessary steps when the Calibration Procedures are run consecutively. For example, the Zero and Calibrate Power Meter message is only displayed when this step needs to be performed.

4.11 SAVING CALIBRATION FILES

Aeroflex recommends that the Test Set’s internal Calibration Files be saved to a USB device prior to servicing and/or after calibrating the unit. To Save Calibration Files to USB device:

STEP	PROCEDURE
1.	Power on Test Set.
2.	Press UTILS Key to access Utilities floating menu.
3.	Select Hardware Settings, Database Status from floating menu.
4.	Connect USB device to Test Set USB Connector.
5.	Press Backup to USB Soft Key.
6.	When complete, remove USB device from Test Set.

NOTE	System Error message as shown in Fig. 4-1 is displayed when Backup to USB Soft Key is pressed before USB device is connected to Test Set.
-------------	---




Fig. 4-1 System Error - No USB Device Connected

4.12 RESTORING CALIBRATION FILES

To restore Saved Calibration files:

STEP	PROCEDURE
1.	Power on Test Set.
2.	Press UTILS Key to access Utilities floating menu.
3.	Select Hardware Settings, Database Status from floating menu.
4.	Connect USB device to Test Set USB Connector.
5.	Press Restore Soft Key. Select Restore From USB Soft Key as source of saved Calibration Files.
6.	When complete, remove USB device from Test Set.

4.13 TEST SET VERIFICATION

4.13.1 Accessing Procedures

Verification Setup Files are found on the 3900 Series Maintenance CD. These files must be downloaded to the Test Set before they can be accessed from the Store/Recall Tile. Refer to the 3900 Series Operation CD for information on downloading files to the Test Set and using the Store/Recall function.

4.13.2 Verification Types

There are two types of Verification Procedures supported for the 3900.

4.13.2.A Calibration Verification

Calibration Verification should be performed following Test Set Calibration. To perform Calibration Verification, perform Verification Procedures 1 through 9.

4.13.2.B System Calibration

System Verification should be performed following completion of any Remove/Install Procedure or to determine if the Test Set is operating within product specifications. To perform System Verification, perform Verification Procedures 1 through 27 or 28 based on Test Set hardware configuration.

4.13.3 Verification Procedures

4.13.3.A Initial Setup

Pre-requisites: None

Equipment: 10 MHz Frequency Standard

STEP	PROCEDURE
1.	Connect the Test Set to an appropriate AC power source.
2.	Set the AC Power Supply Switch to the ON position.
3.	Connect the 10 MHz Frequency Standard to the Test Set External RF I/O Connector.

NOTE	If procedure includes use of RF Generator, connect a 10 MHz frequency standard to RF Generator.
-------------	---

- Press UTILS Key to access the Utilities menu. Select Hardware Settings, Frequency Reference from floating menu.




Fig. 4-2 Select Frequency Reference Tile

- Select External from Reference (Internal/External) drop-down menu.
Test Set system parameters are now ready to be verified.

4.13.3.B Generator Output Frequency

Pre-requisites: None

Equipment: Frequency Counter

STEP	PROCEDURE
1.	Recall Verification Setup File 01. Wait for file to load.
2.	After file loads press UTILS Key. Select Hardware Settings, Frequency Reference from floating menu.
3.	After Tile opens, select Internal from Reference (Internal/External) drop down menu.
4.	Disconnect 10 MHz Frequency Standard from Test Set External RF I/O Connector.
5.	Connect Frequency Counter to Test Set GEN Connector.
6.	Verify Frequency Counter reading is 1 GHz (± 101 Hz).
	<ul style="list-style-type: none">• If reading is correct, go to next step.• If reading is out of tolerance, perform the Test Set TCXO Calibration Procedure.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following key sequence to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
	<ul style="list-style-type: none">• If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.C Generator Output Power

Pre-requisites: None
Equipment: Power Meter

- | STEP | PROCEDURE |
|------|--|
| 1. | Recall Verification Setup File 02. Wait for file to load. |
| 2. | Connect Power Meter to Test Set GEN Connector. |
| 3. | Set Power Meter Frequency to 501.0 MHz. |
| 4. | Set Test Set RF Generator Level to each setting in Table 4-1. Verify Power Meter Level readings for each Test Set RF Generator Level setting in Table 4-1. |

TEST SET RF GENERATOR LEVEL	POWER METER LEVEL
+10 dBm	+10 dBm (±1.0 dB)
0 dBm	0 dBm (±1.0 dB)
-10 dBm	-10 dBm (±1.0 dB)
-20 dBm	-20 dBm (±1.0 dB)
-30 dBm	-30 dBm (±1.0 dB)
-40 dBm	-40 dBm (±1.0 dB)
-50 dBm	-50 dBm (±1.0 dB)
-60 dBm	-60 dBm (±1.0 dB)

Table 4-1 Power Meter Level Settings - Generator Output Power

- If all readings are correct, go to Follow-up Procedures.
- If any reading is out of tolerance, perform the Test Set RF Generator Calibration Procedures.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

- | STEP | PROCEDURE |
|------|--|
| 1. | Press UTILS Key to access the Utilities Menu. |
| 2. | Select Store/Recall from menu. |
| 3. | When Store/Recall Tile opens, select Restore Factory Defaults Soft Key. |
| • | If this procedure is performed as part of System Verification, proceed to next Verification Procedure. |

4.13.3.D Generator Level Flatness

Pre-requisites: Initial Setup

Equipment: Power Meter

STEP	PROCEDURE
1.	Recall Verification Setup File 03. Wait for file to load.
2.	Connect Power Meter to Test Set GEN Connector.
3.	Set Test Set RF Generator Frequency and Power Meter Frequency to each frequency in Table 4-2. Verify Power Meter reading is 0 dBm (± 1.0 dB) for each frequency in Table 4-2.

All models start here

50 MHz	350 MHz	600 MHz	900 MHz
100 MHz	400 MHz	650 MHz	950 MHz
150 MHz	450 MHz	700 MHz	1000 MHz
200 MHz	500 MHz	750 MHz	1050 MHz
250 MHz	550 MHz	800 MHz	3901/3920 Stop Here
300 MHz	350 MHz	850 MHz	

3902/3920/3920B with frequency extension option continue to next table

1100 MHz	1550 MHz	2000 MHz	2400 MHz
1150 MHz	1600 MHz	2050 MHz	2450 MHz
1200 MHz	1650 MHz	2100 MHz	2500 MHz
1250 MHz	1700 MHz	2150 MHz	2550 MHz
1300 MHz	1750 MHz	1900 MHz	2600 MHz
1350 MHz	1800 MHz	2200 MHz	2650 MHz
1400 MHz	1850 MHz	2250 MHz	2700 MHz
1450 MHz	1900 MHz	2300 MHz	
1500 MHz	1950 MHz	2350 MHz	

Table 4-2 Test Set Generator Frequencies - Generator Level Flatness

- If all readings are correct, go to Follow-up Procedures.
- If any reading is out of tolerance, perform the Test Set RF Generator Calibration Procedures.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.E Generator T/R Power Level Accuracy

Pre-requisites: Initial Setup

Equipment: Power Meter

STEP	PROCEDURE
1.	Recall Verification Setup File 04. Wait for file to load.
2.	Connect Power Meter to Test Set T/R Connector.
3.	Set Power Meter Frequency to 501.0 MHz.
4.	Set Test Set Power Level to each setting in Table 4-3. Verify Power Meter Level reading is within tolerance indicated in Table 4-3 for each Test Set Power Level setting.

TEST SET POWER LEVEL	POWER METER LEVEL
-30.0 dBm	-30 dBm (±1 dB)
-40.0 dBm	-40 dBm (±1 dB)
-50.0 dBm	-50 dBm (±1 dB)
-60.0 dBm	-60 dBm (±1 dB)

Table 4-3 Power Meter Settings - Generator T/R Power Level Accuracy

- If all readings are correct, go to Follow-up Procedures.
- If any reading is out of tolerance, perform the Test Set RF Generator Calibration Procedures.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.F Generator T/R Power Level Flatness

Pre-requisites: Initial Setup

Equipment: Power Meter

STEP	PROCEDURE
1.	Recall Verification Setup File 05. Wait for file to load.
2.	Connect Power Meter to Test Set T/R Connector.
3.	Set Test Set RF Generator Frequency and Power Meter Frequency to each frequency in Table 4-4. Verify Power Meter reading is -30 dBm (± 1 dB) for each frequency in Table 4-4.

All models start here

50 MHz	350 MHz	600 MHz	900 MHz
100 MHz	400 MHz	650 MHz	950 MHz
150 MHz	450 MHz	700 MHz	1000 MHz
200 MHz	500 MHz	750 MHz	1050 MHz
250 MHz	550 MHz	800 MHz	3901/3920 Stop Here
300 MHz	350 MHz	850 MHz	

3902/3920/3920B with frequency extension option continue to next table

1100 MHz	1550 MHz	2000 MHz	2400 MHz
1150 MHz	1600 MHz	2050 MHz	2450 MHz
1200 MHz	1650 MHz	2100 MHz	2500 MHz
1250 MHz	1700 MHz	2150 MHz	2550 MHz
1300 MHz	1750 MHz	1900 MHz	2600 MHz
1350 MHz	1800 MHz	2200 MHz	2650 MHz
1400 MHz	1850 MHz	2250 MHz	2700 MHz
1450 MHz	1900 MHz	2300 MHz	
1500 MHz	1950 MHz	2350 MHz	

Table 4-4 Test Set Generator Frequencies - Generator T/R Power Level Flatness

- If all readings are correct, go to Follow-up Procedures.
- If any reading is out of tolerance, perform the Test Set RF Generator Calibration Procedures.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.G RF Power Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 06. Wait for file to load.
2.	After file loads press ZERO on Test Set Meters Tile.
3.	Connect RF Generator to Test Set T/R Connector.
4.	Set RF Generator Frequency to 500 MHz.
5.	Set RF Generator Power Level to 10.5 dBm.
6.	Verify Test Set Power Meter reading is 10.5 dBm (± 0.42 dBm). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a Test Set hardware failure. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.H Inband Power Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator
 Power Splitter
 Power Meter

- | STEP | PROCEDURE |
|------|---|
| 1. | Recall Verification Setup File 07. Wait for file to load. |
| 2. | Press Calibrate on Meters Tile. |
| 3. | Verify No User Cal Errors is displayed on Test Set. |
| 4. | Connect common port of Power Splitter to RF Generator. |
| 5. | Connect one port of Power Splitter to Test Set ANT Connector. |
| 6. | Connect other port of Power Splitter to Power Meter. |
| 7. | Set RF Generator Level to settings in Table 4-5. Record Power Meter reading as Nominal Value for each setting in Table 4-5. |

RF GENERATOR SETTINGS	Test Set RSSI METER
500 MHz at -60 dBm	-60.0 dBm (±1.0 dB)
500 MHz at -50 dBm	-50.0 dBm (±1.0 dB)
500 MHz at -40 dBm	-40.0 dBm (±1.0 dB)
500 MHz at -30 dBm	-30.0 dBm (±1.0 dB)
500 MHz at -20 dBm	-20.0 dBm (±1.0 dB)

Table 4-5 RF Generator Settings - Inband Power Meter Accuracy

- | | |
|----|--|
| 8. | Record Test Set Inband Power Meter reading for each RF Generator Level setting in Table 4-5. |
| 9. | Subtract Nominal value from Test Set Inband Power Meter reading. Verify difference is <1.0 dBm. <ul style="list-style-type: none"> • If all readings are correct, go to Follow-up Procedures. • If any reading is out of tolerance, perform the Test Set Receiver Calibration Procedure. |

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

- | STEP | PROCEDURE |
|------|--|
| 1. | Press UTILS Key to access the Utilities Menu. |
| 2. | Select Store/Recall from menu. |
| 3. | When Store/Recall Tile opens, select Restore Factory Defaults Soft Key. |
| • | If this procedure is performed as part of System Verification, proceed to next Verification Procedure. |

4.13.3.I Analyzer Level Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator
 Power Splitter
 Power Meter

- | STEP | PROCEDURE |
|------|---|
| 1. | Recall Verification Setup File 08. Wait for file to load. |
| 2. | After file loads press UTILS Key twice. Select User Calibration from floating menu. |
| 3. | Press Run User Calibration Soft Key to normalize Test Set. |
| 4. | When progress bar disappears press TEST Key to return to Spectrum Analyzer Tile. |
| 5. | Connect common port of Power Splitter to RF Generator. |
| 6. | Connect one port of Power Splitter to Test Set ANT Connector. |
| 7. | Connect other port of Power Splitter to Power Meter. |
| 8. | Set RF Generator Frequency and Power Meter Frequency to 10 MHz. |
| 9. | Set RF Generator Power Level to -30 dBm. |
| 10. | Record Power Meter reading as Nominal value. |
| 11. | Verify Spectrum Analyzer Center Frequency is set to 10 MHz. |
| 12. | Press Spectrum Analyzer Markers Soft Key. |
| 13. | Press Mkr 1 Soft Key, then the Mkr 1 to PK Soft Key. |
| 14. | Record Marker 1 Level reading from the Spectrum Analyzer. |
| 15. | Subtract Marker 1 Level reading from Power Meter reading. Verify difference between Power Meter reading and Marker 1 Level reading is $< \pm 1.0$ dB. |
| 16. | Repeat Steps 8 through 15 for each frequency listed in Table 4-6: |

All models start here

50 MHz	350 MHz	600 MHz	900 MHz
100 MHz	400 MHz	650 MHz	950 MHz
150 MHz	450 MHz	700 MHz	1000 MHz
200 MHz	500 MHz	750 MHz	1050 MHz
250 MHz	550 MHz	800 MHz	3901/3920 Stop Here
300 MHz	350 MHz	850 MHz	

3902/3920/3920B with frequency extension option continue to next table

1100 MHz	1550 MHz	2000 MHz	2400 MHz
1150 MHz	1600 MHz	2050 MHz	2450 MHz
1200 MHz	1650 MHz	2100 MHz	2500 MHz
1250 MHz	1700 MHz	2150 MHz	2550 MHz
1300 MHz	1750 MHz	1900 MHz	2600 MHz
1350 MHz	1800 MHz	2200 MHz	2650 MHz
1400 MHz	1850 MHz	2250 MHz	2700 MHz
1450 MHz	1900 MHz	2300 MHz	
1500 MHz	1950 MHz	2350 MHz	

Table 4-6 RF Generator Frequencies - Analyzer Level Accuracy

STEP	PROCEDURE
	<ul style="list-style-type: none">• If all readings are correct, go to Follow-up Procedures.• If any reading is out of tolerance, perform the Test Set Receiver Calibration Procedures.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.J Generator FM Residual

Pre-requisites: Initial Setup
Equipment: Modulation Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 09. Wait for file to load.
2.	Connect Modulation Analyzer to Test Set GEN Connector.
3.	Set Modulation Analyzer for 300 Hz to 3 kHz post-detection filtering. Verify Detector setting on Modulation Analyzer is RMS.
4.	Record Residual FM Level reading. Verify Modulation Analyzer FM Level reading is <15 Hz. <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Generator Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.K Generator AM Residual

Pre-requisites: Initial Setup
Equipment: Modulation Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 10. Wait for file to load.
2.	Connect Modulation Analyzer to Test Set GEN Connector.
3.	Set Modulation Analyzer for 300 Hz to 3 kHz post-detection filtering. Verify Detector setting on Modulation Analyzer is Peak + (default setting).
4.	Record Modulation Analyzer Residual AM Level reading. Verify Modulation Analyzer AM Level reading is <0.1%. <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Generator Assy, CAI Module Assy, DAM Carrier Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.L Generator FM Deviation Accuracy

Pre-requisites: Initial Setup
Generator FM Residual Verification Procedure
Equipment: Modulation Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 11. Wait for file to load.
2.	Connect Modulation Analyzer to Test Set GEN Connector.
3.	Set Modulation Analyzer to measure FM with the 15 kHz LP Filter selected. Verify Detector setting on Modulation Analyzer is Peak + (default setting).
4.	Record Modulation Analyzer FM Deviation reading.
5.	Subtract the Residual FM Level reading recorded in Step 4 of the Generator FM Residual Verification Procedure from the Modulation Analyzer FM Deviation reading recorded in Step 4 (above). Verify FM deviation is 10 kHz (± 0.30 kHz). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, DAM Carrier Assy or Generator Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.M Generator FM Modulation Rate

Pre-requisites: Initial Setup
 Generator FM Residual Verification Procedure
Equipment: Modulation Analyzer

STEP	PROCEDURE
------	-----------

1. Recall Verification Setup File 12. Wait for file to load.
2. Connect Modulation Analyzer to Test Set GEN Connector.
3. Set Modulation Analyzer to perform FM measurements with the 15 kHz LP Filter selected.
4. Set Test Set FM Modulation Rate to each setting in Table 4-7. Record Modulation Analyzer FM Deviation Level reading for each FM Modulation Rate in Table 4-7.

TEST SET (M1) AF FIELD	FM DEVIATION
50.0 Hz	6 kHz (± 0.18 kHz)
300.0 Hz	6 kHz (± 0.18 kHz)
10000.0 Hz	6 kHz (± 0.18 kHz)

Table 4-7 FM Modulation Rates - Generator FM Modulation Rate

5. To calculate the FM Deviation Level, subtract the FM Residual reading recorded in Step 4 of Generator FM Residual Verification Procedure from the Modulation Analyzer FM reading.
 - If all readings are correct, go to Follow-up Procedures.
 - If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, DAM Carrier Assy or Generator Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
------	-----------

1. Press UTILS Key to access the Utilities Menu.
 2. Select Store/Recall from menu.
 3. When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
- If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.N Generator FM Modulation Distortion

Pre-requisites: Initial Setup
Equipment: Modulation Analyzer
Audio Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 13. Wait for file to load.
2.	Connect Modulation Analyzer to Test Set GEN Connector.
3.	Set Modulation Analyzer to measure FM with the 3 kHz LP Filter selected.
4.	Connect Audio Analyzer to Modulation Analyzer Modulation Output Connector.
5.	Set Audio Analyzer LP Filter to 30 kHz.
6.	Verify Audio Analyzer Modulation Distortion reading is <1%. <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, DAM Carrier Assy or Generator Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.O Generator AM Modulation Accuracy

Pre-requisites: Initial Setup
Generator AM Residual Verification Procedure
Equipment: Modulation Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 14. Wait for file to load.
2.	Connect Modulation Analyzer to Test Set GEN Connector.
3.	Set Modulation Analyzer to perform AM measurements.
4.	Record Modulation Analyzer AM Modulation reading.
5.	Subtract the Modulation Analyzer AM Level reading recorded in Step 4 of the Generator AM Residual Verification Procedure from the Modulation Analyzer AM Modulation reading recorded in Step 4 (above). Verify AM Modulation is 30% ($\pm 1\%$). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, DAM Carrier Assy or Generator Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.P RF Offset Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 15. Wait for file to load.
2.	Connect RF Generator to Test Set T/R Connector.
3.	Set RF Generator Frequency to 1000.01 MHz. Set RF Generator Power Level to -20 dBm. Verify Test Set RF Offset Meter reading is +10000 Hz (± 1 Hz).
4.	Set RF Generator Frequency to 999.99 MHz. Set RF Generator Power Level to -20 dBm. Verify Test Set RF Offset Meter reading is -10000 Hz (± 1 Hz). <ul style="list-style-type: none"> • If all readings are correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, IF/Video PCB Assy, DAM Carrier Assy or Receiver Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.Q Demod Frequency Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 16. Wait for file to load.
2.	Connect RF Generator to Test Set ANT Connector.
3.	Set RF Generator Frequency to 100 MHz. Set RF Generator Power Level to -10.0 dBm.
4.	Set RF Generator to output a 6 kHz FM signal at a 1 kHz rate.
5.	Verify Test Set Demod Frequency reading is 1000 Hz (± 0.4 Hz). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, IF/Video PCB Assy, DAM Carrier Assy or Receiver Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.R FM Deviation Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 17. Wait for file to load.
2.	Connect RF Generator to Test Set ANT Connector.
3.	Set RF Generator Frequency to 100 MHz at -10.0 dBm. Verify Modulation is OFF.
4.	Record Modulation Analyzer reading as 8901 Residual.
5.	Record Test Set FM reading as 3900 Residual.
6.	Set RF Generator to output a 10 kHz FM signal with 1 kHz deviation rate.
7.	Record Modulation Analyzer reading as 8901 FM.
8.	Record Test Set FM reading as 3900 FM.
9.	Subtract the 8901 Residual from the 8901 FM reading, and record as 8901 Nominal.
10.	Subtract the 3900 Residual from the 3900 FM reading, and record as 3900 Measured.
11.	Verify the value measured on the Test Set is within ± 0.31 kHz of the 8901 Nominal value. <ul style="list-style-type: none"> • If reading is correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, IF/Video PCB Assy, DAM Carrier Assy or Receiver Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.S AM Modulation Meter Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 18. Wait for file to load.
2.	Connect RF Generator to Test Set ANT Connector.
3.	Set RF Generator Frequency to 100 MHz at -10.0 dBm. Verify Modulation is OFF.
4.	Record Modulation Analyzer reading as 8901 Residual.
5.	Record Test Set AM reading as 3900 Residual.
6.	Set RF Generator to output a 50% AM depth at a 1 kHz rate.
7.	Record Modulation Analyzer reading as 8901 AM.
8.	Record Test Set AM reading as 3900 AM.
9.	Subtract the 8901 Residual from the 8901 AM reading, and record as 8901 Nominal.
10.	Subtract the 3900 Residual from the 3900 AM reading, and record as 3900 Measured.
11.	Verify the 3900 Measured value is within $\pm 1.6\%$ of the 8901 Nominal value. <ul style="list-style-type: none"> • If reading is correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy, IF/Video PCB Assy, DAM Carrier Assy or Receiver Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.T Analyzer Frequency and Span Accuracy

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 19. Wait for file to load.
2.	Connect RF Generator to Test Set ANT Connector.
3.	Set RF Generator Frequency to 400 MHz. Set RF Generator Power Level to -20.0 dBm.
4.	Verify Spectrum Analyzer Center Frequency is set to 400 MHz.
5.	Press Spectrum Analyzer Markers Soft Key.
6.	Press Mkr 1 Soft Key then the Mkr 1 to PK Soft Key.
7.	Verify Marker 1 frequency reading is between 399.996500 MHz and 400.003500 MHz.
	<ul style="list-style-type: none"> • If reading is correct go to next step. • If reading is out of tolerance, this indicates a hardware failure in the 3900. Probable source of failure: IF/Video PCB Assy, Receiver Assy, or CAI PCB Assy. Return the 3900 to Aeroflex for repair.
8.	Select 500 MHz span from Span drop-down menu.
9.	Change RF Generator Frequency to 200 MHz.
10.	Press Mkr 1 to PK Soft Key to move Marker 1 to signal peak.
11.	Record Marker 1 frequency reading.
12.	Change RF Generator Frequency to 600 MHz.
13.	Press Mkr 1 to PK Soft Key to move Marker 1 to signal peak.
14.	Record Marker 1 frequency reading.
15.	Verify difference between the marker frequency recorded in Step 11 and the marker frequency recorded in Step 13 is between 395.000000 to 405.000000 MHz.
	<ul style="list-style-type: none"> • If reading is correct go to Follow-up Procedures. • If the reading is out of tolerance, perform the 3900 Analyzer Yig Sweep calibration procedure.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
	<ul style="list-style-type: none"> • If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.U Analyzer Bandwidth Switching Error

Pre-requisites: Initial Setup
Equipment: RF Generator

STEP	PROCEDURE
1.	Recall Verification Setup File 20. Wait for file to load.
2.	After file loads press UTILS Key twice. Select User Calibration from floating menu.
3.	Press Run User Calibration Soft Key to normalize Test Set.
4.	When User Calibration is complete, press TEST Key to return to Spectrum Analyzer Tile.
5.	Connect RF Generator to Test Set ANT Connector.
6.	Set RF Generator frequency to 500 MHz. Set RF Generator Power Level to -30.0 dBm.
7.	Verify RBW Filter is set to 300 Hz. Verify Span is set to 2.0 kHz.
8.	Verify Marker 1 is ON. Verify Marker 1 position is set to 500 MHz.
9.	Record 300 Hz RBW Filter Marker Level reading.
10.	Select 50 kHz from Span drop-down menu.
11.	Select 3 kHz from the RBW drop-down menu.
12.	Record 3 kHz RBW Filter Marker Level reading.
13.	Select 500 kHz from Span drop-down menu.
14.	Select 30 kHz from RBW Filter drop-down menu.
15.	Select 3 kHz VBW Filter drop-down menu.
16.	Record 30 kHz RBW Filter Marker Level reading.
17.	Select 1 MHz from Span drop-down menu.
18.	Select 60 kHz RBW Filter drop-down menu.
19.	Record 60 kHz RBW Filter Marker Level reading.
20.	Select 5 MHz from Span drop-down menu.
21.	Select 300 kHz from RBW Filter drop-down menu.
22.	Record 300 kHz from RBW Filter Marker Level reading.
23.	Select 20 MHz from Span drop-down menu.
24.	Select 6 MHz from RBW Filter drop-down menu.
25.	Record 6 MHz RBW Filter Marker Level reading.
26.	Subtract lowest recorded Marker Level reading from highest recorded Marker Level reading. Verify difference in readings is <1 dB. <ul style="list-style-type: none"> • If all readings are correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: IF/Video PCB Assy, CAI Module Assy or Receiver Assy. Contact Aeroflex Customer Service.

STEP	PROCEDURE
------	-----------

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
------	-----------

1. Press UTILS Key to access the Utilities Menu.
 2. Select Store/Recall from menu.
 3. When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
- If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.V Oscilloscope Amplitude Accuracy

Pre-requisites: Initial Setup
Equipment: Digital Multimeter
 10 k Ω Load

- | STEP | PROCEDURE |
|------|--|
| 1. | Recall Verification Setup File 21. Wait for file to load. |
| 2. | Connect a BNC-T Connector to Test Set FCTN GEN/Demod Out Connector. |
| 3. | Connect a coaxial cable from one end of BNC-T Connector to Digital Multimeter. Terminate connection with a 10 k Ω load. |
| 4. | Connect other end of BNC-T Connector to Test Set Scope Channel 1 Input Connector. |
| 5. | Maximize Scope Tile. |
| 6. | Verify Marker 1 and Marker 2 are ON. |
| 7. | Verify Marker 1 is set to 250 uS. Verify Marker 2 is set to 750 uS. Minimize Scope Tile. |
| 8. | Set Test Set Audio Function Generator Level to first value in Table 4-8. Record Digital Multimeter reading. |

3900 Function Generator Level	3900 V/Div	Error limit from Nominal Value
42.4 mVrms (120.0 mVp-p)	0.02	± 8 mV
106.1 mVrms (300.0 mVp-p)	0.05	± 20 mV
212.1 mVrms (600 mVp-p)	0.10	± 40 mV
424.2 mVrms (1200 mVp-p)	0.20	± 80 mV
1.061 Vrms (3.000 Vp-p)	0.50	± 200 mV
2.121 Vrms (6.000 Vp-p)	1.00	± 400 mV
4.242 Vrms (12.000 Vp-p)	2.00	± 800 mV

Table 4-8 Test Set Audio Function Generator Settings - Scope Amplitude Accuracy

9. Multiply Digital Multimeter reading recorded in Step 8 by 2.8289 and record results as Nominal Value.
10. Select Scope Tile. Press Toggle Marker Soft Key until Delta Level reading is displayed. Compare Marker Delta Level reading to nominal value recorded in Step 9. Verify Marker Delta reading is within the allowed limits specified in Table 4-8.
11. Repeat Steps 8 through 10 for all the levels in Table 4-8.
 - If all readings are correct, go to next step.
 - If reading is out of tolerance this indicates a Test Set hardware failure. Probable source of failure: Front Panel Analog PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.
12. Remove BNC-T Connector from Test Set Channel 1 Input Connector and connect to Test Set Channel 2 Input Connector.
13. Maximize Scope Tile.
14. Select Channel 2 from Trace A Source drop-down menu. Minimize Scope Tile.
15. Set Test Set Audio Function Generator Level to values listed in Table 4-8.
16. Record the Digital Multimeter Level reading for each Audio Function Generator Level in Table 4-8.
17. Multiply each Digital Multimeter Level reading recorded in Step 16 by 2.8289 and record result as the Nominal Value.

STEP	PROCEDURE
18.	Select Scope Tile. Press Toggle Marker Soft Key until Delta Level reading is displayed. Compare Marker Delta Level reading to nominal value recorded in Step 17. Verify Marker Delta reading is within the allowed limits specified in Table 4-8.
19.	Repeat Steps 15 through 18 for all the levels in Table 4-8. <ul style="list-style-type: none">• If all readings are correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Front Panel Analog PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.W Audio Level Meter Accuracy

Pre-requisites: Initial Setup
Equipment: Digital Multimeter

STEP	PROCEDURE
1.	Recall Verification Setup File 22. Wait for file to load.
2.	Connect a BNC-T Connector to Test Set FCTN GEN/Demod Out Connector.
3.	Connect a coaxial cable from one end of the BNC-T Connector to Digital Multimeter.
4.	Connect other end of the BNC-T Connector to Test Set Audio In 1 Connector.
5.	Verify Test Set Audio Function Generator 1 Level is set to 200 mV and Audio Function Generator 1 (A1) is enabled.
6.	Verify Test Set AF Level Meter reading is within $\pm 10\%$ of Digital Multimeter reading.
7.	Set Test Set Audio Function Generator 1 (A1) Level to 1.000 V.
8.	Verify Test Set AF Level Meter reading is within $\pm 10\%$ of Digital Multimeter reading. <ul style="list-style-type: none"> • If all readings are correct, go to next step. • If Reading is out of tolerance this indicates a Test Set hardware failure. Probable source of failure: Front Panel Analog PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.
9.	Maximize Analyzers Tile. Set Source field to Audio 2. Minimize Analyzers Tile.
10.	Move coaxial cable from Audio In 1 Connector to Audio In 2 Connector.
11.	Verify Test Set Audio Function Generator 1 (A1) Level is set to 1.000 V.
12.	Verify Test Set AF Level Meter reading is within $\pm 10\%$ of Digital Multimeter reading.
13.	Set Test Set Audio Function Generator 1 (A1) Level to 200 mV.
14.	Verify Test Set AF Level Meter reading is within $\pm 10\%$ of Digital Multimeter reading. <ul style="list-style-type: none"> • If all readings are correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.X Function Generator Level Accuracy

Pre-requisites: Initial Setup
Equipment: Digital Multimeter
10 k Ω Load

STEP	PROCEDURE
1.	Recall Verification Setup File 23. Wait for file to load.
2.	Connect coaxial cable from FCTN GEN/Demod Out Connector to Digital Multimeter. Terminate connection with a 10 k Ω Load.
3.	Set Digital Multimeter to perform AC Volt measurements.
4.	Verify Digital Multimeter Level reading is 5.000 Vrms (± 50 mVrms). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures• If reading is out of tolerance, perform Function Generator Calibration Procedure.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.Y Function Generator Frequency Accuracy

Pre-requisites: Initial Setup
Equipment: Frequency Counter
10 k Ω Load

STEP	PROCEDURE
1.	Recall Verification Setup File 24. Wait for file to load.
2.	Connect coaxial cable from FCTN GEN/Demod Out Connector to Frequency Counter. Terminate connection with a 10 k Ω Load.
3.	Verify Frequency Counter Frequency reading is 5000 Hz (± 0.25 Hz). <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Front Panel Audio PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.Z Function Generator Total Harmonic Distortion

Pre-requisites: Initial Setup
Equipment: Audio Analyzer
10 k Ω Load

STEP	PROCEDURE
1.	Recall Verification Setup File 25. Wait for file to load.
2.	Connect coaxial cable from FCTN GEN/Demod Out Connector to Audio Analyzer. Terminate connection with a 10 k Ω Load.
3.	Verify Audio Analyzer total harmonic output reading is <0.5%. <ul style="list-style-type: none">• If reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Front Panel Audio PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.AA Audio Frequency Meter Accuracy

Pre-requisites: Initial Setup

Equipment: Frequency Counter

STEP	PROCEDURE
1.	Recall Verification Setup File 26. Wait for file to load.
2.	Connect a BNC-T Connector to Test Set FCTN GEN/Demod Out Connector.
3.	Connect a coaxial cable from one end of BNC-T Connector to Frequency Counter.
4.	Connect other end of BNC-T Connector to Test Set Audio In 1 Connector.
5.	Verify Test Set Audio Frequency Meter reading is within ± 0.4 Hz of Frequency Counter reading. <ul style="list-style-type: none">• If the reading is correct, go to Follow-up Procedures.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Front Panel Audio PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key.
•	If this procedure is performed as part of System Verification, proceed to next Verification Procedure.

4.13.3.AB Sinad/Distortion Meter Accuracy

Pre-requisites: Initial Setup
Equipment: Audio Analyzer

STEP	PROCEDURE
1.	Recall Verification Setup File 27. Wait for file to load.
2.	Connect a BNC-T Connector to Test Set FCTN GEN/Demod Out Connector.
3.	Connect a coaxial cable from one end of BNC-T Connector to Audio Analyzer.
4.	Connect other end of BNC-T Connector to Test Set Audio In 1 Connector.
5.	Record Test Set Sinad Meter reading on Analyzers Tile.
6.	Record Audio Analyzer Sinad reading.
7.	Verify Test Set Sinad Meter reading is within ± 1.01 dB of Audio Analyzer Sinad reading. <ul style="list-style-type: none"> • If the reading is correct, go to next step. • If Reading is out of tolerance, this indicates a Test Set hardware failure. Probable source of failure: Front Panel Audio PCB Assy. Contact Aeroflex Customer Service.
8.	Select Analyzers Tile. Press Noise Meters Soft Key.
9.	Press AF Meter Soft Key until DISTN is selected.
10.	Select Generator Tile. Set Fgen Source A2 Level to 200 mV.
11.	Verify Test Set Distortion Meter reading is within $\pm 0.5\%$ of Audio Analyzer Distortion reading. <ul style="list-style-type: none"> • If reading is correct, go to Follow-up Procedures. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: Front Panel Audio PCB Assy, Front Panel Digital PCB Assy or CAI Module Assy. Contact Aeroflex Customer Service.

Follow-up Procedures

Perform one of the following:

- If this procedure was performed as a stand-alone procedure, perform the following procedure to reset the Factory Default Settings, then remove power from the Test Set and disconnect the test equipment.

STEP	PROCEDURE
1.	Press UTILS Key to access the Utilities Menu.
2.	Select Store/Recall from menu.
3.	When Store/Recall Tile opens, select Restore Factory Defaults Soft Key. <ul style="list-style-type: none"> • If this procedure was performed as part of System Verification, and the Test Set does not have a DMM installed, System Verification is complete. • If this procedure was performed as part of System Verification, and the Test Set has a DMM installed, proceed to next Verification Procedure.

4.13.3.AC DMM Functionality/Accuracy

Pre-requisites: Initial Setup

Equipment: Calibrator

STEP	PROCEDURE
1.	Recall Verification Setup File 28. Wait for file to load.
2.	Verify DMM is set to read DC Volts.
3.	Verify DMM Scale is set to AUTO SCALE. Verify Peak Hold is OFF.
4.	Insert Banana Patch Cable from DMM Positive Input to DMM Negative Input shorting the inputs.
5.	Record DMM reading. Verify DMM reads 0.0 DC Volts (± 10 mV). <ul style="list-style-type: none"> • If reading is correct, go to next step. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
6.	Connect Calibrator to DMM Input. Observe correct polarity.
7.	Set Calibrator to output 10 DC volts.
8.	Record DMM reading. Verify DMM reads 10 DC Volts (± 0.2 V). <ul style="list-style-type: none"> • If reading is correct, go to next step. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
9.	Set DMM to read AC Volts.
10.	Set Calibrator to output 10 AC volts at 60 Hz.
11.	Record DMM reading. Verify DMM reads 10 AC Volts (± 1.0 V). <ul style="list-style-type: none"> • If reading is correct, go to next step. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
12.	Set Calibrator to supply 1,000 Ω resistance.
13.	Set DMM to read Ω . Set DMM Scale to 2 k Ω .
14.	Disconnect all connections from DMM. Record DMM reading. Verify DMM reads 2 k Ω +++ indicating an open. <ul style="list-style-type: none"> • If reading is correct, go to next step. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
15.	Connect Banana Patch Cable from DMM Positive Input to DMM Negative Input shorting the inputs.
16.	Record DMM reading. Verify DMM reads 0 Ω (± 1.0 Ω) indicating a short. <ul style="list-style-type: none"> • If reading is correct, go to next step. • If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
17.	Connect Calibrator the DMM inputs. Set Calibrator to 1 k Ω .

Verification/Calibration Procedures

STEP	PROCEDURE
18.	Record DMM reading. Verify DMM reads 1,000 Ω ($\pm 50 \Omega$). <ul style="list-style-type: none">• If reading is correct, go to next step.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
19.	Set DMM to read DC Amps. Set DMM to AUTO SCALE.
20.	Connect Calibrator to DMM current inputs using Banana Patch Cable. Observe correct polarity.
21.	Set Calibrator to supply 1 DC Amp.
22.	Record DMM reading. Verify DMM reads 1 Amp (± 0.05 Amp). <ul style="list-style-type: none">• If reading is correct, go to next step.• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.
23.	Set DMM to read AC Amps.
24.	Set Calibrator to supply 1 AC Amp at 60 Hz.
25.	Record DMM reading. Verify DMM reads 1 Amp (± 0.05 Amp). <ul style="list-style-type: none">• If reading is out of tolerance, this indicates a hardware failure in the Test Set. Probable source of failure: DMM module. Contact Aeroflex Customer Service.• If this procedure was performed as part of System Verification, System Verification is complete.

4.14 VERIFICATION DATA SHEET

Technician: _____ Date: _____
 Test Set S/N: _____

STEP	PROCEDURE
------	-----------

4.13.3.B, Generator Output Frequency

6.	1 GHz (± 101 Hz)	_____
----	-----------------------	-------

4.13.3.C, Generator Output Power

4.	+10 dBm	+10 dBm (± 1.0 dB)	_____
	0 dBm	0 dBm (± 1.0 dB)	_____
	-10 dBm	-10 dBm (± 1.0 dB)	_____
	-20 dBm	-20 dBm (± 1.0 dB)	_____
	-30 dBm	-30 dBm (± 1.0 dB)	_____
	-40 dBm	-40 dBm (± 1.0 dB)	_____
	-50 dBm	-50 dBm (± 1.0 dB)	_____
	-60 dBm	-60 dBm (± 1.0 dB)	_____

4.13.3.D, Generator Level Flatness

3.	50 MHz	0 dBm (± 1 dB)	_____
	100 MHz	0 dBm (± 1 dB)	_____
	150 MHz	0 dBm (± 1 dB)	_____
	200 MHz	0 dBm (± 1 dB)	_____
	250 MHz	0 dBm (± 1 dB)	_____
	300 MHz	0 dBm (± 1 dB)	_____
	350 MHz	0 dBm (± 1 dB)	_____
	400 MHz	0 dBm (± 1 dB)	_____
	450 MHz	0 dBm (± 1 dB)	_____
	500 MHz	0 dBm (± 1 dB)	_____
	550 MHz	0 dBm (± 1 dB)	_____
	600 MHz	0 dBm (± 1 dB)	_____
	650 MHz	0 dBm (± 1 dB)	_____
	700 MHz	0 dBm (± 1 dB)	_____
	750 MHz	0 dBm (± 1 dB)	_____
	800 MHz	0 dBm (± 1 dB)	_____
	850 MHz	0 dBm (± 1 dB)	_____
	900 MHz	0 dBm (± 1 dB)	_____
	950 MHz	0 dBm (± 1 dB)	_____
	1000 MHz	0 dBm (± 1 dB)	_____
	1050 MHz	0 dBm (± 1 dB)	_____

3901 / 3920 Stop Here

3902 / 3920 /3920B with frequency extension option continue

STEP	PROCEDURE
------	-----------

4.13.3.D, Generator Level Flatness (cont)

3.	1100 MHz	0 dBm (± 1 dB)	_____
	1150 MHz	0 dBm (± 1 dB)	_____
	1200 MHz	0 dBm (± 1 dB)	_____
	1250 MHz	0 dBm (± 1 dB)	_____
	1300 MHz	0 dBm (± 1 dB)	_____
	1350 MHz	0 dBm (± 1 dB)	_____
	1400 MHz	0 dBm (± 1 dB)	_____
	1450 MHz	0 dBm (± 1 dB)	_____
	1500 MHz	0 dBm (± 1 dB)	_____
	1550 MHz	0 dBm (± 1 dB)	_____
	1600 MHz	0 dBm (± 1 dB)	_____
	1650 MHz	0 dBm (± 1 dB)	_____
	1700 MHz	0 dBm (± 1 dB)	_____
	1750 MHz	0 dBm (± 1 dB)	_____
	1800 MHz	0 dBm (± 1 dB)	_____
	1850 MHz	0 dBm (± 1 dB)	_____
	1900 MHz	0 dBm (± 1 dB)	_____
	1950 MHz	0 dBm (± 1 dB)	_____
	2000 MHz	0 dBm (± 1 dB)	_____
	2050 MHz	0 dBm (± 1 dB)	_____
	2100 MHz	0 dBm (± 1 dB)	_____
	2150 MHz	0 dBm (± 1 dB)	_____
	2200 MHz	0 dBm (± 1 dB)	_____
	2250 MHz	0 dBm (± 1 dB)	_____
	2300 MHz	0 dBm (± 1 dB)	_____
	2350 MHz	0 dBm (± 1 dB)	_____
	2400 MHz	0 dBm (± 1 dB)	_____
	2450 MHz	0 dBm (± 1 dB)	_____
	2500 MHz	0 dBm (± 1 dB)	_____
	2550 MHz	0 dBm (± 1 dB)	_____
	2600 MHz	0 dBm (± 1 dB)	_____
	2650 MHz	0 dBm (± 1 dB)	_____
	2700 MHz	0 dBm (± 1 dB)	_____

4.13.3.E, Generator T/R Power Level Accuracy

4.	-30 dBm	-30 dBm (± 1 dB)	_____
	-40 dBm	-40 dBm (± 1 dB)	_____
	-50 dBm	-50 dBm (± 1 dB)	_____
	-60 dBm	-60 dBm (± 1 dB)	_____

STEP PROCEDURE

4.13.3.F, Generator T/R Power Level Flatness

STEP	PROCEDURE
3.	50 MHz -30 dBm (± 1 dB)
	100 MHz -30 dBm (± 1 dB)
	150 MHz -30 dBm (± 1 dB)
	200 MHz -30 dBm (± 1 dB)
	250 MHz -30 dBm (± 1 dB)
	300 MHz -30 dBm (± 1 dB)
	350 MHz -30 dBm (± 1 dB)
	400 MHz -30 dBm (± 1 dB)
	450 MHz -30 dBm (± 1 dB)
	500 MHz -30 dBm (± 1 dB)
	550 MHz -30 dBm (± 1 dB)
	600 MHz -30 dBm (± 1 dB)
	650 MHz -30 dBm (± 1 dB)
	700 MHz -30 dBm (± 1 dB)
	750 MHz -30 dBm (± 1 dB)
	800 MHz -30 dBm (± 1 dB)
	850 MHz -30 dBm (± 1 dB)
	900 MHz -30 dBm (± 1 dB)
	950 MHz -30 dBm (± 1 dB)
	1000 MHz -30 dBm (± 1 dB)
	1050 MHz -30 dBm (± 1 dB)

3901 / 3920 Stop Here

3902 / 3920 /3920B with frequency extension option continue

STEP PROCEDURE

4.13.3.F, Generator T/R Power Level Flatness(cont)

3.	1100 MHz	-30 dBm (± 1 dB)	
	1150 MHz	-30 dBm (± 1 dB)	
	1200 MHz	-30 dBm (± 1 dB)	
	1250 MHz	-30 dBm (± 1 dB)	
	1300 MHz	-30 dBm (± 1 dB)	
	1350 MHz	-30 dBm (± 1 dB)	
	1400 MHz	-30 dBm (± 1 dB)	
	1450 MHz	-30 dBm (± 1 dB)	
	1500 MHz	-30 dBm (± 1 dB)	
	1550 MHz	-30 dBm (± 1 dB)	
	1600 MHz	-30 dBm (± 1 dB)	
	1650 MHz	-30 dBm (± 1 dB)	
	1700 MHz	-30 dBm (± 1 dB)	
	1750 MHz	-30 dBm (± 1 dB)	
	1800 MHz	-30 dBm (± 1 dB)	
	1850 MHz	-30 dBm (± 1 dB)	
	1900 MHz	-30 dBm (± 1 dB)	
	1950 MHz	-30 dBm (± 1 dB)	
	2000 MHz	-30 dBm (± 1 dB)	
	2050 MHz	-30 dBm (± 1 dB)	
	2100 MHz	-30 dBm (± 1 dB)	
	2150 MHz	-30 dBm (± 1 dB)	
	2200 MHz	-30 dBm (± 1 dB)	
	2250 MHz	-30 dBm (± 1 dB)	
	2300 MHz	-30 dBm (± 1 dB)	
	2350 MHz	-30 dBm (± 1 dB)	
	2400 MHz	-30 dBm (± 1 dB)	
	2450 MHz	-30 dBm (± 1 dB)	
	2500 MHz	-30 dBm (± 1 dB)	
	2550 MHz	-30 dBm (± 1 dB)	
	2600 MHz	-30 dBm (± 1 dB)	
	2650 MHz	-30 dBm (± 1 dB)	
	2700 MHz	-30 dBm (± 1 dB)	

4.13.3.G, RF Power Meter Accuracy

6.	10.5 dBm (± 0.4 dB)	
----	--------------------------	--

Verification/Calibration Procedures

STEP PROCEDURE

4.13.3.H, Inband Power Meter Accuracy

3. No User Cal Errors message

RF Generator Level	7. Nominal Value	8. 3900 Inband Power Meter	9. Difference is <±1 dB
-60 dBm	_____	_____	_____
-50 dBm	_____	_____	_____
-40 dBm	_____	_____	_____
-30 dBm	_____	_____	_____
-20 dBm	_____	_____	_____

4.13.3.I, Analyzer Level Accuracy

	10. Nominal Value	14. Marker 1 Level Reading	15. Difference is <±1 dB
10 MHz	_____	_____	_____
50 MHz	_____	_____	_____
100 MHz	_____	_____	_____
150 MHz	_____	_____	_____
200 MHz	_____	_____	_____
250 MHz	_____	_____	_____
300 MHz	_____	_____	_____
350 MHz	_____	_____	_____
400 MHz	_____	_____	_____
450 MHz	_____	_____	_____
500 MHz	_____	_____	_____
550 MHz	_____	_____	_____
600 MHz	_____	_____	_____
650 MHz	_____	_____	_____
700 MHz	_____	_____	_____
750 MHz	_____	_____	_____
800 MHz	_____	_____	_____
850 MHz	_____	_____	_____
900 MHz	_____	_____	_____
950 MHz	_____	_____	_____
1000 MHz	_____	_____	_____
1050 MHz	_____	_____	_____

3901 / 3920 Stop Here

3902 / 3920 /3920B with frequency extension option continue

Verification/Calibration Procedures

STEP PROCEDURE

4.13.3.I, Analyzer Level Accuracy (cont)

	10. Nominal Value	14. Marker 1 Level Reading	15. Difference is $\leq \pm 1\text{ dB}$
1100 MHz	_____	_____	_____
1150 MHz	_____	_____	_____
1200 MHz	_____	_____	_____
1250 MHz	_____	_____	_____
1300 MHz	_____	_____	_____
1350 MHz	_____	_____	_____
1400 MHz	_____	_____	_____
1450 MHz	_____	_____	_____
1500 MHz	_____	_____	_____
1550 MHz	_____	_____	_____
1600 MHz	_____	_____	_____
1650 MHz	_____	_____	_____
1700 MHz	_____	_____	_____
1750 MHz	_____	_____	_____
1800 MHz	_____	_____	_____
1850 MHz	_____	_____	_____
1900 MHz	_____	_____	_____
1950 MHz	_____	_____	_____
2000 MHz	_____	_____	_____
2050 MHz	_____	_____	_____
2100 MHz	_____	_____	_____
2150 MHz	_____	_____	_____
2200 MHz	_____	_____	_____
2250 MHz	_____	_____	_____
2300 MHz	_____	_____	_____
2350 MHz	_____	_____	_____
2400 MHz	_____	_____	_____
2450 MHz	_____	_____	_____
2500 MHz	_____	_____	_____
2550 MHz	_____	_____	_____
2600 MHz	_____	_____	_____
2650 MHz	_____	_____	_____
2700 MHz	_____	_____	_____

Verification/Calibration Procedures

STEP	PROCEDURE
4.13.3.J, Generator FM Residual	
4.	Record Generator FM Level reading Modulation Analyzer FM Level <15 Hz rms
4.13.3.K, Generator AM Residual	
4.	Record Residual AM Level reading Modulation Analyzer AM Level <0.1%
4.13.3.L, Generator FM Deviation Accuracy	
4.	Record FM Deviation reading FM Residual reading from Step 4 of the Generator FM Residual Verification Procedure
5.	Subtract FM Residual reading from FM Deviation reading FM deviation is 10 kHz (± 0.30 kHz)
4.13.3.M, Generator FM Modulation Rate	
4.	Record FM Deviation readings 50.0 Hz 300.0 Hz 10000.0 Hz FM Residual reading from Step 4 of the Generator FM Residual Verification Procedure
5.	Subtract FM Residual reading from each Modulation Analyzer FM reading 50.0 Hz (6 kHz (± 0.18 kHz)) 300.0 Hz (6 kHz (± 0.18 kHz)) 10000.0 Hz (6 kHz (± 0.18 kHz))
4.13.3.N, Generator FM Modulation Distortion	
6.	Modulation Distortion is <1%
4.13.3.O, Generator AM Modulation Accuracy	
4.	Record AM Modulation reading Residual AM Level reading Step 4 of the Generator AM Residual Verification Procedure
5.	Subtract AM Level reading from AM Modulation reading AM Modulation is 30% ($\pm 1\%$)
4.13.3.P, RF Offset Meter Accuracy	
3.	RF Offset Meter +10000 Hz (± 1 Hz)
5.	RF Offset Meter -10000 Hz (± 1 Hz)
4.13.3.Q, Demod Frequency Meter Accuracy	
5.	Demod Frequency 1000 Hz (± 0.4 Hz)

Verification/Calibration Procedures

STEP	PROCEDURE
------	-----------

4.13.3.R, FM Deviation Meter Accuracy

- | | | | |
|-----|---------------|-------|-----|
| 4. | 8901 Residual | _____ | kHz |
| 5. | 3900 Residual | _____ | kHz |
| 7. | 8901 FM | _____ | kHz |
| 8. | 3900 FM | _____ | kHz |
| 9. | 8901 Nominal | _____ | kHz |
| 10. | 3900 Measured | _____ | kHz |

4.13.3.S, AM Modulation Meter Accuracy

- | | | | |
|-----|---------------|-------|---|
| 4. | 8901 Residual | _____ | % |
| 5. | 3900 Residual | _____ | % |
| 7. | 8901 FM | _____ | % |
| 8. | 3900 FM | _____ | % |
| 9. | 8901 Nominal | _____ | % |
| 10. | 3900 Measured | _____ | % |

4.13.3.T, Analyzer Frequency and Span Accuracy

- | | | |
|-----|--|-------|
| 6. | Marker Frequency (400.000000 MHz \pm 0.003500 MHz) | _____ |
| 10. | 200 MHz Marker Frequency | _____ |
| 13. | 600 MHz Marker Frequency | _____ |
| 14. | Difference (400.000000 MHz \pm 5.000000 MHz) | _____ |

4.13.3.U, Analyzer Bandwidth Switching Error

- | | | |
|-----|---|-------|
| 9. | 300 Hz RBW Filter Marker Level reading | _____ |
| 12. | 3 kHz RBW Filter Marker Level reading | _____ |
| 16. | 30 kHz RBW Filter Marker Level reading | _____ |
| 19. | 60 kHz RBW Filter Marker Level reading | _____ |
| 22. | 300 kHz RBW Filter Marker Level reading | _____ |
| 25. | 6 MHz RBW Filter Marker Level reading | _____ |
| 26. | Difference between highest and lowest Marker Level readings <1 dB | _____ |

STEP PROCEDURE

4.13.3.V, Oscilloscope Amplitude Accuracy

8 - 10. Channel 1 Input Connector

3900 AF Generator Level	8. DMM Reading	9. Nominal Value	10. Marker Delta Level	Tolerance (Nominal ±)	Within Limits
42.4 mVrms (120.0 mVp-p)	_____	_____	_____	(±8 mV)	_____
106.1 mVrms (300.0 mVp-p)	_____	_____	_____	(±20 mV)	_____
212.1 mVrms (600 mVp-p)	_____	_____	_____	(±40 mV)	_____
424.2 mVrms (1200 mVp-p)	_____	_____	_____	(±80 mV)	_____
1.061 Vrms (3.000 Vp-p)	_____	_____	_____	(±200 mV)	_____
2.121 Vrms (6.000 Vp-p)	_____	_____	_____	(±400 mV)	_____
4.242 Vrms (12.000 Vp-p)	_____	_____	_____	(±800 mV)	_____

16 - 18. Channel 2 Input Connector

3900 AF Generator Level	16. DMM Reading	17. Nominal Value	18. Marker Delta Level	Tolerance (Nominal ±)	Within Limits
42.4 mVrms (120.0 mVp-p)	_____	_____	_____	(±8 mV)	_____
106.1 mVrms (300.0 mVp-p)	_____	_____	_____	(±20 mV)	_____
212.1 mVrms (600 mVp-p)	_____	_____	_____	(±40 mV)	_____
424.2 mVrms (1200 mVp-p)	_____	_____	_____	(±80 mV)	_____
1.061 Vrms (3.000 Vp-p)	_____	_____	_____	(±200 mV)	_____
2.121 Vrms (6.000 Vp-p)	_____	_____	_____	(±400 mV)	_____
4.242 Vrms (12.000 Vp-p)	_____	_____	_____	(±800 mV)	_____

4.13.3.W, Audio Level Meter Accuracy

- 6.** AF Level Meter ±10% of Digital Multimeter reading _____
- 8.** AF Level Meter ±10% of Digital Multimeter reading _____
- 12.** AF Level Meter ±10% of Digital Multimeter reading _____
- 14.** AF Level Meter ±10% of Digital Multimeter reading _____

4.13.3.X, Function Generator Level Accuracy

- 4.** 5.000 Vrms (±50 mVrms) _____

4.13.3.Y, Function Generator Frequency Accuracy

- 3.** 5000 Hz (±0.25 Hz) _____

Verification/Calibration Procedures

STEP	PROCEDURE	
4.13.3.Z, Function Generator Total Harmonic Distortion		
3.	Total harmonic output is <0.5%	_____
4.13.3.AA, Audio Frequency Meter Accuracy		
5.	Nominal ± 0.4 Hz (5000.0 Hz)	_____
4.13.3.AB, Sinad/Distortion Meter Accuracy		
5.	Test Set Sinad Meter reading	_____
6.	Audio Analyzer Sinad reading	_____
7.	Sinad Meter Reading Nominal ± 1.01 dB (20.0 dB)	_____
11.	Distortion Meter Reading Nominal $\pm 0.5\%$ (20%)	_____
4.13.3.AC, DMM Functionality/Accuracy		
5.	Record DMM reading (Zero volts ± 10 mV)	_____
8.	Record DMM reading (10 DC volts $\pm .2$ V)	_____
11.	Record DMM reading (10 AC volts ± 1 V)	_____
14.	Record DMM reading (2Kohms +++)	_____
16.	Record DMM reading (Zero Ohms ± 1 ohms)	_____
18.	Record DMM reading (1,000 Ohms ± 50 ohms)	_____
22.	Record DMM reading (1 DC AMP $\pm .05$ AMP)	_____
25.	Record DMM reading (1 AC AMP $\pm .05$ AMP)	_____

4.15 CALIBRATION PROCEDURES

This section provides instructions on accessing and using the 3900 Series Calibration System. The Calibration System is an optional feature that is only accessible when the option is installed on the Test Set. The Test Set Calibration Procedure is a user-friendly system that has been integrated into the Test Set. Step-by-step instructions and set-up diagrams are displayed on the Test Set's display.

The Test Set is the controller for all external test equipment used during the Calibration Procedure. Equipment connected to the Test Set via IEEE 488.2 cabling must be configured with the correct IEEE 488.2 address as specified in Table 4-9.

Equipment	IEEE 488.2 Address
Agilent E4418B Power Meter	4
HP 34401A Digital Multimeter	7

Table 4-9 IEEE 488.2 Addresses

The Calibration Procedure should only be performed by Technicians familiar with the setup and operation of the recommended test equipment.

4.15.1 Accessing Calibration System

The 3900 Series Calibration System is only available when the Calibration Option (390XOPT040) is installed in Test Set.

Refer to the 3900 Series Operation CD for information on accessing Test Set Systems.

4.15.2 Calibration Tile Layout

The Calibration Screen contains the following information fields and boxes:

- Calibration column lists available Calibration Procedures.
- Date/Time column indicates the Date and Time the Calibration Procedure was last performed.
- Blue tick boxes turn green to indicate when a Calibration Procedure has been selected.




Fig. 4-3 Calibration Menu Layout

4.15.3 Selecting Calibration Procedure

Click on the name of the Calibration Procedure, **not** the blue indicator box to select a Calibration Procedure. After the procedure is selected, press **SELECT**. The tick box turns **GREEN** to indicate procedure has been selected.

Selecting a top level Calibration Procedure selects all lower level procedures listed under the top level heading. For example, selecting RF Generator enables all RF Generator sub-level Calibration Procedures (PA Detector, Attenuator Response and GEN T/R Port Freq Resp). When a top level Calibration Procedure is selected, the Test Set stops when user action is required (i.e., to change calibration setup).

4.15.4 Soft Keys

The calibration screens contain soft keys that are used in each Calibration Procedure. Soft Key functions are:

4.15.4.A Run Selected Soft Key

Runs the selected Calibration Procedure.

4.15.4.B Run All Soft Key

Runs all selected Calibration Procedures.

4.15.4.C Equipment Needed Soft Key

Opens a list of equipment required for the selected Calibration Procedure. A Calibration Procedure must be selected before pressing this soft key.

4.15.4.D Continue Soft Key

Advances to next calibration screen.

4.15.4.E Alarm On/Off Soft Key

Turns audible notification ON or OFF. When ON, an alarm sounds when user action is required to continue Calibration Procedure (i.e., reconfigure equipment setup).

4.15.5 Zero/Calibrate Message

The Power Meter must be zeroed and calibrated every three hours during the Calibration Procedure. The Test Set monitors the three hour time span and displays the Zero and Calibrate Power Meter prompt when the procedure needs to be performed (refer to Fig. 4-4).




Fig. 4-4 Zero/Calibrate Status Message

4.15.6 Time to Complete

Time estimates are based on a Test Set with a 733 MHz processor. Refer to the UTILS, Operational Status Tile for Test Set processor speed. Procedures are listed in the order they appear on the Calibration menu screen.

Calibration Procedure	Time to Complete	Page
RF Generator Calibration		4 - 52
PA Detect.25or Calibration	4 min	4 - 52
Requires calibration setup change between procedures.		
Attenuator Response Calibration	45 min	4 - 53
GEN Port Freq Response Calibration	7 min	4 - 54
T/R Port Freq Response Calibration	18 min	4 - 55
Requires calibration setup change between procedures.		
Receiver Calibration		4 - 56
Splitter Calibration (Calibration setup change during procedure)	5 min	4 - 56
Requires calibration setup change between procedures.		
IF Gain Calibration	5 min	4 - 58
IF AMP Calibration	2 min	4 - 60
ANT Port AMP Gain Calibration	9 min	4 - 62
ANT Port 0-30 dB Calibration	12 min	4 - 63
ANT Port Linearity Calibration	1 min	4 - 64
Port Delta Calibration	1 min	4 - 65
Requires calibration setup change between procedures.		
T/R Port 0-40 dB Calibration	10 min	4 - 66
T/R Port Linearity Calibration	1 min	4 - 67
Requires calibration setup change between procedures.		
YIG Sweep Calibration	5 min	4 - 68
Requires calibration setup change between procedures.		
Function Generator Calibration	4 min	4 - 69
Requires calibration setup change between procedures.		
Scope DC Calibration	2 min	4 - 70
Requires calibration setup change between procedures.		
Scope AC Calibration	3 min	4 - 71
Requires calibration setup change between procedures.		
TCXO Adjustment Calibration	4 min	4 - 73
Total	2 hrs 18 min	

Table 4-10 Calibration Time Chart

4.16 RF GENERATOR CALIBRATION

4.16.1 PA Detector Calibration

STEP	PROCEDURE
1.	Select PA Detector on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-5 as needed.




Fig. 4-5 PA Detector Calibration Setup

- Press Continue Soft Key. Run is displayed in dialog box, followed by calibration data.
- When the PA Detector Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-6.




Fig. 4-6 PA Detector Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

PA Detector Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with the next Calibration Procedure.

4.16.2 Attenuator Response Calibration

STEP	PROCEDURE
1.	Select Attenuator Response on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure Equipment. Refer to Fig. 4-7 as needed.




Fig. 4-7 Attenuator Response Calibration Setup

- Press Continue Soft Key to run the Attenuator Response Calibration Procedure.
- When the Attenuator Response Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal traces on Test Set resemble signal traces shown in Fig. 4-8.




Fig. 4-8 Attenuator Response Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

**ATTENUATOR RESPONSE CALIBRATION PROCEDURE IS COMPLETE.
IF THIS PROCEDURE WAS PERFORMED AS PART OF SYSTEM CALIBRATION,
PROCEED WITH THE NEXT CALIBRATION PROCEDURE.**

4.16.3 GEN Port Freq Response Calibration

STEP	PROCEDURE
1.	Select GEN Port Freq Resp on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-9 as needed.




Fig. 4-9 GEN Port Calibration Setup

- Press Continue Soft Key to run the GEN Port Freq Response Calibration Procedure.
- When the GEN Port Freq Response Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify the signal traces on the Test Set resemble the signal traces as shown in Fig. 4-10.




Fig. 4-10 GEN Port Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

GEN Port Freq Response Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.16.4 T/R Port Freq Response Calibration

STEP	PROCEDURE
1.	Select T/R Port Freq Resp on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-11 as needed.




Fig. 4-11 T/R Port Calibration Setup

- Press Continue Soft Key to run the T/R Port Freq Response Calibration.
- When the T/R Port Freq Response Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal traces on Test Set resemble signal traces shown in Fig. 4-12.




Fig. 4-12 T/R Port Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

T/R Port Freq Response Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure. Reboot Test Set before proceeding with Receiver Calibration Procedures.

4.17 RECEIVER CALIBRATION

4.17.1 Splitter Calibration

STEP	PROCEDURE
1.	Select Splitter Cal on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-13 as needed.




Fig. 4-13 Splitter Calibration Setup (ANT Port)

- Press Continue Soft Key. Test Set runs ANT Side portion of the Splitter Calibration Procedure. Test Set advances to next calibration setup unless an error is received during the ANT Side portion of the Calibration Procedure.
- At prompt, reconfigure equipment. Switch Power Meter Sensor head to 10 dB pad on REF Port Side; switch 50 Ω load to 10 dB pad on ANT Port Side. Refer to Fig. 4-14 as needed.




Fig. 4-14 Splitter Calibration Setup (REF Port)

STEP

PROCEDURE

6. When the REF Side portion of Splitter Calibration Procedure is complete, verify Calibration Complete is displayed on screen. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-15.




Fig. 4-15 Splitter Calibration Complete

7. Press Continue Soft Key. Wait while Test Set updates system date and time information.

Splitter Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.2 IF Gain Calibration

STEP	PROCEDURE
1.	Select IF Gain on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-16 as needed. If continuing from Splitter Calibration Procedure, remove 50 Ω load and F N/F TNC Adapter from M TNC/M N Adapter on ANT Port Side and connect M TNC/F N Adapter to Test Set ANT Connector.




Fig. 4-16 IF Gain Calibration Setup

- Press Continue Soft Key to run the Channel Cal portion of the IF Gain Calibration Procedure.
- When the Channel Cal portion of the IF Gain Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify the signal trace on the Test Set resembles the signal trace as shown Fig. 4-17.




Fig. 4-17 IF Gain Channel Cal Signal Trace

- Press Continue Soft Key to run the Main Cal portion of the IF Gain Calibration Procedure.

STEP

PROCEDURE

- When the Main Cal portion is complete, verify Calibration Complete is displayed in dialog box. Verify the signal trace on the Test Set resembles the signal trace as shown in Fig. 4-18.




Fig. 4-18 IF Gain Main Cal Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

IF Gain Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.3 IF AMP Calibration

STEP	PROCEDURE
1.	Select IF AMP on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-19 as needed.




Fig. 4-19 IF AMP Calibration Setup

- Press Continue Soft Key to run the Channel Cal portion of IF AMP Calibration Procedure.
- When the Channel Cal portion is complete, verify Calibration Complete is displayed in dialog box. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-20.




Fig. 4-20 IF AMP Channel Cal Signal Trace

- | STEP | PROCEDURE |
|------|--|
| 6. | Press Continue Soft Key to run Main portion of the IF AMP Calibration Procedure. |




Fig. 4-21 IF AMP Main Cal Signal Trace

- When the Main Cal portion of IF AMP Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-21.
- Press Continue Soft Key. Wait while Test Set updates system date and time information.

IF AMP Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.4 ANT Port AMP Gain Calibration

STEP	PROCEDURE
1.	Select ANT Port Amp Gain on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-22 as needed.




Fig. 4-22 ANT Port Amp Gain Calibration Setup

- Press Continue Soft Key to run the ANT Port Amp Gain Calibration Procedure.
- When the ANT Port Amp Gain Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal traces on Test Set resemble signal traces shown in Fig. 4-23.




Fig. 4-23 ANT Port Amp Gain Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

ANT Port AMP Gain Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.5 ANT Port 0-30 dB Calibration

STEP	PROCEDURE
1.	Select ANT Port 0-30 dB on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-24 as needed.




Fig. 4-24 ANT Port 0-30 dB Calibration Setup

- Press Continue Soft Key to run the ANT Port 0-30 dB Calibration Procedure.
- When the ANT Port 0-30 dB Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal traces on Test Set resemble the signal traces shown in Fig. 4-25.




Fig. 4-25 ANT Port 0-30 dB Signal Traces

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

ANT Port 0-30 dB Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.6 ANT Port Linearity Calibration

STEP	PROCEDURE
1.	Select ANT Port Linearity on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-26 as needed.




Fig. 4-26 ANT Port Linearity Calibration Setup

- Press Continue Soft Key to run the ANT Port Linearity Calibration Procedure.
- When the ANT Port Linearity Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-27.




Fig. 4-27 ANT Port Linearity Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

ANT Port Linearity Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.7 Port Delta Calibration

STEP	PROCEDURE
1.	Select Port Delta on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-28 as needed.




Fig. 4-28 Port Delta Calibration Setup

4. Press Continue Soft Key to run the Port Delta Calibration Procedure.
5. When the Port Delta Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box as shown in Fig. 4-29.




Fig. 4-29 Port Delta Calibration Complete

6. Press Continue Soft Key. Wait while Test Set updates system date and time information.

Port Delta Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.8 T/R Port 0-40 dB Calibration

STEP	PROCEDURE
1.	Select T/R Port 0-40 dB on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-30 as needed.




Fig. 4-30 T/R Port 0-40 dB Calibration Setup

- Press Continue Soft Key to run the T/R Port 0-40 dB Calibration Procedure.
- When the T/R Port 0-40 dB Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal traces on Test Set resemble signal traces shown in Fig. 4-31.




Fig. 4-31 T/R Port 0-40 dB Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

T/R Port 0 - 40 dB Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.9 T/R Port Linearity Calibration

STEP	PROCEDURE
1.	Select T/R Port Linearity on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure equipment. Refer to Fig. 4-32 as needed.




Fig. 4-32 T/R Port Linearity Calibration Setup

- Press Continue Soft Key to run the T/R Port Linearity Calibration Procedure.
- When the T/R Port Linearity Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box. Verify signal trace on Test Set resembles signal trace shown in Fig. 4-33.




Fig. 4-33 T/R Port Linearity Signal Trace

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

T/R Port Linearity Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.10 YIG Sweep Calibration

- | STEP | PROCEDURE |
|------|---|
| 1. | Select YIG Sweep on Calibration Tile. Press Run Selected Soft Key. |
| 2. | Disconnect all Test Set connections. Press Continue Soft Key to run the YIG Sweep Calibration Procedure. |
| 3. | When the YIG Sweep Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box as shown in Fig. 4-34. |
| 4. | Press Continue Soft Key. Wait while Test Set updates date and time information. |




Fig. 4-34 YIG Sweep Calibration Complete

YIG Sweep Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure. zero

4.17.11 Function Generator Calibration

STEP	PROCEDURE
1.	Select Function Generator on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key to run the Function Generator Calibration Procedure.
3.	Configure Equipment. Refer to Fig. 4-35 as needed.
4.	Press Continue Soft Key to run the Function Generator Calibration Procedure.




Fig. 4-35 Function Generator Calibration Setup

- When the Function Generator Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box as shown in Fig. 4-36.




Fig. 4-36 Function Generator Calibration Complete

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

Function Generator Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.12 Scope DC Calibration

- | STEP | PROCEDURE |
|------|--|
| 1. | Select Scope DC on Calibration Tile. Press Run Selected Soft Key. |
| 2. | Disconnect all equipment from Test Set Front Panel connectors. Press Continue Soft Key. Bar graphs will be displayed on the plot field during the Calibration Procedure. |




Fig. 4-37 Scope DC Calibration Complete

- When the Scope DC Calibration Procedure is complete, verify Calibration Complete is displayed in dialog box as shown in Fig. 4-37.
- Press Continue Soft Key. Wait while Test Set updates system date and time information.

Scope DC Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.13 Scope AC Calibration

STEP	PROCEDURE
1.	Select Scope AC on Calibration Tile. Press Run Selected Soft Key.
2.	Follow screen prompts. Press Continue Soft Key as needed to advance to next screen.
3.	Configure Equipment. Refer to Fig. 4-38 as needed.




Fig. 4-38 Scope AC Calibration Setup

4. Press Continue Soft Key to run the Scope AC Calibration Procedure.

STEP

PROCEDURE

- When the Scope AC Calibration Procedure is complete, verify Calibration Complete is displayed on screen in dialog box as shown in Fig. 4-39.




Fig. 4-39 Scope AC Calibration Complete

- Press Continue Soft Key. Wait while Test Set updates system date and time information.

Scope AC Calibration Procedure is complete.

If this procedure was performed as part of System Calibration, proceed with next Calibration Procedure.

4.17.14 TCXO Adjustment Calibration

STEP	PROCEDURE
1.	Select TCXO Adjustment on Calibration Tile. Press Run Selected Soft Key.
2.	Configure equipment. Refer to Fig. 4-40 as needed.




Fig. 4-40 TCXO Adjust Calibration Setup

3. Connect 10 MHz External Reference to Frequency Counter Ext Ref port.
4. Configure Frequency Counter to display frequency resolution of 0.01 Hz.
5. Press Continue Soft Key. Press the Select Key to select the DAC Adjust Field.
6. Turn Test Set Rotary knob until Frequency Counter reads 1000.000000 MHz (± 2.0 Hz). Press Done Soft Key to enter value.
7. Press Continue Soft Key to return to the main calibration menu.




Fig. 4-41 TCXO Adjust Calibration Complete

8. Wait while Test Set updates system date and time information.
TCXO Adjustment Calibration Procedure is complete.
If this procedure was performed as part of System Calibration, System Calibration is complete.

4.18 CALIBRATION DATA SHEET

Technician: _____ Date: _____
 Test Set S/N: _____














STEP	PROCEDURE	_____	_____
4.16, RF Generator Calibration			
4.16.1, PA Detector Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.16.2, Attenuator Response Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.16.3, GEN Port Freq Response Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.16.4, T/R Port Freq Response Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.17, Receiver Calibration			
4.17.1, Splitter Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.17.2, IF Gain Calibration			
	Channel Portion		
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
	Main Portion		
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.17.3, IF AMP Calibration			
	Channel Portion		
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
	Main Portion		
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓
4.17.4, ANT Port AMP Gain Calibration			
	Calibration Complete	_____	✓
	Verify signal trace	_____	✓

Verification/Calibration Procedures



STEP	PROCEDURE	
4.17, Receiver Calibration (cont)		
4.17.5, ANT Port 0-30 dB Calibration		
	Calibration Complete	_____ ✓
	Verify signal trace	_____ ✓
4.17.6, ANT Port Linearity Calibration		
	Calibration Complete	_____ ✓
	Verify signal trace	_____ ✓
4.17.7, Port Delta Calibration		
	Calibration Complete	_____ ✓
4.17.8, T/R Port 0-40 dB Calibration		
	Calibration Complete	_____ ✓
	Verify signal trace	_____ ✓
4.17.9, T/R Port Linearity Calibration		
	Calibration Complete	_____ ✓
	Verify signal trace	_____ ✓
4.17.10, YIG Sweep Calibration		
	Calibration Complete	_____ ✓
Miscellaneous Procedures		
4.17.11, Function Generator Calibration		
	Calibration Complete	_____ ✓
4.17.12, Scope DC Calibration		
	Calibration Complete	_____ ✓
4.17.13, Scope AC Calibration		
	Calibration Complete	_____ ✓
4.17.14, TCXO Adjustment Calibration		
	1000.000000 MHz (±2.0 Hz)	_____ ✓

4.19 CALIBRATION KIT CONTENTS

The 3900 Series Calibration Kit (Aeroflex PN 63934) contains the following items:

Part Number	Description	Qty	Item
20339	UG27A Connector	3	
23758	F BNC/M TNC Connector Adapter	1	
23764	BNC F/DBL Banana Plug Connector Adapter	1	
23765	N M/N M Connector Adapter	1	
23766	M TNC/M N Connector Adapter	1	
23766	F N/F TNC Connector Adapter	1	
23768	M TNC/F N Connector Adapter	1	
38209	10 dB, 5 W, N, 12.4 GHz Attenuator	2	
56427	Power Splitter, Type N, Broadband	1	
58525	Termination, 50 Ω, N M	1	
58526	Termination, 10 k Ω, BNC M	1	
59762	Filter, Tubular BP, 610 MHz, 3 dB	1	
62375	50 Ω, N M/TNC M Cable	1	

Verification/Calibration Procedures

Part Number	Description	Qty	Item
63339	58S, S M BNC/S M BNC Cable	2	
63352	1601 Radio Cable	1	

THIS PAGE INTENTIONALLY LEFT BLANK.

Chapter 5 - Remove/Install Procedures

5.1 GENERAL

This chapter contains instructions for removing and installing Test Set assemblies. The instructions provided are for removal and replacement of each assembly. Prerequisite and follow-up instructions are identified as needed.

Remove/Install procedures are grouped as follows:

- Common Procedures apply to all 3900 models.
- 3901/3902 Procedures apply only to these models.
- 3920/3920B Procedures apply only to these models.

NOTE

Due to variations in hardware configuration, actual cable color and assembly appearance may vary from the pictures provided in this chapter.

5.2 SAFETY PRECAUTIONS

Disconnect Test Set from AC Power Source before initiating any procedure.

WARNING

DANGEROUS VOLTAGES ARE PRESENT WHEN CASE ASSEMBLY IS REMOVED WHEN POWER IS PRESENT.

5.3 ESD PRECAUTIONS

**CAUTION**

THIS EQUIPMENT CONTAINS PARTS
SENSITIVE TO DAMAGE
BY ELECTROSTATIC DISCHARGE (ESD).

CAUTION

THE TEST SET CONTAINS PARTS SENSITIVE TO DAMAGE BY ELECTROSTATIC DISCHARGE (ESD). ALL PERSONNEL PERFORMING DISASSEMBLY/REASSEMBLY PROCEDURES SHOULD HAVE KNOWLEDGE OF ACCEPTED ESD PRACTICES AND/OR BE ESD CERTIFIED.

5.4 TOOL REQUIREMENTS

The following tools are required to perform remove and install procedures:

TOOL	SIZE
WRENCH, OPEN END	5/16"
CHANNEL LOCK PLIERS	SMALL
RATCHET/SOCKET	3/16" 1/4"
RATCHET/DEEP SOCKET	9/16" 3/4"
6" & 10" SCREWDRIVER	CROSS RECESSED

5.5 PRELIMINARY PROCEDURES

Aeroflex recommends that the Test Set's internal Calibration Files be saved to a USB device prior to servicing the unit. Calibration Files can then be restored after service is completed. Refer to section titled *Saving Calibration Files* in Chapter 4 for Save and Restore Calibration Files procedure.

5.6 REMOVE/INSTALL PROCEDURES

5.6.1 Common Procedures

Assembly	Remove Procedure	Install Procedure
Attenuator Assembly	5 - 10	5 - 11
Backplane PCB Assembly	5 - 59	5 - 61
CAI PCB Assembly	5 - 14	5 - 15
Case Assembly	5 - 4	5 - 6
CPU Adapter PCB Assembly	5 - 16	5 - 18
CPU Adapter PCB Assembly Battery	5 - 20	5 - 20
DAM Carrier PCB Assembly	5 - 12	5 - 13
Fan Assembly	5 - 31	5 - 32
Handle Assembly	5 - 8	5 - 9
Inverter Supply PCB Assembly	5 - 49	5 - 53
LED Backlight Driver	5 - 52	5 - 53
Keypad Assembly	5 - 48	5 - 48
LCD Assembly	5 - 38	5 - 39
LCD Lens	5 - 41	5 - 42
Power Supply Assembly	5 - 33	5 - 35
Power Termination Assembly	5 - 55	5 - 57
Rear Panel Assembly	5 - 21	5 - 24
Rear Panel PCB Assembly	5 - 28	5 - 28
Rear Panel Audio I/O PCB Assembly	5 - 29	5 - 30
Speaker Wire Harness Assembly	5 - 37	5 - 37

5.6.2 3901/3902 Procedures

Assembly	Remove Procedure	Install Procedure
Disk I/O PCB Assembly	5 - 74	5 - 75
Floppy Drive Assembly	5 - 84	5 - 85
Front Panel Assembly	5 - 76	5 - 78
Front Panel Digital Interface PCB Assembly	5 - 80	5 - 82
Generator Assembly	5 - 86	5 - 89
IF/Video PCB Assembly	5 - 95	5 - 97
Receiver Assembly	5 - 91	5 - 93

5.6.3 3920/3920B Procedures

Assembly	Remove Procedure	Install Procedure
Disk I/O PCB Assembly	5 - 98	5 - 99
Digital Multimeter Assembly	5 - 107	5 - 108
Front Panel Assembly	5 - 100	5 - 102
Front Panel Digital Interface PCB Assembly	5 - 104	5 - 106
Generator Assembly	5 - 86	5 - 89
IF/Video PCB Assembly	5 - 95	5 - 97
Receiver Assembly	5 - 91	5 - 93

USB Cable	5 - 109	5 - 110
-----------	---------	---------

5.7 COMMON PROCEDURES

The following procedures apply to all 3900 models.

5.7.1 Case Assembly

5.7.1.A Remove Case Assembly

5.7.1.A.1 Description

This procedure covers: Remove. Install.


5.7.1.A.2 Preliminary Procedures

None.


WARNING	DANGEROUS VOLTAGES ARE PRESENT WHEN CASE ASSEMBLY IS REMOVED WHEN POWER IS PRESENT.
----------------	--

STEP	PROCEDURE
------	-----------

1. Disconnect external power source and all external cables from Test Set.
2. Remove nine screws securing Chassis Rear Panel to Chassis Assembly.



3. Stand Test Set on end with Front Panel side down.
4. Remove outside screws from each Rear Panel corner bumper (total of eight screws).




5. Remove Chassis Rear Panel from Chassis Assembly.

NOTE	Use care when removing Chassis Rear Panel to avoid damaging internal fingerstock.
-------------	---


STEP

PROCEDURE

6. Loosen outside screw at each corner of Front Panel corner bumper.




7. Grasp both Handle Grips and pull up to slide Case Assembly from Chassis Assembly.



5.7.1.B Install Case Assembly


STEP	PROCEDURE
------	-----------

1. Stand Chassis Assembly on end with display face down.
2. Hold Case Assembly so air vent on bottom of Case Assembly is aligned with the air vent on the bottom of the Chassis Assembly. Slide Case Assembly down over Chassis Assembly.



Bottom Air Vents

NOTE	Use care when sliding Case Assembly over Chassis Assembly to avoid pinching cables or catching the black PC Board retainers on internal assemblies.
-------------	---



PC Board Retainer Clips


3. Align edge of Case Assembly to obtain tight fit with Front Panel Assembly.
4. Install Chassis Rear Panel on Chassis Assembly.

NOTE	Use care when installing Chassis Rear Panel to avoid damaging internal fingerstock.
-------------	---


STEP

PROCEDURE


5. Tighten outside screw of each Chassis Rear Panel corner bumper (total of eight screws). Torque screws to 8 in/lbs.



6. Install nine screws securing Chassis Rear Panel to Chassis Assembly. Torque screws to 8 in/lbs.



7. Tighten outside screw at each corner of Front Panel corner bumper. Torque screws to 8 in/lbs.



5.7.1.B.1 Follow-up Procedures:

None.

5.7.2 Handle Assembly

5.7.2.A Remove Handle Assembly

5.7.2.A.1 Description

This procedure covers: Remove. Install.

5.7.2.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE

1. Reach inside Case Assembly and squeeze together ends of Securing Clip and remove Circular Spacer. Repeat procedure on other side.



2. Squeeze together ends of Securing Clip on inside of Case Assembly. Grasp and pull on outside of Securing Clip to remove Securing Clip from Handle Assembly. Repeat procedure on other side.



3. Grasp both Handle Grips and pull away from sides of Case Assembly to remove Handle Assembly from Case Assembly.

5.7.2.B Install Handle Assembly

STEP	PROCEDURE
1.	Stand Case Assembly on end with front edge facing down.
2.	Grasp each side of Handle Assembly and position Handle Grips on each side of Case Assembly.
3.	Pull out on Handle Grips to align notches on Handle Grips with holes in sides of Case Assembly.



4. Align notches on Handle Assembly with holes in each side of Case Assembly. Release Handle Grips to secure Handle Assembly to Case Assembly.
5. Insert Securing Clip into Handle Grip. Squeeze together ends of Securing Clip and place Circular Spacer around ends of Securing Clip. Repeat procedure on other Handle Grip.

-OR-

6. Reach inside Case Assembly and align Circular Spacer with ends of Securing Clip before inserting Securing Clip into Handle Grip. Insert Securing Clip into Handle Grip, guiding ends of Securing Clip through Circular Spacer.

Align Circular Spacer	Insert Securing Clip

5.7.2.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.3 Attenuator Assembly

5.7.3.A Remove Attenuator Assembly

5.7.3.A.1 Description


This procedure covers: Remove. Install.

5.7.3.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------


1. Disconnect ribbon cable from Attenuator Assembly.



2. Disconnect coaxial cable from each end of Attenuator Assembly.




3. Remove two screws securing Attenuator Assembly to Generator Assembly.




4. Remove Attenuator Assembly from Generator Assembly.

5.7.3.B Install Attenuator Assembly


STEP	PROCEDURE
1.	Place Attenuator Assembly on Generator Assembly.
2.	Install two screws to secure Attenuator Assembly to Generator Assembly. Torque screws to 8 in/lbs.



3.	Attach coaxial cables to each end of Attenuator Assembly. Torque to 8 in/lbs.
----	---



4.	Connect ribbon cable to Attenuator Assembly.
----	--



5.7.3.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.4 DAM Carrier PCB Assembly

5.7.4.A Remove DAM Carrier PCB Assembly

5.7.4.A.1 Description

This procedure covers: Remove. Install.


5.7.4.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE


1. Reposition cable connecting IF/Video PCB Assembly and Rear Panel PCB Assembly to remove DAM Carrier PCB Assembly.



2. Disconnect two coaxial cables from DAM Carrier PCB Assembly.



3. Lift up on card ejectors and remove DAM Carrier PCB Assembly from Card Cage Assembly.



NOTE


DAM Carrier PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing DAM Carrier PCB Assembly to avoid damaging connector pins.

5.7.4.B Install DAM Carrier PCB Assembly


STEP	PROCEDURE
------	-----------

1. Insert DAM Carrier PCB Assembly securely into Card Cage Assembly.

NOTE	DAM Carrier PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing DAM Carrier PCB Assembly to avoid damaging connector pins.
-------------	---



2. Press card ejectors down to secure DAM Carrier PCB Assembly in Card Cage Assembly.
3. Connect coaxial cables to DAM Carrier PCB Assembly as shown below.



5.7.4.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.5 CAI PCB Assembly

5.7.5.A Remove CAI PCB Assembly

5.7.5.A.1 Description

This procedure covers: Remove. Install.


5.7.5.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE

1. Reposition coaxial cable connecting IF Video PCB Assembly and Rear Panel PCB Assembly to remove CAI PCB Assembly.



2. Lift up on card ejectors and remove CAI PCB Assembly from Card Cage Assembly.



NOTE

CAI PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing CAI PCB Assembly to avoid damaging connector pins.


5.7.5.B Install CAI PCB Assembly

STEP	PROCEDURE
------	-----------

1. Insert CAI PCB Assembly securely into Card Cage Assembly.

NOTE

CAI PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing CAI PCB Assembly to avoid damaging connector pins.



2. Press card ejectors down to secure CAI PCB Assembly in Card Cage Assembly.

5.7.5.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.6 CPU Adapter PCB Assembly

5.7.6.A Remove CPU Adapter PCB Assembly

5.7.6.A.1 Description


This procedure covers: Remove. Install.

5.7.6.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------

1. Disconnect ribbon cable and wire harness from CPU Adapter PCB Assembly.



2. Remove four screws securing CPU Adapter PCB Assembly to side of Chassis Assembly.




NOTE

This step applies to the following: 3901 models with SN 298001115 and higher, 3902 models with SN 297001117 and higher, and all 3920 models. Field serviced units with replaced CPU Adapter PCB Assemblies with PN 65681 or 65690.

STEP

PROCEDURE

3. Lift up on card ejectors and remove CPU Adapter PCB Assembly from Card Cage Assembly.



NOTE

CPU Adapter PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing CPU Adapter PCB Assembly to avoid damaging connector pins.

5.7.6.B Install CPU Adapter PCB Assembly


5.7.6.B.1 Preliminary Procedure

If replacing CPU Adapter PCB Assembly, remove protective film from Disk I/O PCB Assembly connector before installing assembly.


STEP	PROCEDURE
------	-----------

1. Insert CPU Adapter PCB Assembly securely into Card Cage Assembly.

NOTE	CPU Adapter PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing CPU Adapter PCB Assembly to avoid damaging connector pins.
-------------	---



2. Press card ejectors down to secure CPU Adapter PCB Assembly in Card Cage Assembly.
3. Install four screws securing CPU Adapter PCB Assembly to side of Chassis Assembly. Torque screws to 6 in/lbs.




NOTE	This step applies to the following: 3901 models with SN 298001115 and higher, 3902 models with SN 297001117 and higher, and all 3920 models. Field serviced units with replaced CPU Adapter PCB Assemblies with PN 7010-4437-200.
-------------	--


STEP

PROCEDURE

4. Connect ribbon cable from Front Panel Assembly to CPU Adapter PCB Assembly.



5. Connect wire harness from Front Panel Assembly to CPU Adapter PCB Assembly.



5.7.6.B.2 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.7 CPU Adapter PCB Assembly Battery

5.7.7.A Remove CPU Adapter PCB Assembly Battery

5.7.7.A.1 Description

This procedure covers: Remove. Install.


5.7.7.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).

Remove CPU Adapter PCB Assembly (5 - 16).

STEP	PROCEDURE
------	-----------

1. Pull back on white clips and remove battery from housing bracket.




WARNING

DO NOT USE A METAL OBJECT TO REMOVE BATTERY FROM HOUSING BRACKET: THIS MAY CAUSE A SHORT BETWEEN THE POSITIVE AND NEGATIVE TERMINALS WHICH MAY CAUSE THE BATTERY TO EXPLODE.

5.7.7.B Install CPU Adapter PCB Assembly Battery

STEP	PROCEDURE
------	-----------

1. Install battery into housing bracket.



2. Press down to secure battery in housing bracket.

5.7.7.B.1 Follow-up Procedures:

Install CPU Adapter PCB Assembly (5 - 18).

Install Case Assembly (5 - 6).

5.7.8 Rear Panel Assembly

5.7.8.A Remove Rear Panel Assembly

5.7.8.A.1 Description


This procedure covers: Remove. Install.

5.7.8.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------

1. Disconnect coaxial cable from Rear Panel PCB Assembly.



2. Remove nut and washer from four connectors on Rear Panel Assembly.




3. Remove two screws securing Aux IF Input Connector to Rear Panel Assembly.




STEP

PROCEDURE


4. Remove two nuts securing Rear Panel Assembly to Rear Panel Audio I/O PCB Assembly. Use care when removing nuts to avoid breakage.



5. Remove 6 shell nuts securing Rear Panel Assembly at three connectors.




6. Remove four screws at each corner of AC Power Switch.




STEP

PROCEDURE


7. Remove two screws from each side of Chassis Assembly.



8. Remove Rear Panel Assembly from Chassis Assembly. Disconnect two wire harnesses from Rear Panel PCB Assembly.



9. Disconnect ribbon cable from Backplane PCB Assembly.




10. Remove Rear Panel Assembly from Chassis Assembly.


5.7.8.B Install Rear Panel Assembly

STEP	PROCEDURE
------	-----------


1. Position Rear Panel Assembly to connect cables to Rear Panel PCB Assembly.



2. Connect ribbon cable from Rear Panel Assembly to Backplane PCB Assembly.



3. Connect wire harnesses from fans on Rear Panel Assembly to Rear Panel PCB Assembly.




4. Install Rear Panel Assembly in Chassis Assembly.


STEP

PROCEDURE


5. Install four screws securing Rear Panel Assembly at AC Power Switch. Torque screws to 6 in/lbs.



6. Install six shell nuts securing Rear Panel Assembly at three connectors. Place Loctite on each screw before installing. Torque screws to 4 in/lbs.




7. Install two nuts securing Rear Panel Assembly to Rear Panel Audio I/O PCB Assembly. Torque nuts to 6 in/lbs.



STEP	PROCEDURE
------	-----------


8. Install nut and washer on four connectors on Rear Panel Assembly. Torque nut to 40 in/lbs.



9. Install two screws securing Chassis Rear Panel at Aux IF Input Connector. Torque screws to 4 in/lbs.




10. Install two screws on each side of Chassis Assembly. Torque screws to 6 in/lbs.



STEP

PROCEDURE

11. Attach coaxial cable connecting IF/Video PCB Assembly and Rear Panel PCB Assembly.



5.7.8.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.7.9 Rear Panel PCB Assembly

5.7.9.A Remove Rear Panel PCB Assembly

5.7.9.A.1 Description

This procedure covers: Remove. Install.

5.7.9.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).

Remove Rear Panel Assembly (5 - 21).

STEP	PROCEDURE
------	-----------

1. Remove Rear Panel PCB Assembly from Backplane PCB Assembly connector.




NOTE	Rear Panel PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing Rear Panel PCB Assembly to avoid damaging connector pins.
-------------	---

5.7.9.B Install Rear Panel PCB Assembly

STEP	PROCEDURE
------	-----------

1. Connect Rear Panel PCB Assembly to Backplane PCB Assembly connector.



5.7.9.B.1 Follow-up Procedures:

Install Rear Panel Assembly (5 - 24).

Install Case Assembly (5 - 6).

5.7.10 Rear Panel Audio I/O PCB Assembly

5.7.10.A Remove Rear Panel Audio I/O PCB Assembly

5.7.10.A.1 Description

This procedure covers: Remove. Install.

5.7.10.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

Remove Rear Panel Assembly (5 - 21).

Remove Rear Panel PCB Assembly (5 - 28).

STEP PROCEDURE

1. Remove Rear Panel Audio I/O PCB Assembly from Rear Panel PCB Assembly.



NOTE	Rear Panel Audio I/O Assembly connects directly into Rear Panel PCB Assembly connector. Use care when removing Rear Panel Audio I/O PCB Assembly to avoid damaging connector pins.
-------------	--


5.7.10.B Install Rear Panel Audio I/O PCB Assembly

STEP	PROCEDURE
------	-----------

- | | |
|----|--|
| 1. | Install Rear Panel Audio I/O PCB Assembly on Rear Panel PCB Assembly at connector interface. |
|----|--|

NOTE

Rear Panel Audio I/O Assembly connects directly into Rear Panel PCB Assembly connector. Use care when installing Rear Panel Audio I/O PCB Assembly to avoid damaging connector pins.



5.7.10.B.1 Follow-up Procedures:

- Install Rear Panel PCB Assembly (5 - 28).
- Install Rear Panel Assembly (5 - 24).
- Install Case Assembly (5 - 6).

5.7.11 Fan Assembly

5.7.11.A Remove Fan Assembly

5.7.11.A.1 Description

This procedure covers: Remove. Install. Procedure applies to both Fan Assemblies.


5.7.11.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Rear Panel Assembly (5 - 21).

STEP PROCEDURE


1. Cut plastic fastener securing fan wire harness to Rear Panel Assembly and remove wires from securing clip.



2. Remove four screws securing Fan Assembly to Rear Panel Assembly




3. Remove Fan Assembly from Rear Panel Assembly.




5.7.11.B Install Fan Assembly

STEP	PROCEDURE
------	-----------


1. Install Fan Assembly in Rear Panel Assembly.



2. Install four screws securing Fan Assembly to Rear Panel Assembly. Tighten until binding is felt. Over tightening may crack Fan Assembly.



3. Insert Fan Assembly wire harness in securing clip and replace plastic fastener.



5.7.11.B.1 Follow-up Procedures:

Install Rear Panel Assembly (5 - 24).

Install Case Assembly (5 - 6).

5.7.12 Power Supply Assembly

5.7.12.A Remove Power Supply Assembly

5.7.12.A.1 Description

This procedure covers: Remove. Install.

5.7.12.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

Remove Front Panel Assembly (5 - 76/5 - 100).


Remove Disk I/O Assembly (5 - 74/5 - 98).

STEP PROCEDURE

1. Remove two screws securing Fan Shroud Bracket to Power Supply Assembly. Remove Fan Shroud Bracket and Fan Shroud Cover from Power Supply Assembly.



2. Remove Fan Shroud Cover from Fan Shroud Bracket.
3. Fully loosen captive screw securing Power Supply Assembly to Chassis Assembly.




4. Remove two screws securing Rear Panel Assembly to Chassis Assembly.




STEP

PROCEDURE

5. Remove four screws securing Power Supply Assembly to Rear Panel Assembly.



6. Remove six shell nuts securing Rear Panel Assembly to Chassis Assembly at three connectors.



7. Separate side of Chassis Assembly from Rear Panel Assembly to allow room to grasp Power Supply Assembly. Grasp Power Supply Assembly and pull to remove Power Supply from Chassis Assembly.

NOTE

Do not pull on wire handle to remove Power Supply Assembly. Rock Power Supply Assembly back and forth in Card Cage Assembly to remove. Power Supply Assembly connects directly into Backplane PCB Assembly. Use care when removing Power Supply Assembly to avoid damaging connector pins.




5.7.12.B Install Power Supply Assembly

5.7.12.B.1 Preliminary Procedure

Replace 1/2 in. double-sided, VHB, adhesive tape on Fan Shroud Bracket.

STEP PROCEDURE


1. Insert Fan Shroud Bracket on Power Supply Assembly. Install two screws securing Fan Shroud Bracket to Power Supply Assembly. Torque screws to 6 in/lbs.



2. Insert Power Supply Assembly in Chassis Assembly. Align Power Supply Assembly with Backplane PCB Assembly connector and press down firmly to ensure proper connection with Backplane PCB Assembly.

NOTE	Power Supply Assembly connects directly into Backplane PCB Assembly. Use care when installing Power Supply Assembly to avoid damaging connector pins.
-------------	---

3. Tighten captive screw securing Power Supply Assembly to Chassis Assembly. Torque screw to 6 in/lbs.




4. Install two screws securing Rear Panel Assembly to Chassis Assembly. Torque screws to 6 in/lbs.




STEP	PROCEDURE
------	-----------


5. Install six shell nuts securing Rear Panel Assembly to Chassis Assembly at three connectors. Place Lock Tight on screws before installing. Torque screws to 4 in/lbs.



6. Install four screws securing Power Supply Assembly to Rear Panel Assembly. Torque screws to 6 in/lbs.



7. Attach Fan Shroud Cover to Fan Shroud Bracket.



5.7.12.B.2 Follow-up Procedures:

- Install Disk I/O PCB Assembly (5 - 74/5 - 75).
- Install Front Panel Assembly (5 - 78/5 - 102).
- Install Case Assembly (5 - 6).

5.7.13 Speaker Wire Harness Assembly

5.7.13.A Remove Speaker Wire Harness Assembly

5.7.13.A.1 Description

This procedure covers: Remove. Install.

5.7.13.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

Remove Disk I/O Assembly (5 - 74/5 - 98).

Remove Power Supply Assembly (5 - 33).

STEP	PROCEDURE
------	-----------

- | | |
|----|--|
| 1. | Remove four screws securing Speaker Wire Harness Assembly to Chassis Assembly. |
|----|--|




- | | |
|----|---|
| 2. | Remove Speaker Wire Harness Assembly from Chassis Assembly. |
|----|---|

5.7.13.B Install Speaker Wire Harness Assembly

STEP	PROCEDURE
------	-----------

- | | |
|----|---|
| 1. | Install Speaker Wire Harness Assembly in Chassis Assembly. |
| 2. | Install four screws to secure Speaker Wire Harness Assembly to Chassis Assembly. Torque screws to 6 in/lbs. |



5.7.13.B.1 Follow-up Procedures:

Install Power Supply Assembly (5 - 35).

Install Disk I/O PCB Assembly (5 - 74/5 - 75).

Install Case Assembly (5 - 6).

5.7.14 LCD Assembly

5.7.14.A Remove LCD Assembly

5.7.14.A.1 Description

This procedure covers: Remove. Install.


5.7.14.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76/5 - 100).

STEP PROCEDURE


1. Remove four screws securing LCD Lens to Front Panel Assembly.



2. Remove LCD Lens from LCD Assembly. Avoid placing tension on connecting cables. Disconnect LCD Assembly cables from Inverter PCB Assembly.



3. Remove four standoff pins securing LCD Assembly to Front Panel Assembly. Remove LCD Assembly from Front Panel Assembly.




4. Remove ribbon cable from LCD Assembly if replacing LCD Assembly.

5.7.14.B Install LCD Assembly

5.7.14.B.1 Preliminary Procedure (if replacing LCD Display):

Remove protective film from front of new LCD Display.


Set LCD Assembly screen adjustment switches to match the configuration of the switches on the LCD Assembly being replaced. If the old LCD Assembly is not available, contact Aeroflex Customer Service. Please have the CPU Adapter PCB Assembly removed from unit and available when contacting customer service.




STEP

PROCEDURE

1. Place LCD Assembly with display side down on Front Panel Assembly. Install four standoff pins securing LCD Assembly to Front Panel Assembly. Torque standoff pins to 2 in/lbs.




2. Connect ribbon cable securely to LCD Assembly.




STEP

PROCEDURE

3. Connect cables from LCD Assembly securely to Inverter PCB Assembly.



4. Install LCD Lens on LCD Assembly. Install four screws securing LCD Lens to LCD Assembly. Torque screws to 2 in/lbs.



5.7.14.B.2 Follow-up Procedures:

Install Case Assembly (5 - 6).

Install Front Panel Assembly (5 - 78/5 - 102).

5.7.15 LCD Lens

5.7.15.A Remove LCD Lens

5.7.15.A.1 Description

This procedure covers: Remove. Install.

5.7.15.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

Remove Front Panel Assembly (5 - 76/5 - 100).


Remove LCD Assembly (5 - 38).

STEP	PROCEDURE
------	-----------

1. Remove screws securing LCD Bracket to Front Panel Assembly (total of 22 screws).



2. Remove LCD Bracket from Front Panel Assembly.



3. Remove LCD Lens from Front Panel Assembly.

5.7.15.B Install LCD Lens


5.7.15.B.1 Preliminary Procedures

Avoid touching surface of LCD Lens prior to installation. If necessary, LCD Lens may be cleaned with deionized water and a lint free cloth.


STEP	PROCEDURE
------	-----------

1. Install LCD Lens in Front Panel Assembly with raised surface facing out. Internal edge of the LCD Lens should be smooth as shown below.

CAUTION VERIFY LCD LENS IS CORRECTLY INSTALLED BEFORE PROCEEDING. INSTALLING THE LCD BRACKET WHEN THE LCD LENS IS INSTALLED "BACKWARDS", MAY RESULT IN DAMAGE TO THE TEST SET.




2. Install LCD Bracket to secure LCD Lens to Front Panel Assembly. Verify LCD Lens is centered in its frame when installing LCD Bracket.



STEP

PROCEDURE

3. Install screws securing LCD Bracket to Front Panel Assembly (total of 22 screws). Torque screws to 8 in/lbs.



5.7.15.B.2 Follow-up Procedures:

- Install LCD Assembly ([5 - 39](#)).
- Install Front Panel Assembly ([5 - 78/5 - 102](#)).
- Install Case Assembly ([5 - 6](#)).

5.7.16 Front Panel PCB Assembly

5.7.16.A Remove Front Panel PCB Assembly

5.7.16.A.1 Description

This procedure covers: Remove. Install.

5.7.16.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76/5 - 100).

STEP	PROCEDURE
------	-----------


1. Remove Rotary Control Knob from Front Panel Assembly. Pull to remove.



2. Place Front Panel Assembly with display side down on work surface. Remove four screws securing LCD Lens to Front Panel Assembly.




3. Remove LCD Lens and place flat on work surface. Avoid placing tension on connecting cables.




STEP

PROCEDURE


4. Remove four standoff pins securing LCD Assembly to Front Panel Assembly.




5. Move LCD Assembly to access Front Panel PCB Assembly.



6. Remove nine screws securing Front Panel PCB Assembly to Front Panel Assembly.



7. Remove Front Panel PCB Assembly from Front Panel Assembly.




5.7.16.B Install Front Panel PCB Assembly

STEP	PROCEDURE
------	-----------


1. Place Front Panel PCB Assembly on Front Panel Assembly.




2. Install nine screws securing Front Panel PCB Assembly to Front Panel Assembly. Torque screws to 6 in/lbs.



3. Reposition LCD Assembly. Install four standoff pins securing LCD Assembly to Front Panel Assembly. Torque standoff pins to 2 in/lbs.



4. Install LCD Lens on LCD Assembly. Install four screws securing LCD Lens to LCD Assembly. Torque screws to 2 in/lbs (32 in oz).



STEP

PROCEDURE

5. Install Rotary Control Knob on Front Panel Assembly.



5.7.16.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

Install Front Panel Assembly (5 - 78/5 - 102).

5.7.17 Keypad Assembly

5.7.17.A Remove Keypad Assembly

5.7.17.A.1 Description

This procedure covers: Remove. Install.

5.7.17.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

Remove Front Panel Assembly (5 - 76/5 - 100).

Remove Front Panel PCB Assembly (5 - 80/5 - 104).

STEP	PROCEDURE
------	-----------


1. Remove Keypad Assembly from Front Panel Assembly.



5.7.17.B Install Keypad Assembly

STEP	PROCEDURE
------	-----------

1. Install Keypad Assembly on Front Panel Assembly. Verify keypads are correctly positioned in Front Panel openings.



5.7.17.B.1 Follow-up Procedures:

Install Front Panel PCB Assembly (5 - 82/5 - 106).

Install Front Panel Assembly (5 - 78/5 - 102).

Case Assembly (5 - 6).

5.7.18 Inverter Supply PCB Assembly

5.7.18.A Remove Inverter Supply PCB Assembly

5.7.18.A.1 Description

This procedure covers: Remove. Install.


5.7.18.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76/5 - 100).

STEP	PROCEDURE
------	-----------


1. Remove four screws securing Display Shield to Front Panel Assembly.



2. Remove two nuts securing Inverter Supply PCB Assembly to Display Shield.




3. Remove Inverter Supply PCB Assembly and black spacer bar from Display Shield. Avoid placing tension on connecting cables.




STEP

PROCEDURE

4. Disconnect W2 Wire Harness from Inverter Supply PCB Assembly.



5. Disconnect wire harnesses from ends of Inverter Supply PCB Assembly.



5.7.18.B Replace Inverter Supply PCB Assembly

The Inverter Supply PCB Assembly is obsolete and has been replaced by the LED Backlight Driver. Refer to [7.3.4, Front Panel Assy \(3920/3920B\)](#) for replacement parts list.

5.7.18.B.1 Preliminary Procedures

STEP	PROCEDURE
------	-----------

1. Trim Inverter Insulator to 3" in length.
2. Center Inverter Insulator between holes in Display Shield.
3. Remove adhesive backing and apply Inverter Insulator to Display Shield.



4. Cut plastic fastener securing W2 Wire Harness, #64985, to Display Shield. Remove W2 Wire Harness, #64985 from Display Shield.
5. Insert new W2 Wire Harness, #90853, through opening in Display Shield.
6. Proceed to [5.7.19.B, Install LED Backlight Driver](#).

5.7.19 LED Backlight Driver

5.7.19.A Remove LED Backlight Driver

5.7.19.A.1 Description

This procedure covers: Remove. Install.


5.7.19.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76/5 - 100).

STEP PROCEDURE


1. Remove four screws securing Display Shield to Front Panel Assembly.



2. Remove Display Shield from Front Panel Assembly. Avoid placing tension on connecting cables.
3. Disconnect wire harnesses from LED Backlight Driver J1, J2 and J3 Connectors.



4. Remove two nuts securing LED Backlight Driver to Display Shield.




5. Remove LED Backlight Driver from Display Shield.
6. Remove nylon spacers and nylon screws from LED Backlight Driver.

5.7.19.B Install LED Backlight Driver


STEP	PROCEDURE
------	-----------

1. Insert two nylon screws through holes in LED Backlight Driver. Secure screws with nylon spacers. Tighten spacers until tension is felt.



CAUTION DO NOT OVER TIGHTEN NYLON SPACERS OR NYLON SCREWS MAY BREAK.


2. Connect two wire harnesses from LCD Assembly to LED Backlight Driver J2 and J3 Connectors.




3. Align LED Backlight Driver nylon screws with holes in Display Shield. Install LED Backlight Driver on Display Shield.

STEP	PROCEDURE
------	-----------


4. Install two nuts to secure LED Backlight Driver to Display Shield. Tighten nuts to 32 in/oz.



5. Connect W2 Wire Harness to LED Backlight Driver J1 Connector.
6. Secure W2 Wire Harness to Display Shield with plastic fastener.



7. Adjust tension on W2 Wire Harness and ensure it is properly connected to LED Backlight Driver.
8. Install Display Shield on LCD Assembly. Install four screws securing Display Shield to LCD Assembly. Torque screws to 2 in/lbs.



5.7.19.B.1 Follow-up Procedures:

Case Assembly ([5 - 6](#)).

Install Front Panel Assembly ([5 - 78/5 - 102](#)).

5.7.20 Power Termination Assembly

5.7.20.A Remove Power Termination Assembly

5.7.20.A.1 Description

This procedure covers: Remove. Install.


5.7.20.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76/5 - 100).

STEP PROCEDURE


1. Remove four screws securing Power Termination Assembly to bottom of Chassis Assembly.



2. Remove two screws securing fan shroud bracket and cover to Power Supply Assembly.




3. Remove fan shroud bracket and cover from Power Termination Assembly.



STEP

PROCEDURE


4. Disconnect two coaxial cables from back of Power Termination Assembly.



5. Pull Power Termination Assembly away from Chassis Assembly to disconnect from Backplane PCB Assembly connector.

NOTE

Power Termination Assembly connects directly into Backplane PCB Assembly. Use care when removing Power Termination Assembly to avoid damaging connector pins.




6. Remove Power Termination Assembly from Chassis Assembly.


5.7.20.B Install Power Termination Assembly

STEP	PROCEDURE
1.	Insert Power Termination Assembly in Chassis Assembly to align with Backplane PCB Assembly connector. Allow room to connect coaxial cables to back of Power Termination Assembly.


NOTE Power Termination Assembly connects directly into Backplane PCB Assembly. Use care when installing Power Termination Assembly to avoid damaging connector pins.



2. Connect two coaxial cables to Power Termination Assembly.




3. Install Power Termination Assembly securely into Chassis Assembly.
4. Install four screws securing Power Termination Assembly to bottom of Chassis Assembly. Torque screws to 6 in/lbs.



STEP

PROCEDURE

5. Install fan shroud and bracket over Power Termination Assembly. Install two screws securing fan shroud and bracket to Power Supply Assembly. Torque screws to 6 in/lbs.



5.7.20.B.1 Follow-up Procedures:

Install Front Panel Assembly ([5 - 78/5 - 102](#)).

Case Assembly ([5 - 6](#)).

5.7.21 Backplane PCB Assembly

5.7.21.A Remove Backplane PCB Assembly

5.7.21.A.1 Preliminary Procedures:


- Remove Case Assembly (5 - 4).
- Remove Attenuator Assembly (5 - 10).
- Remove Generator Assembly (5 - 63/5 - 86).
- Remove Receiver Assembly (5 - 67/5 - 91).
- Remove IF/Video PCB Assembly (5 - 72/5 - 95).
- Remove DAM Carrier PCB Assembly (5 - 12).
- Remove CAI PCB Assembly (5 - 14).
- Remove CPU Adapter PCB Assembly (5 - 16).
- Remove Disk I/O Assembly (5 - 74/5 - 99).
- Remove Floppy Disk Assembly (5 - 84) (3901/3902).
- Remove DMM Assembly ((5 - 107) (3920).
- Remove Power Termination Assembly (5 - 55).
- Remove Power Supply Assembly (5 - 33).
- Remove Front Panel Assembly (5 - 76/5 - 100).
- Remove Front Panel Digital PCB Assembly(5 - 80/5 - 104).
- Remove Rear Panel Assembly (5 - 21).
- Remove Rear Panel PCB Assembly (5 - 28).

STEP PROCEDURE

1. Remove four screws securing Card Cage Assembly to side of Chassis Assembly.



2. Remove four screws securing Card Cage Assembly to bottom of Chassis Assembly.




3. Remove Card Cage Assembly from Chassis Assembly.

STEP

PROCEDURE

4. Remove ten screws securing Backplane PCB Assembly to Chassis Assembly.




5. Remove Backplane PCB Assembly from Chassis Assembly.


5.7.21.B Install Backplane PCB Assembly

STEP	PROCEDURE
------	-----------


1. Install Backplane PCB Assembly in Chassis Assembly.
2. Install ten screws securing Backplane PCB Assembly to Chassis Assembly. Torque screws to 6 in/lbs.



3. Position Card Cage Assembly on top of Backplane PCB Assembly. Install four screws securing Card Cage Assembly to bottom of Chassis Assembly. Torque screws to 6 in/lbs.



STEP	PROCEDURE
4.	Install four screws securing Card Cage Assembly to Chassis Assembly. Torque screws to 8 in/lbs.



5.7.21.B.1 Follow-up Procedures:

- Install Rear Panel PCB Assembly (5 - 28).
- Install Rear Panel Assembly (5 - 24).
- Install Front Panel Digital PCB Assembly(5 - 82/5 - 106).
- Install Power Supply Assembly (5 - 35).
- Install Floppy Disk Assembly (5 - 85) (3901/3902).
- Install DMM Assembly (5 - 108) (3920)
- Install Power Termination Assembly (5 - 57).
- Install Disk I/O Assembly (5 - 75/5 - 99).
- Install Front Panel Assembly (5 - 78/5 - 102).
- Install Generator Assembly 5 - 65/5 - 89).
- Install Receiver Assembly (5 - 70/5 - 93).
- Install IF/Video PCB Assembly (5 - 73/5 - 97).
- Install DAM Carrier PCB Assembly (5 - 13).
- Install CAI PCB Assembly (5 - 15).
- Install CPU Adapter PCB Assembly (5 - 18).
- Install Attenuator Assembly (5 - 11).
- Install Case Assembly (5 - 6).

5.8 3901/3902 PROCEDURES

The following procedures apply specifically to the 3901 and 3902 models.

5.8.1 Generator Assembly 3901/3902

5.8.1.A Remove Generator Assembly

5.8.1.A.1 Description

This procedure covers: Remove. Install.


5.8.1.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Attenuator Assembly (5 - 10).

STEP	PROCEDURE
------	-----------

1. Remove screw securing Generator Assembly to bottom of Chassis Assembly.



2. Remove two screws securing black spacer bar and Generator Assembly to Card Cage Assembly. Remove black spacer bar.




3. Disconnect coaxial cables from Generator Assembly.
4. Disconnect coaxial cable from Receiver Assembly.


STEP

PROCEDURE

5. Remove screw securing Generator Assembly to Card Cage Assembly.



6. Grasp metal support brackets and remove Generator Assembly from Card Cage Assembly.



NOTE


Generator Assembly connects directly into Backplane PCB Assembly. Use care when removing Generator Assembly to avoid damaging connector pins.

5.8.1.B Install Generator Assembly


STEP	PROCEDURE
------	-----------

1. Insert Generator Assembly securely into Card Cage Assembly.


NOTE	Generator Assembly connects directly into Backplane PCB Assembly. Use care when installing Generator Assembly to avoid damaging connector pins.
-------------	---




2. Install screw securing Generator Assembly to Card Cage Assembly. Torque screw to 8 in/lbs.




3. Install black spacer bar. Install screws securing black spacer bar and Receiver and Generator Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.



- | STEP | PROCEDURE |
|------|--|
| 4. | Install screw securing Generator Assembly to bottom of Chassis Assembly. Torque screw to 8 in/lbs. |



5. Connect coaxial cables as shown below.



5.8.1.B.1 Follow-up Procedures:

- Install Attenuator Assembly (5 - 11).
- Install Case Assembly (5 - 6).

5.8.2 Receiver Assembly 3901/3902

5.8.2.A Remove Receiver Assembly

5.8.2.A.1 Description


This procedure covers: Remove. Install.

5.8.2.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP PROCEDURE

1. Remove screw securing Receiver Assembly to bottom of Chassis Assembly.




2. Disconnect coaxial cables from Receiver Assembly.




STEP

PROCEDURE


3. Disconnect coaxial cables from DAM Carrier PCB Assembly and IF/Video PCB Assembly.



4. Remove screws securing black spacer bar and Generator and Receiver Assembly to Card Cage Assembly. Remove black spacer bar.




5. Remove screw securing Receiver Assembly to Card Cage Assembly.



STEP

PROCEDURE

6. Grasp metal support brackets and remove Receiver Assembly from Card Cage Assembly.



NOTE


Receiver Assembly connects directly into Backplane PCB Assembly. Use care when removing Receiver Assembly to avoid damaging connector pins.

5.8.2.B Install Receiver Assembly


STEP	PROCEDURE
------	-----------

1. Insert Receiver Assembly securely into Card Cage Assembly.


NOTE	Receiver Assembly connects directly into Backplane PCB Assembly. Use care when installing Receiver Assembly to avoid damaging connector pins.
-------------	---




2. Install screw securing Receiver Assembly to Card Cage Assembly. Torque screw to 8 in/lbs.



3. Install black spacer bar. Install screws securing black spacer bar and Receiver and Generator Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.




4. Install screw securing Receiver Assembly to bottom of Chassis Assembly. Torque screw to 8 in/lbs.



STEP

PROCEDURE

5. Connect coaxial cables as shown below.



5.8.2.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.8.3 IF/Video PCB Assembly 3901/3902

5.8.3.A Remove IF/Video PCB Assembly

5.8.3.A.1 Description


This procedure covers: Remove. Install.

5.8.3.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------


1. Disconnect coaxial cable from Generator Assembly.
2. Disconnect coaxial cables from IF/Video PCB Assembly.



3. Remove two screws securing IF/Video PCB Assembly to Card Cage Assembly.



4. Grasp metal support brackets and remove IF/Video PCB Assembly from Card Cage Assembly.




NOTE	IF Video PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing IF/Video PCB Assembly to avoid damaging connector pins.
-------------	---

5.8.3.B Install IF/Video PCB Assembly


STEP	PROCEDURE
------	-----------

1. Insert IF/Video PCB Assembly securely into Card Cage Assembly.


NOTE	IF Video PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing IF/Video PCB Assembly to avoid damaging connector pins.
-------------	---



2. Install two screws securing IF/Video PCB Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.



3. Connect coaxial cables as shown below.



5.8.3.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.8.4 Disk I/O PCB Assembly 3901/3902

5.8.4.A Remove Disk I/O PCB Assembly (3901/3902)

5.8.4.A.1 Description


This procedure covers: Remove. Install.

5.8.4.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------


1. Open securing clip and disconnect ribbon cable from Disk I/O PCB Assembly.



2. Disconnect wire harness from Disk I/O PCB Assembly.



3. Remove two screws securing Disk I/O PCB Assembly to Power Supply Assembly.



4. Remove Disk I/O PCB Assembly from Chassis Assembly.

NOTE	Disk I/O PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing Disk I/O PCB Assembly to avoid damaging connector pins.
-------------	---


5.8.4.B Install Disk I/O PCB Assembly (3901/3902)

STEP	PROCEDURE
------	-----------


1. Install Disk I/O PCB Assembly in Chassis Assembly.

NOTE	Disk I/O PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing Disk I/O PCB Assembly to avoid damaging connector pins.
-------------	---


2. Install two screws securing Disk I/O PCB Assembly to Power Supply Assembly. Torque screws to 6 in/lbs.



3. Connect ribbon cable from Floppy Drive Assembly to Disk I/O PCB Assembly and close cable securing clip.



4. Connect wire harness from Speaker Wire Harness Assembly to Disk I/O PCB Assembly.



5.8.4.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.8.5 Front Panel Assembly 3901/3902

5.8.5.A Remove Front Panel Assembly

5.8.5.A.1 Description


This procedure covers: Remove. Install.

5.8.5.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------

1. Place Test Set with display side down on stable work surface. Remove outside screw from each corner of Front Panel corner bumper (total of eight screws).



2. Place Test Set on bottom side on stable work surface. Remove two screws from Test Connector.




3. Remove nuts from GEN, T/R and ANT Connectors.



STEP

PROCEDURE

4. Disconnect wire harness and ribbon cable from CPU Adapter PCB Assembly. Carefully pull through opening in Card Cage Assembly.




5. Remove Front Panel Assembly from Chassis Assembly.

NOTE

Use care when removing Front Panel Assembly to avoid damaging fingerstock.


6. Disconnect cables from Backplane PCB Assembly and Front Panel Digital PCB Assembly.




5.8.5.B Install Front Panel Assembly

STEP	PROCEDURE
------	-----------

1. Attach cables connecting Front Panel Assembly to Backplane PCB Assembly and Front Panel Digital PCB Assembly. Verify cables are secure at both ends.




2. Feed wire harness and ribbon cable from Front Panel Assembly through Card Cage Assembly and connect to CPU Adapter PCB Assembly.



3. Verify all cables and wire harnesses are securely connected and install Front Panel Assembly on Chassis Assembly.


NOTE	Use care when installing Front Panel Assembly to avoid pinching cables and/or damaging fingerstock.
-------------	---

4. Install screw at each corner of Front Panel corner bumpers (total of eight screws). Torque screws to 8 in/lbs.



STEP	PROCEDURE
------	-----------

5. Install two screws on Test Connector. Torque nuts to 4 in/lbs.



6. Install nuts at GEN, T/R and ANT Connectors. Torque nuts to 40 in/lbs.



5.8.5.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.8.6 Front Panel Digital Interface PCB Assembly 3901/3902

5.8.6.A Remove Front Panel Digital Interface PCB Assembly

5.8.6.A.1 Description

This procedure covers: Remove. Install.

5.8.6.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove IF/Video PCB Assembly (5 - 72).

Remove DAM Carrier PCB Assembly (5 - 12).


Remove Front Panel Assembly (5 - 76).

STEP PROCEDURE

1. Remove two screws securing metal heat sink and Front Panel Digital Interface PCB Assembly to Chassis Assembly.



2. Remove three screws securing Front Panel Digital Interface PCB Assembly to Chassis Assembly.




3. Remove screw securing Front Panel Digital Interface PCB Assembly to Chassis Assembly.



STEP

PROCEDURE

4. Remove screw securing Front Panel Digital Interface PCB Assembly to Chassis Assembly.



5. Remove Front Panel Digital Interface PCB Assembly from Chassis Assembly.

NOTE

Use care when removing Front Panel Digital Interface Assembly to avoid damaging components on bottom of assembly.

5.8.6.B Install Front Panel Digital Interface PCB Assembly

STEP	PROCEDURE
------	-----------


1. Place Front Panel Digital Interface PCB Assembly on Chassis Assembly.

NOTE	Use care when installing Front Panel Digital Interface Assembly to avoid damaging components on bottom of assembly.
-------------	---

2. Install three screws securing Front Panel Digital Interface PCB Assembly at front side of Chassis Assembly. Torque screws to 6 in/lbs.




3. Install screw securing Front Panel Digital Interface PCB Assembly inside of Chassis Assembly. Torque screw to 6 in/lbs.



4. Install screw securing corner of Front Panel Digital Interface PCB Assembly at side of Chassis Assembly. Torque screw to 6 in/lbs.



STEP	PROCEDURE
5.	Install metal heat sink and two screws securing Front Panel Digital Interface PCB Assembly to Chassis Assembly. Torque screws to 6 in/lbs.



5.8.6.B.1 Follow-up Procedures:

- Install Front Panel Assembly ([5 - 78](#)).
- Install IF/Video PCB Assembly ([5 - 73](#)).
- Install DAM Carrier PCB Assembly ([5 - 13](#)).
- Install Case Assembly ([5 - 6](#)).

5.8.7 Floppy Drive Assembly 3901/3902

5.8.7.A Remove Floppy Drive Assembly

5.8.7.A.1 Description

This procedure covers: Remove. Install.


5.8.7.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 76).

STEP	PROCEDURE
------	-----------


1. Open securing clip and disconnect ribbon cable from Floppy Drive Assembly.



2. Remove four screws securing Floppy Drive Assembly to Chassis Assembly.




3. Remove Floppy Bracket containing Floppy Drive Assembly from Chassis Assembly.
4. Remove two screws securing Floppy Drive Assembly to Floppy Bracket. Repeat procedure on other side. Remove Floppy Drive Assembly from Floppy Bracket.



5.8.7.B Install Floppy Drive Assembly

STEP	PROCEDURE
------	-----------


1. Install Floppy Drive Assembly in Floppy Bracket. Align holes in Floppy Bracket with screw holes in Floppy Drive Assembly as shown in picture below.




2. Install two screws securing Floppy Drive Assembly to Floppy Bracket. Torque screws to 6 in/lbs. Repeat procedure on other side.



3. Insert Floppy Bracket containing Floppy Drive Assembly in Chassis Assembly.
4. Install four screws securing Floppy Bracket containing Floppy Drive Assembly to Chassis Assembly. Torque screws to 6 in/lbs.



5. Connect ribbon cable from Disk I/O PCB Assembly to Floppy Drive Assembly and close securing clip.



5.8.7.B.1 Follow-up Procedures:

- Install Front Panel Assembly (5 - 78).
- Install Case Assembly (5 - 6).

5.9 3920/3920B PROCEDURES

The following procedures apply specifically to the 3920 and 3920B models.

NOTE

Images show 3920 hardware configuration. 3920B hardware configuration varies slightly from the 3920 but the remove/install procedures are identical.

5.9.1 Generator Assembly 3920/3920B

5.9.1.A Remove Generator Assembly

5.9.1.A.1 Description

This procedure covers: Remove. Install.


5.9.1.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE

1. Remove screw securing Generator Assembly to bottom of Chassis Assembly.




2. Remove two screws securing black spacer bar and Generator Assembly to Card Cage Assembly. Remove black spacer bar.




STEP

PROCEDURE


3. Remove five screws securing metal support bracket and Generator Assembly to Card Cage Assembly. Remove metal support bracket.



4. Disconnect coaxial cables connected to Generator Assembly.
5. Disconnect coaxial cable from Receiver Assembly.




6. Disconnect coaxial cable and ribbon cable from Attenuator Assembly.



STEP

PROCEDURE

7. Grasp metal support brackets and remove Generator Assembly from Card Cage Assembly.



NOTE

Generator Assembly connects directly into Backplane PCB Assembly. Use care when removing Generator Assembly to avoid damaging connector pins.

5.9.1.A.3 Follow-up Procedures:

Remove Attenuator Assembly (5 - 10).


5.9.1.B Install Generator Assembly

5.9.1.B.1 Preliminary Procedures

Install Attenuator Assembly (5 - 11).


STEP PROCEDURE

1. Insert Generator Assembly securely into Card Cage Assembly.




NOTE Generator Assembly connects directly into Backplane PCB Assembly. Use care when installing Generator Assembly to avoid damaging connector pins.


2. Install black spacer bar. Install two screws securing black spacer bar and Receiver and Generator Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.



3. Install screw securing Generator Assembly to bottom of Chassis Assembly. Torque screw to 8 in/lbs.




4. Connect ribbon cable and coaxial cable to Attenuator Assembly. Torque coaxial cable to 8 in/lbs.




STEP

PROCEDURE

5. Connect cables to Generator and Receiver Assembly as shown below.



6. Install metal support bracket. Install five screws securing metal support bracket and Generator Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.



5.9.1.B.2 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.9.2 Receiver Assembly 3920/3920B

5.9.2.A Remove Receiver Assembly

5.9.2.A.1 Description

This procedure covers: Remove. Install.

5.9.2.A.2 Preliminary Procedures


Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------


1. Remove screw securing Receiver Assembly to bottom of Chassis Assembly.



2. Remove two screws securing black spacer bar and Receiver Assembly to Card Cage Assembly. Remove black spacer bar.




3. Remove five screws securing metal support bracket and Receiver Assembly to Card Cage Assembly. Remove metal support bracket.




4. Disconnect coaxial cable from Receiver Assembly.

STEP PROCEDURE


5. Disconnect cables from Receiver Assembly.



6. Disconnect coaxial cables from IF/Video PCB Assembly.
7. Disconnect coaxial cable from DAM Carrier PCB Assembly.



8. Grasp metal support brackets and remove Receiver Assembly from Card Cage Assembly.




NOTE

Receiver Assembly connects directly into Backplane PCB Assembly. Use care when removing Receiver Assembly to avoid damaging connector pins.

5.9.2.B Install Receiver Assembly


STEP PROCEDURE

1. Insert Receiver Assembly securely into Card Cage Assembly.




NOTE Receiver Assembly connects directly into Backplane PCB Assembly. Use care when installing Receiver Assembly to avoid damaging connector pins.

2. Install black spacer bar. Install screws securing black spacer bar and Receiver Assembly to Card Cage Assembly. Torque screws to 8 in/lbs.



3. Install screw securing Receiver Assembly to bottom of Chassis Assembly. Torque screw to 8 in/lbs.




STEP	PROCEDURE
------	-----------

4. Connect cables as shown below.



5. Install metal support bracket. Install five screws securing metal support bracket and Receiver Assembly to Card Cage Assembly. Torque screw to 8 in/lbs.



5.9.2.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.9.3 IF/Video PCB Assembly 3920/3920B

5.9.3.A Remove IF/Video PCB Assembly

5.9.3.A.1 Description

This procedure covers: Remove. Install.


5.9.3.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE

1. Remove five screws securing metal support bracket and IF/Video PCB Assembly to Card Cage Assembly. Remove metal support bracket.




2. Remove screw securing IF/Video PCB Assembly to Card Cage Assembly.




STEP

PROCEDURE

3. Disconnect coaxial cables from DAM Carrier PCB Assembly and IF/Video PCB Assembly.



4. Grasp metal support brackets and remove IF/Video PCB Assembly from Card Cage Assembly.



NOTE

IF Video PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing IF/Video PCB Assembly to avoid damaging connector pins.


5.9.3.B Install IF/Video PCB Assembly

STEP	PROCEDURE
------	-----------

1. Insert IF/Video PCB Assembly securely into Card Cage Assembly.

NOTE


IF Video PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing IF/Video PCB Assembly to avoid damaging connector pins.



2. Connect coaxial cables as shown below.



3. Install metal support bracket. Install five screws securing metal support bracket and Receiver Assembly to Card Cage Assembly. Torque screw to 8 in/lbs.



5.9.3.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.9.4 Disk I/O PCB Assembly 3920/3920B

5.9.4.A Remove Disk I/O PCB Assembly

5.9.4.A.1 Description

This procedure covers: Remove. Install.


5.9.4.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


STEP

PROCEDURE

1. Remove two screws securing Disk I/O PCB Assembly to Power Supply Assembly.



2. Disconnect wire harness cables from Disk I/O PCB Assembly.



3. Remove Disk I/O PCB Assembly from Chassis Assembly.


NOTE	Use care when removing Disk I/O PCB Assembly to avoid pulling Front Panel USB Cable. Disk I/O PCB Assembly connects directly into Backplane PCB Assembly. Use care when removing Disk I/O PCB Assembly to avoid damaging connector pins.
-------------	--

5.9.4.B Install Disk I/O PCB Assembly


STEP	PROCEDURE
------	-----------

1. Install Disk I/O PCB Assembly in Chassis Assembly. Route Front Panel USB Cable so it is positioned between Disk I/O PCB Assembly Oscillator component and connector.


NOTE	Disk I/O PCB Assembly connects directly into Backplane PCB Assembly. Use care when installing Disk I/O PCB Assembly to avoid damaging connector pins.
-------------	---



2. Connect wire harness from Speaker Wire Harness Assembly to Disk I/O PCB Assembly.
3. Connect wire harness from DMM Assembly to Disk I/O PCB Assembly.



4. Install two screws securing Disk I/O PCB Assembly to Power Supply Assembly. Torque screws to 6 in/lbs.



5.9.4.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.9.5 Front Panel Assembly 3920/3920B

5.9.5.A Remove Front Panel Assembly

5.9.5.A.1 Description


This procedure covers: Remove. Install.

5.9.5.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).

STEP	PROCEDURE
------	-----------

1. Place Test Set with display side down on stable work surface. Remove outside screw from each corner of Front Panel corner bumper (total of eight screws).



2. Place Test Set on bottom side on stable work surface. Remove two screws from Test Connector.




3. Remove nuts from GEN, T/R and ANT Connectors.



STEP

PROCEDURE


4. Disconnect wire harness and ribbon cable from CPU Adapter PCB Assembly.



5. Disconnect USB Cable from Front Panel Assembly, accessing from opening in side of Chassis Assembly.




6. Remove Front Panel Assembly from Chassis Assembly. Use care to avoid damaging fingerstock.
7. Disconnect ribbon cable and coaxial cables from Front Panel Digital PCB Assembly and Backplane PCB Assembly.




5.9.5.B Install Front Panel Assembly

STEP	PROCEDURE
------	-----------


1. Connect USB Connector to Front Panel Assembly. Verify USB Cable is positioned properly in Card Cage Assembly, USB Cable should be flat.



2. Connect ribbon cable and coaxial cables from Front Panel Assembly to Front Panel Digital PCB Assembly and Backplane PCB Assembly. Verify cables are tightly secured at both ends.



3. Feed wire harness and ribbon cable from Front Panel Assembly through Card Cage Assembly and connect to CPU Adapter PCB Assembly.



STEP


PROCEDURE

4. Verify all cables and wire harnesses are securely connected and install Front Panel Assembly on Chassis Assembly.

NOTE

Use care when installing Front Panel Assembly to avoid pinching cables and/or damaging fingerstock.

5. Install screw at each corner of Front Panel corner bumpers (total of eight screws). Torque screws to 8 in/lbs.



6. Install two screws on Test Connector. Torque nuts to 4 in/lbs.



7. Install nuts at GEN, T/R and ANT Connectors. Torque nuts to 40 in/lbs.



5.9.5.B.1 Follow-up Procedures:

Install Case Assembly (5 - 6).

5.9.6 Front Panel Digital Interface PCB Assembly 3920/3920B

5.9.6.A Remove Front Panel Digital Interface PCB Assembly

5.9.6.A.1 Description

This procedure covers: Remove. Install.

5.9.6.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).

Remove IF/Video PCB Assembly (5 - 95).

Remove DAM Carrier PCB Assembly (5 - 12).


Remove Front Panel Assembly (5 - 100).

STEP	PROCEDURE
------	-----------

1. Remove screw securing Front Panel Digital Interface PCB Assembly inside of Chassis Assembly.



2. Remove five screws securing Front Panel Digital Interface PCB Assembly at front of Chassis Assembly.



STEP

PROCEDURE

3. Remove screw securing Front Panel Digital Interface PCB Assembly at side of Chassis Assembly.



4. Remove Front Panel Digital Interface PCB Assembly from Chassis Assembly.

NOTE

Use care when removing Front Panel Digital Interface PCB Assembly to avoid damaging components on bottom of assembly.


5.9.6.B Install Front Panel Digital Interface PCB Assembly

STEP	PROCEDURE
------	-----------


1. Place Front Panel Digital Interface PCB Assembly on Chassis Assembly.

NOTE	Use care when installing Front Panel Digital Interface PCB Assembly to avoid damaging components on bottom of assembly.
-------------	---

2. Install five screws securing Front Panel Digital Interface PCB Assembly to Chassis Assembly. Torque screws to 6 in/lbs.



3. Install screw securing Front Panel Digital Interface PCB Assembly to Chassis Assembly. Torque screw to 6 in/lbs.



4. Install screw securing corner of Front Panel Digital Interface PCB Assembly to Chassis Assembly. Torque screw to 6 in/lbs.



5.9.6.B.1 Follow-up Procedures:

- Install Front Panel Assembly (5 - 102).
- Install IF/Video PCB Assembly (5 - 97).
- Install DAM Carrier PCB Assembly (5 - 13).
- Install Case Assembly (5 - 6).

5.9.7 DMM Assembly (3920 Optional Hardware)

5.9.7.A Remove DMM Assembly

5.9.7.A.1 Description

This procedure covers: Remove. Install.

5.9.7.A.2 Preliminary Procedures

Remove Case Assembly (5 - 4).


Remove Front Panel Assembly (5 - 100).

STEP PROCEDURE


1. Remove mounting screw from Disk I/O PCB Assembly.




2. Detach wire harness assembly from DMM Assembly connector pins.



3. Remove three screws securing DMM Assembly to Chassis Assembly.



4. Remove DMM Assembly from Chassis Assembly.




5.9.7.B Install DMM Assembly


STEP

PROCEDURE


1. Insert DMM Assembly in Chassis Assembly. Align DMM connector pins with connector clip when inserting DMM Assembly.




2. Install three screws securing DMM Assembly to Chassis Assembly. Torque screws to 6 in/lbs.



3. Attach wire harness assembly to DMM Assembly connector pins.



4. Install mounting screw to Disk I/O PCB Assembly. Torque screws to 6 in/lbs.



5.9.7.B.1 Follow-up Procedures:

Install Front Panel Assembly (5 - 102).

Install Case Assembly (5 - 6).

5.9.8 USB Cable (3920 Front Panel)

5.9.8.A Remove USB Cable (Front Panel)


5.9.8.A.1 Preliminary Procedures:

Remove Case Assembly (5 - 4).


Remove Power Supply Assembly (5 - 33).

STEP	PROCEDURE
------	-----------

1. Disconnect USB Cable from Backplane PCB Assembly USB Connector.



2. Cut plastic ties (if applicable) securing USB Cable to Card Cage Assembly.




3. Remove USB Cable from Card Cage Assembly.


5.9.8.B Install USB Cable (3920 Front Panel)

STEP PROCEDURE


1. Wrap USB Cable as shown below and secure to Card Cage Assembly with plastic fasteners.



2. Connect female end of USB Cable to Backplane PCB Assembly USB Connector.
3. Route USB Cable so it is positioned between Disk I/O PCB Assembly Oscillator component and connector.



4. Feed male end of USB Cable through front of Card Cage Assembly, under DMM Assembly. Pull USB Cable 2-3" from front edge of Care Cage Assembly.



5.9.8.B.1 Follow-up Procedures:

- Install Power Supply Assembly (5 - 35).
- Install Case Assembly (5 - 6).

Chapter 6 - Interconnect and Assembly Diagrams

6.1 GENERAL

This chapter contains Interconnect and Assembly Diagrams for the 3901/3902 and 3920/3920B. The table below lists assemblies alphabetically. Refer to Chapter 7, Parts List for reference designator identification and part numbers and photos of replaceable parts.


Description	Page
3901/3902 Chassis Assy	6 - 5
3920/3920B Chassis Assy	6 - 9
3901 Composite Assy	6 - 3
3902 Composite Assy	6 - 3
3920 Composite Assy	6 - 6
3920B Composite Assy	6 - 7
3901/3902 Composite Assy Interconnect Diagram	6 - 4
3920 Composite Assy Interconnect Diagram	6 - 7
3920B Composite Assy Interconnect Diagram	6 - 8
Front Panel Cables	6 - 10
Front Panel Assembly	6 - 13
Backplane PCB Assy Connectors	6 - 14

NOTE	Due to variations in hardware configuration, actual cable color and assembly appearance may vary from the pictures provided in this chapter.
-------------	--

THIS PAGE INTENTIONALLY LEFT BLANK.

6.2

3901/3902 COMPOSITE ASSEMBLY



CAUTION:
CONTAINS PARTS AND ASSEMBLIES SUSCEPTIBLE TO
DAMAGE BY ELECTROSTATIC DISCHARGE (ESD).

Fig. 6-1 3901 (24711) and 3902 (24710) Composite Assembly

Subject to Export Control, see Cover Page for details.

6.3 3901/3902 COMPOSITE ASSY INTERCONNECT DIAGRAM




Fig. 6-2 3901/3902 Composite Assy Interconnect Diagram

Subject to Export Control, see Cover Page for details.

6.4

3901/3902 CHASSIS ASSY





Fig. 6-3 3901/3902 (64400) Chassis Assy

6.5

3920/3920B COMPOSITE ASSEMBLY




 **CAUTION:**
CONTAINS PARTS AND ASSEMBLIES SUSCEPTIBLE TO
DAMAGE BY ELECTROSTATIC DISCHARGE (ESD).

Fig. 6-4 3920 (72412) / 3920B (91164) Composite Assembly

Subject to Export Control, see Cover Page for details.

6.6 3920 COMPOSITE ASSY INTERCONNECT DIAGRAM




Fig. 6-5 3920 Composite Ass'y Interconnect Diagram

Subject to Export Control, see Cover Page for details.

6.7 3920B COMPOSITE ASSY INTERCONNECT DIAGRAM





Fig. 6-6 3920B Composite Assy Interconnect Diagram

Subject to Export Control, see Cover Page for details.




 **CAUTION:**
CONTAINS PARTS AND ASSEMBLIES SUSCEPTIBLE TO
DAMAGE BY ELECTROSTATIC DISCHARGE (ESD).

Fig. 6-7 3920/3920B (64417) Chassis Assy

6.9 FRONT PANEL CABLES




Fig. 6-8 3901/3902 Front Panel Cables




Fig. 6-9 3920/3920B Front Panel Cables

6.10 ASSEMBLY AND CABLE LOCATIONS




Fig. 6-10 3901/3902/3920 Assembly Locations




Fig. 6-11 3920B Assembly Locations




Fig. 6-12 3901/3902/3920 Cable Locations




Fig. 6-13 3920B Cable Locations




Fig. 6-14 Rear Panel Cables




Fig. 6-15 Power Term Cables

6.11 FRONT PANEL ASSEMBLY




Fig. 6-16 Front Panel Assembly
3901/3902 (64402) / 3920/3920B (64418)





Fig. 6-17 Front Panel Assembly (64418-C0/D0)



*J18 Applies to 3920 only and is a USB connection.
*J15 Applies to 3901/3902 only.

Fig. 6-18 Backplane PCB Assy Connectors (65654)

Chapter 7 - Parts List

7.1 GENERAL

This section contains the part numbers and descriptions for replaceable parts and assemblies in the 3901, 3902, 3920 and 3920B Test Sets. All items apply to 3901, 3902, 3920 and 3920B except as indicated.

ASSEMBLY	PAGE
3901/3902 Assemblies/Subassemblies	7 - 2
3901/3902 Composite Assembly	7 - 2
3901/3902 Chassis Assy	7 - 3
Front Panel Assy (3901/3902)	7 - 4
Rear Panel Assy	7 - 4
3920/3920B Assemblies/Subassemblies	7 - 5
3920 Composite Assembly	7 - 5
3920B Composite Assembly	7 - 6
3920/3920B Chassis Assy	7 - 7
Front Panel Assy (3920/3920B)	7 - 8
Rear Panel Assy	7 - 8
CPU Adapter Battery	7 - 8
DMM Fuse	7 - 8
Replacement Parts Pictures	7 - 9
Composite Assembly Replacement Parts	7 - 9
Chassis Assembly Replacement Parts	7 - 10
Front Panel Replacement Parts	7 - 13
Miscellaneous Parts	7 - 14
Accessories	7 - 15
Standard Accessories	7 - 15
Optional Accessories	7 - 16

7.2 3901/3902 ASSEMBLIES/SUBASSEMBLIES

7.2.1 3901/3902 Composite Assembly

Refer to [Fig. 6.2 3901/3902 Composite Assembly](#).

	Reference Designator	Part Number	Description
	1	10226	CASE,WRAP
	2	35404	SPACER,CASE SUPPORT
	A1	64400	MECH ASSY,CHASSIS
1	A2	64405	MECH ASSY,REAR PANEL
	A3	64413	MECH ASSY,ATTENUATOR
2	A4	64420	MECH ASSY,GENERATOR
	A5	87419	PCB ASSY, IF VIDEO
	A7	64419	MECH ASSY,RECEIVER
3	A8	65682	PCB ASSY,CAI
	A9	67344	PURCH,MOLDED HANDLE
	A10	65691	PCB ASSY,DAM CARRIER
	W9	62566	COAX ASSY,ATT/GEN
		10456	AC25023 FRONT/REAR COVER

NOTE

- 1 64405, Rear Panel Assy must be returned to the factory for model and serial number identification and confirmation before replacement assembly will be shipped.
- 2 64420, Mech Assy, Generator is obsolete. Contact Customer Service for replacement information.
- 3 65682, PCB Assy, CAI is obsolete. Replaced by 92823.

7.2.2 3901/3902 Chassis Assy

Refer to [Fig. 6.4 3901/3902 Chassis Assy](#).

	Reference Designator	Part Number	Description
	1	9424	BRACKET, FAN SHROUD
1	2	9995	PANEL, CHASSIS REAR
	3	9422	BRACKET, POWER SUPPLY MTG64417
1	4	9831	CHASSIS, MAIN
1	5	9426	BRACKET, FLOPPY
1	6	69675	RUBBER, GAP PAD .100 THK
1	7	56617	HEATSINK, DIGITAL PCB
	8	10455	COVER, FAN SHROUD
	9	9421	BRACKET, CARD CAGE
	A1	65654	PCB ASSY, BACKPLANE
	A2	65673	PCB ASSY, FT PNL DIG INTRF
	A3	65659	PCB ASSY, REAR PANEL
	A4	64402	MECH ASSY, FRONT PANEL
	A5	65690	PCB ASSY, CPU ADAPTER
	A6	64401	MECH ASSY, POWER SUPPLY
	A7	64408	MECH ASSY, POWER TERM
	A8	67342	ASSY, FLOPPY DRIVE
	A9	65650	PCB ASSY, DISK I/O
	A10	65676	PCB ASSY, RP AUDIO I/O
	B1	64409	FAN ASSY
	B2	64414	FAN ASSY
	LS1	64983	WIRE HARN ASSY, SPEAKER
	W1	62903	RIBBON CA ASSY, 10-C, 8.3LG
	W2	62903	RIBBON CA ASSY, 10-C, 8.3LG
	W5	62909	RIBBON CA ASSY, GPIB
	W6	62831	COAX ASSY,CONF,11.0,SSMB,F,RA/SMA,M,ST
	W7	62830	COAX ASSY,CONF,11.0,SSMB,F,RA/SSMB,F,RA
1	W11	63129	CABLE ASSY, FFC, TYPE D, 38MM
	W13	62908	RIBBON CA ASSY,2MM,20-C,4.0L
	W14	63313	COAX ASSY,RG316,6.0,SSMB,F,RA/SSMB,F,RA
	W15	63313	COAX ASSY,RG316,6.0,SSMB,F,RA/SSMB,F,RA

NOTE

1 Indicates obsolete part. Contact Customer Service for replacement information.

7.2.3 Front Panel Assy (3901/3902)

Refer to [Fig. 6.11 Front Panel Assembly](#).

	Reference Designator	Part Number	Description
	3	11235	BUMPER, CORNER FRONT
	5	30704	KNOB, SPNR, 1.5 DIA, X.66LG, ST DK
	8	33785	SHIELD, DISPLAY
2	12	35402	SPACER, INVERTER BRD
	13	35866	STANDOFF, SHIELD HEX
	14	46682	LENS, TS TFT DISPLAY
	22	35603	SCREW, 4-40 3 3/8, NYLON
3	25	35403	SPACER, 390X SPINNER
	26	9427	BRACKET, FT PNL LENS
4	27	34224	GASKET, SPACER, SPINNER
	A1	65653	PCB ASSY, FRONT PANEL
1	A2	67353	DISPLAY, LCD, 6.4"
	A3	67355	ASSY, KEYPAD
1	A4	67330	PCB ASSY, INVERTER SPLY
	W1	62902	CABLE ASSY, DISPLAY
5	W2	64985	WIRE HARN ASSY, INVERTER

NOTE

- 1 Indicates obsolete part. Contact Customer Service for replacement information.
- 2 35402, Spacer, 390X Spinner is obsolete. Replaced by 90661.
- 3 35403, Spacer, Inverter Brd is obsolete. Replaced by 89875.
- 4 34224, Gasket, Spacer, Spinner is obsolete. Replaced by 89874.
- 5 64985, Wire Harness Assy, Inverter is obsolete. Replaced by 90583.

7.2.4 Rear Panel Assy

Reference Designator	Part Number	Description
--	10227	BUMPER, CORNER REAR

7.2.5 CPU Adapter Battery

Reference Designator	Part Number	Description
--	46825	BATTERY, LITHIUM, 3V

7.3 3920/3920B ASSEMBLIES/SUBASSEMBLIES

7.3.1 3920 Composite Assembly

Refer to Fig. 6.5 3920/3920B Composite Assembly.

	Reference Designator	Part Number	Description
	1	10226	CASE,WRAP
	2	35404	SPACER,CASE SUPPORT
	3	33521	PLATE,HOLD DOWN
	A1	64417	MECH ASSY,CHASSIS,3920
1	A2	64421	MECH ASSY,REAR PANEL,3920
	A3	64413	MECH ASSY,ATTENUATOR
2	A4	64420	MECH ASSY,GENERATOR,3920
	A5	87419	PCB ASSY, IF VIDEO
	A7	64419	MECH ASSY,RECEIVER,3920
3	A8	65682	PCB ASSY,CAI
	A9	67344	PURCH,MOLDED HANDLE
	A10	65691	PCB ASSY,DAM CARRIER
	W9	62566	COAX ASSY,ATT/GEN
		10456	AC25023 FRONT/REAR COVER
		63938	KIT,STD CORD/ACCESSORY

NOTE

- 1 64421, Rear Panel Assy must be returned to the factory for model and serial number identification and confirmation before replacement assembly will be shipped.
- 2 64420, Mech Assy, Generator is obsolete. Contact Customer Service for replacement information.
- 3 65682, PCB ASSY, CAI is obsolete. Replaced by 92823.

7.3.2 3920B Composite Assembly

Refer to [Fig. 6.5 3920/3920B Composite Assembly](#).

	Reference Designator	Part Number	Description
	1	10226	CASE, WRAP
	2	35404	SPACER, CASE SUPPORT
	3	33521	PLATE, HOLD DOWN
	A1	64417	MECH ASSY, CHASSIS, 3920
1	A2	64421	MECH ASSY, REAR PANEL, 3920*
	A3	64413	MECH ASSY, ATTENUATOR
	A4	91532	MECH ASSY, GENERATOR, LOW NOISE, 3920B
	A5	87419	PCB ASSY, IF VIDEO
	A7	64419	MECH ASSY, RECEIVER, 3920
2	A8	65682	PCB ASSY, CAI
	A9	67344	PURCH, MOLDED HANDLE
	A10	65691	PCB ASSY, DAM CARRIER
	W9	62566	COAX ASSY, ATT/GEN
		10456	AC25023 FRONT/REAR COVER
		63938	KIT, STD CORD/ACCESSORY

NOTE

- 1 64421, Rear Panel Assy must be returned to the factory for model and serial number identification and confirmation before replacement assembly will be shipped.
- 2 65682, PCB ASSY, CAI is obsolete. Replaced by 92823.

7.3.3 3920/3920B Chassis Assy

Refer to [Fig. 6.8 3920/3920B Chassis Assy](#).

Reference Designator	Part Number	Description
1	9424	BRACKET, FAN SHROUD
2	9421	BRACKET, CARD CAGE
3	9999	PANEL, CHASSIS REAR
4	9422	BRACKET, POWER SUPPLY MTG
5	9832	CHASSIS, MAIN,3920
6	10455	COVER, FAN SHROUD
A1	65654	PCB ASSY, BACKPLANE
A2	65686	PCB ASSY, FT PNL DIG INTRFC
A3	65659	PCB ASSY, REAR PANEL
A4	64418	MECH ASSY, FRONT PANEL, 3920
A5	65690	PCB ASSY, CPU ADAPTER
A6	64401	MECH ASSY, POWER SUPPLY
A7	64408	MECH ASSY, POWER TERM
A9	65688	PCB ASSY, DISK I/O
A10	65676	PCB ASSY, RP AUDIO I/O
A11	64416	MECH ASSY, DMM, 3920
B1	64409	FAN ASSY
B2	64414	FAN ASSY
LS1	64983	WIRE HARN ASSY, SPEAKER
W1	62903	RIBBON CA ASSY, 10-C,8.3LG
W2	62903	RIBBON CA ASSY, 10-C,8.3LG
W5	62909	RIBBON CA ASSY, GPIB
W6	62831	COAX ASSY,CONF,11.0,SSMB,F,RA/SMA,M,ST
W7	62830	COAX ASSY,CONF,11.0,SSMB,F,RA/SSMB,F,RA
W13	62908	RIBBON CA ASSY,2MM,20-C,4.0L
W14	63313	COAX ASSY,RG316,6.0,SSMB,F,RA/SSMB,F,RA
W15	63313	COAX ASSY,RG316,6.0,SSMB,F,RA/SSMB,F,RA
W17	62376	CABLE ASSY, USB-A/USB M INI-B

7.3.4 Front Panel Assy (3920/3920B)

Refer to [Fig. 6.11 Front Panel Assembly](#).

	Reference Designator	Part Number	Description
	3	11235	BUMPER, CORNER FRONT
	5	30704	KNOB, SPNR, 1.5 DIA, X.66LG, ST DK
	8	33785	SHIELD, DISPLAY
1	12	35402	SPACER, INVERTER BRD
	13	35866	STANDOFF, SHIELD HEX
	14	46682	LENS, TS TFT DISPLAY
	18	42264	INSULATOR, INVERTER
	22	35603	SCREW, 4-40 3 3/8, NYLON
2	25	35403	SPACER, 390X SPINNER
	26	9427	BRACKET, FT PNL LENS
3	27	34224	GASKET, SPACER, SPINNER
	A1	65653	PCB ASSY, FRONT PANEL
4	A2	67353	DISPLAY, LCD, 6.4"
5	A3	67355	ASSY, KEYPAD
6	A4	67330	PCB ASSY, INVERTER SPLY
	W1	62902	CABLE ASSY, DISPLAY
7	W2	64985	WIRE HARN ASSY, INVERTER

NOTE

- 1 35402, Spacer, 390X Spinner is obsolete. Replaced by 90661.
- 2 35403, Spacer, Inverter Brd is obsolete. Replaced by 89875.
- 3 34224, Gasket, Spacer, Spinner is obsolete. Replaced by 89874.
- 4 67353, Display, LCD 6.4" is obsolete. Replaced by 90611.
- 5 Replacing Keypad Assy 67355 may require replacement of the following items: 89875 and 89874. Contact Aeroflex Customer Service before ordering replacement for 67355.
- 6 67330, PCB Assy, Inverter Sply is obsolete. Replaced by 90585. Replacing Inverter Supply PCB Assembly (67330) requires the following items: 90585, 90853, 42264 and 90661.
- 7 64985, Wire Harness Assy, Inverter is obsolete. Replaced by 90583.

7.3.5 Rear Panel Assy

Reference Designator	Part Number	Description
--	10227	BUMPER, CORNER REAR

7.3.6 CPU Adapter Battery

Reference Designator	Part Number	Description
--	46825	BATTERY, LITHIUM, 3V

7.3.7 DMM Fuse

Reference Designator	Part Number	Description
--	56083	FUSE, 3A, 125V, PCB MOUNT

7.4 REPLACEMENT PARTS PICTURES

NOTE


Graphics are for reference only. Part appearance may vary depending on part revision.

7.4.1 Composite Assembly Replacement Parts

10226
CASE, WRAP




33521
PLATE, HOLD DOWN (3920 only)




35404
SPACER, CASE SUPPORT




64413
MECH ASSY, ATTENUATOR




64421
64405
MECH ASSY, REAR PANEL



64419
MECH ASSY, RECEIVER




64420 (obsolete)
MECH ASSY, GENERATOR




7.4.1 Composite Assembly Replacement Parts (cont)


87419
PCB ASSY, IF VIDEO



65682 (replaced by 92823)
PCB ASSY, CAI



65691
PCB ASSY, DAM CARRIER



67344
ASSY, HANDLE




7.4.2 Chassis Assembly Replacement Parts


9422
BRACKET, POWER SUPPLY MTG




9424
BRACKET, FAN SHROUD



9421
BRACKET, CARD CAGE




9995 (obsolete)
PANEL CHASSIS REAR (390X)




7.4.2 Chassis Assembly Replacement Parts (cont)

9999
PANEL CHASSIS REAR (3920)




10455
COVER, FAN SHROUD




64401
MECH ASSY, POWER SUPPLY




64402 (3901/3902)
MECH ASSY, FRONT PANEL



64408
MECH ASSY, POWER TERM




64418 (3920)
MECH ASSY, FRONT PANEL



64409
FAN ASSY (B1)




64414
FAN ASSY (B2)



7.4.2 Chassis Assembly Replacement Parts (cont)


64416 (n/a 3901/3902)
DMM (DIGITAL MULTIMETER)




64983
WIRE HARNESS ASSY, SPEAKER



65650 (3901/3902)
PCB ASSY, DISK I/O




65654
BACKPLANE PCB ASSY




65688 (3920)
PCB ASSY, DISK I/O



65659
PCB ASSY, REAR PANEL




65673 (obsolete)
PCB ASSY, FNT PANEL DIGITAL
INTERFACE




7.4.2 Chassis Assembly Replacement Parts (cont)


65676
PCB ASSY, REAR PANEL AUDIO I/O




65686 (3920)
PCB ASSY, FNT PANEL DIGITAL INTERFACE



65690
PCB ASSY, CPU ADAPTER




67342
ASSY, FLOPPY DRIVE



*Appearance varies depending on board revision.

7.4.3 Front Panel Replacement Parts


9427
BRACKET, FNT PANEL LENS



11235
BUMPER, CORNER FRONT



33785
SHIELD, DISPLAY




30704
KNOW, SPINNER, 1.5 DIA. X .66LG, ST DK



7.4.3 Front Panel Replacement Parts (cont)

89875
SPACER, 390X SPINNER
*Requires 89874




89874
GASKET, SPACER, SPINNER
*Used with 89875




90585
PCB ASSY, LED BACKL




67355
ASSY, KEYPAD



65653
PCB ASSY, FRONT PANEL



90611
DISPLAY, LCD, LED BACKLIGHT, 6.4"



7.4.4 Miscellaneous Parts

10227
BUMPER, CORNER REAR






46825
BATTERY, LITHIUM, 3V













7.5 ACCESSORIES

7.5.1 Standard Accessories

Item	Part Number	Description
	10456	AC25023 COVER, LID
	6047	MANUAL, CD, OP, 3900 SERIES
	6050	MANUAL, GETTING STARTED, 3900 SERIES

7.5.1.A Std Cord/Accessory Kit (63938)

Item	Part Number	Description
	9143	AC25044 ANTENNA, BNC, 800 MHZ
	9145	AC25045 VHF ANTENNA
	9147	AC25043 UHF ANTENNA
	20327	CONN, BNC JACK/N PLUG
	23758 (Qty 2)	AC25027 TNC TO BNC ADAPTER
	56078 (Qty 2)	FUSE, 3 AMP, FAST, 5MMX20MM, 250V
	27477	POWER CORD, RT IEC RECPT, BS PLG
	27478	SUPPLY LEAD
	27480	POWER CORD, RT IEC RECPT CNT PL
	27516	CABLE ASSY MAINS RT-ANG

7.5.2 Optional Accessories

Part Number	Description
6047	MANUAL, CD, OP, 3900 SERIES
6048	MANUAL, CD, MN, 3900 SERIES
9143	AC25044 ANTENNA BNC 800 MHZ
9145	AC25045 ANTENNA VHF
9147	AC25043 ANTENNA UHF
9149	AC25042 HF ANTENNA
10225	AC25012 SOFT PADDED CASE
10228	AC25029 ACCESSORY POUCH
10456	AC25023 FRONT/REAR COVER
20327	CONNECTOR, BNC JACK/N PLUG
23758	AC25027 TNC TO BNC ADAPTER
47293	AC4105, RETURN LOSS BRIDGE, 1.3 GHZ
58520	AC25061 50 OHM 250 WATT 5 GHZ
62303	CORD, AC, NEMAS-15, IEC320-C13, RA
63928	AC25036 DC/AC CONVERTER, 12 VDC to 110-120 VAC
63931	AC25055 QMA ADAPTER KIT (3920)
63934	390XOPT040, CALIBRATION KIT
63936	AC24009 DMM TEST LEAD KIT (3920/3920B only)
64009	AC8645 MICROPHONE
67411	AC25014 OSCILLOSCOPE PROBE KIT
67442	AC25013 KIT, 10/20 dB Pads, TNC
67478	AC24011 20 AMP CURRENT SHUNT 0.01 OHM
67479	AC24010 10 AMP CURRENT SHUNT 0.01 OHM
82556	AC25059 6 DB/150 W 1.5 GHZ ATTENUATOR
82557	AC25060 10 DB/150 W 1.5 GHZ ATTENUATOR
89243	AC25083 3920 TRANSIT CASE W/WHEELS
90322	AC25084 RACK MOUNT ASSEMBLY, 6U
90323	AC25085 RACK MOUNT ASSEMBLY, 5U

NOTE

Contact Aeroflex Sales or Customer Service for the most current list of available accessories.

Appendix A - I/O Connectors and Pin-Out Tables

A.1 CONNECTOR FUNCTIONS

Connector Name	Connector Type	Signal IN/OUT	Signal Type
MIC/ACC	8 Pin DIN	IN/OUT	See Pin-Out Table
GPIB (IEEE-488)	24 Pin Champ	IN/OUT	See Pin-Out Table
Serial Connector	9 Way, D-Type Plug	IN/OUT	See Pin-Out Table
Parallel Connector	25 Way, D-Type Socket	IN/OUT	See Pin-Out Table
VGA Monitor Output	15 Way, D-Type	OUT	See Pin-Out Table
Ethernet	Standard T-RJ45	IN/OUT	See Pin-Out Table
USB	Standard USB	IN/OUT	See Pin-Out Table
USB Client Connector	Standard USB	Reserved for future use	See Pin-Out Table
PS/2 Interface	Standard PS/2	Reserved for future use	See Pin-Out Table
Test Connector	Open Connector	IN/OUT	See Pin-Out Table

A.2 MIC/ACC CONNECTOR PIN-OUT TABLE




Fig. A-1 Microphone and Accessory Connector

Pin Number	Signal Name	Signal Type	I/O
1	MIC Switch (PTT)	TTL	Out
2	MIC Audio	Audio	In
3	Demod Audio	Audio	Out
4		No connection	
5		2-13 Vdc	
6		No connection	
7	MIC Switch (PTT)	TTL	In
8	GND	Instrument ground	

Table A-1 MIC/ACC Connector Pin-Out Table

A.3 GPIB CONNECTOR PIN-OUT TABLE




Fig. A-2 GPIB Connector Pin Locations

Pin Connector	Function	Pin Connector	Function
1	Data I/O 1	13	Data I/O 5
2	Data I/O 2	14	Data I/O 6
3	Data I/O 3	15	Data I/O 7
4	Data I/O 4	16	Data I/O 8
5	EOI	17	REN
6	DAV	18	Pair with 6
7	NRFD	19	Pair with 7
8	NDAC	20	Pair with 8
9	IFC	21	Pair with 9
10	SRQ	22	Pair with 10
11	ATN	23	Pair with 11
12	Ground Shield	24	Logic Grounds

Table A-2 GPIB Connector Pin-Out Table

A.4 SERIAL CONNECTOR PIN-OUT TABLE




Fig. A-3 Serial Connector Pin Locations

Pin Connector	Function	Pin Connector	Function
1	DCD	6	DSR
2	Rx Data In	7	RTS
3	Tx Data Out	8	CTS
4	DTR	9	RI
5	Ground		

Table A-3 Serial Connector Pin-Out Table




Fig. A-4 Null Modem Connections

A.5 PARALLEL CONNECTOR PIN-OUT TABLE



Fig. A-5 Parallel Connector Pin Locations
Parallel Connector Pin-Out Table

Pin Connector	Function	Pin Connector	Function
1	Strobe	10	ACK
2	Data 0	11	BUSY
3	Data 1	12	PE
4	Data 2	13	SLCT
5	Data 3	14	AUTOFD
6	Data 4	15	EROR
7	Data 5	16	INIT
8	Data 6	17	SLCT IN
9	Data 7	18 to 25	Ground

A.6 VGA MONITOR OUTPUT CONNECTOR PIN-OUT TABLE




Fig. A-6VGA Monitor Output Pin Locations

Pin Connector	Function	Pin Connector	Function
1	Red video	9	No Connection
2	Green video	10	Sync Return
3	Blue video	11	Monitor ID 0
4	Monitor ID 2	12	Monitor ID 1
5	Ground	13	Horizontal Sync
6	Red return	14	Vertical Sync
7	Green return	15	Monitor ID 3
8	Blue return		

Table A-4 VGA Monitor Output Connector Pin-Out Table

A.7 ETHERNET AND USB CONNECTORS PIN-OUT TABLE




Fig. A-6 Ethernet and USB Connectors

A.7.0.A Ethernet Connector Pin-Out Table

Pin Connector	Signal Type	Signal Name	I/O
1	DATA	TX (+)	OUT
2	DATA	TX (-)	OUT
3	DATA	RX (+)	IN
4	DATA	Rx(-)	IN
5	GND	GND	GND
6	GND	GND	GND
7	GND	GND	GND
8	GND	GND	GND

Table A-5 Ethernet Connector Pin-Out Table

A.7.0.B USB Connector Pin-Out Table

Pin Connector	Signal Type	Signal Name	I/O
1	PWR	VCC	
2	DATA	(-) DATA	I/O
3	DATA	(+) DATA	I/O
4	PWR	GND	
5	PWR	VCC	
6	DATA	(-) DATA	I/O
7	DATA	(+)DATA	I/O
8	PWR	GND	

Table A-6 USB Connector Pin-Out Table

A.8 PS/2 INTERFACE CONNECTORS PIN-OUT TABLE




Fig. A-7 PS/2 Interfaces

Pin Connector	Signal Type	Signal Name	Description
1	Bi-Directional	DATA	DATA
2	No Connection		
3	Power	GND	GND
4	Power	+5 V	Supply Voltage
5	Bi-Directional	CLK	Clock
6	No Connection		
Shell	Earth Ground		Chassis Ground

Table A-7 PS/2 Interface Connector Pin-Out Table

A.9 TEST CONNECTOR PIN-OUT TABLE




Fig. A-8 Test Connector

Pin Connector	Signal Type	Pin Connector	Signal Type
1	Serial In 1	9	Serial Out
2	Digital In 2	10	Digital Out 2
3	Digital In 3	11	Digital Out 3
4	Digital In 4	12	Digital Out 4
5	Digital In 5	13	Digital Out 1
6	No Connection	14	No Connection
7	Ground	15	Ground
8	PGM V+ Out		

Table A-8 Test Connector Pin-Out Table

THIS PAGE INTENTIONALLY LEFT BLANK.

Appendix B - 3900 Platform Specifications

3900 Platform Specifications apply to the 3901, 3902, 3920 and 3920B Test Sets except when otherwise indicated.

B.1 RF SIGNAL GENERATOR

B.1.1 Frequency

B.1.1.A Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920, 3920B Standard)

*3920B refer to Phase Noise Specifications for freq >1.0 GHz

10 MHz to 2.7 GHz (3902, 3920, 3920B Freq Extension Option [390XOPT058])

B.1.1.B Resolution

1 Hz

B.1.1.C Accuracy

Frequency Standard ± 1 count

B.1.2 Output Level

B.1.2.A Range

T/R: -130.0 to -30.0 dBm

Duplex: -130.0 to +10.0 dBm (+10 dBm max for CW or FM; 0 dBm max for complex modulation)

B.1.2.B Resolution

0.1 dB

B.1.2.C Accuracy (for level >-110 dBm)

T/R: ± 1.0 dB (Typical better than ± 0.6 dB), ± 2.0 dB (≥ 1800 MHz)

GEN: ± 1.0 dB (Typical better than ± 0.6 dB), ± 2.0 dB (≥ 1800 MHz)

RF Generator (cont)

B.1.3 Spectral Purity

B.1.3.A Residual FM

3901/3901/3920

<15 Hz RMS (300 Hz to 3 kHz bandwidth)

3920B

<5 Hz RMS (300 Hz to 3 kHz bandwidth)

B.1.3.B Residual AM

<0.1% RMS (300 Hz to 3 kHz bandwidth)

B.1.3.C Harmonics

<-25 dBc (Typical -30 dBc, RF Level set at +10 dBm)

B.1.3.D Non Harmonics

3901/3902/3920

<-55 dBc (all frequencies except Crossovers)

<-35 dBc (Crossover frequency = 3411.4 MHz - Generator frequency)

3920B

<-55 dBc (all frequencies except Crossovers)

<-35 dBc (At 2nd order Crossover frequency)

(10 MHz to 1.0 GHz: Crossover = 1400 MHz - Generator frequency)

(1 to 2.6 GHz: Crossover = 3400 MHz - Generator frequency)

(Tracking Generator: Crossover = 3410.7 MHz - Generator frequency)

B.1.3.E Phase Noise

3901/3902/3920

20 kHz Offset: <-93 dBc/Hz (RF <1.05 GHz)

<-90 dBc/Hz (RF >1.05 to 2.7 GHz)

3920B

1 kHz Offset: <-100 dBc/Hz (RF ≤500 MHz)

<-96 dBc/Hz (RF >500 to ≤1000 MHz)

<-90 dBc/Hz (RF >1000 to ≤2600 MHz)

10 kHz Offset: <-110 dBc/Hz (RF ≤500 MHz)

<-106 dBc/Hz (RF >500 to ≤1000 MHz)

<-95 dBc/Hz (RF >1000 to ≤2600 MHz)

RF Generator (cont)

B.1.4 Modulation

B.1.4.A Selections

OFF, AM, FM, FM 50 μ s, FM 75 μ s, FM 750 μ s, AM USB, AM LSB

B.1.4.B Internal FM

B.1.4.B.1 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920, 3920B Standard)

*3920B refer to Phase Noise Specifications for freq >1.0 GHz

10 MHz to 2.7 GHz (3902, 3920, 3920B Freq Extension Option [390XOPT058])

B.1.4.B.2 Deviation

± 0.001 to ± 150 kHz, OFF

B.1.4.B.3 Accuracy

3% (From ± 1 kHz to ± 100 kHz deviation, 20 Hz to 15 kHz rate)

B.1.4.B.4 Resolution

1 Hz

B.1.4.B.5 Deviation Rate

20 Hz to 15 kHz

B.1.4.B.6 Waveform

Sine, Square, Triangle, Ramp, Digital Coded Squelch (DCS), Dual Tone Multiple Frequency (DTMF)

B.1.4.B.7 THD

<1% (1 kHz rate, 6 kHz deviation, 300 Hz to 3 kHz BW, Sine)

RF Generator (cont)

Modulation (cont)

B.1.4.C Internal AM

B.1.4.C.1 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920, 3920B Standard)

*3920B refer to Phase Noise Specifications for freq >1.0 GHz

10 MHz to 2.7 GHz (3902, 3920, 3920B Freq Extension Option [390XOPT058])

B.1.4.C.2 Modulation Range

0% to 100%

B.1.4.C.3 Accuracy

1% (Modulation from 10 to 90%)

B.1.4.C.4 Resolution

0.1%

B.1.4.C.5 Rate

20 Hz to 15 kHz

B.1.4.C.6 Waveform

Sine, Square, Triangle, Ramp, Digital Coded Squelch (DCS), Dual Tone Multiple Frequency (DTMF)

B.1.4.C.7 THD

<1% (1 kHz rate, 30 to 70% AM, 300 Hz to 3 kHz BW, Sine)

B.1.4.D Internal Single-Sideband (SSB)

B.1.4.D.1 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920, 3920B Standard)

*3920B refer to Phase Noise Specifications for freq >1.0 GHz

10 MHz to 2.7 GHz (3902, 3920, 3920B Freq Extension Option [390XOPT058])

B.1.4.D.2 Modulation Selection

Upper-Sideband (USB) or Lower-Sideband (LSB)

B.1.4.D.3 Modulation Range

0% to 100%

B.1.4.D.4 Resolution

0.1%

B.1.4.D.5 Rate

300 Hz to 3 kHz

B.1.4.D.6 Waveform

Sine, Square, Triangle, Ramp, Digital Coded Squelch (DCS), Dual Tone Multiple Frequency (DTMF)

RF Generator (cont)

Modulation (cont)

B.1.4.E External AM/FM/SSB

B.1.4.E.1 Audio Inputs

With 1 V_{rms}, AM/FM/SSB have same characteristics as internal sources, ±10% of indicated setting.

Audio 1 or Audio 2 Input from 20 Hz to 15 kHz, (300 Hz to 3 kHz SSB), Unbalanced 8 V_{rms} maximum modulation input level.

B.1.4.E.2 Microphone Input

With 50 mV_{rms}, AM/FM/SSB have same characteristics as internal sources, ±10% of indicated setting.

MIC Input from 100 Hz to 15 kHz (300 Hz to 3 kHz SSB)

B.1.4.F Internal I-Q (Option)

B.1.4.F.1 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920, 3920B Standard)

*3920B refer to Phase Noise Specifications for freq >1.0 GHz

10 MHz to 2.7 GHz (3902, 3920, 3920B Freq Extension Option [390XOPT058])

B.1.4.F.2 Modulation Selection

IQ Creator® file downloads for custom I-Q modulation

B.2 RF RECEIVER

B.2.1 Demodulation Selections

OFF, AM, FM, FM 50 μ s, FM 75 μ s, FM 750 μ s, AM USB, AM LSB

B.2.2 Frequency Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.2.3 Sensitivity

B.2.3.A Pre-Amp OFF

<-100 dBm (10 dB SINAD, FM, 25 kHz, 1 kHz rate, 6 kHz FM Deviation, 300 Hz to 3.4 kHz AF Filter)

B.2.3.B Pre-Amp ON

<-113 dBm (10 dB SINAD, FM, 25 kHz, 1 kHz rate, 6 kHz FM Deviation, 300 Hz to 3.4 kHz AF Filter, Pre-Amp On)

B.2.4 Selectivity

B.2.4.A IF Bandwidth

6.25, 8.33, 10, 12.5, 25, 30, 100, 300 kHz Filters

B.2.5 Demod Output Level

B.2.5.A FM

2.5 Vrms \pm 10% (for deviation \pm 1/2 of selected BW; 25 kHz BW same output level as 30 kHz BW)

B.2.5.B AM

2.25 Vrms \pm 10% (for 100% AM)

B.3 RF RECEIVE MEASUREMENTS

B.3.1 AM Meter

B.3.1.A Range

0% to 100%

B.3.1.B Scales

1% to 100% in a 1, 2, 5 sequence, plus Autoscale

B.3.1.C Resolution

0.1%

B.3.1.D Accuracy

±3% + source residual, ±1 count (30 to 90% AM, IF BW set appropriately for the received modulation bandwidth)

B.3.1.E AM

B.3.1.E.1 Rate

20 Hz to 15 kHz (IF BW set appropriately for the received modulation BW)

B.3.1.E.2 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.3.1.E.3 RF Level

T/R: -10 to +50 dBm

ANT: -80 to +10 dBm

RF Receive Measurements (cont)

B.3.2 FM Deviation Meter

B.3.2.A Range

0 to 150 kHz

B.3.2.B Scales

1 to 200 kHz in a 1, 2, 5 sequence, plus Autoscale

B.3.2.C Resolution

10 Hz

B.3.2.D Accuracy

±3% plus source residual, ±1 count (1 to 150 kHz FM deviation, IF BW set appropriately for the received modulation BW)

B.3.2.E FM

B.3.2.E.1 Rate

20 Hz to 20 kHz (IF BW set appropriately for the received modulation BW)

B.3.2.E.2 RF Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.3.2.E.3 RF Level

T/R: -10 to +50 dBm

ANT: -80 to +10 dBm

B.3.3 RF Counter

B.3.3.A Frequency

Range (Usable from 100 kHz, Autotune)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.3.3.B Resolution

1 Hz

B.3.3.C Accuracy

Frequency Standard ± 1 count

B.3.3.D Level (Range)

T/R: -10 to +50 dBm (Find level is selectable)

ANT: -60 to +10 dBm (Find level is selectable)

RF Receive Measurements (cont)

B.3.4 RF Error Meter

B.3.4.A Counter Range

0 to ± 2.5 MHz from Receiver frequency (6 MHz IF BW)

B.3.4.B Accuracy

Frequency Standard ± 1 count

B.3.4.C Resolution

1 Hz

B.3.4.D Level

T/R: -10 to +50 dBm

ANT: -60 to +10 dBm

B.3.5 Demodulation

B.3.5.A Demod Counter

B.3.5.A.1 Frequency

Range

20 Hz to 20 kHz (1 to 100 kHz FM Deviation, IF BW set appropriately for the received modulation BW)

20 Hz to 10 kHz (30% to 90% AM, IF BW set appropriately for the received modulation BW).

Resolution

0.1 Hz

Accuracy

± 50 ppm (± 10 ppm Typical)

B.3.5.A.2 Input Waveform

Sine or Square

B.3.5.A.3 RF Characteristics

Input RF (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

RF Level

T/R: -10 to +50 dBm

ANT: -80 to +10 dBm

RF Receive Measurements (cont)

B.3.6 RF Power Meter (Broad band)

B.3.6.A Frequency

B.3.6.A.1 Range (Usable from 2 MHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.3.6.A.2 Level

100 mW to 125 W (Usable from 10 mW)

B.3.6.A.3 Resolution

4 digits for W or 0.1 dB

B.3.6.A.4 Accuracy

10%, ± 1 digit

B.3.6.B Power Measurement Range

T/R: 100 mW to 125 W (25% on/off ratio)

B.3.7 RF Power Meter (In Band)

B.3.7.A Frequency

B.3.7.A.1 Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)

10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.3.7.A.2 Level

T/R: -60 to +51 dBm: Lowest reading is receiver BW dependent (Narrower bandwidths can measure lower levels).

ANT: -100 to +10 dBm: Lowest reading is receiver BW dependent (Narrower bandwidths can measure lower levels).

B.3.7.A.3 Resolution

0.1 dB

B.3.7.A.4 Accuracy (after User Calibration)

± 1 dB (Input Level above minimum for selected BW (display not yellow) typically better than ± 0.6 dB).

B.3.7.B AM Filter BW

6.25, 8.33, 10, 12.5, 25 and 30 kHz

B.3.7.C FM Filter BW

6.25, 10, 12.5, 25, 30, 100, and 300 kHz

B.4 AUDIO FUNCTION GENERATOR(S)

Up to 3 function generators can be combined into 1 Output signal

B.4.1 Waveshape

Sine, Square, Triangle, Ramp, Digital Coded Squelch (DCS), Dual Tone Multiple Frequency (DTMF)

B.4.2 Frequency

B.4.2.A Range

Sine: 20 Hz to 40 kHz (usable 1 Hz to 40 kHz)

Square: 20 Hz to 4 kHz (usable 1 Hz to 4 kHz)

B.4.2.B Resolution

0.1 Hz

B.4.2.C Accuracy

±50 ppm, ±10 ppm Typical

B.4.3 Level (Sine)

B.4.3.A Range

1 mV to 5 Vrms into a 10 k Ω load

B.4.3.B Resolution

0.1 mV

B.4.3.C Accuracy

±1% of setting (10 k Ω load)

B.4.4 Impedance

3901/3902: 600 Ω (nominal)

3920/3920B: <10 Ω

B.4.5 Spectral Purity

<0.5% (1 kHz, 5 Vrms, 80 kHz BW, 10 k Ω load, Sine)

<1.0% (Typical, 20 Hz to 40 kHz, 100 mV to 5 Vrms, 80 kHz BW, 10 k Ω load, Sine)

B.5 AUDIO & MODULATION MEASUREMENTS

B.5.1 AF Counter

B.5.1.A Frequency Range

20 Hz to 20 kHz (usable from 10 Hz)

B.5.1.B Resolution

0.1 Hz

B.5.1.C Accuracy

±50 ppm max, ±10 ppm Typical

B.5.1.D Waveshape

Sine or Square

B.5.1.E Input Level Range

3901/3902: 10 mV to 8 Vrms

3920/3920B: 10 mV to 30 Vrms

B.5.1.F Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference

Audio 1 and 2: Balanced, 600 Ω differential input

B.5.1.G Impedance

Hi-Z (>10 k Ω) Unbalanced input

600 Ω Unbalanced input (8 Vrms Maximum input*)

600 Ω Balanced input

*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.2 AF Level Meter

B.5.2.A Frequency Range

20 Hz to 20 kHz

B.5.2.B Accuracy

3901/3902: 5% (Unbalanced, Hi-Z, 300 to 3 kHz, 0.1 to 8 Vrms)

3920/3920B: 5% (Unbalanced, Hi-Z, 300 to 3 kHz, 0.1 to 30 Vrms)

B.5.2.C Level Range

3901/3902: 0 to 8 Vrms

3920/3920B: 0 to 30 Vrms

B.5.2.D Resolution

B.5.2.D.1 Volts

1 mV (Input <1 V)

10 mV (Input ≥1 V)

B.5.2.D.2 dBr, dBV, dBm

0.01 dB

B.5.2.E Scales

B.5.2.E.1 Volts

20 mV to 50 V in a 1, 2, 5 sequence, plus Autoscale

B.5.2.E.2 dBr

1 dBr to 100 dBr in a 1, 2, 5 sequence plus Autoscale

B.5.2.E.3 dBV

-40, -20, 0, 20, 40 dBV plus Autoscale

B.5.2.E.4 dBm

-30, -20, -10, 0, 10, 20, 30, 40 dBm plus Autoscale

B.5.2.F Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference

Audio 1 and 2: Balanced, 600 Ω differential input

B.5.2.G Impedance

Hi-Z (>10 kΩ) Unbalanced input

600 Ω Unbalanced input (8 Vrms Maximum input*)

600 Ω Balanced input

*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.3 SINAD Meter

B.5.3.A Range

0 to 60 dB

B.5.3.B Resolution

0.01 dB

B.5.3.C Accuracy

±1 dB, ±1 count (SINAD >3 dB, ≤40 dB, 5 kHz LP AF Filter)

B.5.3.D Signal Frequency

300 Hz to 5 kHz

B.5.3.E Signal Level

3901/3902: 0.1 to 8 Vrms

3920/3920B: 0.1 to 30 Vrms

B.5.3.F Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference

Audio 1 and 2: Balanced, 600 Ω differential input

B.5.3.G Impedance

Hi-Z (>10 kΩ) Unbalanced input

600 Ω Unbalanced input (8 Vrms Maximum input*)

600 Ω Balanced input

*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.4 Distortion Meter

B.5.4.A Range

0.0% to 100.0%

B.5.4.B Resolution

0.1%

B.5.4.C Accuracy

< \pm 0.5% (Distortion 1% to 10%, 5 kHz LP AF Filter)
< \pm 1.0% (Distortion 10% to 20%, 5 kHz LP AF Filter)

B.5.4.D Signal Frequency

300 Hz to 5 kHz (Entry Range 0 to 24,000 Hz)

B.5.4.E Signal Level

3901/3902: 0.1 to 8 Vrms
3920/3920B: 0.1 to 30 Vrms

B.5.4.F Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference
Audio 1 and 2: Balanced, 600 Ω differential input

B.5.4.G Impedance

Hi-Z (>10 k Ω) Unbalanced input
600 Ω Unbalanced input (8 Vrms Maximum input*)
600 Ω Balanced input
*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.5 Hum and Noise

B.5.5.A Modes

Mode	Stimulus	Stimulus Port	Measurement Input	Measurement Port
1	RF Generator	TR/GEN	AF Input	Audio In 1/2
2	AF Generator	Fctn Gen Out	RF Receiver	TR/ANT

B.5.5.B Meter Range

-100 to 0 dB

B.5.5.C Resolution

0.01 dB

B.5.5.D Accuracy

± 1 dB, ± 1 count (> -60 dB, ≤ -20 dB)

B.5.5.E Signal Frequency

300 Hz to 5 kHz (Entry range 0 to 24,000 Hz)

B.5.5.F Audio Input Signal Level (Mode 1)

3901/3902: 0.1 to 8 Vrms

3920/3920B: 0.1 to 30 Vrms

B.5.5.G RF Level Input (Mode 2)

T/R: -10 to +50 dBm

ANT: -80 to +10 dBm

B.5.5.H Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference

Audio 1 and 2; Balanced, 600 Ω differential input

B.5.5.I Impedance

Hi-Z (> 10 k Ω) Unbalanced input

600 Ω Unbalanced input (8 Vrms Maximum input*)

600 Ω Balanced input

*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.6 Signal to Noise Ratio

B.5.6.A Modes

Mode	Stimulus	Stimulus Port	Measurement Input	Measurement Port
1	RF Generator	TR/GEN	AF Input	Audio In 1/2
2	AF Generator	Fctn Gen Out	RF Receiver	TR/ANT

B.5.6.B Meter Range

0 to 60 dB

B.5.6.C Resolution

0.01 dB

B.5.6.D Accuracy

± 1 dB, ± 1 count (>3 dB, ≤ 40 dB, 5 kHz LP AF Filter)

B.5.6.E Signal Frequency

300 Hz to 5 kHz (Entry range 0 to 24,000 Hz)

B.5.6.F Audio Input Signal Level (Mode 1)

3901/3902: 0.1 to 8 Vrms

3920/3920B: 0.1 to 30 Vrms

B.5.6.G RF Level Input (Mode 2)

T/R: -10 to +50 dBm

ANT: -80 to +10 dBm

B.5.6.H Front Panel Inputs

Audio 1 or 2: Unbalanced, Chassis reference

Audio 1 and 2: Balanced, 600 Ω differential input

B.5.6.I Impedance

Hi-Z (>10 k Ω) Unbalanced input

600 Ω Unbalanced input (8 Vrms Maximum input*)

600 Ω Balanced input

*600 Ω Unbalanced input auto-switches to Hi-Z @ 8 Vrms (3920 only)

Audio & Modulation Measurements (cont)

B.5.7 Audio Filters (Characteristic Response)

Filter	Type	Ripple	-1 dB	-60 dB
NONE	No Filter	--	--	--
300 Hz	Low-Pass	<0.23 dB, above 20 Hz	330 Hz	590 Hz
5 kHz	Low-Pass	<0.02 dB, above 20 Hz	5.5 kHz	6.7 kHz
15 kHz	Low-Pass	<0.01 dB, above 20 Hz	16.1 kHz	17.8 kHz
20 kHz	Low-Pass	<0.01 dB, above 20 Hz	20.4 kHz	21 kHz
0.3 to 3.4 kHz	Band-Pass	<1.7 dB	320 Hz/3.8 kHz	60 Hz/5.2 kHz
0.3 to 5 kHz	Band-Pass	<1.7 dB	320 Hz/5.2 kHz	60 Hz/9.6 kHz
0.3 to 15 kHz	Band-Pass	<1.7 dB	320 Hz/16.1 kHz	60 Hz/19.9 kHz
0.3 to 20 kHz	Band-Pass	<1.7 dB	200 Hz/20.4 kHz	60 Hz/21 kHz
PSOPH/C-MSG	Band-Pass	Per C-MSG Spec	Per C-MSG Spec	Per C-MSG Spec
PSOPH/CCITT	Band-Pass	Per CCITT Spec	Per CCITT Spec	Per CCITT Spec
300 Hz	High-Pass	<1.7 dB	320 Hz	60 Hz

B.6 CHANNEL ANALYZER

With the exception of the following, refer to Spectrum Analyzer Specifications for all other Channel Analyzer specifications.

B.6.1 Frequency

B.6.1.A Range (Usable from 100 kHz)

10 MHz to ± 2.5 MHz from Receiver Center Frequency within specified range
10 MHz to 1.05 GHz (3901, 3920 Standard)
10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.6.2 Span

B.6.2.A Width

2 kHz to 5 MHz

B.6.2.B Range

2 kHz to 5 MHz in a 1, 2, 5 sequence (Span may be entered numerically down to 1 Hz resolution)

B.6.3 Level

B.6.3.A Ref Level Range

± 60 dBm from measured Level within specified range
T/R: -50 to +50 dBm
ANT: -90 to +10 dBm

B.6.4 Resolution Bandwidth

B.6.4.A Selections

300 Hz, 3 kHz, 60 kHz

B.6.5 Sweep

B.6.5.A Frequency Sweep Time

50 ms to 100 s in a 1, 2, 5 sequence

B.7 RF SPECTRUM ANALYZER

B.7.1 Frequency

B.7.1.A Range (Usable from 100 kHz)

10 MHz to 1.05 GHz (3901, 3920 Standard)
10 MHz to 2.7 GHz (3902, 3920 Freq Extension Option [390XOPT058])

B.7.1.B Resolution

1 Hz

B.7.1.C Accuracy

Refer to Frequency Standard I/O Specifications

B.7.2 Span

B.7.2.A Mode

Start/Stop, Center/Span, Zero Span

B.7.2.B Width

2 kHz to full span

B.7.2.C Range

Selection is 2 kHz to Full Span in a 1, 2, 5 sequence, plus Zero Span (Span may be entered numerically down to 1 Hz resolution)

B.7.2.D Accuracy

±1% of span width

B.7.3 Display Accuracy

Span Accuracy + Freq Accuracy +50% of RBW

B.7.4 Markers

B.7.4.A Marker Accuracy

±1% of span width

B.7.4.B Track

Frequencies (or time) and amplitudes

B.7.4.C Number of Markers

Vertical Markers: 6
Horizontal Markers: 2

RF Spectrum Analyzer (cont)

Markers (cont)

B.7.4.D Marker Functions

Marker to Peak
 Marker to Minimum
 Marker to Center Frequency
 Marker sets Vertical Scale (Zero Span only)
 Marker to Next Right/Left
 Marker to Ref Level
 Marker sets Span

B.7.5 Level

B.7.5.A Ref Level Range

T/R: -50 to +50 dBm
 ANT: -90 to +10 dBm

B.7.5.B Vertical Scales

1, 2, 5, 10 dB/division

B.7.5.C Reference Level Resolution

0.1 dB

B.7.5.D Ref Level Units

dBm, dB μ V, dBmV

B.7.5.E Dynamic Range

70 dB (Antenna, no attenuation, Ref Level -30 dBm, 30 kHz RBW)

B.7.5.F Bandwidth Switching Error

± 1 dB (After Normalize)

B.7.5.G Log Linearity

± 1 dB (RBW: 3 kHz, 30 kHz, 60 kHz, 300 kHz, 6 MHz)
 ± 1 dB (300 Hz RBW Typical)

B.7.5.H Accuracy

± 1 dB (Input signal -10 dB from Ref Level, Normalized, Pre-Amp OFF)

B.7.5.I Attenuator Selections

0 to 50 dB of attenuation, controlled by changing the Ref Level.

B.7.5.J 3rd Order Intermodulation

-60 dBc (Input Level of -30 dBm, Ref Level at -20 dBm)

B.7.5.K Harmonic Spurious

-55 dBc (Input Level of -30 dBm, Ref Level at -20 dBm)

RF Spectrum Analyzer (cont)

Level (cont)

B.7.5.L **Non-Harmonic Spurious**

-60 dBc (Input Level of -30 dBm, Ref Level at -20 dBm)

B.7.5.M **Displayed Average Noise Level (DANL)**

-125 dBm (Typical, 300 Hz RBW, ANT Port terminated, 20 sweep average)

B.7.6 **Resolution Bandwidth**

B.7.6.A **Selections**

300 Hz, 3 kHz, 30 kHz, 60 kHz, 300 kHz, 6 MHz

B.7.6.B **RBW 60 dB/3 dB Filter Shape**

>10:1

B.7.6.C **Selectivity - Filter Shape**

60 dB/3 dB ratio better than 10:1

B.7.6.D **Accuracy**

±10% of RBW for 3 kHz, 30 kHz, 60 kHz, 300 kHz

-10%/+25% of RBW for 6 MHz

±20% of RBW for 300 Hz

B.7.6.E **Bandwidth Switching Error**

±1 dB

B.7.7 **Video Bandwidth**

10 Hz to 1 MHz in a 1, 3, 10 sequence, NONE

B.7.8 **Sweep**

B.7.8.A **Frequency Sweep Time**

100 ms to 100 S in a 1, 2, 5 sequence

B.7.8.B **Zero Span Sweep Time**

50 ms to 100 S in a 1, 2, 5 sequence

B.7.8.C **Sweep Trigger Source**

Internal and External

B.7.8.D **Trigger Modes**

Continuous (Repeat), Single (Single-shot)

RF Spectrum Analyzer (cont)

B.7.9 Function/Feature

B.7.9.A Display Modes

Live, Average, Max Hold

B.7.9.B Averages

1 to 100

B.8 TRACKING GENERATOR (OPTION)

Reference RF Generator Specifications for 3920B Tracking Generator.

B.8.1 Tracking Generator Output

(measured at Center Frequency)

Refer to RF Signal Generator section for:

Frequency Range and Accuracy

Output Level Range, Resolution, Accuracy and Spectral Purity

B.8.2 Span and Sweep Time

Same as Spectrum Analyzer

B.8.3 Tracking Generator Controls

Output Port Selection, RF Level, Reference Call

B.9 OSCILLOSCOPE

B.9.1 Display

B.9.1.A Traces

2

B.9.1.B Trace Types

Live, Captured, Accumulated

B.9.1.C Markers

2

B.9.1.D Marker Functions

Time with Amplitude, deviation or % depth

Delta Marker (including $1/\Delta\tau$, e.g., Hz)

B.9.2 Vertical

B.9.2.A 3 dB Bandwidth

16 MHz

B.9.2.B Frequency Range

DC to 4 MHz (40 MS/s sampling rate)

B.9.2.C Input Range

0 to 100 V_{peak} maximum, Category I

B.9.2.D Scales

2 mV to 20 V/division in a 1, 2, 5 sequence (8(h) x 10 (w) graticule display)

B.9.2.E Accuracy

5% of full scale (DC to 1 MHz)

10% of full scale (1 to 4 MHz)

B.9.2.F Resolution

Better than 1% of full scale

B.9.2.G Coupling

DC, AC, GND

Oscilloscope (cont)

B.9.3 **Horizontal**

B.9.3.A **Sweep Factors**

1 μ s to 1 Sec/division in a 1, 2, 5 sequence

B.9.3.B **Accuracy**

>1.5% of full scale

B.9.3.C **Resolution**

>1% of full scale

B.9.3.D **Input Impedance**

1 M Ω , 20 pF

1 M Ω , 20 pF

B.9.4 **Trigger**

B.9.4.A **Trigger Source**

Trace A, Trace B, EXT, (or Trace C with no CH1 or CH2 Input)

B.9.4.B **Trigger Edge**

Rising/Falling

B.9.4.C **Trigger Mode**

Auto/Normal

Continuous/Single

B.9.4.D **External Trigger Level**

Hi-Z BNC Input on the rear panel of the unit

Adjustable from -5 to +5 V

B.10 FREQUENCY STANDARD I/O

B.10.1 Internal Frequency Standard Output (OCXO)

B.10.1.A Frequency

10 MHz (nominal)

B.10.1.B Output Level

1 Vpp (Nominal) into 50 Ω

B.10.1.C Temperature Stability (0 to 50° C)

± 0.01 ppm

B.10.1.D Aging Rate

± 0.1 ppm/Year after 1 month continuous use.

B.10.1.E Warm Up Time

Less than 5 min. to ± 0.02 ppm

B.10.2 External Frequency Input

B.10.2.A Frequency

10 MHz

B.10.2.B Input Level

1 to 5 Vpp for Sine waves
3.3/5 V TTL for Square waves

B.10.2.C Connector

BNC socket (10 k Ω Input/50 Ω Output)

B.11 AUDIO SPECTRUM ANALYZER (OPTION)

B.11.1 Frequency Range

Start and Stop Frequency: 0 to 24,000 Hz

B.11.2 Resolution

1 Hz

B.11.3 Accuracy

±50 ppm, ±10 ppm Typical

B.11.4 Span

2 kHz minimum to 24 kHz maximum

B.11.5 Level

Vertical Scales

1, 2, 5, 10, 20 dB per division

B.11.5.A Reference Level

0 dB Full Scale (dBr)

B.11.5.B Dynamic Range

Greater than 120 dB

B.11.5.C Accuracy

±1 dB from 300 Hz to 15 kHz

B.11.6 Markers

Number of Markers: 2

B.12 DIGITAL MULTIMETER (3920 ONLY)

B.12.1 AC/DC Voltmeter

B.12.1.A Full Scale Ranges

200 mV, 2 V, 20 V, 200 V, 2,000 V, Auto
(150 VAC RMS or VDC maximum input, Category II)

B.12.1.B Resolution

3 1/2 digits (2000 counts)

B.12.1.C Accuracy

DC: $\pm 1\%$ FS, ± 1 count
AC: $\pm 5\%$ FS, ± 1 count

B.12.1.D AC Volts Frequency Range

50 Hz to 20 kHz

B.12.2 AC/DC AM Meter

B.12.2.A Full Scale Ranges

200 mA, 2 A, 20 A, Auto
(20 A range uses optional external shunt connected to Voltmeter)

B.12.2.B Maximum Open Circuit Input Voltage

30 Vrms referenced to Common or Earth Ground, Category I

B.12.2.C Resolution

3 1/2 digits (2000 counts)

B.12.2.D Accuracy

DC: $\pm 5\%$ FS, ± 1 count
AC: $\pm 5\%$ FS, ± 1 count
AC Volts Frequency Range
50 Hz to 10 kHz

B.12.3 Ohm Meter

B.12.3.A Full Scale Ranges

200 Ω , 2 k Ω , 20 k Ω , 200 k Ω , 2 M Ω , 20 M Ω , Auto

B.12.3.B Resolution

3 1/2 digits (2000 counts)

B.12.3.C Accuracy

$\pm 5\%$ FS, ± 1 count

Digital Multimeter (cont)

B.12.4 External Shunt (Optional Accessory)

B.12.4.A Rating (Category I)

10 AMPS, 100 mV
20 AMPS, ON 1 minute, OFF 4 minutes

B.12.4.B Accuracy (18 to 28 degrees C)

DC to 10 kHz, $\pm 0.25\%$

B.12.4.C Temperature Coefficient

0.005 %/° C

B.13 INPUT/OUTPUT CONNECTORS

B.13.1 ANT (RF Input)

B.13.1.A Connector Type

TNC

B.13.1.B Function

Receiver Input (Input port)

B.13.1.C Impedance

50 Ω (nominal)

B.13.1.D VSWR (with Attenuation ≥10 dB):

Better than 1.44:1 (RF freq. <1.05 GHz)

Better than 1.58:1 (RF freq. >1.05 GHz to <2.7 GHz)

B.13.1.E Input Protection

10 W with warning above +17 dBm (Remove power immediately when alarm sounds).

B.13.2 T/R (RF Input/Output)

B.13.2.A Connector Type

Type N

B.13.2.B Function

RF Power Input, Generator low-level Output (Input/Output Connector)

B.13.2.C Impedance

50 Ω (nominal)

B.13.2.D VSWR

Better than 1.2:1 (RF freq. <1.05 GHz)

Better than 1.3:1 (RF freq. >1.05 GHz to <2.7 GHz)

B.13.2.E Input Protection

T/R RF Input Power On/Off:

Peak RF Power	Maximum Time On	Minimum Time Off
≤50 W	Continuous	--
>50 W, ≤125 W	30 seconds	2 minutes
>125 W, ≤200 W **	5 seconds**	5 minutes**

T/R RF Input Alarm Activation*:

Alarm	Temperature		Peak RF Power
ON	>100° C	OR	>125 W
OFF	<100° C	AND	<125 W

*Remove power from Test Set immediately if Overload Alarm triggers.

** Applies to 3920 only.

Input/Output Connectors (cont)

B.13.3 GEN (RF Output)

B.13.3.A Connector Type

TNC

B.13.3.B Function

Generator high-level Output (Output Connector)

B.13.3.C Impedance

50 Ω (nominal)

B.13.3.D VSWR (with level <0 dBm):

Better than 1.7:1 (RF freq. <1.05 GHz)

Better than 1.9:1 (RF freq. >1.05 GHz to <2.7 GHz)

B.13.3.E Input Protection

10 W with warning above +23 dBm (Remove power immediately when alarm sounds).

B.13.4 GPIB

B.13.4.A Connector Type

24 pin IEEE

B.13.4.B Function

IEEE-488.1-1997

B.13.5 Ethernet

B.13.5.A Connector Type

8 Position, RJ-45 100/10 Mbit/s

B.13.5.B Function

10/100 Base-T Network Connection

B.13.6 RS-232

B.13.6.A Connector Type

9-Pin, D-sub Male

B.13.6.B Baud Rates

300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200

B.13.6.C Stop Bits

1 or 2

B.13.6.D Parity

Odd, Even, None

Input/Output Connectors (cont)

B.13.7 Video

B.13.7.A Connector Type

15-pin, D-sub, VGA

B.13.7.B Function

VGA for external monitor

B.13.8 IF Output

B.13.8.A Connector Type

BNC

B.13.8.B Function

10.7 MHz Receiver IF

B.13.8.C Output Level

Proportional to Receive Signal Level

B.13.9 MIC/Accessory

B.13.9.A Connector Type

8 position, Female DIN

B.13.9.B Function

Microphone connection, Modulation Input, Demod Output, PTT Operation

B.13.10 Parallel Port

B.13.10.A Connector Type

25 position, Female D-sub

B.13.10.B Function

Printer Interface

B.13.11 USB

B.13.11.A Connector Type

Twin USB Standard connection (Rear Panel)
Single USB Standard connection (Front Panel 3920 only)

B.13.11.B Function

USB Version 1.1 interface (Mouse enabled)

Input/Output Connectors (cont)

B.13.12 PS/2 Interfaces (3901/3902 only)

B.13.12.A Connector Type

Dual PS/2 Connectors

B.13.12.B Function

Keyboard interface

B.13.13 Test Port

B.13.13.A Connector Type

15 position, Female 3 Tier D-sub

B.13.13.B Function

Programmable I/O and voltage Output (optional interface)

B.13.14 Auxiliary IF Input

B.13.14.A Connector Type

High-density dual inline

B.13.14.B Function

External digital receiver input (optional interface)

B.14 ENVIRONMENTAL

B.14.1 Operating Temperature

0 to 50°C (Tested in accordance with MIL-PRF-28800F Class 3)

B.14.2 Warm-up Time

15 minutes

B.14.3 Storage Temperature

-40 to 71°C (Tested in accordance with MIL-PRF-28800F Class 3)

B.14.4 Relative Humidity

80% up to 31°C decreasingly linearly to 50% at 40°C
(Tested in accordance with MIL-PRF-28800F Class 3)

B.14.5 Altitude

4,000 m (13,123 ft) (Tested in accordance with MIL-PRF-28800F Class 3)

B.14.6 Shock and Vibrations

30 G Shock (Functional Shock)
5-500 Hz random vibrations
(Tested in accordance with MIL-PRF-28800F Class 3)

B.14.7 Use

Pollution Degree 2

B.14.8 EMC

3920/3920B: EN 61326, Class A

B.14.9 Reliability

>8,000 hour calculated MTBF (MIL-HDBK-217F, Notice 2)

B.15 SAFETY STANDARDS

3901/3902: UI 61010B-1, EN 61010-1, CSA C22.2 No. 61010-1
3920/3920B: UL 61010-1

B.16 DIMENSIONS AND WEIGHT

Height	Width	Depth
19.7 cm	35.6 cm	52.0 cm
7.75 in	14.0 in	20.5 in
Weight	16.5 kg (36.8 lbs)	

B.17 AC POWER REQUIREMENTS

B.17.1 Voltage

100 V to 120 VAC @ 60 Hz
220 V to 240 VAC @ 50 Hz

B.17.2 Power Consumption

Nominally 120 W (200 W Max)

B.17.3 Mains Supply Voltage Fluctuations

≤10% of the nominal voltage

B.17.4 Fuse Requirements

3 A, 250 V, Type F

B.18 GENERAL FEATURES

B.18.1 LCD Display

B.18.1.A Screen Size

6.4 in. diagonal

B.18.1.B Active Area

129.6 mm (h) x 97.44 mm (v)

B.18.1.C Resolution

640 x 480 pixels

B.18.2 Disk Storage (3901/3902 only)

3.5 inch Floppy Disk
Internal hard disk of 30 GB available for user storage

THIS PAGE INTENTIONALLY LEFT BLANK.

Appendix C - Controls and Connectors

C.1 FRONT PANEL CONTROLS AND CONNECTORS




Fig. C-1 3901/3902 Front Panel Controls and Connectors




Fig. C-2 3920/3920B Front Panel Controls and Connectors

C.1.1 Soft Keys (1)

The soft keys perform and activate various Test Set functions.

C.1.2 HELP Key (2)

Accesses operation description for Test Set fields and functions.

C.1.3 RETURN Key (3)

Returns the soft key menu back one level each time the key is pressed.

- C.1.4 TEST (4)**
Selects the TEST function or displays the TEST floating menu.
- C.1.5 CONFIG (5)**
Selects the CONFIG (Configuration) function or displays the CONFIG floating menu.
- C.1.6 UTILS (6)**
Selects the Utilities function or displays the Utilities floating menu.
- C.1.7 TAB Key (7)**
TAB key sequentially moves screen focus to a different Tile or opens a floating menu.
- C.1.8 SELECT Key (8)**
Activates selected fields, selects a field for editing, deselects a field to prevent editing or changes the state of a button.
- C.1.9 CANCEL Key (9)**
When data input keys are used to select a Numeric Entry Box or Text Entry Box for editing this key cancels any changes that have been made and restores the original setting as long as the ENTER key or the SELECT key has not been pressed. CANCEL does not restore a value to a previous setting if the setting has been changed using the cursor keys or rotary control knob.
While a menu is displayed, pressing CANCEL closes the menu without activating the highlighted menu item.
- C.1.10 Cursor Keys (10)**
Navigates focus to the left, right, up or down between menu levels, fields, boxes and buttons.
- C.1.11 ENTER Key (11)**
Enables values entered using the data input keys.
- C.1.12 Data Input and Entry Keys (12)**
Enter numeric, alphabetic and symbolic values or text into a selected data entry box.
- C.1.13 Backspace Key (13)**
When a numeric entry box or a text box is selected for editing, this key deletes the character or digit to the left of the position indicator.
- C.1.14 Rotary Control Knob (14)**
The rotary control sets, selects or adjusts features of the Test Set.
- C.1.15 ASSIGN Key (15)**
Various functions are adjusted by assigning the functions to the Rotary Control knob.
- C.1.16 Display HOLD Key (16)**
Freezes the display to allow the user to capture and save the current screen display.
- C.1.17 Power Supply On/Standby Key (17)**
This key is referred to throughout the manual as the On/Standby key. Initiates the Power-down sequence, saving all current settings and results and placing the Test Set in Standby mode.

C.1.18 3.5 inch Floppy Disk Drive (18) (3901/3902)

The 3.5 inch floppy disk drive provides an interface to the Test Set for downloading data, settings and captured display files.

C.1.19 Digital Multimeter (DMM) (18) (3920)

The Digital Multimeter (DMM) Multimeter measures AC and DC voltage, current and resistance within $\pm 5\%$ full scale of the selected range, up to 400 Volts AC or DC, 3 Amps of current and 40 M Ω of resistance.

C.1.20 RF Input and Output Connectors

C.1.20.A Audible and Visual Overload Warning

If the RF Signal applied to the ANT Connector exceeds the safe maximum level, an audible and visual warning is triggered. The overload warning is also triggered if excessive reverse power is applied to the RF GEN Connector.

CAUTION IF THE WARNING TRIGGERS, REDUCE THE INPUT POWER IMMEDIATELY.

DO NOT POWER DOWN THE TEST SET AS THIS DOES NOT REMOVE THE OVERLOAD POWER FROM THE CONNECTION.

WARNING DO NOT DISCONNECT THE RF CABLE FROM THE TEST SET AS THIS MAY CAUSE BURNS TO HANDS.

C.1.20.B ANT (Antenna) Connector (19)

RF analyzer input is a 50 Ω TNC input, providing maximum sensitivity input to the RF Analyzer.

CAUTION THE RATED MAXIMUM INPUT LEVEL IS +10 DBM.

C.1.20.C T/R Connector (20)

Duplexed RF Gen output and high power RF Analyzer input is a 50 Ω N type connector which provides an RF Gen output connection and an RF analyzer input and broadband power meter connection.

CAUTION THE MAXIMUM INPUT POWER LEVEL IS 125 W.

C.1.20.D GEN (Generator) Connector (21)

RF Gen output is a 50 Ω TNC output, providing the maximum RF output level from the RF Generator. Connector is reverse power protected to a level of +10 dBm.

C.1.20.E MIC/ACC Connector (22)

Microphone and accessory connector is an 8 pin DIN connection with ring-lock. Connector provides EXT MOD Input and DEMOD Out.

C.1.20.F Audio IN Connectors (Audio Inputs 1 and 2) (23)

AUDIO IN 1 and 2 are the primary AF Input and EXT MOD Input Connectors.

C.1.20.G FCTN GEN/DEMODO Connector (24)

(Function Generator and Demodulated Signal Output)

FCTN GEN/DEMODO Connector is the primary AF GEN Output. Connector can also be used for Demod Audio, Audio 1, Audio 2 or MIC.

C.1.20.H Scope CH1/CH2 Connectors (Oscilloscope Inputs) (25)

Scope CH1 and CH2 connectors are the dedicated inputs to the dual-trace oscilloscope providing a maximum input rating of 100 Vpeak.

C.1.20.I Test Connector (26)

Reserved for future development.

CAUTION

DO NOT CONNECT A VGA MONITOR TO THIS CONNECTOR.

C.1.20.J USB Connector (27)

The front panel USB Connector is a USB standard connection that allows connection of USB 1.1 devices (e.g. a USB memory stick or network connectors). The Front Panel USB Connector is only found on the 3920 Test Set.

C.2 REAR PANEL CONTROLS AND CONNECTORS




Fig. C-3 Rear Panel Controls and Connectors

C.2.1 AC Power Connector (30)

AC Power Connector accepts an IEC 320 connector. Refer to Appendix B, *3900 Platform Specifications* for the required supply voltage, frequency and power consumption specifications.

C.2.2 AC Power Fuse (31)

Refer to Appendix G, *Fuse Replacement Procedure*, for complete fuse replacement instructions.

C.2.3 AC Power Switch (32)

The AC Power Switch disconnects the 3900 from the AC power supply.

C.2.4 Rear Cooling Outlets (33)

Observe all CAUTION statements in this manual regarding proper Test Set ventilation. Also refer to the section titled *Installation Requirements; Ventilation* in Chapter 2 of the 3900 Series Operation Manual.

C.2.5 IF Output Signal Connector (34)

IF Output Signal is available at this BNC connector. The 10.7 MHz IF Output is the RF signal received and down-converted by the Test Set RF Analyzer. The output level is -10 dBm typical at 10.7 MHz (50 Ω nominal).

C.2.6 Ext Ref I/O External Interface (35)

The External Reference I/O Connector is a BNC connection used to connect the Test Set to an external frequency standard, or to output the internal frequency standard from the Test Set to other equipment.

C.2.7 Audio Input Connector (36)

Auxiliary I/O Audio Connector is internally connected and ready for future development. Do not make any external connection to this connector.

C.2.8 External Trigger Signal Input Connector (37)

The External Trigger Signal Input is the external trigger input for the Oscilloscope. Connection has an Input impedance 10 k Ω .

C.2.9 Audio Output Connector (38)

Auxiliary I/O Audio Connector is internally connected and ready for future development. Do not make any external connection to this connector.

C.2.10 Synchronization Signal Input/Output Connector (39)

This BNC connection is used with the TETRA Base Station Test System for base station receivers generating a sync output signal.

C.2.11 Auxiliary IF Input Connector (LVDS) (40)

Reserved for future development.

C.2.12 GPIB/IEEE-488 Interface Connection (41)

Connector provides for connection to a GPIB/IEEE-488 interface bus.

C.2.13 Standard USB Client Connector (42)

Reserved for future development.

C.2.14 PS/2 Mouse Interface Connector (43)

PS/2 mouse support is not enabled at this time. Use USB Connector for mouse option.

C.2.15 Keyboard Interface Connector (44)

Keyboard Interface Connector is a standard PS/2 connection.

C.2.16 USB X2 Connector (45)

Connector is a double USB standard connection that allows connection of USB 1.1 devices (e.g. a USB memory stick or Network connectors).

C.2.17 Ethernet Connector (46)

Ethernet Connector is a standard Base T RJ45 connection.

C.2.18 VGA Monitor Output Connector (47)

Connector is a standard VGA style, 15 way, D-type connection that allows a VGA monitor or video projector to duplicate the Test Set's screen display.

C.2.19 RS-232 Serial Connector (48)

Standard 9 way, D-type connection. Reserved for future development.

C.2.20 Parallel Printer Output Connector (49)

Parallel Printer Output Connector is a standard 25 way, D-type printer connection.

Appendix D - Shipping Test Set

D.1 REPACKING FOR SHIPPING

Aeroflex Test Sets returned to factory for calibration, service or repair must be repackaged and shipped subject to the following conditions:

CAUTION

FAILURE TO PROPERLY PACKAGE THE TEST SET FOR SHIPMENT MAY RESULT IN DAMAGE DURING SHIPMENT. PRODUCT WARRANTY AND FREIGHT INSURANCE (IF PURCHASED) DO NOT COVER SHIPPING DAMAGES RESULTING FROM IMPROPER PACKAGING.

D.1.1 Return Authorization

Do not return any products to factory without authorization from Aeroflex Customer Service Department.

D.1.1.A CONTACT:

Aeroflex	
	Customer Service Dept.
	10200 West York Street
	Wichita, Kansas 67215
Telephone:	800-835-2350
FAX:	316-524-2623
email:	americas.service@aeroflex.com

D.2 TAGGING TEST SETS

All test sets must be tagged with:

- Owner's identification and address.
- Nature of service or repair required.
- Model No. and Serial No.

D.3 SHIPPING CONTAINERS


Test Sets must be repackaged in original shipping containers using Aeroflex packing materials. If original shipping containers and materials are not available, contact Aeroflex Customer Service Department for shipping instructions.

D.4 FREIGHT COSTS

All freight costs on non-warranty shipments are assumed by the customer.


D.5 REPACKING PROCEDURE

- | STEP | PROCEDURE |
|------|---|
| 5. | Place Test Set in storage position as shown with handle adjusted and locked against Test Set. |




CAUTION DO NOT SHIP THE TEST SET WITH HANDLE EXTENDED. FAILURE TO PLACE HANDLE AGAINST TEST SET AS SHOWN MAY RESULT IN DAMAGE TO THE UNIT.

6. Place one foam insert on a solid flat surface. Fold cardboard insert and place in foam insert as shown.




7. Place Test Set in foam insert. Cardboard insert should be against rear bumper guards.




Shipping Test Set

STEP	PROCEDURE
8.	Fold cardboard insert around Test Set rear bumper guard and secure by attaching other foam insert



9. Secure accessory box in foam inserts (if applicable).



10. Place secured Test Set in shipping carton. Close shipping container lids and seal with shipping tape or an industrial stapler.



NOTE

If returning Test Set to Aeroflex for service, make sure the Return Authorization (RA#) is clearly marked on the exterior of the ship carton.

THIS PAGE INTENTIONALLY LEFT BLANK.

Appendix E - Calibration/Verification Equipment

E.1 CALIBRATION EQUIPMENT

The following table identifies test equipment required to perform 3900 calibration procedures. Due to the remote command structure of the calibration software, other equipment meeting the specifications of the equipment listed in this Appendix **may not** be substituted for the required models.

Equipment	Model
10 MHz Standard	N/A
3900 Calibration Kit	Aeroflex PN 63934 (7001-4444-900)
Digital Multimeter	HP 34401A
Frequency Counter	HP 53131A w/ Option 030
IEEE 488.2 Cable	N/A
Power Meter	Agilent E4418B
Power Meter Sensor Head	Agilent E4412A

E.2 VERIFICATION EQUIPMENT

The following table identifies test equipment needed to perform 3900 verification procedures. Other equipment meeting the specifications of the equipment listed in this Appendix may be substituted for the listed models.

Equipment	Model
3900 Calibration Kit	Aeroflex PN 63934 (7001-4444-900)
Audio Analyzer	HP 8903A
Calibrator	Fluke 5100B or equivalent
Digital Multimeter	HP 34401A
Frequency Counter	HP 53131A w/ Option 030
Modulation Analyzer	HP 8901A
Power Meter	Agilent E4418B
Power Meter Sensor Head	Agilent E4412A
RF Generator	HP ESG-3000A

THIS PAGE INTENTIONALLY LEFT BLANK.

Appendix F - Ethernet Crossover Cable

F.1 GENERAL INFORMATION

This cable can be used to cascade hubs or for connecting two Ethernet stations back-to-back without a hub.

NOTE

It is important that each pair is kept as a pair: TX+ and TX- must be in a pair and RX+ and RX- must be together in another pair (refer to table).
The "+" side of each pair is called the "tip" and the "-" side of each pair is called the "ring."

To Network Interface Card 1		
Common Color	Signal Name	Pin
WHT/ORN	TX+	1
ORN	TX-	2
WHT/GRN	RX+	3
BLU		4
WHT/BLU		5
GRN	RX-	6
WHT/BRN		7
BRN		8






Diagram illustrating the connector pinout for the Network Interface Card 1. The connector is shown from two perspectives: TOP and FRONT. The TOP view shows pins 1 and 8 labeled at the top. The FRONT view shows pins 1 and 8 labeled at the bottom.

Ethernet Crossover Cable

To Network Interface Card 2		
Pin	Signal Name	Common Color
3	RX+	WHT/GRN
6	RX-	GRN
1	TX+	WHT/ORN
4		BLU
5		WHT/BLU
2	TX-	ORN
7		WHT/BRN
8		BRN

The diagram shows two views of an RJ45 connector. The top view is labeled 'TOP:' and shows a rectangular connector with eight pins. Pin 1 is on the left and pin 8 is on the right. The front view is labeled 'FRONT:' and shows the same connector from a different angle, also with pin 1 on the left and pin 8 on the right.

Appendix G - Fuse Replacement Instructions

STEP	PROCEDURE		
1.	Verify 3900 is OFF and AC Power is disconnected from Test Set.		
2.	Press inward on pressure clip to remove Fuse Carrier.		
			
3.	Remove Fuse Carrier from Test Set.		
	 <p data-bbox="704 1270 915 1297">AC Fuse Carrier</p>		
4.	Replace fuse:		
	3 A, 250 V, Type F 20 mm Cartridge Fuse (F3AL250V) Aeroflex P/N: 56078 (5106-0000-055)		
	<table border="1"><tr><td data-bbox="354 1486 540 1528">CAUTION</td><td data-bbox="581 1478 1461 1556">FOR CONTINUOUS PROTECTION AGAINST FIRE, REPLACE FUSE WITH FUSES OF THE SPECIFIED VOLTAGE AND CURRENT RATINGS.</td></tr></table>	CAUTION	FOR CONTINUOUS PROTECTION AGAINST FIRE, REPLACE FUSE WITH FUSES OF THE SPECIFIED VOLTAGE AND CURRENT RATINGS.
CAUTION	FOR CONTINUOUS PROTECTION AGAINST FIRE, REPLACE FUSE WITH FUSES OF THE SPECIFIED VOLTAGE AND CURRENT RATINGS.		
5.	Install Fuse Carrier by pressing into place.		
6.	Install Fuse Cover.		

THIS PAGE INTENTIONALLY LEFT BLANK.

Appendix H - Abbreviations

AC	Alternating Current
ACC	Accessory
A/D	Analog to Digital
AF	Audio Frequency
AGC	Automatic Gain Control
AM	Amplitude Modulation
AMP	Amplitude
ANT	Antenna
Aud	Audio
Assy	Assembly
BW	Bandwidth
CAI	Common Air Interface
CH	Channel
CONFIG	Configuration
CPU	Central Processing Unit
DAC	Digital to Analog Converter
DAM	Data Acquisition Module
dB	decibel
dBm	decibel relative to 1 mW
dBr	decibel relative to arbitrary reference value
dBV	decibel relative to 1 Volt
dBW	decibel relative to 1 Watt
dBV	decibel relative to 1 Micro Volt
DC	Direct Current
Demod	Demodulated
DMM	Digital Multimeter
Ext	External
FCTN	Function
Fig.	Figure
FM	Frequency Modulation
FPGA	Field Programmable Gate Array
Freq	Frequency
GEN	Generator
GHz	Giga Hertz
GND	Ground
GPIB	General Purpose Interface Bus
Hz	Hertz
IC	Internal Component

Abbreviations

IF	Intermediate Frequency
In	Inch
Inc	Increments
I/O	Input/Output
kHz	Kilo Hertz
Lbs.	Pounds
LED	Light-Emitting Diode
LP	Low Pass (Filter)
LVDS	Low Voltage Differential Signal
MHz	Mega Hertz
MIC	Microphone
Mkr	Marker
Mod	Modulation
MSps	Mega Samples per second
mV	Milli Volt
PCB	Printed Circuit Board
Pk/PK	Peak
ppm	Parts per Million
Psoph	Psophometric
PTT	Push to Talk
PWR	Power
RAM	Random Access Memory
RBW	Resolution Bandwidth
REF	Reference
RF	Radio Frequency
RMS	Root Mean Square
Rx	Receive
S	Seconds
SQ	Squelch
TCXO	Temperature Controlled Crystal Oscillator
T/R	Transmit/Receive
Tx	Transmit
UTILS	Utilities
UUT	Unit Under Test
V	Volts
VAC	Voltage Alternating Current
VBW	Video Bandwidth
VGA	Video Graphics Array
Vid	Video
W	Watt
μs	Micro Seconds
μV	Micro Volt

THIS PAGE INTENTIONALLY LEFT BLANK.

As we are always seeking to improve our products, the information in this document gives only a general indication of the product capacity, performance and suitability, none of which shall form part of any contract. We reserve the right to make design changes without notice.

CHINA / Beijing	Tel: [+86] (10) 6539 1166	Fax: [+86] (10) 6539 1778
CHINA / Shanghai	Tel: [+86] (21) 5109 5128	Fax: [+86] (21) 6457 7668
FINLAND	Tel: [+358] (9) 2709 5541	Fax: [+358] (9) 804 2441
FRANCE	Tel: [+33] 1 60 79 96 00	Fax: [+33] 1 60 77 69 22
GERMANY	Tel: [+49] 8131 2926-0	Fax: [+49] 8131 2926-130
HONG KONG	Tel: [+852] 2832 7988	Fax: [+852] 2834 5364
INDIA	Tel: [+91] (0) 80 4115 4501	Fax: [+91] (0) 80 4115 4502
JAPAN	Tel: [+81] 3 3500 5591	Fax: [+81] 3 3500 5592
KOREA	Tel: [+82] (2) 3424 2719	Fax: [+82] (2) 3424 8620
SCANDINAVIA	Tel: [+45] 9614 0045	Fax: [+45] 9614 0047
*SINGAPORE	Tel: [+65] 6873 0991	Fax: [+65] 6873 0992
UK / Cambridge	Tel: [+44] (0) 1763 262277	Fax: [+44] (0) 1763 285353
*UK / Stevenage	Tel: [+44] (0) 1438 742200	Fax: [+44] (0) 1438 727601
	Freephone: 0800 282388	
*USA	Tel: [+1] (316) 522 4981	Fax: [+1] (316) 522 1360
	Toll Free: 800 835 2352	

* Indicates Regional Sales/Service Center

EXPORT CONTROL WARNING: This document contains controlled technical data under the jurisdiction of the Export Administration Regulations (EAR), 15 CFR 730-774. It cannot be transferred to any foreign third party without the specific prior approval of the U.S. Department of Commerce Bureau of Industry and Security (BIS). Violations of these regulations are punishable by fine, imprisonment, or both.



Our passion for performance is defined by three attributes represented by these three icons: solution-minded, performance-driven, customer-focused.