



## **Operating Manual**

# **Digital Radiocommunication Tester for DECT CMD60**

**1050.9008.60**

Printed in the Federal  
Republic of Germany



**Data Sheet**

**Safety Instructions**  
**Certificate of quality**  
**EC Certificate of Conformity**  
**List of R & S Representatives**

<b>1</b>	<b>Preparation for Use .....</b>	<b>Tabbed Divider 1</b>
<b>2</b>	<b>Manual Operation .....</b>	<b>Tabbed Divider 2</b>
	<b>    Getting Started</b>	
	<b>    Description of the Menus (Reference Description)</b>	
<b>3</b>	<b>Remote Control .....</b>	<b>Tabbed Divider 3</b>
<b>4</b>	<b>Maintenance .....</b>	<b>Tabbed Divider 4</b>
<b>5</b>	<b>Testing the Rated Specifications.....</b>	<b>Tabbed Divider 5</b>
<b>Annex A (Interfaces).....</b>		<b>Tabbed Divider 6</b>
<b>Annex B (List of Error Messages) .....</b>		<b>Tabbed Divider 7</b>
<b>Annex C (List of Commands) .....</b>		<b>Tabbed Divider 8</b>
<b>Annex D (Program Example) .....</b>		<b>Tabbed Divider 9</b>
<b>Index .....</b>		<b>Tabbed Divider 10</b>



## Safety Instructions

This unit has been designed and tested in accordance with the EC Certificate of Conformity and has left the manufacturer's plant in a condition fully complying with safety standards.

To maintain this condition and to ensure safe operation, the user must observe all instructions and warnings given in this operating manual.

1. The unit may be used only in the operating conditions and positions specified by the manufacturer. Unless otherwise agreed, the following applies to R&S products:  
Pollution severity 2, overvoltage category 2, IP degree of protection 2X, altitude max. 2000 m.  
The unit may be operated only from supply networks fused with max. 16 A.
2. For measurements in circuits with voltages  $V_{rms} > 30$  V, suitable measures should be taken to avoid any hazards.  
(using, for example, appropriate measuring equipment, fusing, current limiting, electrical separation, insulation).
3. If the unit is to be permanently wired, the PE terminal of the unit must first be connected to the PE conductor on site before any other connections are made (installation and cabling of the unit to be performed only by qualified technical personnel).
4. For permanently installed units without built-in fuses, circuit breakers or similar protective devices, the supply circuit must be fused such as to provide suitable protection for the users and equipment.
5. Prior to switching on the unit, it must be ensured that the nominal voltage set on the unit matches the nominal voltage of the AC supply network.  
If a different voltage is to be set, the power fuse of the unit may have to be changed accordingly.
6. Units of protection class I with disconnectible AC supply cable and appliance connector may be operated only from a power socket with earthing contact and with the PE conductor connected.
7. It is not permissible to interrupt the PE conductor intentionally, neither in the incoming cable nor on the unit itself as this may cause the unit to become electrically hazardous.  
Any extension lines or multiple socket outlets used must be checked for compliance with relevant safety standards at regular intervals.
8. If the unit has no power switch for disconnection from the AC supply, the plug of the connecting cable is regarded as the disconnecting device. In such cases it must be ensured that the power plug is easily reachable and accessible at all times (length of connecting cable approx. 2 m). Functional or electronic switches are not suitable for providing disconnection from the AC supply.  
If units without power switches are integrated in racks or systems, a disconnecting device must be provided at system level.
9. Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed.  
Prior to performing any work on the unit or opening the unit, the latter must be disconnected from the supply network.  
Any adjustments, replacements of parts, maintenance or repair may be carried out only by authorized R&S technical personnel.  
Only original parts may be used for replacing parts relevant to safety (eg power switches, power transformers, fuses). A safety test must be performed after each replacement of parts relevant to safety.  
(visual inspection, PE conductor test, insulation-resistance, leakage-current measurement, functional test).
10. Any additional safety instructions given in this manual are also to be observed.

### Safety-related symbols used on equipment and documentation from R&S:

Observe operating instructions	Weight indication for units >18 kg	PE terminal	Ground terminal	Danger! Shock hazard	Warning! High temperatures Warning! Hot surfaces	Ground





Certificate No.: 9502035

This is to certify that:

Equipment type	Order No.	Designation
CMD60	1050.9008.60	Dig. Radiocommunication Tester

complies with the provisions of the Directive of the Council of the European Union on the approximation of the laws of the Member States

- relating to electrical equipment for use within defined voltage limits  
(73/23/EEC revised by 93/68/EEC)
- relating to electromagnetic compatibility  
(89/336/EEC revised by 91/263/EEC, 92/31/EEC, 93/68/EEC)

Conformity is proven by compliance with the following standards:

EN61010-1 : 1993 + A2 : 1995

EN50081-1 : 1992

EN50082-1 : 1992

Affixing the EC conformity mark as from 1995

**ROHDE & SCHWARZ GmbH & Co. KG**  
**Mühldorfstr. 15, D-81671 München**

Munich, 1999-01-12

Central Quality Management FS-QZ / Becker



# Index

## A

ACCEPT RFPI.....	2.4; 2.6
Action .....	2.94
Action step.....	2.94
Additional Measurements .....	2.56
ADPCM .....	2.60; 2.87; 2.88
Amplifier .....	2.77
Antenna.....	2.66
Audio measurements.....	2.28; 2.31
Autotest .....	2.92
 Autotest menus.....	2.19
AUTO TEST.....	2.92
AUTO TEST Active .....	2.109
AUTO TEST COPY .....	2.111
AUTO TEST EDIT .....	2.93
AUTO TEST End.....	2.109
BIT ERROR RATE CONFIGURATION.....	2.106
CONDITIONAL GOTO CONFIGURATION.....	2.108
DISPLAY RESULTS.....	2.110
POWER RAMP CONFIGURATION.....	2.101
RF MODULATION CONFIGURATION .....	2.103
SIGNALLING FP-TEST CONFIGURATION .....	2.99
SIGNALLING PP-TEST CONFIGURATION .....	2.95
TIMING CONFIGURATION.....	2.105

## B

BACKSPACE .....	2.20; 2.25
Bandpass .....	2.87
Basic Operating Instructions.....	2.20
BEARER HANDOVER.....	2.39
BEARER RELEASE .....	2.40
BER.....	2.16; 2.17; 2.46
Bit error rate.....	2.17
Bit P0.....	2.13; 2.40
BURST .....	2.54

## C

CARRIER # OFFSET .....	2.29; 2.66
CLEAR .....	2.20
CONDITIONAL GOTO.....	2.108
CONFIG .....	2.21
Config. Menus for Add. Measurements.....	2.86
 Configuration menus.....	2.19; 2.61
ADD. MEASUREMENTS CONFIGURATION.....	2.86
AF GENERATOR CONFIGURATION.....	2.89
AF METER CONFIGURATION .....	2.87
BIT ERROR RATE CONFIGURATION.....	2.75
Configuration Main Menu.....	2.61
DISTORTION METER CONFIGURATION .....	2.88
HARDWARE OPTIONS .....	2.84
MULTITONE AUDIO ANALYSIS CONFIG. ....	2.90
OTHER CONFIGURATION PARAMETERS.....	2.85
POWER RAMP CONFIGURATION .....	2.70
PRINTER .....	2.80
REPORT .....	2.83
RF CONNECTOR/EXT. ATT.....	2.77
RF-MODULATION CONFIGURATION .....	2.72
SIGNALLING FP-TEST CONFIGURATION .....	2.66
SIGNALLING PP-TEST CONFIGURATION .....	2.63; 2.67
SOFTWARE OPTIONS .....	2.84
SYNCHRONIZATION.....	2.78

TIMING CONFIGURATION.....	2.74
TX TEST CONFIGURATION .....	2.70

Configuration Menus for Measurements.....	2.70
CONNECT/EXT. ATT.....	2.62
CONNECTION ESTABLISHED.....	2.12
Connection of CMD60.....	2.2
Connection to AC supply.....	2.3
CONST.ENVELOP.....	2.54
Contrast .....	2.2; 2.3
COUNTER .....	2.57
COUNTER MODE.....	2.57
CTR06.....	2.61
CURRENT.....	2.57
Current BER.....	2.46
Current FER .....	2.46
Current measurements.....	2.56; 2.86

## D

Data pattern .....	2.15; 2.42; 2.46
DATA TYPE .....	2.14
DECT audio measurements .....	2.60
DECT BURST .....	2.54
DECT channel numbers .....	2.29
DECT channel spacing.....	2.65
DECT frequencies .....	2.29
DECT Measurements .....	2.38
DECT test mode.....	2.5; 2.7; 2.9; 2.11
DECT timing.....	2.79
DECT Transmitter Measurements .....	2.12
DECT Receiver Measurements .....	2.16
DECT-Testmode .....	2.7
DEVIATION .....	2.53
Distortion measurements .....	2.88
Dummy bearer.....	2.5; 2.7; 2.9; 2.11; 2.27; 2.28; 2.64
DUMMY IF TRAFFIC .....	2.38; 2.64
DYNAMIC .....	2.71

## E

ECHO.....	2.28; 2.31; 2.33; 2.36
ENTER .....	2.20
ESCAPE SEQUENCE .....	2.39
EXP. POWER .....	2.49
EXTERN .....	2.54
EXTERNAL .....	2.49

## F

FER.....	2.16; 2.17; 2.46
FORCE TRANSMIT .....	2.38
Frame erasure rate .....	2.17
FREE RUN.....	2.49
Frequency accuracy .....	4.1
Frequency counter .....	2.56
Frequency drift .....	2.15; 2.43
Frequency offset .....	2.13; 2.38; 2.43; 2.48; 2.51
Front-panel view.....	1.1

## G

General Configuration Menus.....	2.77
Getting Started.....	2.1

**H**

HARDCOPY .....	2.21
Hardkeys .....	2.21
HIGH DYNAMIC .....	2.13

**I**

IEEE ADDRESS .....	2.62
ILLUM .....	2.25

**J**

Jitter .....	2.15; 2.45
--------------	------------

**K**

KEY HELP .....	2.25
----------------	------

**L**

Lead time .....	2.91
LOCAL .....	2.20
LOCKED .....	2.32
Longterm BER .....	2.46
Longterm FER .....	2.46
Loop toggle .....	2.20
LOOPBACK .....	2.28; 2.33

**M**

MAC message .....	2.39
Main Menu .....	2.26
Main power switch .....	2.2
Maintenance .....	4.1
Manual Test .....	2.27
MASTER .....	2.78
Master/slave operation .....	2.79
Max. $\pm$ Modulation .....	2.48; 2.51
Max. $\pm$ sync field modulation .....	2.43
Max. $\pm$ B field modulation .....	2.43
MEAS. WINDOW .....	2.49
MEMCARD .....	2.23; 2.24
Memory Card .....	2.23; 2.24; 2.111
MENU HOME .....	2.21; 2.26
Menu Structure .....	2.18
MENU UP .....	2.21

## Menus

ADDITIONAL MEASUREMENTS .....	2.56
BIT ERROR RATE .....	2.46
BURST ANALYSIS .....	2.48
CONNECTION ESTABLISHED .....	2.38
MULTITONE AUDIO ANALYSIS .....	2.58
POWER RAMP .....	2.40
POWER VERSUS TIME .....	2.50
RF MODULATION .....	2.42
RF SIGNAL GENERATOR .....	2.53
RF-MODULATION .....	2.51
SIGNALLING FP-TEST .....	2.32
SIGNALLING PP-TEST .....	2.27
TIMING .....	2.45

MODULATION .....	2.14
Modulation deviation .....	2.13; 2.38
Module Test .....	2.48
MT message .....	2.39
MULTI BEARER .....	2.76
Multibearer .....	2.46
Multitone measurements .....	2.59; 2.90

**N**

NORMAL .....	2.28; 2.31; 2.33; 2.36
Normal transmit power .....	2.38
Notch filter .....	2.88
NTP .....	2.13; 2.38; 2.48
Number key .....	2.20
Numerical input .....	2.20

**O**

OCXO .....	4.1
OCXO reference oscillator .....	2.3
Operating menus .....	2.18; 2.26

**P**

Packet delay .....	2.15; 2.45
Packet type .....	2.15
Path attenuation .....	2.77
PC-AT keyboard .....	2.20
Peak value .....	2.87
PMID .....	2.5; 2.12; 2.13; 2.32; 2.33; 2.35
Poor Signal Quality .....	2.38
Portable Part MAC Identity .....	2.5; 2.33
Power cable .....	2.2
Power Fuses .....	1.7
POWER RAMP .....	2.12
Power socket .....	2.2
Preamble .....	2.15
Preparation for Use .....	1.1
Printer .....	2.110
Putting into Operation .....	1.6

**Q**

Q packet .....	2.64
Q0 packet .....	2.63
Q0 PROTO .....	2.63
Q3 packet .....	2.63
Q3 PROTO .....	2.63
Q6 packet .....	2.64
Q6 PROTO .....	2.64
QE PROTO .....	2.64
QMUX TABLE .....	2.64

**R**

Rack 19" .....	1.6
Radio Fixed Part Identity .....	2.5; 2.7; 2.9; 2.11; 2.27; 2.33
Rear-panel view .....	1.1
RECALL .....	2.24
REF OUT 3 .....	2.78
REF. FREQ .....	2.78
Reference frequency .....	2.78
Reference oscillator .....	4.1
RESET .....	2.21
RF IN 2 .....	2.77
RF IN/OUT .....	2.2; 2.77
RF OUT2 .....	2.77
RF connection .....	2.3
RFPI .....	2.5; 2.7; 2.9; 2.11; 2.27; 2.32; 2.33; 2.35
RISING SLOPE .....	2.49
RMS .....	2.87
Rms values .....	2.87

**S**

SAVE.....	2.23
SAVE/RECALL functions.....	2.23
Selection with confirmation.....	2.20
Serial number of the unit.....	2.84
SETUP CONNECT.....	2.27
Signal generator .....	2.56
SIGNALLING FP TEST .....	2.4; 2.6
SIGNALLING FP TEST menu.....	2.35
Signalling Menus .....	2.63
SIGNALLING PP TEST .....	2.8; 2.10
Signalling status .....	2.32
SLAVE.....	2.78
Slot.....	2.5; 2.7
Softkey .....	2.20
Spectrum analyzer.....	1.8
Standby .....	2.3
START.....	2.20
STOP BREAK .....	2.20
STOP CONDITION.....	2.13
Storage of Parameters.....	2.20
SYNC PORT.....	2.78
Synchronization .....	2.9; 2.11; 2.27; 2.32; 2.79

**T**

T_DATA_IN.....	2.54
TCXO .....	4.1
Test mode .....	2.32
Testing of the Frequency Accuracy .....	4.1
Testing the Rated Specifications .....	5.1
Text input.....	2.20
Time Accuracy.....	2.45
Timing accuracy .....	2.15
TIMNG.....	2.14
Traffic bearer .....	2.28; 2.32; 2.35
TRIGGER .....	2.49
TRIGGER DELAY .....	2.49

**U**

Unit keys.....	2.20
UNLOCKED.....	2.32
USER .....	2.22; 2.24
USER DATA.....	2.55

**V**

Voltage measurements.....	2.56
Voltmeter.....	2.56

**Z**

Zero adjustment.....	2.56; 2.86
ZERO OFFSET .....	2.86

