

MAXIM

MAX9424 Evaluation Kit

General Description

The MAX9424 evaluation kit (EV kit) is a fully assembled and tested surface-mount printed circuit (PC) board. The EV kit includes the MAX9424, a four-channel low-skew PECL/LVPECL-to-ECL/LVECL translator. The EV kit accepts differential PECL/LVPECL input signals and converts these differential ECL/LVECL signals at an operating frequency up to 3GHz.

The MAX9424 EV kit is a four-layer PC board with 50Ω controlled-impedance traces. It can also be used to evaluate the MAX9425/MAX9426/MAX9427 PECL/LVPECL-to-ECL/LVECL translators with different internal input and output terminations (Table 3).

Features

- ◆ Controlled 50Ω Coplanar Impedance Traces
- ◆ Output Trace Lengths Matched to < 1mil (25.4 x 10⁻³mm)
- ◆ Frequency Range
 - 2GHz (min) at Asynchronous Mode
 - 3GHz (min) at Synchronous Mode
- ◆ 32-Pin TQFP 5mm x 5mm Package
- ◆ Surface-Mount Construction
- ◆ Fully Assembled and Tested

Ordering Information

PART	TEMP RANGE	IC PACKAGE
MAX9424EVKIT	0°C to +70°C	32 TQFP 5mm x 5mm

Note: To evaluate the MAX9425EHJ/MAX9426EHJ/MAX9427EHJ, request a MAX9425EHJ/MAX9426EHJ/MAX9427EHJ free sample with the MAX9424EVKIT.

Component List

DESIGNATION	QTY	DESCRIPTION
C1, C2, C3	3	10μF ±10%, 10V tantalum capacitors (case B) AVX TAJB106K010R or Kemet T494B106010AS
C4–C12	9	0.1μF ±10%, 16V X7R ceramic chip capacitors (0603) Taiyo Yuden EMK107BJ104KA or Murata GRM39X7R104K016A or equivalent
C13–C21	9	0.01μF ±10%, 16V X7R ceramic capacitors (0402) Taiyo Yuden EMK105BJ103KW or Murata GRM36X7R103K016AD or equivalent
JU1–JU4	4	3-pin headers

DESIGNATION	QTY	DESCRIPTION
R1, R2, R5–R8	6	49.9Ω ±1% resistors (0402)
R3, R4	0	Not installed, resistor (0402)
R9–R36	28	100Ω ±1% resistors (1210), 1/4W
IN0–IN3, IN0–IN3, OUT0–OUT3, OUT0–OUT3, CLK, CLK	18	SMA edge-mount connectors
U1	1	MAX9424EHJ (32-pin TQFP 5mm x 5mm)
None	4	Shunts
None	1	MAX9424 PC board
None	1	MAX9424 EV kit data sheet
None	1	MAX9424 data sheet

Component Suppliers

SUPPLIER	PHONE	FAX	WEBSITE
AVX	843-946-0238	843-626-3123	www.avxcorp.com
Kemet	864-963-6300	864-963-6322	www.kemet.com
Murata	770-436-1300	770-436-3030	www.murata.com
Taiyo Yuden	800-348-2496	847-925-0899	www.t-yuden.com

Note: Please indicate that you are using the MAX9424/MAX9425/MAX9426/MAX9427 when contacting these component suppliers.

MAX9424 Evaluation Kit

Quick Start

The MAX9424 EV kit is a fully assembled and tested surface-mount board. Follow the steps below to verify board operation. **Do not turn on the power supplies until all connections are completed.**

Recommended Equipment

- Signal generator (e.g., Agilent 8133A 3GHz pulse generator)
- 12GHz (min) bandwidth oscilloscope with internal 50Ω termination (e.g., Tektronix11801C digital sampling oscilloscope with the SD-24 sampling head)
- Three power supplies:
 - a) One 2.0V ±0.001V with 1A current capability
 - b) One adjustable -3.50V to -0.375V with 200mA current capability
 - c) One adjustable 4.375V to 7.50V with 300mA current capability
- Additional power supply (for VBAIS): one adjustable 2.50V to 5.00V with 1A current capability

Asynchronous Operation

- 1) Verify that shunts are across jumpers JU1 (SEL) and JU3 (EN) pins 1 and 2, and jumpers JU2 (SEL) and JU4 (EN), pins 2 and 3.
- 2) Connect two matched coax cables to OUT1 and OUT $\bar{1}$. Connect the other end of the cables to an oscilloscope.
- 3) Connect two matched coax cables to IN1 and IN $\bar{1}$. Connect the other end of the cables to a signal generator that provides differential square waves with the following settings:
 - a) Frequency = 2GHz
 - b) $V_{IH} = 3.4V$, $V_{IL} = 3.2V$
 - c) Duty cycle = 50%
- 4) Connect one coax cable to the trigger output of the signal generator. Connect the other end to the trigger input of the oscilloscope.
- 5) Connect a 2.000V power supply to the VGG pad. Connect the supply ground to the GND pad closest to VGG.
- 6) Connect a 5.30V power supply to the VCC pad. Connect the supply ground to the GND pad closest to VCC.
- 7) Connect a -1.30V power supply to the VEE pad. Connect the supply ground to the GND pad closest to VEE.

- 8) Connect a 3.40V power supply to the VBIAS pad. Connect the supply ground to the GND pad closest to VBAIS.
- 9) Connect CLK and all unused positive inputs (IN0, IN2, IN3) to the VBIAS pad.
- 10) Connect \overline{CLK} and all unused negative inputs ($\overline{IN0}$, $\overline{IN2}$, $\overline{IN3}$) to VGG.
- 11) Turn on the power supplies in the following order: **VCC, VGG, VEE, then VBIAS.**
- 12) Enable the pulse generator and verify the differential output signal:
 - a) Frequency = 2GHz
 - b) $V_{OD} \geq 400mV$
 - c) Duty cycle = 50%

Note: To evaluate other channels, make sure corresponding output termination resistors on the EV kit board are removed, and the unused outputs are terminated with a 50Ω termination resistor. To eliminate signal distortion, use matched cables of the same type and length for both the inputs and outputs. All unused inputs should be biased.

Detailed Description

The MAX9424 EV kit contains an extremely fast, low-skew quad PECL/LVPECL-to-ECL/LVECL translator. The EV kit demonstrates ultra-low propagation delay and channel-to-channel skew, and can be operated synchronously with an external clock, or in asynchronous mode, depending on the state of the SEL input.

Power Supply

MAX9424–MAX9427 are specified with outputs terminated with 50Ω to $V_{CC} - 2V$. In order to terminate the outputs with 50Ω to $V_{CC} - 2V$ using the 50Ω oscilloscope input termination, VGG is set to 2.000V. An additional 2.50V to 5.00V power supply is required to bias all unused positive inputs to a known state. All unused negative inputs should be connected to VGG. To avoid damaging the IC, turn on the power supply in the following sequence: VCC, VGG, VEE, then VBIAS. In an actual application, VCC, VGG, and VEE can have different supplies (refer to the MAX9424–MAX9427 data sheet), and VBIAS can be eliminated.

Enable and Select

The MAX9424 provides pins EN and \overline{EN} to enable the outputs, and pins SEL and \overline{SEL} to select asynchronous or synchronous operation. The MAX9424 EV kit incorporates jumpers JU1–JU4 to drive these pins to either VBIAS or VGG (see Tables 1 and 2).

MAX9424 Evaluation Kit

Evaluates: MAX9424-MAX9427

Table 1. Jumpers JU1 and JU2 Functions

JU1 SHUNT LOCATION	MAX9424 SEL PIN	JU2 SHUNT LOCATION	MAX9424 SEL PIN	MAX9424 OPERATING MODE
1 and 2	Connected to VBIAS	2 and 3	Connected to VGG	Asynchronous mode
2 and 3	Connected to VGG	1 and 2	Connected to VBIAS	Synchronous mode
All other combinations (not driven externally)				Undefined

Table 2. Jumpers JU3 and JU4 Functions

JU3 SHUNT LOCATION	MAX9424 EN PIN	JU4 SHUNT LOCATION	MAX9424 EN PIN	MAX9424 OUTPUTS
1 and 2	Connected to VBIAS	2 and 3	Connected to VGG	Enabled
2 and 3	Connected to VGG	1 and 2	Connected to VBIAS	Disabled
All other combinations (not driven externally)				Undefined

An external signal can be used to drive any of the EN, $\overline{\text{EN}}$, SEL, and $\overline{\text{SEL}}$ control pins by removing the shunt completely from the appropriate jumpers and connecting the external signal to the appropriate SMA connector. The MAX9424 EV kit does not provide SMA connectors for EN, $\overline{\text{EN}}$, SEL, and $\overline{\text{SEL}}$. **Before connecting external signals to the EN, $\overline{\text{EN}}$, SEL, and $\overline{\text{SEL}}$ pins, verify there are no shunts across jumpers JU1–JU4, and add SMA connectors to the appropriate pads.**

Evaluating the MAX9425/MAX9426/MAX9427

The MAX9424 EV kit is a four-layer PC board with 50Ω controlled-impedance input traces with 50Ω termination (two parallel 100Ω resistors). All output signal traces are also 50Ω controlled-impedance traces with 49.9Ω termination resistors.

The MAX9424 EV kit can be used to evaluate the MAX9425/MAX9426/MAX9427 after some modifications. Table 3 shows the on-chip input and output termination resistor arrangement for each part.

Table 3. On-Chip Input and Output Termination

PART	INPUT TERMINATION RESISTOR	OUTPUT TERMINATION RESISTOR
MAX9424	Open	Open
MAX9425	Open	50Ω
MAX9426	100Ω	Open
MAX9427	100Ω	50Ω

- To evaluate the MAX9425, replace the MAX9424EHJ with a MAX9425EHJ and remove all output termination resistors R1 to R8. The output is half-amplitude compared to an open output because of the voltage-divider formed by the on-chip series 50Ω and the 50Ω oscilloscope input.
- To evaluate the MAX9426, replace the MAX9424EHJ with a MAX9426EHJ and remove all input termination resistors R9 to R24.
- To evaluate the MAX9427, replace the MAX9424EHJ with a MAX9427EHJ and remove all input and output termination resistors R1 to R24. The output is half-amplitude compared to an open output because of the voltage-divider formed by the on-chip series 50Ω and the 50Ω oscilloscope input.

MAX9424 Evaluation Kit

Evaluates: MAX9424-MAX9427




Figure 1. MAX9424 EV Kit Schematic

MAX9424 Evaluation Kit

Evaluates: MAX9424-MAX9427




Figure 2. MAX9424 EV Kit Component Placement Guide—Component Side




Figure 3. MAX9424 EV Kit PC Board Layout—Component Side




Figure 4. MAX9424 EV Kit PC Board Layout—Inner Layer 2 (GND Layer)

MAX9424 Evaluation Kit




Figure 5. MAX9424 EV Kit PC Board Layout—Inner Layer 3 (VCC Layer)




Figure 6. MAX9424 EV Kit PC Board Layout—Solder Side




Figure 7. MAX9424 EV Kit Component Placement Guide—Solder Side

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

6 **Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600**