

MPC860ADS

Product Brief **MPC860ADS - Application Development System**

INTRODUCTION

The MPC860ADS is an Applications Development System (ADS) designed to aid hardware and software developers of the MPC860 PowerQUICC, PowerPC QUad Integrated Communication Controller, in quickly evaluating and developing applications for this device. All of the hardware resources needed to download and debug application software are provided, such as large blocks of flash and Dynamic RAM for the processor, serial port, clock generation option circuitry, logic analyzer connectors, expansion connectors as well as monitor/debugger hardware and software. The logic analyzer connectors provide the user with access to all of the processor's pins in order to monitor bus activity. The expansion connectors let the user attach user hardware applications and utilize board resources to verify a design.


To serve as a convenient platform for software development, the MPC860ADS is provided with MPC8Bug, a monitor/debugger, for the PowerQUICC. The monitor/debugger provides operations of memory dump and set, single instruction execution, breakpoints and downloads, as well as a self-test verification suite. This monitor is downloaded via the MPC860ADI-PC or MPC860ADI-SUN4 which plugs into the user host system and connected to the ADS via a parallel ribbon cable.

The MPC860ADS board has a Ball Grid Array (BGA) socket to accomodate the MPC860 and its successors.

MPC860 APPLICATION DEVELOPMENT SYSTEM FEATURES

- General Features
 - Supports the MPC860 up to 50MHz operation
 - On Board (MPC8Bug) Debugger Software with Host Debugger Interface (via ADI)
 - Crystal and Clock Generator options for the MPC860
 - PCMCIA (PC Card) Port Connector (2.1+ Standard)
 - Expansion Connectors Providing All the MPC860 Device Signals
 - 4 MBytes of 60ns DRAM on a standard 72 pin SIMM socket (handles up to 64 MByte)
 - Automatic DRAM SIMM identification.
 - 2 MBytes of Flash on a SIMM socket (handles up to 64MByte)
 - Automatic Flash SIMM identification
 - +5Vdc & +12V Power Supply connectors (+12V only required for programming of PC Card Flash)
 - RS232 port on SMC1 with low power option; DB9 connector
 - IrDA - Infra-red Transceiver on SCC2 with shutdown option
 - 10-Base-T Ethernet port on SCC1 using MC68160 (EEST)
 - Soft/Hard RESET and ABORT push buttons
 - RUN , FLASH ON, DRAM ON, ETH ON, IRD ON, RS232 ON, PCMCIA ON, VPP-GOOD, 5V and 3.3V Status Indicators (LED's)
 - On-board Debug Port Controller with ADI I/F and Port Connector
 - 3.3V/2V MPC860 internal logic operation, 3.3V MPC860 I/O operation

FIGURE 1-1 MPC860ADS Block Diagram



Freescale Semiconductor, Inc.

MPC860 Application Development System Part Number List

Part Number	Description
MPC860ADS	MPC860 Application Development System Includes User Manual, MPC8Bug and User manual, MPC860 Silicon Errata and ADS errata.
MPC860ADS - PC	MPC860 Application Development System with Interface Card for IBM-PC Includes User Manual, MPC8Bug and User manual, MPC860 Silicon Errata, ADS errata, ADI-PC host board and parallel connecting cable.
MPC860ADS- SUN4	MPC860 Application Development System with Interface Card for SUN4 Includes User Manual, MPC8Bug and User manual, MPC860 Silicon Errata, ADS errata, ADI-SUN4 host board and parallel connecting cable.

How to Reach Us:

Home Page:
www.freescale.com

E-mail:
support@freescale.com

USA/Europe or Locations Not Listed:
Freescale Semiconductor
Technical Information Center, CH370
1300 N. Alma School Road
Chandler, Arizona 85224
+1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:
Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
support@freescale.com

Japan:
Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:
Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:
Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.