

<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>
<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>
Constant Voltage, Constant Current Bench Supply Jumper Selectable Vin = 10V to 40V Vout = 0V - 24V @ 0A - 3A	Constant Voltage, Constant Current Bench Supply Jumper Selectable Vin = 10V to 40V Vout = 0V - 24V @ 0A - 3A	Constant Voltage, Constant Current Bench Supply Jumper Selectable Vin = 10V to 40V Vout = 0V - 24V @ 0A - 3A	Constant Voltage, Constant Current Bench Supply Jumper Selectable Vin = 10V to 40V Vout = 0V - 24V @ 0A - 3A

<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>
<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>
Constant Voltage, Constant Current Bench Supply			
Jumper Selectable	Jumper Selectable	Jumper Selectable	Jumper Selectable
Vin = 10V to 40V			
Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A

<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>
<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>
Constant Voltage, Constant Current Bench Supply			
Jumper Selectable	Jumper Selectable	Jumper Selectable	Jumper Selectable
Vin = 10V to 40V			
Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A

<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>	<b>DEMO 2132A</b>
<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>	<b>LT3081ER</b>
Constant Voltage, Constant Current Bench Supply			
Jumper Selectable	Jumper Selectable	Jumper Selectable	Jumper Selectable
Vin = 10V to 40V			
Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A	Vout = 0V - 24V @ 0A - 3A