

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS

DC890B QuickStart Guide

DESCRIPTION

Demonstration circuit DC890B along with QuickEval-II™ software provides a USB based Windows PC hosted digital data acquisition system supporting CMOS/LVDS output ADCs up to 250Msps. The DC890B must be powered from an external 6 ± 0.5 VDC power supply when operating in LVDS mode. When operating in CMOS mode, the external power supply is optional. The Linear Technology supplied QuickEval-II evaluation software automatically detects the DC890B and can also detect many of the standard ADC demonstration circuits boards. The DC890B will not enable LVDS mode unless an external 6.0VDC power source is available. The QuickEval-II system provides for fast and easy performance evaluation of high speed

ADCs. FastDAACS collects up to 256K word samples and then performs various analyses on the data including calculating SNR, SINAD, THD, SFDR and ENOB. The digitized input, an FFT of the collected data, the Primitive Wave of the sample set or an IFFT of modified frequency domain data is plotted to a display window to facilitate analyzing distortion products and sources. Figure 1 shows a picture of the DC890B. The DC890B is connected to the ADC demonstration circuit via a 100 pin edge connector, to the PC by a USB A-B cable and to an optional power supply either by a 5mm power plug or optionally by turrets. Figure 2 details the connections.




Figure 1. DC890B FastDAACS Board

OPERATING PRINCIPLES

The DC890B is capable of collecting a block of data samples from an ADC demonstration circuit initiated either by an internally generated trigger or an externally supplied 2.5V CMOS level trigger of user-selected edge. The external trigger is TTL or CMOS compatible (the trigger line is diode clamped to the 2.5V Rail through a 475Ω resistor). Refer to the QuickEval-II

Software Help for information on the various operating modes and options. The Conversion clock to the DC890B is supplied via the ADC demonstration circuit either from an optional on board oscillator if installed or an external signal generator connected to the ADC demonstration circuit.

QUICK START PROCEDURE

To prevent damage to the DC890B, it is important to follow the equipment setup procedure outlined below:

1. Do not plug the DC890B into the PC USB port before running the installation program
 2. Download the QuickEval-II installation program from <http://www.linear.com/software/>.
 3. Run the QuickEval-II installation program and follow the on-screen instructions.
- NOTE:** The QuickEval-II evaluation software requires a PC running Windows98, 2000, or XP with an available USB port.
4. Connect the DC890B to the USB port and supply external power to the DC890B, if you will be using the LVDS mode. Do not use a USB cable longer than 2m or the board may not reset properly. (See note in trouble shooting section.)
 5. Connect only 2.5V CMOS or LVDS output ADC demonstration circuits directly to the DC890B via the 100 pin edge connector. All Linear Technology DC890 compatible demo boards meet these requirements. Apply DC power to the ADC demonstration circuit.
 6. Each ADC demonstration board also comes with a Quick Start guide similar to this one and should be referred to for specific usage details relevant to the demonstration circuit being evaluated.

Please refer to it for proper jumper settings, input power requirements and input signal levels and frequency ranges.

7. Apply an appropriate conversion clock and analog input signal to the ADC demonstration board.
8. Open the QuickEval-II software and from the **Configure** Menu, select *FastDAACS*. Then also from the **Configure** menu, click on **Device** and scroll through the list of Linear Technology Corporation ADCs and select the device part number on the attached demo board.
9. Select **Processing Options** (the hammer icon) menu and verify that under **Trigger Mode**, **No Trigger Wait** is selected
10. Enter the exact sample rate in Mhz and select the sample size in the provided fields in QuickEval-II page 1.
11. If the sampled signal is not coherent with the encode clock, select an appropriate windowing function from the pull down menu.
12. Initiate a data collection cycle by clicking the green **Collect** button; it will turn red during the collection cycle. An FFT should appear on the screen along with a plot of the sampled data. Make sure the input level is not over ranging the ADC. See online help for specific guidance on using the QuickEval-II Software.

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS




Figure 2. DC890B FastDAACS Basic Connection Locations

USEFUL SOFTWARE TOOLS

The QuickEval-II software includes tools for automatic software updates and for quickly retrieving documentation from the World Wide Web.

The Download Datasheets feature is particularly useful to laptop users, who can use this feature to download the data sheets and Quick Start guides in one step, thus making them available even when the laptop is not connected to the Internet.

NOTE: Adobe Acrobat reader is required to view the documents and is available at <http://www.adobe.com>.

To update the QuickEval-II software (requires an internet connection):

□ Choose “Update Program” from the Tools menu.
This automatically updates the main program and drivers for individual demo circuits.

To view the Quick Start Guide for the DC890B demonstration board:

□ Choose “View Controller QS Guide” from the View menu.

To View the Quick Start Guide for the Device:

□ Choose “View Device QS Guide” from the View menu. This will bring up the product page in your de-

fault browser. Select documentation for “Reference Design”.

To download data sheets (requires an internet connection):

- ❑ Choose “Download Data Sheets” from the Tools menu.

All datasheets and Quick Start guides for all products in the QuickEval-II family are downloaded to the QuickEval-II program folder and placed in the *dsheets* folder.

OPTIONAL CONNECTIONS TO THE DC890B

- ❑ In CMOS mode the DC890B can operate from the USB power, however in LVDS mode, the Spartan-III FPGA IO ring drivers draw considerable supply current to bias the active LVDS terminations. The DC890B has provisions for a 5mm power plug for an external 6V ± 0.5 V supply. The DC890B automatically detects the presence of external power and disables the USB power input.
- ❑ X1: The DC890B has provisions for an external trigger input, Edge selectable by software. This permits initiating data block capture by an external event.
- ❑ J2: A JTAG connector is provided for downloading custom FPGA software to the board. Grounding pin

3 of J2 automatically puts the FPGA into JTAG programming mode. User developed code can be loaded into the FPGA without compromising the factory installed code. JUMPER PINS 4 & 6 OF PIC Programming connector J1 to disable the microcontroller when using custom FPGA code. Refer to the schematic for further details. **This feature is provided due to customer requests. Development of custom code will not be supported by the factory.**

- ❑ J7 & J8 locations (not installed) provide access to 6 additional FPGA pins for test purposes. These pins also drive LED indicators useful for debug purposes. Xilinx provides logic analysis and data collection features through JTAG via ChipScope.

LED INDICATORS

The DC890B provides system status via 8 LEDs:

LED-1.TRANSFER – Indicates a USB data transfer from the QuickEval-II to the PC is in progress.

LED-2.SEEP – Indicates access of the optional demonstration circuit Serial Electrically Erasable PROM on select demonstration boards. Information in this SEEP permits QuickEval-II software to configure the DC890B properly for the device under evaluation using the auto detect demo board feature in the Configure/Device Menu.

LED-3.RST – Indicates assertion of either a hard or soft reset.

LED-4.DCM_RDY– In LVDS mode, led 4 blinks to alert the user that the sample clock is either

not present or outside the required frequency range (Fin must be > 50 MHz). A steady on condition indicates the Digital Clock Module is locked to the input sample clock. In CMOS mode LED 4 functions as a Power On/FPGA programmed Indicator.

LED-5.RUN ON TRIGGER – Indicates that the board is set to run on trigger (versus halt on trigger mode).

LED-6.DATA_RDY – Indicates completion of data block acquisition.

LED-7.RUN – Indicates the board is ARMED to collect a block of data.

LED-8.TRIGGER – indicates that a trigger was received and data collection has started.

CIRCUIT DETAILS

A schematic, parts list and parts placement drawings are attached to the end of this Quick Start Guide for reference only.

TROUBLE SHOOTING GUIDE

Problem: DC890B is plugged in, but QuickEval-II software still does not recognize DC890B board.

Solution: Assuming that the USB hardware in your computer is operational (Try verifying an operational USB port with another USB device such as a USB Memory stick, printer or scanner if available.), the likely cause is improper installation of the USB drivers, which results in Windows recognizing the DC890B as an “Unknown Device”. If this is the case, the problem can be corrected by the following procedure:

- 1) Unplug the DC890B board from the USB port.
- 2) Re-install the QuickEval-II Software. **CAREFULLY** following the on-screen instructions. This **MAY** require a reboot of your computer. The on-screen instructions will inform you if that is the case.
- 3) If the problem persists, please choose “Contact Software Support” from the Tools Menu for assistance from LTC staff.

Problem: Demonstration circuit software loads properly, but will not run or gives “Device Not Accessible” errors.

Solution: Verify the demonstration circuit is properly powered up and a correct (signal level and frequency) conversion clock is applied. (The DC890B can operate from the USB port power in CMOS mode but will not load the FPGA with the LVDS code unless external power is detected.) Set the correct sample rate for the applied conversion clock as QuickEval-II software uses the sample size and rate to determine the watch dog time out period to reset the DC890B if the USB bus should hang. Refer to

the appropriate demonstration circuit Quick Start Guide for details.

Problem: Collected data samples look like noise or appear corrupted.

Solution: Make sure the proper device has been selected in the QuickEval-II software, the factory jumper settings are present and for LVDS output demo boards, external power is applied to the DC890B otherwise the captured data will not be properly interpreted.


Problem: QuickEval-II reports it cannot reset the DC890B.

Solution: Make sure either a powered USB port is used or external power is supplied. **DO NOT USE A USB CABLE LONGER THAN 2 METERS.** The time delay of a longer USB cable may result in the DC890B intercepting the reset.


Problem: USB Bus appears to be hung.

Solution: As the DC890B is used in a lab environment where power may be inappropriately sequenced, cables unintentionally disconnected etc, some users have reportedly had their USB bus hang. This condition is easily rectified by right clicking properties under my computer -> Hardware -> Device Manager -> and then right clicking on the appropriate USB bus controller and again selecting properties. The device status generally reports that it is working properly. Select the Advanced tab. You will notice a refresh button. Device manager has queried the port and as a result reset the bus.

REVISION HISTORY			
ECO REV	DESCRIPTION	DATE APPROVED	
A	PROTOTYPE A		
B	COF USB SPEED & FBGA ISEN		





CUSTOMER NOTICE		CONTRACT NO.	L LINEAR TECHNOLOGY	TITLE: SCHEMATIC FastTRACES		REVR B	SHEET 1 OF 4
LINEAR TECHNOLOGY HAS MADE A BEST EFFORT TO DESIGN A CIRCUIT THAT MEETS CUSTOMER-SPECIFIED SPECIFICATIONS; HOWEVER, IT REMAINS THE CUSTOMER'S RESPONSIBILITY TO VERIFY, PROPER AND RELIABLE OPERATION IN THE ACTUAL APPLICATION. ANY SIGNIFICANTLY AFFECT CIRCUIT BOARD LAYOUT, OR RELIABILITY, CONTACT LINEAR FOR ASSISTANCE.		APPROVALS	DRAWN BY E. TRELLEZ	SIZE	DESIGN NO.	DATE: 6/22/2005 11:38:30a	
		APPROVED	CHECKED	B	DC8390B		
		DESIGNER E. TRELLEZ	DESIGNER E. TRELLEZ				
		TECHNICAL SUPPORT	TECHNICAL SUPPORT				
		1-500 McCarthy Blvd. Milpitas, CA 95035 Phone: (408) 492-3946 Fax: (408) 492-3947	Customer Use Only Confidential				





USB_ON [SH4]

REG_PDDR3/4HP [SH1]



CUSTOMER NOTICE	CONTRACT NO.	APPROVALS	TITLE: SCHEMATIC FastDARCS
LINeAR TECHNOLOGY HAS MADE A BEST EFFORTIC DESIGN & CIRCUIT THAT MEETS CUSTOMER-SPECIFIED SPECIFICATIONS. HOWEVER, IT REMAINS THE CUSTOMERS RESPONSIBILITY TO VERIFY PROPER AND RELIABLE OPERATION IN THE ACTUAL APPLICATION. PRODUCT SUBSTITUTION AND RELATED CIRCUIT BOARD LAYOUT MAY SIGNIFICANTLY AFFECT CIRCUIT PERFORMANCE OR RELIABILITY. CONACT LINeAR TECHNOLOGY APPLICATIONS ENGINEER NO. 001511 FOR SUPPORT. THIS CIRCUIT IS PROPRIETARY TO LINeAR TECHNOLOGY AND IS NOT FOR USE WITH OTHER TECHNOLOGY PARTS.	DC890B	REV: B	DATE: 6/02/2005 11:38:50a SHEET 3 OF 4





CUSTOMER NOTICE	CONTRACT NO.	LINEAR TECHNOLOGY Fast DIACS		
LTC4210-1CS6 TITLE: SCHEMATIC	APPROVALS	DRAWN E. TRELLOZ	REVIEWED (Fast Data Analysis & Acquisition System)	Customer Use Only
LTC1410ES6 TITLE: SCHEMATIC	APPROVALS	VERIFIED CHECKED	APPLIED PRINTED	Customer Use Only
LTC6905CS5-96 TITLE: SCHEMATIC	APPROVALS	IMPROVED PRINTED	ENGINEER E. TRELLOZ	Customer Use Only
U2 U1 U3 U4 U5 U6 U7 U8 U9 U10 U11 U12 U13 U14 U15 U16 U17 U18 U19 U20 U21 U22 U23 U24 U25 U26 U27 U28 U29 U30 U31 U32 U33 U34 U35 U36 U37 U38 U39 U40 U41 U42 U43 U44 U45 U46 U47 U48 U49 U50 U51 U52 U53 U54 U55 U56 U57 U58 U59 U60 U61 U62 U63 U64 U65 U66 U67 U68 U69 U70 U71 U72 U73 U74 U75 U76 U77 U78 U79 U80 U81 U82 U83 U84 U85 U86 U87 U88 U89 U90 U91 U92 U93 U94 U95 U96 U97 U98 U99 U100 U101 U102 U103 U104 U105 U106 U107 U108 U109 U110 U111 U112 U113 U114 U115 U116 U117 U118 U119 U120 U121 U122 U123 U124 U125 U126 U127 U128 U129 U130 U131 U132 U133 U134 U135 U136 U137 U138 U139 U140 U141 U142 U143 U144 U145 U146 U147 U148 U149 U150 U151 U152 U153 U154 U155 U156 U157 U158 U159 U160 U161 U162 U163 U164 U165 U166 U167 U168 U169 U170 U171 U172 U173 U174 U175 U176 U177 U178 U179 U180 U181 U182 U183 U184 U185 U186 U187 U188 U189 U190 U191 U192 U193 U194 U195 U196 U197 U198 U199 U199 U200 U201 U202 U203 U204 U205 U206 U207 U208 U209 U209 U210 U211 U212 U213 U214 U215 U216 U217 U218 U219 U219 U220 U221 U222 U223 U224 U225 U226 U227 U228 U229 U229 U230 U231 U232 U233 U234 U235 U236 U237 U238 U239 U239 U240 U241 U242 U243 U244 U245 U246 U247 U248 U249 U249 U250 U251 U252 U253 U254 U255 U256 U257 U258 U259 U259 U260 U261 U262 U263 U264 U265 U266 U267 U268 U269 U269 U270 U271 U272 U273 U274 U275 U276 U277 U278 U279 U279 U280 U281 U282 U283 U284 U285 U286 U287 U288 U289 U289 U290 U291 U292 U293 U294 U295 U296 U297 U298 U299 U299 U300 U301 U302 U303 U304 U305 U306 U307 U308 U309 U309 U310 U311 U312 U313 U314 U315 U316 U317 U318 U319 U319 U320 U321 U322 U323 U324 U325 U326 U327 U328 U329 U329 U330 U331 U332 U333 U334 U335 U336 U337 U338 U339 U339 U340 U341 U342 U343 U344 U345 U346 U347 U348 U349 U349 U350 U351 U352 U353 U354 U355 U356 U357 U358 U359 U359 U360 U361 U362 U363 U364 U365 U366 U367 U368 U369 U369 U370 U371 U372 U373 U374 U375 U376 U377 U378 U379 U379 U380 U381 U382 U383 U384 U385 U386 U387 U388 U389 U389 U390 U391 U392 U393 U394 U395 U396 U397 U398 U398 U399 U399 U400 U401 U402 U403 U404 U405 U406 U407 U408 U409 U409 U410 U411 U412 U413 U414 U415 U416 U417 U418 U419 U419 U420 U421 U422 U423 U424 U425 U426 U427 U428 U429 U429 U430 U431 U432 U433 U434 U435 U436 U437 U438 U439 U439 U440 U441 U442 U443 U444 U445 U446 U447 U448 U449 U449 U450 U451 U452 U453 U454 U455 U456 U457 U458 U459 U459 U460 U461 U462 U463 U464 U465 U466 U467 U468 U469 U469 U470 U471 U472 U473 U474 U475 U476 U477 U478 U479 U479 U480 U481 U482 U483 U484 U485 U486 U487 U488 U489 U489 U490 U491 U492 U493 U494 U495 U496 U497 U498 U498 U499 U499 U500 U501 U502 U503 U504 U505 U506 U507 U508 U509 U509 U510 U511 U512 U513 U514 U515 U516 U517 U518 U519 U519 U520 U521 U522 U523 U524 U525 U526 U527 U528 U529 U529 U530 U531 U532 U533 U534 U535 U536 U537 U538 U539 U539 U540 U541 U542 U543 U544 U545 U546 U547 U548 U549 U549 U550 U551 U552 U553 U554 U555 U556 U557 U558 U559 U559 U560 U561 U562 U563 U564 U565 U566 U567 U568 U569 U569 U570 U571 U572 U573 U574 U575 U576 U577 U578 U579 U579 U580 U581 U582 U583 U584 U585 U586 U587 U588 U589 U589 U590 U591 U592 U593 U594 U595 U596 U597 U598 U598 U599 U599 U600 U601 U602 U603 U604 U605 U606 U607 U608 U609 U609 U610 U611 U612 U613 U614 U615 U616 U617 U618 U619 U619 U620 U621 U622 U623 U624 U625 U626 U627 U628 U629 U629 U630 U631 U632 U633 U634 U635 U636 U637 U638 U639 U639 U640 U641 U642 U643 U644 U645 U646 U647 U648 U649 U649 U650 U651 U652 U653 U654 U655 U656 U657 U658 U659 U659 U660 U661 U662 U663 U664 U665 U666 U667 U668 U669 U669 U670 U671 U672 U673 U674 U675 U676 U677 U678 U679 U679 U680 U681 U682 U683 U684 U685 U686 U687 U688 U689 U689 U690 U691 U692 U693 U694 U695 U696 U697 U698 U698 U699 U699 U700 U701 U702 U703 U704 U705 U706 U707 U708 U709 U709 U710 U711 U712 U713 U714 U715 U716 U717 U718 U719 U719 U720 U721 U722 U723 U724 U725 U726 U727 U728 U729 U729 U730 U731 U732 U733 U734 U735 U736 U737 U738 U739 U739 U740 U741 U742 U743 U744 U745 U746 U747 U748 U749 U749 U750 U751 U752 U753 U754 U755 U756 U757 U758 U759 U759 U760 U761 U762 U763 U764 U765 U766 U767 U768 U769 U769 U770 U771 U772 U773 U774 U775 U776 U777 U778 U779 U779 U780 U781 U782 U783 U784 U785 U786 U787 U788 U789 U789 U790 U791 U792 U793 U794 U795 U796 U797 U798 U798 U799 U799 U800 U801 U802 U803 U804 U805 U806 U807 U808 U809 U809 U810 U811 U812 U813 U814 U815 U816 U817 U818 U819 U819 U820 U821 U822 U823 U824 U825 U826 U827 U828 U829 U829 U830 U831 U832 U833 U834 U835 U836 U837 U838 U839 U839 U840 U841 U842 U843 U844 U845 U846 U847 U848 U849 U849 U850 U851 U852 U853 U854 U855 U856 U857 U858 U859 U859 U860 U861 U862 U863 U864 U865 U866 U867 U868 U869 U869 U870 U871 U872 U873 U874 U875 U876 U877 U878 U879 U879 U880 U881 U882 U883 U884 U885 U886 U887 U888 U889 U889 U890 U891 U892 U893 U894 U895 U896 U897 U898 U898 U899 U899 U900 U901 U902 U903 U904 U905 U906 U907 U908 U909 U909 U910 U911 U912 U913 U914 U915 U916 U917 U918 U919 U919 U920 U921 U922 U923 U924 U925 U926 U927 U928 U929 U929 U930 U931 U932 U933 U934 U935 U936 U937 U938 U939 U939 U940 U941 U942 U943 U944 U945 U946 U947 U948 U949 U949 U950 U951 U952 U953 U954 U955 U956 U957 U958 U959 U959 U960 U961 U962 U963 U964 U965 U966 U967 U968 U969 U969 U970 U971 U972 U973 U974 U975 U976 U977 U978 U979 U979 U980 U981 U982 U983 U984 U985 U986 U987 U988 U989 U989 U990 U991 U992 U993 U994 U995 U996 U997 U998 U998 U999 U999 U1000 U1001 U1002 U1003 U1004 U1005 U1006 U1007 U1008 U1009 U1009 U1010 U1011 U1012 U1013 U1014 U1015 U1016 U1017 U1018 U1019 U1019 U1020 U1021 U1022 U1023 U1024 U1025 U1026 U1027 U1028 U1029 U1029 U1030 U1031 U1032 U1033 U1034 U1035 U1036 U1037 U1038 U1039 U1039 U1040 U1041 U1042 U1043 U1044 U1045 U1046 U1047 U1048 U1049 U1049 U1050 U1051 U1052 U1053 U1054 U1055 U1056 U1057 U1058 U1059 U1059 U1060 U1061 U1062 U1063 U1064 U1065 U1066 U1067 U1068 U1069 U1069 U1070 U1071 U1072 U1073 U1074 U1075 U1076 U1077 U1078 U1079 U1079 U1080 U1081 U1082 U1083 U1084 U1085 U1086 U1087 U1088 U1089 U1089 U1090 U1091 U1092 U1093 U1094 U1095 U1096 U1097 U1098 U1098 U1099 U1099 U1100 U1101 U1102 U1103 U1104 U1105 U1106 U1107 U1108 U1109 U1109 U1110 U1111 U1112 U1113 U1114 U1115 U1116 U1117 U1118 U1119 U1119 U1120 U1121 U1122 U1123 U1124 U1125 U1126 U1127 U1128 U1129 U1129 U1130 U1131 U1132 U1133 U1134 U1135 U1136 U1137 U1138 U1139 U1139 U1140 U1141 U1142 U1143 U1144 U1145 U1146 U1147 U1148 U1149 U1149 U1150 U1151 U1152 U1153 U1154 U1155 U1156 U1157 U1158 U1159 U1159 U1160 U1161 U1162 U1163 U1164 U1165 U1166 U1167 U1168 U1169 U1169 U1170 U1171 U1172 U1173 U1174 U1175 U1176 U1177 U1178 U1179 U1179 U1180 U1181 U1182 U1183 U1184 U1185 U1186 U1187 U1188 U1189 U1189 U1190 U1191 U1192 U1193 U1194 U1195 U1196 U1197 U1198 U1198 U1199 U1199 U1200 U1201 U1202 U1203 U1204 U1205 U1206 U1207 U1208 U1209 U1209 U1210 U1211 U1212 U1213 U1214 U1215 U1216 U1217 U1218 U1219 U1219 U1220 U1221 U1222 U1223 U1224 U1225 U1226 U1227 U1228 U1229 U1229 U1230 U1231 U1232 U1233 U1234 U1235 U1236 U1237 U1238 U1239 U1239 U1240 U1241 U1242 U1243 U1244 U1245 U1246 U1247 U1248 U1249 U1249 U1250 U1251 U1252 U1253 U1254 U1255 U1256 U1257 U1258 U1259 U1259 U1260 U1261 U1262 U1263 U1264 U1265 U1266 U1267 U1268 U1269 U1269 U1270 U1271 U1272 U1273 U1274 U1275 U1276 U1277 U1278 U1279 U1279 U1280 U1281 U1282 U1283 U1284 U1285 U1286 U1287 U1288 U1289 U1289 U1290 U1291 U1292 U1293 U1294 U1295 U1296 U1297 U1298 U1298 U1299 U1299 U1300 U1301 U1302 U1303 U1304 U1305 U1306 U1307 U1308 U1309 U1309 U1310 U1311 U1312 U1313 U1314 U1315 U1316 U1317 U1318 U1319 U1319 U1320 U1321 U1322 U1323 U1324 U1325 U1326 U1327 U1328 U1329 U1329 U1330 U1331 U1332 U1333 U1334 U1335 U1336 U1337 U1338 U1339 U1339 U1340 U1341 U1342 U1343 U1344 U1345 U1346 U1347 U1348 U1349 U1349 U1350 U1351 U1352 U1353 U1354 U1355 U1356 U1357 U1358 U1359 U1359 U1360 U1361 U1362 U1363 U1364 U1365 U1366 U1367 U1368 U1369 U1369 U1370 U1371 U1372 U1373 U1374 U1375 U1376 U1377 U1378 U1379 U1379 U1380 U1381 U1382 U1383 U1384 U1385 U1386 U1387 U1388 U1389 U1389 U1390 U1391 U1392 U1393 U1394 U1395 U1396 U1397 U1398 U1398 U1399 U1399 U1400 U1401 U1402 U1403 U1404 U1405 U1406 U1407 U1408 U1409 U1409 U1410 U1411 U1412 U1413 U1414 U1415 U1416 U1417 U1418 U1419 U1419 U1420 U1421 U1422 U1423 U1424 U1425 U1426 U1427 U1428 U1429 U1429 U1430 U1431 U1432 U1433 U1434 U1435 U1436 U1437 U1438 U1439 U1439 U1440 U1441 U1442 U1443 U1444 U1445 U1446 U1447 U1448 U1449 U1449 U1450 U1451 U1452 U1453 U1454 U1455 U1456 U1457 U1458 U1459 U1459 U1460 U1461 U1462 U1463 U1464 U1465 U1466 U1467 U1468 U1469 U1469 U1470 U1471 U1472 U1473 U1474 U1475 U1476 U1477 U1478 U1479 U1479 U1480 U1481 U1482 U1483 U1484 U1485 U1486 U1487 U1488 U1489 U1489 U1490 U1491 U1492 U1493 U1494 U1495 U1496 U1497 U1498 U1498 U1499 U1499 U1500 U1501 U1502 U1503 U1504 U1505 U1506 U1507 U1508 U1509 U1509 U1510 U1511 U1512 U1513 U1514 U1515 U1516 U1517 U1518 U1519 U1519 U1520 U1521 U1522 U1523 U1524 U1525 U1526 U1527 U1528 U1529 U1529 U1530 U1531 U1532 U1533 U1534 U1535 U1536 U1537 U1538 U1539 U1539 U1540 U1541 U1542 U1543 U1544 U1545 U1546 U1547 U1548 				

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS

Item	Qty	Reference	Part Description	Manufacturer / Part #
1	3	C80,C81,C89	CAP,TANT,470uF,10V,20%, 7343	AVX TPSE477M010R0050
2	0	C94 (Opt)	CAP,TANT,470uF,10V,20%, 7343	AVX TPSE477M010R0050
3	0	C88 (Opt)	CAP, POLY-TA, 1000uF, 4V 20%,7343	KEMET T530X108M004ASE006
4	1	C88	CAP, POLY-TA, 680uF, 4V 20%, 7343	KEMET,T520D687M004ASE025
5	1	C36	CAP, 330uF16V 20PCT	NICHICON UPL1C331MPH6
6	9	C1,C2,C32,C35,C38,C76,C78, C79,C92	CAP, X5R 10uF 6.3V 20% 1206	TAIYO YUDEN JMK316BJ106ML-T
7	1	C82	CAP,TANT,4.7uF,10V,20%,3216	AVX TAJA475M010R
8	5	C8,C37,C60,C77,C91	CAP, X7R 1uF 10V 10% 0603	AVX, 0603ZD105KAT
9	1	C83	CAP, X5R 0.22uF 16V 20% 0603	AVX, 0603YD224MAT
10	15	C11,C12,C27-31,C34,C42,C44, C52,C53,C57,C62,C85	CAP, X7R 0.1uF 16V 10% 0603	AVX 0603YC104KAT
11	43	C13-26,C39,C40,C45-50,C54-56, C58,C59,C61,C63-75,C90,C93	CAP, X5R,0.1uF,10V,10%,0402	AVX, 0402ZD104KAT
12	1	C43	CAP, X7R 0.047uF 16V 10% 0603	AVX 0603YC473KAT
13	5	C4,C5,C33,C84,C87	CAP, X7R 0.01uF 16V 10% 0603	AVX 0603YC103KAT
14	1	C10	CAP, X7R 2200pF 25V 10% 0603	AVX 06033C222KAT2A
15	0	C9 (Opt)	CAP, X7R 2200pF 25V 10% 0603	AVX 06033C222KAT2A
16	1	C41	CAP, X7R 1000pF 25V 10% 0603	AVX 06033C102KAT2A
17	0	C86 (Opt)	CAP, X7R 1000pF 25V 10% 0603	AVX 06033C102KAT2A
18	1	C51	CAP, NPO,100pF,25V,10% 0603	AVX 06033A101KAT2A
19	3	C3,C6,C7	CAP, NPO 22pF 50V 10% 0603	AVX 06035A220KAT
20	9	D1-8,D12	LED, GRN 0603	LITE ON LTST-C190KGKT
21	1	D10	DIODE, DUAL SCHOTTKY, SOT23	DIODES INC. BAT54S
22	2	D11,D13	RECTIFIER,GP,1A,50V,SMA	DIODE INC, S1A
23	2	D9,D14	DIODE, GP 200V 200MA ,SOD323	DIODES INC. BAV20WS
24	1	J1	HEADER, 3X2, 2mm	COMM CON 2202S-06G2
25	0	J7,J8 (Opt)		
26	1	J2	HEADER, 2X7, 2mm	MOLEX, 87831-1420
27	0	J3,J11 (Opt)	HEADER, 2X1, 2mm	COMM CON 3201S-02G2
28	1	J4	HEADER, 3X1,100MIL	COMM CON 3801S-03G2

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS

Item	Qty	Reference	Part Description	Manufacturer / Part #
29	1	J5	CON,EDGE,100PIN, 0.063	SAMTEC MEC8-150-02-L-D-EM2
30	1	J6	CON, USB-B, 4 PINS, SINGLE THR. HOLE	MILL-MAX, 897-30-004-90-000
31	1	J9	CONNECTOR, POWER 5mm	CUI INC. PJ-002A-SMT
32	0	J10 (Opt)	HEADER, 3X1, 2mm	COMM CON 3201S-03G2
33	1	L1	CHOKE, COMMON MODE, QUAD, 5uH	COILCRAFT TTDLF4500
34	1	L2	IND, PWR, 2.2UH, D52LC	TOKO D52LC #A914BYW-2R2M
35	0	L3 (Opt)	IND, PWR, 2.2UH, D52LC	TOKO D52LC #A914BYW-2R2M
36	5	Q1,Q6,Q8,Q9,Q12	XSTR, NPN, SOT23	DIODES INC. MMBT3904-7
37	2	Q7,Q13	XSTR, PNP SOT23	DIODES INC, MMBT3906-7
38	4	Q2,Q3,Q4,Q5	XSTR, MOSFET,SOT23	VISHAY,SI2316DS
39	2	Q10,Q11	XSTR, MOSFET,SOT23	DIODES INC. SEMI, 2N7002-7
40	1	R102	RES, 2.21MEG OHMS 1% 1/16W 0603	AAC CR16-2214FM
41	1	R92	RES, 422K OHMS 1% 1/16W 0603	AAC CR16-4223FM
42	1	R95	RES, 324K OHMS 1% 1/16W 0603	AAC CR16-3243FM
43	1	R93	RES, 200K OHMS 1% 1/16W 0603	AAC CR16-2003FM
44	5	R6,R17,R67,R68,R79	RES, 100K OHMS 1% 1/16W 0603	AAC CR16-1003FM
45	1	R94	RES, 16.2K OHMS 1% 1/16W 0603	AAC CR16-1622FM
46	1	R3	RES, 14K OHMS 1% 1/16W 0603	AAC CR16-1402FM
47	14	R4,R10,R15,R16,R46,R66,R71, R72,R73,R82,R84,R88,R91,R105,	RES, 10K OHMS 1% 1/16W 0603	AAC CR16-1002FM
48	10	R61,R81,R83,R90,R96,R112- R115,R119	RES, 4.75K OHMS 1% 1/16W 0402	VISHAY, CRCW04024751F
49	6	R21,R103,R104,R117,R118,R137	RES, 4.75K OHMS 1% 1/16W 0603	AAC CR16-4751FM
50	0	R77 (Opt)	RES, 4.75K OHMS 1% 1/16W 0603	AAC CR16-4751FM
51	4	R14,R48,R85,R89	RES, 2K OHMS 1% 1/16W 0603	AAC CR16-2001FM
52	1	R11	RES, 1.5K OHMS 1% 1/16W 0603	AAC CR16-1501FM
53	9	R8,R18,R40,R41,R44,R45,R78,R80, R106	RES, 1.00K OHMS 1% 1/16W 0603	AAC CR16-1001FM
54	0	R75,R107,R108 (Opt)	RES, 1.00K OHMS 1% 1/16W 0603	AAC CR16-1001FM
55	12	R9,R25-32,R43,R110,R111	RES, 475 OHM 1% 1/16W 0603	AAC CR16-4750FM

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS

Item	Qty	Reference	Part Description	Manufacturer / Part #
56	2	R47,R53	RES, 332 OHM 1% 1/16W 0603	VISHAY, CRCW04023320F
57	3	R74,R76,R138	RES, 332 OHM 1% 1/16W 0402	AAC CR05-3320FM
58	5	R1,R2,R19,R38,R52	RES, 100 OHM 1% 1/16W 0603	AAC CR16-1000FM
59	0	R120-R136 (Opt)	RES, 100 OHM 1% 1/20W 0201	VISHAY, CRCW0201-101J200RT7
60	17	R7,R20,R24,R54,R55-60,R62-65, R69,R70,R116	RES, 49.9 OHM 1% 1/16 0402	AAC CR05-49R9FM
61	3	R34,R86,R87	RES, 33.2 OHMS 1% 1/16W 0603	AAC CR16-33R2FM
62	2	R12,R13	RES, 22.1 OHMS 1% 1/16W 0603	AAC CR16-22R1FM
63	4	R22,R23,R39,R51	RES, 10 OHMS 5% 1/16W 0603	AAC CR16-100JM
64	5	R97-101	RES, 10 OHMS 1% 1/8W 1206	AAC CR18-10R0FM
65	1	R42	RES, 0 OHM JUMPER 0402	VISHAY CRCW04020000ZSTDE
66	0	R50 (Opt)	RES, 0 OHM JUMPER 0402	VISHAY CRCW04020000ZSTDE
67	1	R109	RES, 0 OHM JUMPER 0805	AAC CJ10-000M
68	1	R49	RES, 0.1 OHMS 1% 1/8W 0805	Vishay WSL0805R1000FEA
69	3	R5,R33,R37	RES, 49.9K OHMS 1% 1/16W 0603	AAC CR16-4992FM
70	2	R35,R36	RES 2X4 ARRAY, CHIP, 100 OHM, ISO	ROHM MNR14E0ABJ101
71	1	SW1	SWITCH, LIGHT TOUCH, 2 PINS	PANASONIC, EVQPPDA25
72	5	TP2-3,G2,G3,G5	TURRET	MILL MAX 2308-2
73	0	TP1,G4,G6 (Opt)		
74	1	U17	I.C., 93LC46BT-I/OT, SOT23-6	MICROCHIP 93LC46BT-I/OT
75	1	U7	I.C., FT245BM, LQFP32	FUTURE TECH.,(FTDICHIP) FT245BM
76	1	U10	IDT71T75602S200PF	IDT71T75602S200PF
77	0	U10 (Opt)	71V2556S200PF	71V2556S200PF
78	1	U19	IC, LT1529CQ-5	LINEAR TECH. LT1529CQ-5
79	1	U4	IC, LT1763CS8	LINEAR TECH. LT1763CS8
80	1	U8	IC, LT1763CS8-3.3	LINEAR TECH. LT1763CS8-3.3
81	1	U5	IC, LTC1726EMS8-2.5	LINEAR TECH. LTC1726EMS8-2.5
82	2	U3,U14 (tape & reel)	IC, LTC1844ES5-3.3	LINEAR TECH. LTC1844ES5-3.3
83	1	U21	IC, LDO,1.5A,DD-5(Q PKG)	LINEAR TECH, LT1963EQ-2.5

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 890B

FastDAACS

Item	Qty	Reference	Part Description	Manufacturer / Part #
84	1	U1	IC, LTC2921CGN-3.3	LINEAR TECH. LTC2921CGN-3.3
85	1	U16	IC, LTC4210-1CS6	LINEAR TECH. LTC4210-1CS6
86	1	U15	IC, LTC4300A-1CMS8	LINEAR TECH. LTC4300A-1CMS8
87	1	U12	IC, LTC4410ES6	LINEAR TECH. LTC4410ES6
88	1	U2	IC, OSC,SOT23-5	LINEAR TECH, LTC6905CS5-96
89	1	U11	IC, NC7SP17P5X	FAIRCHILD, NC7SP17P5X
90	1	U18	IC, FF,DUAL, HC, TSSOP14	PHILIPS, 74HC74PW
91	1	U6 (in trays)	IC, PIC16LF877A-I/PT	MICROCHIP, PIC16LF877A-I/PT
92	1	U9	IC, XC3S200-4PQ208	XILINX, XC3S200-4PQ208
93	1	U13	IC, SEEPPROM,4MEG,SO8	ST MICRO, M25P40-VMN6TP
94	1	U20	IC, SWREG,SYNC,BUCK,	LINEAR LTC3411EMS
95	1	X1	CONN, BNC 50 OHM	CONNEX 112404
96	1	Y1	CRYSTAL, 10MHZ, HC49-SMT	ECS INC. ECS-100-18-5P
97	4		Stand Off, 1/4 X 4-40	Microplastic
98	4		Screw, 4-40 - 1/4"	Screw
99	1		PCB, PRINTED CIRCUIT BOARD	DEMO CIRCUIT 890B
100	1		HEATSINK,BGA (FOR U9)	AAVID/THERMALLOY, 374324B00035