


BOTTOM SILKSCREEN  
DC3042A-2

REV 05

FOR ADI CUSTOMER USE ONLY



MODE	R3	R4	R6	R7
PULSE SKIP	OPEN	0 or OPEN *	100K	POPULATED OR OPEN **
FORCED CONT.	100K	0	OPEN	OPEN

\*\* MODESYNC PIN IS CLOCK OUTPUT WHEN R7 IS POPULATED.  
\* IF R7 IS POPULATED R4 MUST BE OPEN.