

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1344A

## SINGLE 5A LOW QUIESCENT CURRENT STEPDOWN DV/DC CONVERTER

LTC3834EFE

## DESCRIPTION

Demonstration circuit 1346A is a low quiescent current step-down DC/DC converter featuring the LTC®3834 in a 16-pin GN package. The DC1344A is programmed to generate a regulated 3.3V@5A output from a 4.5V to 32V input voltage.

To maximize battery usage, the demo circuit allows low dropout operation when the input voltage is close to the output voltage. Its selectable burst mode operation reduces the IC supply current at light loads to extend battery life. The phase-lockable frequency allows the LTC3834 to be synchronized by an external signal. The output voltage of the LTC3834 can track an external ramp voltage signal during power-up and

power-down. Also, the built-in current foldback prevents the overheating of output MOSFETs during short-circuit.

All these features make the circuit a high performance solution for applications in automotive and battery-operated systems, telecom and distributed DC power systems.

**Design files for this circuit board are available. Call the LTC factory.**

LTC is a registered trademark of Linear Technology Corporation

**Table 1. Performance Summary ( $T_A = 25^\circ\text{C}$ )**

PARAMETER	CONDITION	MINIMUM	TYPICAL	MAXIMUM
Input Voltage Range		4.5V		32V
Maximum Output Current	$4.5\text{V} < V_{IN} < 32\text{V}$		5A	
Output Voltage $V_{OUT}$	$0\text{A} < I_{OUT} < 5\text{A}$	3.234V	3.3V	3.366V
Output Ripple $V_{OUT}$	$I_{OUT} = 5\text{A}$ (20MHz BW) $V_{IN} = 36\text{V}$ , $F_{SW} = 400\text{kHz}$			36mVp-p
Nominal Switching Frequency			400kHz	
Efficiency	$V_{IN} = 14\text{V}$ , $I_{OUT} = 3.5\text{A}$ , 400kHz Switching Frequency		91.5%	

## QUICK START PROCEDURE

Demonstration circuit 1344A is easy to set up to evaluate the performance of the LTC3834EFE. Refer to 0 for proper measurement equipment setup and follow the procedure below:

**NOTE:** When measuring the input or output voltage ripple, care must be taken to avoid a long ground lead on the oscilloscope probe. Measure the input or output voltage ripple by touching the probe tip directly across the Vin or Vout and GND terminals. See Figure 2 for proper scope probe technique.

1. Place VOUT jumper in the OFF position, the PLLPF jumper (JP2) at the selected frequency and the

MODE jumper (JP3) in desired Mode (Burst, CCM or DCM) position. Table 2 shows the default setting for DC1346A.

JP1 TRACK/SS	JP2 PLLPF	JP3 MODE	JP4 $V_{OUT}$
SS	400kHz	DCM	ON

Table 2. Default Jumper Settings

2. With power off, connect a 4.5V-32V, 6A power supply to VIN and GND.

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1344A

## SINGLE 5A LOW QUIESCENT CURRENT STEPDOWN DV/DC CONVERTER


3. Connect a load to VOUT and GND (maximum load is 5A).
  4. Move the VOUT jumper to the ON position.
  5. Turn on the power at the input.

**NOTE:** Make sure that the input voltage is above 4.5V, but does not exceed 32V.


6. Check for proper output voltages. V<sub>OUT</sub> should measure 3.3V (could vary from 3.234V to 3.366V).

**NOTE:** If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

- Once proper output voltages are established, adjust the load within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters.




## **Figure 1. Proper Measurement Equipment Setup**



**Figure 2. Measuring Input or Output Ripple**

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1344A

## SINGLE 5A LOW QUIESCENT CURRENT STEPDOWN DV/DC CONVERTER



NOTES: UNLESS OTHERWISE SPECIFIED

3

LTC CONFIDENTIAL - FOR CUSTOMER USE ONLY  
Customer Notice

1930 McCARTHY BLVD.  
MILPITAS, CA 95035  
408-432-1900  
408-434-0507 FAX

Title Single 5A Low Quiescent Current Step-Down DC/DC Converter  
Size Document Number Demo Circuit 1344A LTC3834EFE  
Date Wednesday October 2007 Sheet 1 of 1