

BRIDGE POWER

OUTPUT

+

-

HIGH

LOW



BRIDGE POWER  
GND

VD OUTPUT  
HIGH LOW GND



DC VOLTAGE CALIBRATION CENTER

BRIDGE POWER

TEST CONFIGURATION

VD OUTPUT

VOLTAGE DIVIDER MODE

VD CALIBRATION

STD=NULL+VD+OCCAL

STD=VD=NULL+SECREF

STD=VD=NULL+OCCAL

SEC VOLTAGE REFERENCE

DC CALIBRATOR

VOLTAGE DIVIDER

NULL DETECTOR

GND















