



# Model 7711/7712

## User's Guide

PA-818 Rev. B / 8-03

A GREATER MEASURE OF CONFIDENCE

The following safety precautions should be observed before using this product and any associated instrumentation. Although some instruments and accessories would normally be used with non-hazardous voltages, there are situations where hazardous conditions may be present.

This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid possible injury. Read and follow all installation, operation, and maintenance information carefully before using the product. Refer to the manual for complete product specifications.

If the product is used in a manner not specified, the protection provided by the product may be impaired.

The types of product users are:

**Responsible body** is the individual or group responsible for the use and maintenance of equipment, for ensuring that the equipment is operated within its specifications and operating limits, and for ensuring that operators are adequately trained.

**Operators** use the product for its intended function. They must be trained in electrical safety procedures and proper use of the instrument. They must be protected from electric shock and contact with hazardous live circuits.

**Maintenance personnel** perform routine procedures on the product to keep it operating properly, for example, setting the line voltage or replacing consumable materials. Maintenance procedures are described in the manual. The procedures explicitly state if the operator may perform them. Otherwise, they should be performed only by service personnel.

**Service personnel** are trained to work on live circuits, and perform safe installations and repairs of products. Only properly trained service personnel may perform installation and service procedures.

Keithley products are designed for use with electrical signals that are rated Measurement Category I and Measurement Category II, as described in the International Electrotechnical Commission (IEC) Standard IEC 60664. Most measurement, control, and data I/O signals are Measurement Category I and must not be directly connected to mains voltage or to voltage sources with high transient over-voltages. Measurement Category II connections require protection for high transient over-voltages often associated with local AC mains connections. Assume all measurement, control, and data I/O connections are for connection to Category I sources unless otherwise marked or described in the Manual.

Exercise extreme caution when a shock hazard is present. Lethal voltage may be present on cable connector jacks or test fixtures. The American National Standards Institute (ANSI) states that a shock hazard exists when voltage levels greater than 30V RMS, 42.4V peak, or 60VDC are present. **A good safety practice is to expect that hazardous voltage is present in any unknown circuit before measuring.**

Operators of this product must be protected from electric shock at all times. The responsible body must ensure that operators are prevented access and/or insulated from every connection point. In some cases, connections must be exposed to potential human contact. Product operators in these circumstances must be trained to protect themselves from the risk of electric shock. If the circuit is capable of operating at or above 1000 volts, **no conductive part of the circuit may be exposed.**

Do not connect switching cards directly to unlimited power circuits. They are intended to be used with impedance limited sources. NEVER connect switching cards directly to AC mains. When connecting sources to switching cards, install protective devices to limit fault current and voltage to the card.

Before operating an instrument, make sure the line cord is connected to a properly grounded power receptacle. Inspect the connecting cables, test leads, and jumpers for possible wear, cracks, or breaks before each use.

When installing equipment where access to the main power cord is restricted, such as rack mounting, a separate main input power disconnect device must be provided, in close proximity to the equipment and within easy reach of the operator.

For maximum safety, do not touch the product, test cables, or any other instruments while power is applied to the circuit under test. ALWAYS remove power from the entire test system and discharge any capacitors before: connecting or disconnecting cables or jumpers, installing or removing switching cards, or making internal changes, such as installing or removing jumpers.

Do not touch any object that could provide a current path to the common side of the circuit under test or power line (earth) ground. Always make measurements with dry hands while standing on a dry, insulated surface capable of withstanding the voltage being measured.


The instrument and accessories must be used in accordance with its specifications and operating instructions or the safety of the equipment may be impaired.


Do not exceed the maximum signal levels of the instruments and accessories, as defined in the specifications and operating information, and as shown on the instrument or test fixture panels, or switching card.


When fuses are used in a product, replace with same type and rating for continued protection against fire hazard.


Chassis connections must only be used as shield connections for measuring circuits, NOT as safety earth ground connections.

If you are using a test fixture, keep the lid closed while power is applied to the device under test. Safe operation requires the use of a lid interlock.

If a  screw is present, connect it to safety earth ground using the wire recommended in the user documentation.

The  symbol on an instrument indicates that the user should refer to the operating instructions located in the manual.

The  symbol on an instrument shows that it can source or measure 1000 volts or more, including the combined effect of normal and common mode voltages. Use standard safety precautions to avoid personal contact with these voltages.

The  symbol indicates a connection terminal to the equipment frame.

The **WARNING** heading in a manual explains dangers that might result in personal injury or death. Always read the associated information very carefully before performing the indicated procedure.

The **CAUTION** heading in a manual explains hazards that could damage the instrument. Such damage may invalidate the warranty.

Instrumentation and accessories shall not be connected to humans.

Before performing any maintenance, disconnect the line cord and all test cables.

To maintain protection from electric shock and fire, replacement components in mains circuits, including the power transformer, test leads, and input jacks, must be purchased from Keithley Instruments. Standard fuses, with applicable national safety approvals, may be used if the rating and type are the same. Other components that are not safety related may be purchased from other suppliers as long as they are equivalent to the original component. (Note that selected parts should be purchased only through Keithley Instruments to maintain accuracy and functionality of the product.) If you are unsure about the applicability of a replacement component, call a Keithley Instruments office for information.

To clean an instrument, use a damp cloth or mild, water based cleaner. Clean the exterior of the instrument only. Do not apply cleaner directly to the instrument or allow liquids to enter or spill on the instrument. Products that consist of a circuit board with no case or chassis (e.g., data acquisition board for installation into a computer) should never require cleaning if handled according to instructions. If the board becomes contaminated and operation is affected, the board should be returned to the factory for proper cleaning/servicing.

The information in this User's Guide is organized as follows:

Introduction on [page 2](#)

- Available accessories on [page 2](#)

Card configuration — schematic on [page 3](#)

Expansion on [page 4](#)

- Multiplexer examples on [page 4](#)
- $4 \times 4$  Blocking matrix example on [page 7](#)
- $4 \times 4$  Non-blocking matrix example on [page 8](#)

Wiring procedure on [page 10](#)

Operation on [page 11](#)

- Channel assignments on [page 11](#)

Close/Open channels on [page 11](#)

- Multiple channel operation on [page 11](#)

S-parameters on [page 12](#)

- Unlocking calibration on [page 12](#)
- CALibration subsystem on [page 13](#)

SYSTem subsystem on [page 14](#)

Measurement considerations on [page 15](#)

- Termination of unused connectors on [page 15](#)
- Power handling on [page 15](#)
- Additional measurement uncertainty on [page 16](#)

Application example on [page 18](#)

Service on [page 22](#)

- Performance verification on [page 22](#)
- Replaceable parts on [page 24](#)

# Introduction

If you have any questions after reviewing this information, please contact your local Keithley representative or call one of our Applications Engineers at 1-800-KEITHLEY (U.S. and Canada only).

The Model 7711/7712 is a single-pole dual  $1 \times 4$  RF Multiplexer module (8 channels, no measurement capability). The  $1 \times 4$  multiplex is a cascading tree design — one of the channels of each bank is always connected to a common out. The  $1 \times 4$  multiplex is also referred to as a single-pole 4-throw (SP4T) switch. Refer to the simplified schematic in [Figure 1](#) or the specifications. The multiplex switching can be used to connect one instrument to multiple devices (1:N) or multiple instruments to a single device (N:1). This card expands the Integra Series' general purpose AC switching capability by providing an RF switching capability above 1MHz. Each card has the following features:

- 10 SMA connectors with  $50\Omega$  impedance
- Frequencies (refer to specifications)  
Model 7711 — up to 2 GHz  
Model 7712 — up to 3.5 GHz
- Two channels can be closed at one time—one channel to OUT A (channels 1–4) and one to OUT B (channels 5–8)
- Designed specifically for use with the Integra Series including Keithley's Models 2700, 2701 and 2750 Multimeter / Data Acquisition Systems

**NOTE** All references to the Model 27xx apply to the Models 2700, 2701, and 2750.

With this in mind, the capability of the Model 27xx is expanded for applications such as the following:

- General AC and digital signal routing to and from test equipment. This includes oscilloscopes, function generators, pulse generators, counter/timers, and signal analysis tools including network and jitter analyzers. Also, this includes diverse applications that require RF and digital routing plus DC measurements for research, development, burn-in and production testing, AC ripple and noise test for switching power supplies, and DC-DC converters.
- Research, development, and burn-in of temperature compensated oscillators.
- Research, development, and production test of communications or networking products including Ethernet, DSL, DS3, T1/E1, etc.

**WARNING** Before operating the Model 27xx with an accessory card, verify that the card is properly installed and the mounting screws are tightly fastened. If the mounting screws are not properly connected, an electrical shock hazard may be present.

## Available accessories

### Model 7711 only

7711-BNC-SMA	Male SMA to Female BNC, five 0.15m (0.5ft) cables (Insertion loss < 1dB@1GHz, VSWR < 1.5@ 1GHz)
7051-2	BNC cable, male to male, 0.6m (2ft.)
7051-5	BNC cable, male to male, 1.5m (5ft.)
7051-10	BNC cable, male to male, 3.0m (10ft.)

## Model 7711/7712


7712-SMA-1	SMA cable, male to male, flexible, low loss, 1m (3.3ft) (Insertion loss < 0.65dB @ 2GHz, VSWR < 1.11 @2GHz)
7712-SMA-N	Female SMA to Male N-Type Adapter
S46-SMA-1	SMA cable, male to male, 0.3m (1ft)
S46-SMA-0.5	SMA cable, male to male, 0.15m (0.5ft)

## Card configuration—schematic

Figure 1 shows a simplified schematic diagram of the Model 7711/7712 module. As shown, the Model 7711/7712 has channels that are grouped into dual  $1 \times 4$  multiplexers. The multiplexer's design allows 1 channel of each set of 4 to be closed at a time (1 of 4 tree structure). Also, channels 1 and 5 are normally closed to OUT A and OUT B, respectively.

**NOTE** The Model 7711/7712 relays are set to close channels 1 and 5 a few seconds after either a power cycle or a \*RST command is issued (see Figure 1 for a schematic).

Figure 1  
**Simplified schematic for Model 7711/7712**



**NOTE** To close channels 1 and 5 on a Model 7711/7712 in slot 1, send: `:ROUT:MULT:CLOS (@101,105)`

The channels are controlled over the bus or from the front panel. The grounds for these channels are non-isolated. Detailed connection information is contained later in this guide. By using the `ROUT:MULT` commands (refer to Section 2 of the Model 27xx User's Manual), they can be manually configured.

# Expansion

One Model 7711/7712 configuration is a dual (2 bank)  $1 \times 4$  multiplexer. A single Model 7711/7712 module can also be configured as a  $4 \times 4$  blocking matrix. The 7711/7712 can be combined with additional modules to further expand its multiplexing and matrix switching capabilities (specifications may degrade when the Model 7711/7712 is used in multiple module configurations). Refer to [Table 1](#) for possible expansion information. Examples of multiplexer and blocking matrix expansion follow [Table 1](#).

*Table 1*  
**Matrix and multiplex expansion**

Number of 7711/7712 Cards	Multiplexer				Blocking Matrix			
	$1 \times 4$	$1 \times 8$	$1 \times 12$	$1 \times 16$	$4 \times 4$	$4 \times 8$	$4 \times 12$	$4 \times 16$
1	X				X			
2	X	X	X		X	X		
3	X	X	X	X	X*	X	X	X

\*Using four cards in a Model 2750, a  $4 \times 4$  non-blocking matrix can be created (see the  $4 \times 4$  non-blocking matrix example on page 9).

**NOTE** The commands in this section are formatted as follows: Command (@Model 27xx Slot #, Channel #)

## Multiplexer examples

**NOTE** To minimize noise within the system, terminate unused channels with  $50\Omega$  loads. If  $50\Omega$  loads are not available, terminating unused connectors with a cable may also reduce noise within the system.


[Figure 2](#) shows how to create a  $1 \times 8$  SP8T MUX (single-pole eight-throw multiplex) using two Model 7711 cards. Channels 1 and 2 are connected to OUT A and OUT B of the second card in slot two. Terminate unused channels (in the example, channels 3 and 4 on the Model 7712 in slot one) with a  $50\Omega$  load.

[Figure 3](#) shows how to create a  $1 \times 12$  MUX using two Model 7711 cards.

**NOTE** Channels 3 and 4 (of 7711 in slot 1) may also be connected to other banks that will create a  $1 \times 12$  multiplexer (or a  $1 \times 16$  multiplexer). See [Figure 4](#) for a  $1 \times 12$  example. The following is a list of sample commands needed to operate the  $1 \times 8$  multiplexer.

**NOTE** The command “ROUTe:MULTiple:CLOSe (@<channel list>)” closes one channel per bank (two banks per Model 7711/7712 module), and opens all other channels within the same bank.

Figure 2  
**1 x 8 MUX expansion**



NOTE: The simplified schematic is shown in the power up state (Channels 1 and 5 are closed for cards in slots 1 and 2).

Grayed channels are not used in this 1 x 8 SP8T MUX.







Figure 3  
1 × 12 MUX expansion




## 4 × 4 Blocking matrix example

Figure 4 shows how to connect a single Model 7711 in a 4 × 4 blocking matrix. This configuration provides a convenient way to connect four DUTs to four different test instruments. In this configuration, one channel of bank 1 (channels 1 – 4) may be routed to any channel of bank 2 (channels 5 – 6). Use a short coaxial cable to connect OUT A to OUT B (S46-SMA-0.5). contains example commands.

Figure 4

### 4 × 4 blocking matrix expansion



NOTE: The simplified schematic is shown in the power up state (Channels 1 and 5 closed).

Table 2

### 4 × 4 Blocking matrix commands

Command	Signal path
ROUTe:MULTiple:CLOSe (@101,105)	Routes signal through channels 1 and 5
ROUTe:MULTiple:CLOSe (@103,106)	Routes signal through channels 3 and 6

## 4 x 4 Non-blocking matrix example

Using a Model 2750 and four Model 7711/7712 cards, a 4 × 4 non-blocking matrix can be created. [Figure 5](#) shows how to connect the 7711/7712 modules. This configuration provides a convenient way to simultaneously connect up to 4 DUTs to 4 different test instruments. Use a short coaxial cable to connect the OUTs of each module as shown. contains a couple of sample commands to control the matrix.

To use , select the IN connection (IN 1 – IN 4), and then in the same square select the OUT connection (OUT1 - OUT4). Send the ROUTe:MULTiple:CLOSe command with the channels in both “Ch” columns.

Table 3

**4 × 4 Sample non-blocking matrix commands**

Command	Signal path
ROUTe:MULTiple:CLOSe (@101,405)	Routes signal from IN1(OUT A of slot 1) through OUT4 (OUT B of slot 4).
ROUTe:MULTiple:CLOSe (@101,405,108,302)	Routes signal from IN1 (OUT A of slot 1) through OUT4 (OUT B of slot 4), and also from IN2 (OUT B of slot 1) through OUT1 (OUT A of slot 4).

Table 4

**4 × 4 Non-blocking matrix channels**


IN	Ch	Ch	OUT
IN 1	101	405	OUT4
	102	401	OUT3
	103	305	OUT2
	104	301	OUT1

IN	Ch	Ch	OUT
IN 3	201	407	OUT4
	202	403	OUT3
	203	307	OUT2
	204	303	OUT1

IN	Ch	Ch	OUT
IN 2	105	406	OUT4
	106	402	OUT3
	107	306	OUT2
	108	302	OUT1

IN	Ch	Ch	OUT
IN 4	205	408	OUT4
	206	404	OUT3
	207	308	OUT2
	208	304	OUT1

Figure 5  
**4 x 4 Non-blocking matrix expansion**



# Wiring procedure


**WARNING** Do not exceed the maximum specifications for the Model 7711/7712 module. Refer to Appendix A for specifications.

The default closed channels are 1 and 5 — the lowest number in each bank. At power-up, the lowest numbered channel in each bank will always be closed. If using a saved setup that calls for another channel to be closed, the card will be switched to that channel but only after the firmware has finished "waking up." Therefore, the lowest channel will ALWAYS be closed for at least a brief time at power-up. The user needs to verify that nothing is connected to the lowest channel in each bank that could be damaged.

The connectors on the card are standard SMA type connectors. When making or breaking connections, use a torque wrench to produce mating torque of 0.9 N•m (8in•lbs).

**NOTE** Use a box-spanner torque wrench similar to Suhner Type 74 Z-1-0-21, Identification number 543130. This wrench is for SMA connectors with a 1.00 N•m torque with 8.0mm (0.315 in.) across the flats.

Figure 6  
**Model 7711/7712 channel connections**



**WARNING** Do not touch live RF (radio frequency) conductors, even at low voltages! RF behaves differently than DC or low frequency AC. Low voltage RF can cause severe burns. RF signals spread out over body areas generating substantial currents at the points of contact with RF conductors.

Make all connections using correct wire size. If BNC connections are required, use the SMA to BNC adapter cables (see [Available accessories on page 2](#)).

## Specifications

Full Model 7711/7712 specifications are included at the end of this User Guide.

# Operation

**NOTE** The Model 7711/7712 modules cannot be included in scanlists.

Detailed information to close and open switching module channels is provided in Section 2 of the Model 27xx User's Manual. The following summarizes basic operation and provides operating information specific to the Model 7711/7712.

## Channel assignments

**NOTE** Measurement functions cannot be assigned to Model 7711/7712 modules. For example, if a Model 7711/7712 is installed in slot 1 and the *SENSE:FUNC 'VOLT:AC', (@101)* command is sent, a -221, "Settings Conflict" error would be reported.

The Model 2700/2701 has two slots for switching modules, and the Model 2750 has five slots. To control the appropriate switching module, the slot number must be included with the switching module channel number when you specify a channel. The channel assignment is formatted as follows:

SCH     where: S is the slot number  
              CH is the channel number

Examples:

101 = Slot 1, Channel 1

210 = Slot 2, Channel 10

506 = Slot 5, Channel 6 (Model 2750)

**NOTE** For remote operation, the 3-digit channel assignment is included in the channel list parameter for the commands.

## Close/Open channels

### Multiple channel operation

**WARNING** Multiple channel operation should only be performed by experienced test engineers who recognize the dangers associated with multiple channel closures.

For the Model 7711/7712, multiple channel operation provides control of one or two Model 7711/7712 modules in a Model 2700/2701 (or up to 5 in a Model 2750). OUT A automatically switches as appropriate for channels 1 – 4, and OUT B automatically switches as appropriate for channels 5 – 8 for each module. When you close two channels in a single module (one for OUT A and one for OUT B), the appropriate channels will close channels outside of the banks (or on other modules) are not affected by channel closures.

The following paragraphs summarize multiple channel operation for the front panel and from the remote interface (bus).

#### Front panel

- For the Models 2700/2701 and 2750, the MULTI option of the CLOSE key can be used to close a channel.
- For the Models 2700/2701 and 2750, the ALL option of the OPEN key closes channels 1 and 5 to OUT A and OUT B respectively.

## Remote interface

ROUT:MULT:CLOS <clist> — Closes specified channels (unlisted channels not affected unless in the same bank).

ROUT:MULT:CLOS? — Returns list of all closed channels.

ROUT:MULT:CLOS:STAT? <clist> — Query closed channels in list (1 = closed).

ROUT:OPEN:ALL — Closes channels 1 and 5 to OUT A and OUT B respectively

The following command is not available:

ROUT:MULT:OPEN <clist> — Invalid command for the Model 7711/7712 module.

**NOTE** For example, if a Model 7711/7712 is installed in slot 1 and the *ROUT:MULT:OPEN (@101)* command is sent, a -221, “Settings Conflict” error would be reported.

## DMM measurements

None of the channels of the 7711/7712 module are connected to the internal DMM (the channels cannot be connected to the backplane). If your test system requires DMM measurements, you can use a measure card in one of the other mainframe slots or you can use the front panel inputs of the Model 27xx.

Remember to use multiple channel operation to control the 7711/7712 module and system channel operation to control a measure card for DMM measurements. If you attempt to close a 7711/7712 module channel using front panel system channel operation, the message “NO MEAS CARD” will be displayed briefly.

If you use front panel inputs for measurements, make sure that the front panel INPUT switch is in the out (F) position.

## S-parameters

S-parameters allow a text string of up to 238 ASCII characters to be stored on a module. This can be used for system calibration of cable and module losses. The calibration text string is stored on the module, independent of the Model 27xx mainframe.

## Unlocking calibration

Use the following sequence of commands to unlock calibration (factory default code):

```
CAL:PROT:CODE "KI0027xx"
CAL:PROT:CARD1:INIT
CAL:PROT:CARD1:SPAR ". . . . ."
CAL:PROT:CARD1:SAVE
```

where: xx = 00 (for 2700)  
      xx = 01 (for 2701)  
      xx = 50 (for 2750)

**NOTE** Your mainframe calibration unlock code will remain the factory default code unless it is changed.

## CALibration subsystem

Commands to perform output operations are listed in Table 5. Details on these commands follow the table.

**NOTE** The following commands for the CALibration subsystem are specific to the Model 7711/7712 module. It is only available if a Model 7711/7712 is installed.

Table 5  
**CALibration subsystem commands**

Command	Description	Default
<b>2700/2701 Commands</b> CALibration :PROTected :CARD1 :INITiate :SPARameters <string>  :SPARameters? :CARD2 :SPARameters?	Path to CARD1 commands. Initiate command—required before sending s-parameters. Enter up to 238 characters for storage of S-parameter information about the card in slot 1.  Query the ASCII information for CARD1. Path to CARD2 commands. Query the ASCII information for CARD2.	Empty
<b>2750 Commands (only)</b> CALibration :CARD1 :INITiate :SPARameters <string>  :CARD :SPARameters? <NRf>	Path to CARD commands. Initiate command—required before sending s-parameters. Enter up to 238 characters for storage of S-parameter information about the card in slot 1.  Path to s-parameter queries. Query the ASCII information for card in slot <NRf>.	Empty

### :SPARameters <string>

If the card in this slot is not a valid RF card (Model 7711, etc.), then a -221, “Settings Conflict” error is returned. Any valid ASCII information can be stored in the string space; it is not error checked in any way.

**NOTE** S-parameter data can only be **written** to a card in slot 1. The S-parameters are treated like card-cal constants, meaning that you must send a CAL:PROT:CARD1:INIT command before sending the SPARameters, and they are only saved on the card after a CAL:PROT:CARD1:SAVE command. The S-parameter can be **read** from any slot.

### :SPARameters? <NRf>

#### Query S-parameter

S-parameter data can only be written to a card in slot 1. This is consistent with other Integra series type card calibrations that are allowed in slot 1 only. Also, the Model 2750 can be queried using CAL:PROT:CARD1:SPAR

**NOTE** Errors +518 and +519 are provided to flag corrupted S-parameter information or flag S-parameter information that was not properly initialized.



# SYSTem subsystem

Commands to perform system operations are listed in [Table 6](#). Details on these commands follow the table.

**NOTE** The following commands for the Model 7711/7712 SYSTem subsystem are included here for reference.

Table 6  
SYSTem subsystem commands

Command	Description	Default
<b>2700/2701 Commands</b> :SYSTem :CARD1 :CARD2 :SNUMber? :SWRevision? :VMAX? :MUX? :SNOpen? :BANKs?	Path to queries for slot 1 card. Path to queries for slot 2 card. Request serial number of card in Slot x. Request firmware revision of card in Slot x. Query the highest allowed voltage on this card. Return TRUE if this card support ANY mux channels. Query whether the card is of the "single, no-open" type. This query returns the number of banks on the card. If the card is not of the Single, No-Open type, then a -221 "Settings Conflict" error results with this query.	
<b>2750 Commands (only)</b> :CARD :SNUMber? <NRf> :SWRevision? <NRf> :VMAX? <NRf> :MUX? <NRf> :SNOpen? <NRf> :BANKs? <NRf>	Path to queries (slot is designated by <NRf> after query command). Request serial number of card in Slot x. Request firmware revision of card in Slot x. Query the highest allowed voltage on this card. Return TRUE if this card support ANY mux channels. Query whether the card is of the "single, no-open" type. This query returns the number of banks on the card. If the card is not of the Single, No-Open type, then a -221 "Settings Conflict" error results with this query.	

:CARD1  
:CARD2

## Model 2700/2701 commands

If no card is in slot 1, then all commands in [Table 6](#) generate a -241 "hardware missing" error. If the card does not support the feature or channels being queried, then 0 will be returned.

:MUX?

Returns either a 1 or 0. (For a Model 7711/7712 card, a 0 is returned.)

:SNOpen?

"single, no-open" type — The card is organized into banks of channels, and one channel must always be closed within that bank. The Model 7711 is representative of this class with two banks of 4 channels each. Returns either a 1 or 0. (For a 7711/7712 card, a 1 is returned.)

## :CARD

### Model 2750 commands only

If no card is in slot <NRf>, then all of these commands will generate a -241 “hardware missing” error. If the card does not support the feature or channels being queried, then 0 will be returned.

Unlike the Model 2700/2702, the Model 2750 SYST:CARD queries have the slot passed as a <NRf> following the query (rather than incorporated into the command name). For compatibility with existing Model 2700/2702 software, the Model 2750 also accepts SYST:CARD1 or SYST:CARD2 (not recommended for queries when developing new software).

Example: To query the maximum voltage allowed on the card in slot 3, send:

```
:SYST:CARD:VMAX? 3
```

## Measurement considerations

### Termination of unused connectors


To minimize noise within the system, terminate unused channels with 50Ω loads. If 50Ω loads are not available, terminating unused connectors with a cable may also reduce noise within the system.

### Power handling

The graph in [Figure 7](#) shows the maximum amount of power per channel that can be routed using the Model 7711 or Model 7712 while maintaining proper digital multimeter accuracy. Power levels of up to 10 watts at frequencies > 200MHz can be used, but this may cause measurement errors. For example, routing 10 watts of power at 1GHz may cause the Model 2700/2702 to have an additional 6μV offset uncertainty when measuring DC voltages. For the Model 2750, the precision low level circuitry may cause uncertainty of 30μV. Moving the Model 7711/7712 to a higher number slot will reduce this uncertainty.

Figure 7

**Carry power (per channel) vs. frequency**



## Additional measurement uncertainty

Table 7 lists additional uncertainty to the published specifications for the Model 7708. Other modules, such as the Model 7700 (which measures thermocouple temperature), are also affected by this heat but are still within published specification. The amount of uncertainty is dependent on:

- Model 7711/7712 slot location
- The amount of time the channel is programmed as an output
- Which other model 77XX module(s) are being used

The listed uncertainty in Table 7 is listed for channels 4 and 8 closed. The uncertainty is linear—for each channel programmed as input or off, there will be approximately 25 percent reduction in the listed on uncertainty. Table 8 lists the percentage of additional uncertainty for specific channel pairs closed.

Table 7  
**Additional uncertainty for Model 7711/7712**

Thermocouple	Range	7708
J	-200 to 0°C 0 to +768°C	
K	-200 to 0°C 0 to +1372°C	0.4
N	-200 to 0°C 0 to +1300°C	0.75 0.15
T	-200 to 0°C 0 to +400°C	0.4
E	-200 to 0°C 0 to +1000°C	0.15
R	0 to +400°C 0 to +1768°C	1.5
S	0 to +400°C 0 to +1768°C	1.5
B	350 to 1100°C 0 to +1820°C	2.4 0.6

Notes:

1. The above listed uncertainties are guaranteed by design for thermocouple types J, K, N, T, E, R, S, B.
2. When the Model 7711/7712 and Model 7708 are used together, the Model 7711/7712 must be installed in the lowest numbered slot.  
For example: Model 2700/2701: 7711/7712 in slot 1, 7708 in slot 2  
Model 2750: 7711/7712 in slot 2, 7708 in slot 3

*Table 8*

***Percent of additional uncertainty***

Channels closed	Percent of additional uncertainty (from <a href="#">Table 7</a> )
4 and 8	100%
2 and 8	75%
3 and 8	75%
4 and 6	75%
4 and 7	75%
1 and 8	50%
2 and 6	50%
2 and 7	50%
3 and 6	50%
3 and 7	50%
4 and 5	50%
1 and 6	25%
1 and 7	25%
2 and 5	25%
2 and 6	25%
1 and 5	0%

# Application example

The following application example is for power supply testing. For basic overview and switching, refer to [Figure 8](#). For the tests performed, refer to the provided code ([Figure 9](#)). Basic knowledge for Visual Basic functions, such as the CStr() function, as well as how forms work in Visual Basic, is required to fully understand the example.

Figure 8  
**Simplified connection schematic (one power supply shown)**




Figure 9  
**Visual basic application example—power supply testing**

```

'' -----
'' 7711 Application Example
'' -----
'' This program tests a set of power supplies using a 2750 loaded with a 7700,
'' 7711, and a 7705.
''
'' The following occurs:
'' 1) The 7700 takes DCV, ACV, 2W OHMS (CONT), and TEMP measurements.
'' 2) Limits are used in each of the measurements by the 7700.
''    A) DCV limits are set to 10% of the power supply's output.
''    B) ACV limits are 108 and 132V.
''    C) 2W OHMS limits are -0.01 and 2 ohms.
''    D) TEMP limits are 70 and 125 C.
''
'' 3) RF switching to an oscilloscope is obtained using a 7711 where the AC ripple
''    is measured.
''
'' 4) A 7705 is used to switch loads and to control the line input voltage
''    to the DUTs (power supplies).
''
'' Please note:
'' The maximum number of power supplies that can be used with this example is 4.
'' -----

```

```

Option Explicit
'-----
' Constants
'-----
Const MAXLEN = 6400 ' Constant used with ENTER function.
Const LENGTH = 6400 ' Constant used with ENTER function.
Const ENTER_TIMEOUT = 3000 ' Length of time the ENTER function will wait for a query.
Const ADDRESS = 16 ' DMM setup address.

' Slot assignments.
Const SLOT_7700 = 1
Const SLOT_7711 = 2
Const SLOT_7705 = 3

' Number of configurations, power supply units, and functions.
Const NUMBER_OF_DUTS = 4
Const NUMBER_OF_FUNCTIONS = 4 ' DCV, ACV, CONT, and TEMP.
Const NUMBER_OF_SUPPLY_CONFIGURATIONS = 4 ' Includes HIGH/ LOW line and 10%/90% load.
Const N_READINGS = NUMBER_OF_DUTS * NUMBER_OF_FUNCTIONS * NUMBER_OF_SUPPLY_CONFIGURATIONS

' Constants to define limits for the different measurements.
Const POWER_SUPPLY_VOLTAGE = 5 ' Voltage output of power supplies.
Const DCV_MAX = POWER_SUPPLY_VOLTAGE * 1.1 ' Allow power supply to vary by 10%.
Const DCV_MIN = POWER_SUPPLY_VOLTAGE * 0.9
Const ACV_MAX = 132 ' ACV input voltage to power supply limits.
Const ACV_MIN = 108
Const CONT_MAX = 2 ' Limit failure will occur at 2 ohms or more.
Const CONT_MIN = -0.01
Const TEMP_MAX = 125 ' Max. and min. limits for temperature.
Const TEMP_MIN = 70

' Constants to define power supply configurations.
Const HIGH_LINE = 1
Const LOW_LINE = 2
Const TEN_PERCENT_LOAD = 1
Const NINETY_PERCENT_LOAD = 2

' Global variables.
Dim Status As Integer ' Variable used by the send() function.
Dim Readings(N_READINGS) As String ' Array to store readings.
Dim Reading_Counter As Integer ' Index to Readings().

'-----
' 7700 Channel Configurations
'-----
' Configure_Limits(,,) -
' Sets the limits for a given channel given by the constants defined above.
'
' Configure_7700_DCV(,) -
' Sets a channel to measure DCV.
'
' Configure_7700_ACV() -
' Configures a channel to measure ACV.
'
' Configure CONT() -
' Configures the channel to measure 2W ohms.
' This measurement is used instead of CONT, so we can select the ohm's limits.
'
' Configure_7700_TEMP() -
' Sets a channel to measure temperature using *RST default.
'
' Configure_Channel() -
' Uses the above functions to do the following on the 7700:
' 1. Sets channels 1,5,9, and 13 to DCV.
' 2. Sets channels 2,6,10, and 14 to ACV.
' 3. Sets channels 3,7,11, and 15 to CONT.
' 4. Sets channels 4,8,12, and 16 to TEMP.
' 5. Places the box into Auto-Configuration Mode.
'
' Note: Auto-configuration mode brings in the individual channels'
' settings when that channel is closed.
'-----
Private Sub Configure_7700_Limits(Channel_Num As Integer, Ulimit As Integer, Llimit As Integer)
    Dim Channel_Str As String
    Dim Upper_Limit As String
    Dim Lower_Limit As String

    Channel_Str = ",(@" & CStr(Channel_Num) & ")" ' Converts a number to an ASCII channel parameter.
    Upper_Limit = CStr(Ulimit)
    Lower_Limit = CStr(Llimit)

    Call send(ADDRESS, "CALC3:LIM1:STAT ON" & Channel_Str, Status) ' Enable Limit1 for DCV.
    Call send(ADDRESS, "CALC3:LIM1:UPP:DATA " & Upper_Limit & Channel_Str, Status) ' Set upper limit.
    Call send(ADDRESS, "CALC3:LIM1:LOW:DATA " & Lower_Limit & Channel_Str, Status) ' Set lower limit.
End Sub

Private Sub Configure_7700_DCV(Channel_Num As Integer, Power_Supply_DCV As Integer)
    Dim Channel_Str As String

    Channel_Str = ",(@" & CStr(Channel_Num) & ")"
    Call send(ADDRESS, "SENS:FUNC 'VOLT:DC'" & Channel_Str, Status) ' Set channel to measure DCV.
    Call send(ADDRESS, "SENS:VOLT:DC:RANG 100" & Channel_Str, Status) ' Set voltage range(Power Supply is at 5V).

    Call Configure_7700_Limits(Channel_Num, DCV_MAX, DCV_MIN)
End Sub

Private Sub Configure_7700_ACV(Channel_Num As Integer)
    Dim Channel_Str As String

    Channel_Str = ",(@" & CStr(Channel_Num) & ")"
    Call send(ADDRESS, "SENS:FUNC 'VOLT:AC'" & Channel_Str, Status) ' Set channel to measure ACV.
    Call send(ADDRESS, "SENS:VOLT:AC:RANG 150" & Channel_Str, Status) ' Set voltage range.
    Call Configure_7700_Limits(Channel_Num, ACV_MAX, ACV_MIN)
End Sub

```

```

Private Sub Configure_7700_CONT(Channel_Num As Integer)
    Dim Channel_Str As String

    Channel_Str = ",(@" & CStr(Channel_Num) & ")"
    Call send(ADDRESS, "SENS:FUNC 'RES'" & Channel_Str, Status) ' Set channel to measure 2W ohms.
    Call send(ADDRESS, "SENS:RES:RANG 10" & Channel_Str, Status) ' Set resistance range.
    Call send(ADDRESS, "SENS:RES:NPLC 0.1" & Channel_Str, Status) ' Set measurement speed to fast.

    Call Configure_7700_Limits(Channel_Num, CONT_MAX, CONT_MIN)
End Sub

Private Sub Configure_7700_TEMP(Channel_Num As Integer)
    Dim Channel_Str As String

    Channel_Str = ",(@" & CStr(Channel_Num) & ")"
    Call send(ADDRESS, "SENS:FUNC 'TEMP'" & Channel_Str, Status) ' Set channel to TEMP measurement.
    Call send(ADDRESS, "SENS:TEMP:TRAN TC" & Channel_Str, Status) ' Select thermocouple measurement.
    Call send(ADDRESS, "SENS:TEMP:TC:TYPE T" & Channel_Str, Status) ' Use T thermocouples.
    Call send(ADDRESS, "SENS:TEMP:TC:RJUN:RSEL INT" & Channel_Str, Status) ' Use internal reference junction.

    Call Configure_7700_Limits(Channel_Num, TEMP_MAX, TEMP_MIN)
End Sub

Private Sub Configure_7700_Channels()
    Dim I As Integer
    Dim POWER_SUPPLY_VOLTAGE As Integer

    For I = 0 To NUMBER_OF_DUTS - 1
        Call Configure_7700_DCV(1 + (I * NUMBER_OF_DUTS) + (SLOT_7700 * 100), POWER_SUPPLY_VOLTAGE)
        Call Configure_7700_ACV(2 + (I * NUMBER_OF_DUTS) + (SLOT_7700 * 100))
        Call Configure_7700_CONT(3 + (I * NUMBER_OF_DUTS) + (SLOT_7700 * 100))
        Call Configure_7700_TEMP(4 + (I * NUMBER_OF_DUTS) + (SLOT_7700 * 100))
    Next

    Call send(ADDRESS, "ROUT:CLOS:ACON ON", Status) ' Place instrument in auto-configure mode.
End Sub

'' -----
'' 7705 Configurations
'' -----
'' Configure Power Supplies(,) -
'' Uses the 7705 switch card to change the input voltage to the power supplies.
'' They may run at either high line or low line. A load of 10% or 90% is also
'' selected in this function.
''
'' Assume the following for the 7705:
'' 1) Channels 1 to 4 connect each of the possible DUTS to HIGH LINE.
'' 2) Channels 11 to 14 connect each of the possible DUTS to LOW LINE.
'' 3) Channels 21 to 24 connect each of the possible DUTS to 10% load.
'' 4) Channels 31 to 34 connect each of the possible DUTS to 90% load.
'' -----

Private Sub Configure_Power_Supplies(Line As Integer, Load As Integer)
    Dim Min_Channel, Max_Channel As String

    ' Insert code here to turn off power supply outputs.

    Min_Channel = CStr((SLOT_7705 * 100) + 1)
    Max_Channel = CStr((SLOT_7705 * 100) + NUMBER_OF_DUTS + 40)
    Call send(ADDRESS, "ROUT:MULT:OPEN (@" & Min_Channel & ":" & Max_Channel & ")", Status) ' Open all 7705 channels.

    Select Case (Line)
        Case HIGH LINE
            Min_Channel = CStr((SLOT_7705 * 100) + 1)
            Max_Channel = CStr((SLOT_7705 * 100) + NUMBER_OF_DUTS)
            Call send(ADDRESS, "ROUT:MULT:CLOS (@" & Min_Channel & ":" & Max_Channel & ")", Status)

        Case LOW LINE
            Min_Channel = CStr((SLOT_7705 * 100) + 1 + 10)
            Max_Channel = CStr((SLOT_7705 * 100) + NUMBER_OF_DUTS + 10)
            Call send(ADDRESS, "ROUT:MULT:CLOS (@" & Min_Channel & ":" & Max_Channel & ")", Status)
    End Select

    Select Case (Load)
        Case TEN PERCENT LOAD
            Min_Channel = CStr((SLOT_7705 * 100) + 1 + 20)
            Max_Channel = CStr((SLOT_7705 * 100) + NUMBER_OF_DUTS + 20)
            Call send(ADDRESS, "ROUT:MULT:CLOS (@" & Min_Channel & ":" & Max_Channel & ")", Status)

        Case NINETY PERCENT LOAD
            Min_Channel = CStr((SLOT_7705 * 100) + 1 + 30)
            Max_Channel = CStr((SLOT_7705 * 100) + NUMBER_OF_DUTS + 30)
            Call send(ADDRESS, "ROUT:MULT:CLOS (@" & Min_Channel & ":" & Max_Channel & ")", Status)
    End Select

    ' Insert code here to configure and/ or turn on power supply outputs.
End Sub

'' -----
'' Measurement Functions
'' -----
'' Take_Measurements() -
'' Closes the appropriate channels and takes a measurement using READ? command.
'' -----

```

```

Private Sub Take_Measurements()
    Dim I, J As Integer
    Dim Channel_Num As Integer
    Dim Channel_Str As String
    Dim Reading As String

    For I = 1 To NUMBER_OF_DUTS
        Channel_Num = (SLOT_7711 * 100) + I
        Channel_Str = "@" & CStr(Channel_Num) & " "
        Call send(ADDRESS, "ROUT:MULT:CLOS " & Channel_Str, Status)

        For J = 1 To NUMBER_OF_FUNCTIONS
            Channel_Num = (SLOT_7700 * 100) + J + ((I - 1) * NUMBER_OF_DUTS)
            Channel_Str = "@" & CStr(Channel_Num) & " "
            Call send(ADDRESS, "ROUT:CLOS " & Channel_Str, Status)
            Call send(ADDRESS, "READ?", Status)
            Call enter(Reading, MAXLEN, LENGTH, ADDRESS, Status)

            Readings(Reading_Counter) = Reading
            Reading_Counter = Reading_Counter + 1
        Next J

        ' Insert code here to take oscilloscope measurements.
    Next I
End Sub

' Main Function
Private Sub Start_Click()
    Reading_Counter = 0
    Call settimeout(ENTER_TIMEOUT)

    Call initialize(21, 0)

    Call send(ADDRESS, "*RST", Status)
    Call send(ADDRESS, "INIT:CONT OFF", Status)
    Call send(ADDRESS, "FORM:ELEM READ,UNIT", Status)

    Call Configure_7700_Channels
    Call Configure_Power_Supplies(HIGH_LINE, TEN_PERCENT_LOAD)
    Call Take_Measurements
    Call Configure_Power_Supplies(HIGH_LINE, NINETY_PERCENT_LOAD)
    Call Take_Measurements
    Call Configure_Power_Supplies(LOW_LINE, TEN_PERCENT_LOAD)
    Call Take_Measurements
    Call Configure_Power_Supplies(LOW_LINE, NINETY_PERCENT_LOAD)
    Call Take_Measurements
End Sub

```



# Service

**WARNING** All service information is intended only for qualified service personnel. Do not attempt to service the Model 7711/7712 unless you are qualified to do so.

## Performance verification

The following tests are used to verify the RF characteristics of the Model 7711/7712 card. S-parameters are obtained by measuring VSWR and insertion loss among the common output and channel. The following equipment is recommended for the tests in this section:

1. Agilent HP 8753ES Network Analyzer (6GHz) with options 6 and 10.
2. 50 $\Omega$  3.5MM test port cables (1m cables).
3. Agilent HP 85033D, 3.5mm Calibration Kit.
4. Phase matched 3.5mm female-female thru-adapter.


## Instrument setup

1. Turn on the network analyzer and the mainframe with the Model 7711/7712 installed. Allow the analyzer to warm-up for at least 1 hour.
2. Calibrate the network analyzer from 100MHz to 3.5GHz using the appropriate calibration kit. The calibration routine should include a load, short, open, and pass-through procedure. Use SMA style connectors in the calibration process.

## VSWR

1. Connect cables as shown in [Figure 10](#).
2. Close channel 1.
3. Select S11 or S22 measurement on the analyzer.
4. Display VSWR graph on network analyzer.
5. Verify specifications.  
For the Model 7711, verify at 100MHz, 500MHz, 1GHz, 1.5GHz, and 2GHz.  
For the Model 7712, verify at 500MHz, 1GHz, 2.5GHz, and 3.5GHz.  
Refer to the VSWR section of the Model 7711 or 7712 specification values at the end of this User's Guide for acceptable limits.
6. Repeat procedure for remaining channels. Change the network analyzer connection from OUT A to OUT B when verifying channels 5–8.

Figure 10  
**VSWR and insertion loss verification**




## Insertion loss

1. Connect cables as shown in [Figure 10](#).
2. Close channel 1.
3. Select S12 or S21 measurement on the analyzer.
4. Display Log Magnitude plot on the network analyzer.
5. Verify specifications.  
 For the Model 7711, verify at 100MHz, 500MHz, 1GHz, 1.5GHz, and 2GHz.  
 For the Model 7712, verify at 500MHz, 1GHz, 2.5GHz, and 3.5GHz.  
 Refer to the Insertion Loss section of the Model 7711 or 7712 specifications values for acceptable limits.
6. Repeat procedure for remaining channels. Change the network analyzer connection to Port 2 to OUT B when verifying channels 5–8.

## Cross-talk

1. Connect cables as shown in [Figure 11](#) (Channel 1 to port 1 and channel 2 to port 2, 50 $\Omega$  load on OUT A).
2. Close channel 1 (all other channels will open).
3. Display Log Magnitude plot on the network analyzer.
4. Select S12 measurement.
5. Verify specifications.  
For the Model 7711, verify at 100MHz, 500MHz, 1GHz, 1.5GHz, and 2GHz.  
For the Model 7712, verify at 500MHz, 1GHz, 2.5GHz, and 3.5GHz.  
Refer to the Ch-Ch cross-talk section of the Model 7711 or 7712 specifications values for acceptable limits.
6. Repeat procedure for remaining channels in both banks. There are six possible combinations for each bank of 4 channels (combinations in bank 1: 1-2, 1-3, 1-4, 2-3, 3-4). When verifying cross-talk in the second bank, connect the 50 $\Omega$  load on OUT B.

Figure 11  
**Cross-talk verification**



## Replaceable parts

This section contains replacement parts information and the component layout drawing for the Model 7711/7712.

### Parts list

Replaceable parts for the Model 7711/7712 are listed in [Table 9](#).

## Ordering information

To place an order, or to obtain information concerning replacement parts, contact your Keithley representative or the factory (see back cover for addresses). When ordering parts, be sure to include the following information:

- Card model number (Model 7711/7712).
- Card serial number.
- Part description.
- Component designation (if applicable).
- Keithley part number.

## Factory service

If the instrument is to be returned to Keithley Instruments for repair, perform the following:

- Call the Repair Department at 1-888-KEITHLEY for a Return Material Authorization (RMA) number.
- Carefully pack the instrument in the original packing carton.
- Write ATTENTION REPAIR DEPARTMENT and the RMA number on the shipping label.

## Component layout

The component layout for the Model 7711 is provided in [Figure 12](#). [Figure 13](#) is the Model 7712 component layout.

Figure 12  
Model 7711 component layout




Figure 13  
Model 7712 component layout




Table 9  
Model 7711/7712 parts list

Circuit designation	Description	Keithley part no.
+5VD+5VR,GNDD	SURFACE MOUNT PCB TEST POINT	CS-1026
C1,C3,C6,C19	CAP, 47P, 5%, 100V, CERAMIC (0805)	C-465-47P
C2,C4,C5,C18,C20-C24	CAP, .1UF, 20%, 50V CERAMIC(1206)	C-418-.1
C7-C17	CAP, 470U, 20%, 25V, ALUM ELEC	C-622-470
CR1,CR2	DIODE MBR5130LT3	RF-115
J100	CONN, RT ANGLE DUAL ROW RECEPT	CS-1065-1
J1-J8,J10A,J10B*	CONN, RT ANGLE JACK SMA 50 OHM	CS-1136
K1-K6: Model 7711	HIGH FREQ RELAY	RL-238
Model 7712)	RF RELAY	RL-268
L1,L2	FERRITE CHIP 600 OHM BLM32A07(1206)	CH-62
Q1-Q6	TRANS, NPN SILICON	TG-389
R1,R2,R11	RES, 1K, 1%, 100MW, THICK FILM (0805)	R-418-1K
R10	RES, 10K, 1%, 100MW, THICK FILM (0805)	R-418-10K
R12-R17	RES, 2.55K, 1%, 1W THICK FILM	R-418-2.55K
R3-R8	RES, 43.2, 1%, 100MW THICK FILM (0805)	R-418-43.2
R9	RES, 357K, 1%, 100MW, THICK FILM(0805)	R-418-357K
U1,U2	IC, QUAD 2 IN AND, 74HCT08(SOIC)	IC-837
U10	IC, 8 STAGE SHIFT/STORE,MC14094BD(SOIC)	IC-772
U3	IC, 2.5V CASCADABLE SERIAL EEPROM	LSI-212
U5	IC, +5V VOLTAGE REGULATOR, LM2940CT	IC-576
U7	IC, DARLINGTON ARRAY, ULN2003L (SOIC)	IC-969
U8	IC, RETRIG., MULTIVIB, 74HC123AM (SOIC)	IC-788
U9	IC, HEX SCHMITT INVERT TRIGGER	IC-1397
Hardware Model 7711/7712	MODIFIED TOP COVER MODIFIED BOTTOM COVER STANDOFF MALE-FEMALE BAR CODE S/N LABEL SERIAL NUMBER LABEL 4-40 PEM NUT MODIFIED TOP COVER MODIFIED BOTTOM COVER TOP CARD COVER 4-40X3/16 PHIL. PAN HD SEMS #4-40 X 1/4 LG. PHIL.FLAT HD.SCREW #4-40 X 1/4 LG. PHIL.FLAT HD.SCREW BOTTOM CARD COVER	V-7711-304A V-7711-303A ST-166-25 MC-612A MC-285 FA-131 7711-304A 7711-303A 7703-302C 4-40X3/16PPHSEM 4-40X1/4PFH 4-40X1/4PFH 7703-301B
Model 7711 Specific hardware	SCANNER BOARD ASSEMBLY CONNECTOR BRACKET	7711-100B 7711-301-1A
Model 7712 Specific hardware	SCANNER BOARD ASSEMBLY CONNECTOR BRACKET	7712-100A 7711-301-2A

# 7711 50W 2GHz Multiplexer Specifications

## GENERAL

**Relay Type:** High Frequency Electromechanical

**Contact Configuration:** Dual 1x4 Multiplexer, single pole four throw, Channels 1 and 5 are normally closed.

**Notes:** One channel in each multiplex bank is always closed to the corresponding OUT connector.

**Close Channel:** ROUTe:CLOSe allows a single channel in a multiplex bank to be closed.  
ROUTe:MULTiple:CLOSe allows two channels (One in each bank) to be closed at one time.

**Open Channel:** ROUTe:OPEN:ALL closes CH1 and CH5 to OUT A and OUT B respectively.

**Actuation Time:** <10mS

**Firmware:** Specified for Model 2700 rev. B04 and Model 2750 rev. A03 or higher.

**Connector Type:** Ten External Rear Panel SMA connectors.

**Mating Torque:** 0.9 N•m (8 in-lb).

## INPUTS (CHANNELS 1-8)

**Maximum Signal Level:** Any channel to any channel or chassis (1-8)  
30Vrms (42V peak for AC waveforms) or  
60VDC, 0.5A.

**Maximum Power:** 20W per module, 10W per channel.\*

**Safety:** Conforms to European Union Directive 73/23/EEC  
EN61010-1, CAT I.

**EMC:** Conforms with European Union Directive 89/336/EEC;  
EN61326-1.

### Isolation:

**Multiplexer to Multiplexer:** >1GΩ

**Center to Shield:** >1GΩ, <25pF

**Channel to Channel:** >100MΩ

**Contact Life:** 1x10<sup>6</sup> No Load, 1x10<sup>5</sup> Rated Load (resistive load)

**Contact Potential:** <6μV

**Contact Resistance:** <0.5Ω (Initial), <1Ω (End Of Life)




**Rise Time:** <300ps (Guaranteed by design)

**Signal Delay:** <3ns

## MODEL ACCESSORIES AVAILABLE


7711-SMA-BNC	Male SMA to Female BNC Cables (Five, 0.15m (0.5ft) cables)
7051-2	BNC cable, male to male, 0.6m (2ft.)
7051-5	BNC cable, male to male, 1.5m (5ft.)
7051-10	BNC cable, male to male, 3.0m (10ft.)
7712-SMA-1	SMA cable, male to male, 1.0m (3.3 ft.)
7712-SMA-N	Female SMA to Male N-Type Adapter
S46-SMA-1	SMA cable, male to male, 0.3m (1 ft.)
S46-SMA-0.5	SMA cable, male to male, 0.15m (0.5 ft.)

\* Refer to 7711/7712 User's Guide (PA-818) for measurement considerations.





# 7711 50W 2GHz Multiplexer Specifications



## AC Performance: (Includes end of life)

For  $Z_{load} = Z_{source} = 50\Omega$

	<100MHz	500MHz	1GHz	1.5GHz	2GHz
<b>Insertion Loss MAX</b>	0.4dB	0.6dB	1.0dB	1.2dB	2.0dB
<b>VSWR MAX</b>	1.1	1.2	1.2	1.3	1.7
<b>Ch-Ch Cross-talk<sup>1</sup> MAX</b>	-85dB	-65dB	-55dB	-45dB	-35dB

<sup>1</sup> Specification assumes 50 $\Omega$  termination.

## Environmental

**Operating Environment:** Specified for 0°C to 50°C  
Specified for 80% RH at 35°C

**Storage Environment:** -25°C to 65°C

**Weight:** <0.50Kg (1.1 lb.)

Specifications subject to change without notice.

# 7712 50W 3.5GHz Multiplexer

## GENERAL

**Relay Type:** High Frequency Electromechanical

**Contact Configuration:** Dual 1x4 Multiplexer, single pole four throw, Channels 1 and 5 are normally closed

**Notes:** One channel in each multiplex bank is always closed to the corresponding OUT connector.

**Close Channel:** ROUTe:CLOSE allows a single channel in a multiplex bank to be closed.

ROUTe:MULTiple:CLOSE allows two channels (One in each bank) to be closed at one time.

**Open Channel:** ROUTe:OPEN:ALL closes CH1 and CH5 to OUT A and OUT B respectively.

**Actuation Time:** <10mS

**Firmware:** Specified for Model 2700 rev. B04 and Model 2750 rev. A03 or higher.

**Connector Type:** Ten External Rear Panel SMA connectors

**Mating Torque:** 0.9 N•m (8 in-lb).

## INPUTS (CHANNELS 1-8)

**Maximum Signal Level:** Any channel to any channel or chassis (1-8)  
30Vrms (42V peak for AC waveforms) or  
42VDC, 0.5A.

**Maximum Power:** 20W per module. 10W per channel.\*

**Safety:** Conforms to European Union Directive 73/23/EEC  
EN61010-1, CAT I.

**EMC:** Conforms with European Union Directive 89/336/EEC;  
EN61326-1.

**Isolation:**

**Multiplexer to Multiplexer:** >1G $\Omega$

**Center to Shield:** >1G $\Omega$ , <20pF

**Channel to Channel:** >100M $\Omega$

**Contact Life:** 5x10<sup>6</sup> No Load, 1x10<sup>5</sup> Rated Load (Resistive load)

**Contact Potential:** <12 $\mu$ V

**Contact Resistance:** <0.5 $\Omega$  (Initial), <1 $\Omega$  (End Of Life)




**Rise Time:** <200ps (Guaranteed by design)


**Signal Delay:** <1.5ns

## MODEL ACCESSORIES AVAILABLE

7712-SMA-1	SMA cable, male to male, 1m (3.3 ft)
7712-SMA-N	Female SMA to Male N-Type Adapter
S46-SMA-1	SMA cable, male to male, 0.3m (1ft)
S46-SMA-0.5	SMA cable, male to male, 0.15m (0.5 ft.)

\* Refer to 7711/7712 User's Guide (PA-818) for measurement considerations.





## AC Performance: (Includes end of life)

For  $Z_{load} = Z_{source} = 50\Omega$

	<500MHz	1GHz	2.4GHz	3.5GHz
<b>Insertion Loss MAX</b>	0.5dB	0.65dB	1.1dB	1.3dB
<b>VSWR MAX</b>	1.15	1.2	1.45	1.45
<b>Ch-Ch Crosstalk<sup>1</sup> MAX</b>	-75dB	-70dB	-50dB	-45dB

<sup>1</sup> Specification assumes 50 $\Omega$  termination.

## ENVIRONMENTAL

**Operating Environment:** Specified for 0°C to 50°C

Specified for 80% RH at 35°C

**Storage Environment:** -25°C to 65°C

**Weight:** <.50Kg (1.1 lb.)

Specifications subject to change without notice.



Specifications are subject to change without notice.

All Keithley trademarks and trade names are the property of Keithley Instruments, Inc. All other trademarks and trade names are the property of their respective companies.



**Keithley Instruments, Inc.**

28775 Aurora Road • Cleveland, Ohio 44139 • 440-248-0400 • Fax: 440-248-6168  
**1-888-KEITHLEY (534-8453) • [www.keithley.com](http://www.keithley.com)**

<b>Sales Offices:</b>	<b>BELGIUM:</b>	Bergensesteenweg 709 • B-1600 Sint-Pieters-Leeuw • 02-363 00 40 • Fax: 02-363 00 64
	<b>CHINA:</b>	Yuan Chen Xin Building, Room 705 • 12 Yumin Road, Dewai, Madian • Beijing 100029 • 8610-82251886 • Fax: 8610-82251892
	<b>FINLAND:</b>	Halsuantie 2 • 00420 Helsinki, Finland • 09-53 06 65 60 • Fax: 09-53 06 65 65
	<b>FRANCE:</b>	3, allée des Garays • 91127 Palaiseau Cédex • 01-64 53 20 20 • Fax: 01-60 11 77 26
	<b>GERMANY:</b>	Landsberger Strasse 65 • 82110 Germering • 089-84 93 07-40 • Fax: 089-84 93 07-34
	<b>GREAT BRITAIN:</b>	Unit 2 Commerce Park, Brunel Road • Theale, Berkshire RG7 4AB • 0118-929 75 00 • Fax: 0118-929 75 19
	<b>INDIA:</b>	1/5, Eagles Street • Langford Town • Bangalore 560 025 • 080 212 80-27 • Fax: 080 212 80 05
	<b>ITALY:</b>	Viale San Gimignano, 38 • 20146 Milano • 02-48 39 16 01 • Fax: 02-48 30 22 74
	<b>JAPAN:</b>	New Pier Takeshiba North Tower 13F • 11-1, Kaigan 1-chome • Minato-ku, Tokyo 105-0022 • 81-3-5733-7555 • Fax: 81-3-5733-7556
	<b>KOREA:</b>	2FL., URI Building • 2-14 Yangjae-Dong • Seocho-Gu, Seoul 137-888 • 82-2-574-7778 • Fax: 82-2-574-7838
	<b>NETHERLANDS:</b>	Postbus 559 • 4200 AN Gorinchem • 0183-63 53 33 • Fax: 0183-63 08 21
	<b>SWEDEN:</b>	c/o Regus Business Centre • Frosundaviks Allé 15, 4tr • 16970 Solna • 08-50 90 46 00 • Fax: 08-655 26 10
	<b>TAIWAN:</b>	13F-3, NO. 6, Lane 99, Pu-Ding Road, Hsinchu, Taiwan, ROC. • 886-3-572-9077 • Fax: 886-3-572-9031