



LINEAR TECHNOLOGY CORPORATION

DC762A REV 3

03/22/05

NOTES: UNLESS OTHERWISE SPECIFIED,

1. DO NOT INSTALL BATTERY PACK UNTIL LED1 IS SCREWED DOWN.

2. SPREAD A THIN COAT OF THERMAL GREASE ON THE EXPOSED METAL WHERE INDICATED.

3. PLACE LED1 WHERE INDICATED AND PLEASE NOTE POLARITY.

4. INSTALL SCREW, NUT AND WASHER IN TWO LOCATIONS WHERE SHOWN. TIGHTEN SCREW 1/4 PAST FINGER TIGHTNESS.

5. INSTALL BOTH WIRES FOR + AND - TERMINALS ON PCB, WHERE INDICATED. INSTALL CORRESPONDING WIRES TO LED1 MATCHING POLARITY PER WIRE. (REFER TO ASSEMBLED PCB FOR VISUAL AID)

6. CUT ASSEMBLED SCREW LENGTH TO HEXNUT LEVEL.

7. INSTALL BATTERY PACK.

DETAIL - 'A'

SCALE: NONE

4