



1. BREAK BOARDS FROM THE PANEL WHEN ASSEMBLY IS COMPLETE.
2. OPTIONAL COMPONENTS ARE UNSTUFFED AND SHOULD BE FREE OF SOLDER AFTER ASSEMBLY.
3. JUMPER SHUNTS INSTALLATION: JP1-JP9 PIN 1-2
4. CONNECTORS J1 AND P1 MUST BE SOLDER
5. DO NOT PUT TWO BOARDS TOGETHER.(DO NOT INSERT J1 IN TO P1).

**LINEAR**  
**TECHNOLOGY**

<div> <div>APPROVALS</div> <div> <div> <div></div> <div>DATE</div> </div> <div> <div></div> <div>INT</div> </div> </div> </div>		<div> <div> <div></div> <div>DRAWN</div> </div> <div> <div></div> <div>CHECK</div> </div> </div>		<div> <div> <div>ANTONNIA K3-10-06</div> <div>PINKESH S 3-10-06</div> </div> <div> <div></div> <div>ENGR</div> </div> </div>	
		<div> <div>SCALE = NONE</div> <div> <div>DES- 0000</div> <div>SHT 1 of 2</div> </div> </div>		<div> <div> <div>SIZE</div> <div> <div>A</div> <div>DC985A-A&amp;B</div> </div> </div> <div> <div>REV. 2</div> <div></div> </div> </div>	



Scale = None