



Silkscreen Top

DC1082A-D AND A-F Assy Drawing (ONLY U1 IS DIFFERENT)

- JPA : INSTALL 0 OHM RES. ON PIN 3-5, 4-6 AS SHOW.
- JPC : INSTALL 0 OHM RES. ON PIN 1-3, 2-4 AS SHOW.
- JPD : INSTALL 0 OHM RES. ON PIN 3-4 AS SHOW.
- JPB, JPE, JPF : OPEN.