

APPENDIX

Firmware Update

Background The APS-7000 firmware can be upgraded using the USB A port on the front panel. See your local distributor or the GW Instek website for the latest firmware information.



Note

- Ensure the DUT is not connected.
 - Ensure the output is off.
-

1. Insert a USB Flash Drive into the USB port on front panel of the APS-7000.
 - The USB drive should include the **gw.sbt** file in a directory name “gw”(USB\gw:).

Steps

1. Press the *Menu* key. The Menu setting will appear on the display. 
2. Use the scroll wheel to go to item 11, *Special Function* and press *Enter*.
3. Key in the password when prompted and then press *Enter*.
 - The password is “5004”.
4. Go to Item 1, *Update Main Program* and press *Enter*.

Exit

5. Wait for the unit to update. Upon completion the unit will automatically reset.
-

Example



Password setting screen