

## PEL-3212H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	2	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
GRA-414-E	01RA414E000T	2	PEL-3111 3U Frame(Optional)

## PEL-3323H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	3	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
GRA-414-E	01RA414E000T	3	PEL-3111 3U Frame(Optional)

## PEL-3424H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	4	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	2	Bus Bar Connector
GRA-414-E	01RA414E000T	4	PEL-3111 3U Frame(Optional)

## PEL-3535H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	5	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	3	Bus Bar Connector
GRA-414-E	01RA414E000T	5	PEL-3111 3U Frame(Optional)

## PEL-3322H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	1	1KW LOAD Master
PEL-3211H	01EL321H00GT	1	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
GRA-413-E	01RA413E000T	1	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000T	1	PEL-3111 3U Frame(Optional)

## PEL-3533H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	1	1KW LOAD Master
PEL-3211H	01EL321H00GT	2	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
GRA-413-E	01RA413E000T	2	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000T	1	PEL-3111 3U Frame(Optional)

## PEL-3744H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	1	1KW LOAD Master
PEL-3211H	01EL321H00GT	3	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
PEL-009	11EL-00900101	1	Bus Bar Connector
GRA-413-E	01RA413E000T	3	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000T	1	PEL-3111 3U Frame(Optional)

## PEL-3955H (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111H	01EL311H00GT	1	1KW LOAD Master
PEL-3211H	01EL321H00GT	4	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
PEL-009	11EL-00900101	1	Bus Bar Connector
GRA-413-E	01RA413E000T	4	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000T	1	PEL-3111 3U Frame(Optional)