



**Agilent E5810B  
LAN/GPIB/USB  
Gateway**

**Rackmount Installation  
Guide (Option 300)**




**Agilent Technologies**


## Rackmount Kit (Option 300)

Item	Part number	Description	Quantity	Item	Part number	Description	Quantity
A	E5810-00031	Rack ear - side	1	E	0515-1114	Panhead screw, M4X10	8
B	E5810-00022	Rack ear - half rack	1	F	0570-1577	Machine screw	4
C	E5810-00035	Power adapter holder	1	G	0590-0804	Machine nut	4
D	0950-5481	Power adapter	1				

- 1 Remove both rubber bumpers from the E5810B.
- 2 Using a Torx screwdriver, attach the rack ear - half rack (B) to the E5810B with three panhead screws, M4X10 (E).
- 3 Plug the E5810B power adapter (D) into the DC power port of the E5810B. Place the power adapter into the power adapter holder (C).
- 4 Using a Torx screwdriver, attach the rack ear - side (A) to the E5810B and the power adapter holder (C) with five panhead screws, M4X10 (E).



- Using a Torx screwdriver, attach the rack ears to the rack with four machine screws (F) and four machine nuts (G).



**www.agilent.com**

**Contact us**

To obtain service, warranty, or technical assistance, contact us at the following phone or fax numbers:

United States:

(tel) 800 829 4444 (fax) 800 829 4433

Canada:

(tel) 877 894 4414 (fax) 800 746 4866

China:

(tel) 800 810 0189 (fax) 800 820 2816

Europe:

(tel) 31 20 547 2111

Japan:

(tel) 0120 (421) 345 (fax) 0120 (421) 678

Korea:

(tel) (080) 769 0800 (fax) (080) 769 0900

Latin America:

(tel) (305) 269 7500

Taiwan:

(tel) 0800 047 866 (fax) 0800 286 331

Other Asia Pacific Countries:

(tel) (65) 6375 8100 (fax) (65) 6755 0042

Or visit Agilent World Wide Web at:

[www.agilent.com/find/assist](http://www.agilent.com/find/assist)

Product specifications and descriptions in this document are subject to change without notice. Always refer to the Agilent Web site for the latest revision.

© Agilent Technologies, Inc. 2014

First Edition, May 26, 2014  
E5810-90008



**Agilent Technologies**