

IFR 2975 VERIFICATION SETUP FILES

To support units with IFR 2975 Software Version 1.9

PURPOSE

The purpose of this document is to provide instructions for the installation of IFR 2975 Verification Setup Files into the IFR 2975. The Verification Setup Files are utilized when the Verification Procedures in the IFR 2975 Maintenance Manual are performed.

COPY VERIFICATION SETUP FILES TO FLOPPY DISK

- 1) Format a Floppy Disk in DOS Format.
- 2) Copy the **maintenance.tar.gz** file from *http://www.p25.com* or CD to the Floppy Disk.
- 3) Rename the file to **reload.tgz** on the Floppy Disk.

INSTALL VERIFICATION SETUP FILES IN IFR 2975

- 1) Go to the Firmware Install Screen by pressing **MODE, 7, 4** on the IFR 2975 Keypad.
- 2) Insert the Floppy Disk into the IFR 2975 Floppy Disk Drive.
- 3) Press the "**Check Floppy**" Softkey.
- 4) When the copy process is complete, remove the Floppy Disk from the IFR 2975 Floppy Disk Drive.
- 5) Press the "**Reload System**" Softkey.
- 6) Press the "**Start Install**" Softkey. The Verification Setup Files are stored under the MAINTENANCE Directory in the IFR 2975 Setups.

AEROFLEX CONTACT INFORMATION

For additional assistance, contact:

Aeroflex
Sales Support Department
10200 West York Street
Wichita, Kansas 67215
Telephone: (800) 835-2352 (Option 4)
FAX: (316) 524-2623
Em ail: techsupport@aeroflex.com

Aeroflex
Customer Service Department
10200 West York Street
Wichita, Kansas 67215
Telephone: (800) 835-2350
FAX: (316) 524-2623
Em ail: service@aeroflex.com

COPYRIGHT ^) Aeroflex 2005

Any unauthorized distribution or reproduction of this document or software is prohibited.