


This sheet includes board numbers 2000 and 3000.


Toll Free 1-800-SENSCORE
SENSCORE
 innovatively designed
 with your time in mind.
 3200 Sencore Drive
 Sioux Falls, SD 57107
 Call Collect 605-339-0100 In SD

P3
 3
 P3
 2
 P3
 1
 LEAKAGE VOLTAGE OUTPUT

P1
 2
 P1
 1
 P4
 1
 P4
 3
 P4
 8
 P4
 6
 P4
 2
 P4
 5
 P4
 4
 D/A CONTROL
 LINE SYNC
 AUTO OFF
 BATTERY MONITOR
 +12V
 GND
 +5V
 -5V

LC77 LEAKAGE SUPPLY
43B314
3000 BOARD





- P1 2
- P1 1
- P4 1
- P4 3
- P4 8
- P4 6
- P4 2
- P4 5
- P4 4

D/A CONTROL
 LINE SYNC
 AUTO OFF
 BATTERY MONITOR
 +12V
 GND
 +5V
 -5V


P4 7 +18V

USE BOARD 43B314:A

11/18/86



Toll Free 1-800-SENCOA
 3200 Sencora Drive
 Sioux Falls, SD 57107
 Call Collect 605-339-0101



3000 BOARD — LEAKAGE SUPPLY