



LC77 AUTO-Z BLOCK DIAGRAM

LC77 BLOCK DIAGRAM



12/18/86 FOR BOARD 438313A



LC77 LEAKAGE SUPPLY
43B314
3000 BOARD

USE BOARD 43B314-A


11/18/86

This sheet includes board numbers 2000 and 3000.


Toll Free 1-800-SENSCORE
innovatively designed
3200 Sensors Drive
Sioux Falls, SD 57107
Call Collect 605-339-0100 In SD




LC77 DISPLAY
438312
1000 BOARD




1000 BOARD — DISPLAY




TOGGLE SWITCH BOARD (Foil Side)



TOGGLE SWITCH BOARD (Component Side)



DISPLAY BOARD (Component Side)



DISPLAY BOARD (Foil Side)