

Index

Numerics

2D manual mode 4-6
2D/3D automatic mode 4-6
3D manual mode 4-6

A

age of data C-12, C-20
almanac 4-14
altitude C-10
altitude/up velocity C-10
AM alarm C-10
antenna 1-7
AP Auxiliary Port characteristics C-11
architecture 1-1
architecture of system 4-14
ASCII format C-1
ASICs
 Colossus RF 1-1
ASIGs
 Scorpion DSP 1-1
automatic output packets A-2
automatic position and velocity reports A-3

B

background packets A-5
backup power for
 almanac 1-2
 ephemeris 1-2
 last position 1-2
 real-time clock 1-2
backwards incompatibility A-6
battery back-up (BBU) 2-2
baud rate 3-2
block diagram of system 4-15
bulkhead antenna drawing F-6
Bullet II antenna drawing F-5

C

C/A code 4-1
cautions xxiv
Checksum C-4
circuit board drawing F-4
Coarse/Acquisition (C/A) code 4-1
cold start 4-2
command packets sent to receiver A-8
communication failure 1-12
communication ports
 independently configurable 1-2
 serial I/O 1-2
configuring protocols 3-8
coordinate systems 4-9
copyrights ii
CP Compact Position solution C-12

D

data string C-4
data strings table C-9
DC Differential Corrections C-13
DCE (Data Communication Equipment) 1-6
DD Delta Differential corrections C-14
default operating mode 4-6
default satellite mask settings 4-4
Department of Defense xxi
DGPS automatic 4-7
DGPS for position 4-8
DGPS off 4-7
DGPS on 4-7
differential
 correction 1-4
 GPS 3-7
differential GPS 3-7
 operating modes 4-7
 packets A-4
disclaimers ii
document conventions xxiii
DOP mask 4-5
DTE (Data Terminal Equipment) 1-6
dynamic limits 4-11

dynamics code A-14

E

earth centered earth fixed A-25, A-43
ECEF A-25, A-43
EEROM (electrically erasable ROM) 1-2
electrically erasable ROM (EEROM) 1-2
elevation mask 4-4
ephemeris 4-14
error codes C-23

F

File Transfer Protocol (FTP) site xxiii
fix modes 4-6
ftp.trimble.com xxiii

G

garage search strategy 4-3
GPS xxi
GPS time of day C-10
GPS timing 4-12
GPSSK D-1
 files D-1
 start-up D-2
GPSSK or TAIP Toolkit D-1
GSA messages E-5
GSV message E-6

H

HAE A-25, A-43
health report 1-12
height above ellipsoid A-25, A-43
Help on-line D-2
hot start 4-3

I

ID Identificaton Number C-15
initialization packets A-3
interconnect diagram 1-10
interface protocols 1-3
interruption of GPS signal E-9
IP Initial Position C-16

L

L1 carrier frequency 4-1
latitude and longitude conversion C-8
latitude conversion C-8
LN Long Navigation message C-17
longitude conversion C-8

M

mechanical drawings F-1
memory, non-volatile 1-2
message
 delimiter C-4
 format qualifiers C-3
 format table C-3
 identifier C-4
miniature antenna drawing F-7
Monitor32 interface program 1-12
mounting 2-3

N

National Marine Electronics Assn. (NMEA) E-1
navigation processor 4-14
NMEA 0183 1-3
 coordinate system 4-10
 data output 3-5
 message format E-2
 message options E-3
non-volatile memory 1-2
notes xxiv

O

operating limits table 4-11
organization xxii
other information xxiii
output packets A-2
overview 1-2

P

packet
 BB A-13
 descriptions A-18
packet structure A-17
packets
 automatic output A-2
 automatic position and velocity reports A-3

- background A-5
- backwards incompatibility A-6
- BB or setup parameters A-13
- command, sent to receiver A-8
- datums A-84
- descriptions A-18
- differential GPS A-4
- initialization to speed start-up A-3
- output at power-up A-4
- recommended A-6
- reports sent to user A-11
- satellite data A-5
- set fix mode A-14
- speed start-up A-3
- structure A-17
- superpackets A-70
- timing A-4
- packets output at power-up A-4
- parity 3-2
- PDOP switch 4-5
- polling schemes 1-3
- Port 2 re-configuring 3-8
- ports
 - communication 1-2
 - dual data 1-2
 - serial 1-1
- position accuracy 4-8
- position and velocity reports A-3
- power
 - 9-32 VDC 1-1
 - cable 1-9
- power requirements table 2-2
- Power-up with BBRAM E-9
- Power-up with no BBRAM E-9
- PPS 4-13
- PR Protocol message C-18
- protocol summary 3-4
- protocols 1-3
 - binary packet 1-3
- PT Port characteristics message C-19
- PV Position/Velocity solution C-20

Q

- query for single sentence C-27

R

- RAM memory 2-2
- raw measurement data A-28
- re-acquisition 4-11

- reader comment form xxii, 1
- real-time clock 2-2
- receiver health report 1-12
- receiver module 1-5
- recommended TSIP packets A-6
- repeatability checks 2-3
- report packets sent to user A-11
- response to query C-27
- revision notice ii
- RF section 1-2
- RM Reporting Mode C-21
- RMC message E-7
- RT Reset Mode C-22
- RTCM SC-104 input 1-4

S

- SA 4-8
- sample communication session C-29
- sample PV message C-5
- satellite
 - acquisition 4-1
 - mask settings 4-4
 - message 4-1
- satellite data packets A-5
- scheduled reporting frequency interval C-27
- SCorpion DSP ASIC 1-1
- SEEPROM 3-11
- selective availability (SA) 4-8
- serial port
 - baud rate C-11, C-19
 - characteristics 3-2
 - data bits C-11
 - parity C-11, C-19
 - stop bits C-11, C-19
- serial port characteristics 3-2
- serial time output 4-12
- set fix mode A-14
- set qualifier C-28
- setup parameters or packet BB A-13
- signal processor 4-14
- SNR mask 4-5
- specifications F-1
- speed start-up A-3
- split search strategy 4-3
- spread spectrum signals 1-7
- ST Status C-23
- status codes C-23
- superpackets A-70
- synchronization signal 1-2
- Synchronized Measurements Report A-58

T

TAIP 1-3
 coordinate system 4-10
 data output 3-5
 data string format C-9
 message
 format C-3
 qualifier
 query C-27
 response C-27
 scheduled reporting C-27
 set C-28
 vehicle ID C-15
 message identifier C-9
 reporting frequency C-27
 reporting mode
 checksum flag C-21
 scheduled reporting flag C-21
 vehicle ID flag C-21
 sample communications C-29
 tool kit see GPSSK D-1
 Toolkit or GPSSK D-1
TAIP messages supported C-2
TANS protocol (Trimble Advanced Navigation
 Sensor) A-1
technical assistance xxiii
time and distance reporting C-6
time to first fix 4-2
timing 3-6
timing packets A-4
timing pulse output (PPS) 4-13
tips xxiv
TM Time/Date message C-25
tool kit B-1
 TAIP see GPSSK D-1
Tool Kit program disk B-1
trademarks ii
Trimble ASCII Interface Protocol (TAIP) C-1
Trimble Standard Interface Protocol (TSIP) 1-3
TSIP 1-3
 data output 3-4
 tool kit B-1
TSIP coordinate systems 4-9
TSIP superpackets A-70
TSIPCHAT 3-9, B-1
 commands 3-10
 DOS program 3-9
TSIPMonitor 32 program 1-12
TSIPMonitor32 B-2

U

update rate 4-11

V

vehicle ID C-4
vertical velocity C-10
VR Version Number C-26
VTG message E-7

W

warm start 4-2
warnings xxiv
WNRO 3-6
World Wide Web (WWW) site xxiii
www.trimble.com/support/support.htm xxiii

X

X1 Extended Status message C-26

Z

ZDA message E-8