


XP7

Адрес	Цепь	←
Панель УШЯИ.687422.018, -XS6	~13.5V	1
	~13.5V	2
	~13.5V	3
	32	4




XS2.2

Цепь	↗
GND	1
+12V	2
GND	4
-12V	3
GND	6
+5V	5
GND	8
-5.2V	7
GND	10
-2V	9

XP8

Адрес	Цепь	←
Панель УШЯИ.687422.018, -XS5	~7.2V	1
	~7.2V	2
	~7.2V	3
	~7.2V	4



XP9

Адрес	Цепь	←
Панель УШЯИ.687422.018, -XS4	~7.5V	1
	~7.5V	2

