

Адрес	Цепь	Сигнал
1	A1/AD0	AD0
2	A2/AD1	AD1
3	A3/AD2	AD2
4	A4/AD3	AD3
5	A5/AD4	AD4
6	A6/AD5	AD5
7	A7/AD6	AD6
8	A8/AD7	AD7
9	A9/AD8	AD8
10	A10/AD9	AD9
11	A11/AD10	AD10
12	A12/AD11	AD11
13	A13/AD12	AD12
14	IRDE+PF4	PF4

