



FLUKE®

Auto Mode Decision Diagram



Measurement Ranges and Accuracy



- For SMD components use PM 9542SMD Adapter or the PM 9540/TWE SMD Tweezers.
- For larger components use PM 9542A RCL Adapter.
- For in-circuit measurement of components use PM 9541A Kelvin Clips Test Cable or the PM 9540/TWE SMD Tweezers.
- For two-wire measurement plug two normal test leads into the upper connectors.
- Center segments of digits flash when Component exceeds measurement range. (R > 200 MΩ, C > 100 mF, L > 20 kH, Q or D > 500).
- Resistances or inductances are measured with **DC BIAS 2V** on.
- Discharge capacitors before connecting.
- ZERO TRIM** compensates:
  - Contact and line resistances (up to 10 Ω in short circuit).
  - Stray capacitances in open circuit.
- Measurement frequency 1 kHz fixed.
- Measurement update rate: 2 measurements per second.

