

Quick Reference Guide

HP 8753D Network Analyzer



**HEWLETT
PACKARD**

**HP Part No. 08753-90259
Printed in USA June 1994**

© Copyright Hewlett-Packard Company 1991, 1992, 1993, 1994
All Rights Reserved. Reproduction, adaptation, or translation without
prior written permission is prohibited, except as allowed under the
copyright laws.
1212 Valley House Drive, Rohnert Park, CA 94928-4999, USA

Quick Reference Guide Overview

- Chapter 1, “HP 8753D Descriptions” describes analyzer features and functions.
- Chapter 2, “Making Measurements” contains step-by-step procedures for making a basic measurement, and using the display and marker functions.
- Chapter 3, “Making Mixer Measurements” contains a procedure for making a conversion loss measurement, using the frequency offset mode.
- Chapter 4, “Printing, Plotting, or Saving Measurement Results” contains procedures for saving to disk or the analyzer memory, and printing or plotting displayed measurements.
- Chapter 5, “Optimizing Measurement Results” describes some techniques and functions for achieving the best measurement results.
- Chapter 6, “Application and Operation Concepts” contains information about some of the applications and analyzer operation.
- Chapter 7, “Specifications and Measurement Uncertainties” contains information on the analyzer’s dynamic range and 7 mm test port performance capabilities.
- Chapter 8, “Menu Maps” contains the menus related to all the front panel keys.
- Chapter 9, “Key Definitions” contains a cross reference that shows softkeys and the corresponding front panel key.
- Chapter 10, “Error Messages” contains a table of all the possible error messages.
- Chapter 11, “Compatible Peripherals” contains lists of equipment that is compatible with the analyzer. Some HP-IB information is also included.
- Chapter 12, “Preset State and Memory Allocation” contains information on the analyzer internal memory and the analyzer parameters that correspond to a preset state.


For additional information refer to:

- *HP 8753D Network Analyzer Installation and Quick Start Guide*
- *HP 8753D Network Analyzer User’s Guide*
- *HP 8753D Network Analyzer Programmer’s Guide*

HP 8753D Network Analyzer Documentation Set




The **Installation and Quick Start Guide** familiarizes you with the HP 8753D network analyzer's front and rear panels, electrical and environmental operating requirements, as well as procedures for installing, configuring, and verifying the operation of the HP 8753D.



The **User's Guide** shows how to make measurements, explains commonly-used features, and tells you how to get the most performance from your analyzer.



The **Quick Reference Guide** provides a summary of all available user features.



The **Programmer's Guide** provides programming information including: an HP-IB command reference, an HP-IB programming reference, as well as programming examples.



The **System Verification and Test Guide** provides the system verification and performance tests and the Performance Test Record for your HP 8753D network analyzer.


HP 8753D Description and Options

Analyzer Description

- Combined digital signal processing and microprocessor controls
- Direct print or plot output of displayed measurement results, with a time stamp, to a compatible peripheral with a serial, parallel, or HP-IB interface.
- Instrument states storage in internal memory for the following times, or on disk indefinitely.
 - Temperature at 70 °C 250 days (0.68 year)
 - Temperature at 40 °C 1244 days (3.4 years)
 - Temperature at 25 °C 11904 days (32.6 years) typical
- Automatic sweep time that selects the minimum sweep time for the given IF bandwidth, number of points, averaging mode, frequency range, and sweep type.
- Built-in service diagnostics are available to simplify troubleshooting procedures.
- Performance flexibility through trace math, data averaging, trace smoothing, electrical delay, and accuracy enhancement.
- Accuracy enhancement methods that range from normalizing data to complete one or two port vector error correction with up to 1601 measurement points, and TRL*/LRM*.
- External source mode capability that allows you to phase lock the analyzer's receiver to an external source.
- Tuned receiver mode
- Reflection and transmission measurements in either 50 or 75 ohm impedance
- Receiver/source frequency offset mode

- Power meter calibration
- Test system automation with the addition of an HP 9000 series 200 or 300 computer
- External keyboard compatibility
- LIF/DOS disk format
- Integration of a high capacity micro-floppy disk drive
- Internal automation, using test sequencing
- A general purpose input/output (GPIO) bus

Front Panel Features



pg62d

Figure 1-1. HP 8753D Front Panel

1. **LINE switch.** This switch controls ac power to the analyzer. 1 is on, 0 is off.
2. **Display.** This shows the measurement data traces, measurement annotation, and softkey labels. The display is divided into specific information areas, illustrated in Figure 1-2.
3. **Softkeys.** These keys provide access to menus that are shown on the display.
4. **STIMULUS function block.** The keys in this block allow you to control the analyzer source's frequency, power, and other stimulus functions.
5. **RESPONSE function block.** The keys in this block allow you to control the measurement and display functions of the active display channel.
6. **ACTIVE CHANNEL keys.** The analyzer has two independent display channels. These keys allow you to select the active channel. Then any function you enter applies to this active channel.


7. **The ENTRY block.** This block includes the knob, the step \uparrow \downarrow keys, and the number pad. These allow you to enter numerical data and control the markers.
8. **INSTRUMENT STATE function block.** These keys allow you to control channel-independent system functions such as the following:

- copying, save/recall, and HP-IB controller mode
- limit testing
- external source mode
- tuned receiver mode
- frequency offset mode
- test sequence function
- harmonic measurements (option 002)
- time domain transform (option 010)

HP-IB STATUS indicators are also included in this block.

9. **PRESET key.** This key returns the instrument to either a known factory preset state, or a user preset state that can be defined.
10. **PORT 1 and PORT 2.** These ports output a signal from the source and receive input signals from a device under test. PORT 1 allows you to measure S_{12} and S_{11} . PORT 2 allows you to measure S_{21} and S_{22} .
11. **PROBE POWER connector.** This connector (fused inside the instrument) supplies power to an active probe for in-circuit measurements of ac circuits.
12. **R CHANNEL connectors.** These connectors allow you to apply an input signal to the analyzer's R channel, for frequency offset mode.
13. **Disk drive.** This 3.5 inch drive allows you to store and recall instrument states and measurement results for later analysis.

Analyzer Display



pg64d

Figure 1-2. Analyzer Display (Single Channel, Cartesian Format)

The analyzer display shows various measurement information:

- The grid where the analyzer plots the measurement data.
 - The currently selected measurement parameters.
 - The measurement data traces.
1. **Stimulus start value.** This value could be any one of the following:
 - the start frequency of the source in frequency domain measurements
 - the start time in CW mode (0 seconds) or time domain measurements
 - the lower power value in power sweep

When the stimulus is in center/span mode, the center stimulus value is shown in this space.

2. **Stimulus stop Value.** This value could be any one of the following:

- The stop frequency of the source in frequency domain measurements.
- The stop time in time domain measurements or CW sweeps.
- The upper limit of a power sweep.

When the stimulus is in center/span mode, the span is shown in this space. The stimulus values can be blanked.

3. **Status Notations.** This area shows the current status of various functions for the active channel.

The following notations are used:

Avg = Sweep-to-sweep averaging is on. The averaging count is shown immediately below.

Cor = Error correction is on.

C? = Stimulus parameters have changed from the error-corrected state, or interpolated error correction is on.

C2 = Full two-port error-correction is active when either the power range for each port is different (uncoupled), or the **TESTSET HOLD** is activated.

Del = Electrical delay has been added or subtracted, or port extensions are active.

ext = Waiting for an external trigger.

Ofs = Frequency offset mode is on.

Of? = Frequency offset mode error, the IF frequency is not within 10 MHz of expected frequency. LO inaccuracy is the most likely cause.

Gat = Gating is on (time domain option 010 only).

H=2 = Harmonic mode is on, and the second harmonic is being measured. (Harmonics option 002 only.)


H=3 = Harmonic mode is on, and the third harmonic is being measured. (Harmonics option 002 only.)

- Hld = Hold sweep.
- man = Waiting for manual trigger.
- PC = Power meter calibration is on.
- PC? = The analyzer's source could not be set to the desired level, following a power meter calibration.
- P? = Source power is unlevelled at start or stop of sweep.
- P↓ = Source power has been automatically set to minimum, due to receiver overload.
- PRm = Power range is in manual mode.
- Smo = Trace smoothing is on.
- tsH = Indicates that the test set hold mode is engaged.
- That is, a mode of operation is selected which would cause repeated switching of the step attenuator. This hold mode may be overridden.
- ↑ = Fast sweep indicator. This symbol is displayed in the status notation block when sweep time is less than 1.0 second. When sweep time is greater than 1.0 second, this symbol moves along the displayed trace.
- * = Source parameters changed: measured data in doubt until a complete fresh sweep has been taken.

4. **Active Entry Area.** This displays the active function and its current value.
5. **Message Area.** This displays prompts or error messages.
6. **Title.** This is a descriptive alpha-numeric string title that you define and enter through an attached keyboard.
7. **Active Channel.** This is the number of the current active channel, selected with the **ACTIVE CHANNEL** keys. If dual channel is on with an overlaid display, both channel 1 and channel 2 appear in this area.
8. **Measured Input(s).** This shows the S-parameter, input, or ratio of inputs currently measured, as selected using the **MEAS** key. Also indicated in this area is the current display memory status.

9. **Format.** This is the display format that you selected using the **FORMAT** key.
10. **Scale/Div.** This is the scale that you selected using the **SCALE/REF** key, in units appropriate to the current measurement.
11. **Reference Level.** This value is the reference line in Cartesian formats or the outer circle in polar formats, whichever you selected using the **SCALE/REF** key. The reference level is also indicated by a small triangle adjacent to the graticule, at the left for channel 1 and at the right for channel 2.
12. **Marker Values.** These are the values of the active marker, in units appropriate to the current measurement.
13. **Marker Stats, Bandwidth.** These are statistical marker values that the analyzer calculates when you access the menus with the **MKR FCTN** key.
14. **Softkey Labels.** These menu labels redefine the function of the softkeys that are located to the right of the analyzer display.
15. **Pass Fail.** During limit testing, the result will be announced as **PASS** if the limits are not exceeded, and **FAIL** if any points exceed the limits.

Rear Panel Features and Connectors



pg6 134 d

Figure 1-3. HP 8753 Rear Panel

1. **Serial number plate.**
2. **Ext Mon.** Red, green, and blue video output connectors provide analog red, green, and blue video signals which you can use to drive an external monitor such as the HP 3571A/B or monochrome monitor such as the HP 35731A/B. You can use other analog multi-sync monitors if they are compatible with the analyzer's 25.5 KHz scan rate and video levels: 1 V_{p-p}, 0.7 V=white, 0 V=black, -0.3 V sync, sync on green.
3. **HP-IB connector.** This allows you to connect the analyzer to an external controller, compatible peripherals, and other instruments for an automated system.
4. **PARALLEL interface.** This connector allows the analyzer to output to a peripheral with a parallel input. Also included, is a general purpose input/output (GPIO) bus that can control eight output bits and read five input bits through test sequencing.
5. **RS-232 interface.** This connector allows the analyzer to output to a peripheral with an RS-232 (serial) input.

6. **KEYBOARD input (DIN).** This connector allows you to connect an external keyboard. This provides a more convenient means to enter a title for storage files, as well as substitute for the analyzer's front panel keyboard. The keyboard must be connected to the analyzer before the power is switched on.
7. **Power cord receptacle, with fuse.**
8. **Line voltage selector switch.**
9. **10 MHZ REFERENCE ADJUST. (Option 1D5)**
10. **10 MHZ PRECISION REFERENCE OUTPUT. (Option 1D5)**
11. **EXTERNAL REFERENCE INPUT connector.** This allows for a frequency reference signal input that can phase lock the analyzer to an external frequency standard for increased frequency accuracy.
12. **AUXILIARY INPUT connector.** This allows for a dc or ac voltage input from an external signal source, such as a detector or function generator, which you can then measure, using the S-parameter menu.
13. **EXTERNAL AM connector.** This allows for an external analog signal input that is applied to the ALC circuitry of the analyzer's source. This input analog signal amplitude modulates the RF output signal.
14. **EXTERNAL TRIGGER connector.** This allows connection of an external negative-going TTL-compatible signal that will trigger a measurement sweep. The trigger can be set to external through softkey functions.
15. **TEST SEQUENCE.**

Outputs a TTL signal that can be programmed in a test sequence to be high or low, or pulse (10 μ seconds) high or low at the end of a sweep for robotic part handler interface.
16. **LIMIT TEST.**

Outputs a TTL signal of the limit test results as follows:

 - Pass: TTL high
 - Fail: TTL low

17. BIAS INPUTS AND FUSES.

These connectors bias devices connected to port 1 and port 2. The fuses (1 A, 125 V) protect the port 1 and port 2 bias lines.

- 18. TEST SET INTERCONNECT.** This allows you to connect an HP 8753D Option 011 analyzer to an HP 85046A/B or 85047A S-parameter test set using the interconnect cable supplied with the test set. The S-parameter test set is then fully controlled by the analyzer.
- 19. Fan.** This fan provides forced-air cooling for the analyzer.

Changes between the HP 8753A/B/C/D

Table 1-1.
Comparing the HP 8753 Family of Network Analyzers

Feature	8753A	8753B	8753C	8753D
Fully integrated measurement system (built-in test set)	No	No	No	Yes
Test port power range (dBm)	†	†	†	+10 to -85
Auto/manual power range selecting	No	No	No	Yes
Port power coupling/uncoupling	No	No	No	Yes
Internal disk drive	No	No	No	Yes
Precision frequency reference (option 1D5)	No	No	No	Yes
Frequency range - low end	300 kHz	300 kHz	300 kHz	30 kHz
Ext. freq. range to 6 GHz (option 006)	No	Yes	Yes	Yes
75Ω system impedance (option 075)	†	†	†	Yes
TRL*/LRM* correction	No	No	No	Yes
Power meter calibration	No	Yes	Yes	Yes
Interpolated error correction	No	Yes	Yes	Yes
Max. Error corrected measurement points	801	1601	1601	1601
Segmented error correction in freq. list mode	No	No	Yes	Yes
Color CRT	No	No	Yes	Yes
Test sequencing	No	Yes	Yes	Yes

Table 1-1.
Comparing the HP 8753 Family of Network Analyzers
(continued)

Feature	8753A	8753B	8753C	8753D
Automatic sweep time	No	Yes	Yes	Yes
External source capability	No	Yes	Yes	Yes
Tuned receiver mode	No	Yes	Yes	Yes
Printer/plotter buffer	No	Yes	Yes	Yes
Harmonic measurements (option 002)	No	Yes	Yes	Yes
Frequency offset mode (mixer measurements)	No	Yes	Yes	Yes
dc bias to test device	†	†	†	Yes
Interfaces: RS-232, parallel, and DIN keyboard	No	No	No	Yes
User-defined preset	No	No	No	Yes
Non-volatile memory	16 Kbytes	16 Kbytes	16 Kbytes	512 Kbytes
Dynamic Range				
30 kHz to 3 GHz	100 dB	100 dB	100 dB	110 dB
3 GHz to 6 GHz	N/A	80 dB	80 dB	105 dB
Real time clock	No	No	No	Yes

† For this network analyzer, feature is dependent on the test set being used.

1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. 15. 16. 17. 18. 19. 20. 21. 22. 23. 24. 25. 26. 27. 28. 29. 30. 31. 32. 33. 34. 35. 36. 37. 38. 39. 40. 41. 42. 43. 44. 45. 46. 47. 48. 49. 50. 51. 52. 53. 54. 55. 56. 57. 58. 59. 60. 61. 62. 63. 64. 65. 66. 67. 68. 69. 70. 71. 72. 73. 74. 75. 76. 77. 78. 79. 80. 81. 82. 83. 84. 85. 86. 87. 88. 89. 90. 91. 92. 93. 94. 95. 96. 97. 98. 99. 100.

Making Measurements

Table 2-1. Connector Care Quick Reference

| Handling and Storage | |
|---|--|
| Do | Do Not |
| Keep connectors clean
Extend sleeve or connector nut
Use plastic end-caps during storage | Touch mating-plane surfaces
Set connectors contact-end down |
| Visual Inspection | |
| Do | Do Not |
| Inspect all connectors carefully
Look for particles, scratches, and dents | Use a damaged connector - ever |
| Connector Cleaning | |
| Do | Do Not |
| Try compressed air first
Use isopropyl alcohol
Clean connector threads | Use any abrasives
Get liquid into plastic support beads |
| Gaging Connectors | |
| Do | Do Not |
| Clean and zero the gage before use
Use the correct gage type
Use correct end of calibration block
Gage all connectors before first use | Use an out-of-spec connector |
| Making Connections | |
| Do | Do Not |
| Align connectors carefully
Make preliminary connection lightly
Turn only the connector nut
Use a torque wrench for final connect | Apply bending force to connection
Over tighten preliminary connection
Twist or screw any connection
Tighten wrench past "break" point |

Basic Measurement Sequence and Example

Basic Measurement Sequence


There are five basic steps when you are making a measurement.

1. Connect the device under test and any required test equipment.
2. Choose the measurement parameters.
3. Perform and apply the appropriate error-correction.
4. Measure the device under test.
5. Output the measurement results.

Basic Measurement Example

Step 1. Connect the device under test and any required test equipment.

1. Make the connections as shown in Figure 2-1.



pg0111d

Figure 2-1. Basic Measurement Setup

Step 2. Choose the measurement parameters.

2. Press **PRESET** **PRESET: FACTORY**.

Setting the Frequency Range

3. To set the center frequency to 134 MHz, press:

CENTER **134** **M/L**

4. To set the span to 30 MHz, press:

SPAN **30** **M/μ**

Setting the Source Power

5. To change the power level to -5 dBm, press:

MENU **POWER** **-5** **x1**

Setting the Measurement

6. To change the number of measurement data points to 101, press:

MENU **NUMBER OF POINTS** **101**

7. To select the transmission measurement, press:

MEAS **Trans: FWD 521 (B/R)**

8. To view the data trace, press:

SCALE REF **AUTOSCALE**

Step 3. Perform and apply the appropriate error-correction.

9. Refer to the “Optimizing Your Measurement Results” chapter.
10. To save the instrument state and error-correction in the analyzer internal memory, press:

SAVE RECALL **SELECT DISK INTERNAL MEMORY RETURN**
SAVE STATE

Step 4. Measure the device under test.

11. Replace any standard used for error-correction with the device under test.
12. To measure the insertion loss of the bandpass filter, press:

MARKER **134** **M/μ**

Step 5. Output the measurement results.

13. To create a hardcopy of the measurement results, press:

COPY **PRINT** (or **PLOT**)


To View Both Measurement Channels

DISPLAY

DUAL CHAN ON

MORE

SPLIT DISP ON



aw000027


Figure 2-2. Dual Channel with Split Display ON

DISPLAY

DUAL CHAN ON

MORE

SPLIT DISP OFF



aw000028

Figure 2-3.
Dual Channel with Split Display OFF

To Save a Data Trace to the Display Memory

Press **DISPLAY** **DATA** → **MEMORY**.

To View the Measurement Data and Memory Trace

1. To view a data trace that you have already stored to the active channel memory, press:

DISPLAY **MEMORY**

2. To view both the memory trace and the current measurement data trace, press:

DISPLAY **DATA and MEMORY**

To Divide Measurement Data by the Memory Trace

1. You must have already stored a data trace to the active channel memory.
2. Press **DISPLAY** **DATA/MEM**.

To Subtract the Memory Trace from the Measurement Data Trace

1. You must have already stored a data trace to the active channel memory.
2. Press **DISPLAY** **DATA-MEM**.

To Ratio Measurements in Channel 1 and 2

1. Press **CH 1** **MENU** **NUMBER OF POINTS**.
2. Press **CH 2** **MENU** **NUMBER OF POINTS** and enter the same value that you observed for the channel 1 setting.
3. Press **DISPLAY** **DUAL CHAN ON MORE D2/D1 TO D2 ON**.

To Title the Active Channel Display

1. Press **DISPLAY MORE TITLE** to access the title menu.
2. Press **ERASE TITLE** and enter the title you want for your measurement display.
 - a. Turn the front panel knob to move the arrow pointer to the first character of the title.
 - b. Press **SELECT LETTER**.
 - c. Repeat the previous two steps to enter the rest of the characters in your title. You can enter a title that has a maximum of 50 characters.
 - d. Press **DONE** to complete the title entry.





Figure 2-4.
Example of a Display Title

To Activate Display Markers

MARKER **MARKER 1**

Delta Markers

1. Press **MARKER** Δ **MODE MENU** Δ **REF=1** to make marker 1 a reference marker.
2. To move marker 1 to any point that you want to reference:
3. Press **MARKER** Δ and move marker 2 to any position that you want to measure in reference to marker 1.



aw000032

Figure 2-5. Marker 1 as the Reference Marker

Searching for the Maximum Amplitude

1. Press **MARKER FCTN** **MARKER SEARCH**.
2. Press **SEARCH: MAX**.


Searching for the Minimum Amplitude

1. Press **MARKER FCTN** **MARKER SEARCH**.
2. Press **SEARCH: MIN**.

Making Mixer Measurements

Conversion Loss Using the Frequency Offset Mode

Conversion loss is the measure of efficiency of a mixer. It is the ratio of side-band IF power to RF signal power, and is usually expressed in dB. The mixer translates the incoming signal, (RF), to a replica, (IF), displaced in frequency by the local oscillator, (LO). Frequency translation is characterized by a loss in signal amplitude and the generation of additional sidebands. For a given translation, two equal output signals are expected, a lower sideband and an upper sideband.



pg694d

Figure 3-1.
An Example Spectrum of RF, LO, and IF Signals Present in a Conversion Loss Measurement

Swept RF/IF Mixer Measurements

The HP 8753 allows you to make a swept RF/IF conversion loss measurement. You can make this measurement by using the analyzer's frequency offset measurement mode.

Frequency Offset Mode

This mode of operation allows you to offset the analyzer's source by a fixed value, above or below the HP 8753's receiver. For example, this allows you to use a device input frequency range that is different from the receiver input frequency range.

The following procedure describes the swept IF conversion loss measurement of a broadband component mixer.

1. Set the LO source to the desired CW frequency and power level.
For this example the LO source is set to the following values:

CW frequency = 1000 MHz
power = 13 dBm


2. Initialize the analyzer by pressing **PRESET** on the HP 8753.
3. From the front panel of the HP 8753, set the desired receiver frequency and source output power, by pressing:

```
SYSTEM INSTRUMENT MODE FREQ OFFSET MENU
FREQ OFFSET ON
START 100 (M/μ)
STOP 350 (M/μ)
MENU
POWER 0 (x1)
```

4. Connect the instruments as shown in Figure 3-2.

Note You must activate the frequency offset mode *before* you disconnect the R channel jumper.

Caution To prevent connector damage, use an adapter (HP part number 1250-1462) as a connector saver for R CHANNEL IN.



pg6106d

Figure 3-2. Connections for a Conversion Loss Measurement

- To view the absolute input power to the HP 8753's R channel, press:

```

MEAS
INPUT PORTS
R
  
```

- To set the frequency offset mode LO frequency from the analyzer, press:


```

SYSTEM
INSTRUMENT MODE
FREQ OFFSET MENU
LO MENU
FREQUENCY: CW 1000 M/μ
POWER: FIXED 13 x1
RETURN
  
```

7. To select the converter type and a high-side LO measurement configuration, press:


DOWN CONVERTER
RF > LO

Notice, in this high-side LO, down conversion configuration, the HP 8753's source is actually sweeping backwards, as shown in Figure 3-3. The measurements set-up diagram is shown in Figure 3-4.



pg6155d

Figure 3-3. Diagram of Measurement Frequencies



pg6103d

Figure 3-4. Measurement Setup from Display

8. View the conversion loss, shown in Figure 3-5.

VIEW MEASURE

9. Scale the data for best vertical resolution.

SCALE REF

AUTOSCALE




Figure 3-5. Conversion Loss Example Measurement

$$\text{Conversion loss} = \frac{\text{(output power)}}{\text{(input power)}}$$

In this measurement, you set the input power and measured the output power. Figure 3-5 shows the absolute loss through the mixer versus mixer output frequency.

For procedures on removing systematic frequency response errors, and on performing a source power meter calibration, see the "Optimizing Your Measurement Results" chapter in the *HP 8753D Network Analyzer User's Guide*.

Printing, Plotting, and Saving Measurement Results

Printing or Plotting Your Measurement Results

If the printing or plotting peripheral is not already connected and configured, refer to the “Compatible Peripherals” chapter in the *HP 8753D Network Analyzer User’s Guide* for procedures.

Defining the Print or Plot

Note The print or plot definition is lost if you cycle the power. However, you can save the print or plot definition by saving the instrument state.

If the Peripheral is a Printer

1. Press **COPY** **DEFINE PRINT**.
2. Press **PRINT** until the correct printer choice appears:
 - Choose **PRINT: MONOCHROME** if you are using a black and white printer, or you want just black and white from a color printer.
 - Choose **PRINT: COLOR** if you are using a color printer.
3. Press **AUTO-FEED** until the correct choice appears:
 - Choose **AUTO-FEED ON** if you want to print one measurement per page.
 - Choose **AUTO-FEED OFF** if you want to print multiple measurements per page.

Note

Laser printers and some DeskJet printers do not begin to print until a full page, or a partial page and a form feed, have been received.

If You are Using a Color Printer

1. Press **PRINT COLORS**.
 2. If you want to modify the print colors, select the print element and then choose an available color.
-

Note

You can set all the print elements to black to create a hardcopy in black and white.

Since the media color is white or clear, you could set a print element to white if you do not want that element to appear on your hardcopy.


To Reset the Printing Parameters to Default Values

1. Press **(COPY) DEFINE PRINT DEFAULT PRINT SETUP**.

| Printing Parameter | Default |
|--------------------|------------|
| Printer Mode | Monochrome |
| Auto Feed | ON |
| Printer Colors | |
| Channel 1 Data | Magenta |
| Channel 1 Memory | Green |
| Channel 2 Data | Blue |
| Channel 2 Memory | Red |
| Graticule | Cyan |
| Warning | Black |
| Text | Black |

If the Peripheral is a Plotter

1. Press **COPY** **DEFINE PLOT**.
2. Choose which of the following measurement display elements that you want to appear on your plot:
 - PLOT DATA ON** plots the measurement data trace.
 - PLOT MEM ON** plots the displayed memory trace.
 - PLOT GRAT ON** plots the graticule and the reference line.
 - PLOT TEXT ON** plots the displayed text (marker values and softkey labels not included).
 - PLOT MKR ON** plots the displayed markers, and marker values.



pg6150d

Figure 4-1. Plot Components Available through Definition

3. Press **AUTO-FEED** until the correct choice appears:
 - Choose **AUTO-FEED ON** if you want a “page eject” sent to the plotter or HPGL compatible printer after each time you press **PLOT**.
 - Choose **AUTO-FEED OFF** if you want multiple plots on the same sheet of paper.

Note

The peripheral ignores **AUTO-FEED ON** when you are plotting to a quadrant.

4. Press **MORE** and select the plot element where you want to change the pen number. For example, **PEN NUM DATA** and then modify

the pen number. The pen number selects the color if you are plotting to an HPGL/2 compatible color printer.

Press **[x1]** after each modification.

**Table 4-1.
Default Pen Numbers
and Corresponding Colors**

| Pen Number | Color |
|------------|---------|
| 0 | white |
| 1 | cyan |
| 2 | magenta |
| 3 | blue |
| 4 | yellow |
| 5 | green |
| 6 | red |
| 7 | black |

Table 4-2. Default Pen Numbers for Plot Elements

| Corresponding Key | Plot Element | Channel
1
Pen
Numbers | Channel
2
Pen
Numbers |
|--------------------------|------------------------------|--------------------------------|--------------------------------|
| PEN NUM DATA | Measurement Data Trace | 2 | 3 |
| PEN NUM MEMORY | Displayed Memory Trace | 5 | 6 |
| PEN NUM GRATICULE | Graticule and Reference Line | 1 | 1 |
| PEN NUM TEXT | Displayed Text | 7 | 7 |
| PEN NUM MARKER | Displayed Markers and Values | 7 | 7 |

Note

You can set all the print elements to black for a plot in black and white.


You must define the pen numbers for each measurement channel (channel 1 and channel 2).

5. Press **MORE** and select each plot element line type that you want to modify.

- Select **LINE TYPE DATA** to modify the line type for the data trace. Then enter the new line type, followed by **(x1)**.
- Select **LINE TYPE MEMORY** to modify the line type for the memory trace. Then enter the new line type, followed by **(x1)**.

Table 4-3. Default Line Types for Plot Elements

| Plot Elements | Channel 1
Line Type Numbers | Channel 2
Line Type Numbers |
|---------------|--------------------------------|--------------------------------|
| Data Trace | 7 | 7 |
| Memory Trace | 7 | 7 |



pg9135d


Figure 4-2. Line Types Available

Note

You should set the parameter between 0 and 7; a parameter in this range sets the line type as shown in Figure 4-2. A parameter in the range of 8 to 10 also specifies a solid line.

You must define the line types for each measurement channel (channel 1 and channel 2).

6. Press **SCALE PLOT** until the selection appears that you want.
- Choose **SCALE PLOT [FULL]** if you want the normal scale selection for plotting. This includes space for all display annotations such as marker values and stimulus values. The entire analyzer display fits within the defined boundaries of P1 and P2 on the plotter, while maintaining the exact same aspect ratio as the display.
 - Choose **SCALE PLOT [GRATE]** if you want the outer limits of the graticule to correspond to the defined P1 and P2 scaling point on the plotter. (Intended for plotting on preprinted rectangular or polar forms.



pg6157d

Figure 4-3. Locations of P1 and P2

7. Press **PLOT SPEED** until the plot speed appears that you want.
- Choose **PLOT SPEED [FAST]** for normal plotting.
 - Choose **PLOT SPEED [SLOW]** for plotting directly on transparencies: the slower speed provides a more consistent line width.

To Reset the Plotting Parameters to Default Values

Press **(COPY) DEFINE PLOT MORE MORE**
DEFAULT PLOT SETUP.

Table 4-4. Plotting Parameter Default Values

| Plotting Parameter | Default |
|---------------------|----------------------|
| Select Quadrant | Full page |
| Auto Feed | ON |
| Define Plot | All plot elements on |
| Plot Scale | Full |
| Plot Speed | Fast |
| Line Type | 7 (solid line) |
| Pen Numbers | |
| Channel 1 Data | 2 |
| Channel 2 Data | 3 |
| Channel 1 Memory | 5 |
| Channel 2 Memory | 6 |
| Channel 1 Graticule | 1 |
| Channel 2 Graticule | 1 |
| Channel 1 Text | 7 |
| Channel 2 Text | 7 |
| Channel 1 Marker | 7 |
| Channel 2 Marker | 7 |

Aborting a Print or Plot Process

1. Press the **LOCAL** key.
2. If your peripheral is not responding, press **LOCAL** again.

Saving an Instrument State

Places Where You Can Save

- analyzer internal memory
- floppy disk using the analyzer's internal disk drive
- floppy disk using an external disk drive

What You Can Save to the Analyzer's Internal Memory

You can save instrument states in the analyzer internal memory, along with the following list of analyzer settings. The default filenames are REG(0-32).

- active measurement calibration
- displayed memory trace
- active power meter calibration
- print/plot definitions
- measurement parameters
 - frequency range
 - number of points
 - sweep time
 - output power
 - sweep type
 - measurement type

Note

When the ac line power is switched off, the internal memory uses a battery. The data retention time with the 3 V, 1.2 Ah battery is as follows:

| | |
|----------------------|------------------------------|
| Temperature at 70 °C |250 days (0.68 year) |
| Temperature at 40 °C |1244 days (3.4 years) |
| Temperature at 25 °C |11904 days (32.6 years) |

typical

What You Can Save to a Floppy Disk

You can save an instrument state and/or measurement results to a disk. The default filenames are FILEn, where n gets incremented by one each time a file with a default name is added to the directory. The default filenames for data only files are DATAn, where the first n is incremented by one each time a file with a default name is added to the directory. The second n is the channel where the measurement was made. When you save a file to disk, you can choose to save some or all of the following:

- all settings listed above for internal memory
- displayed measurement data trace
- displayed user graphics
- data only

Caution

DO NOT use single-sided floppy disks in the analyzer disk drive.

To Save an Instrument State

You can save up to 32 files in the analyzer internal memory. The number of register files that the analyzer allows you to save depends on the size of associated error-correction sets, memory traces, and power meter calibrations. Refer to the “Preset State and Memory Allocation” chapter for further information.

1. Press **SAVE RECALL** **SELECT DISK** and select one of the storage devices:
 - INTERNAL MEMORY**
 - INTERNAL DISK**
 - EXTERNAL DISK**
2. Press **SAVE RECALL** **SAVE STATE**.

The analyzer saves the state in the next available register, if you are saving to internal memory, or saves the state to disk.

Note

If you have saved enough files that you have used all the default names (FILE0 - FILE9), you must do one of the following:

- rename an existing file
 - re-save a file
 - delete an existing file
-


To Save Measurement Results

Note You can only save measurement data to a disk. The analyzer internal memory can only store instrument states and memory traces.

The analyzer stores data in arrays along the processing flow of numerical data, from IF detection to display. These arrays are points in the flow path where data is accessible, usually via HP-IB. You can choose from three different arrays which vary in modification flexibility when they're recalled.

| Define Save | Modification Flexibility
During Recall |
|----------------|---|
| Raw Data Array | Most |
| Data Array | Medium |
| Format Array | Least |

You can also save data-only. This is saved to disk with default filenames DATA0D1 to DATA9D1, for channel 1, or DATA0D2 to DATA9D2, for channel 2. However, these files are not instrument states and cannot be recalled.



pg624d

Figure 4-4. Data Processing Flow Diagram

1. If you want to title the displayed measurement, refer to "Titling the Displayed Measurement," located in the "Printing, Plotting, and Saving Measurement Results" chapter of the *HP 8753D Network Analyzer User's Guide*.
2. Press **SAVE RECALL** **SELECT DISK**.
3. Choose one of the following disk drives:
 - INTERNAL DISK**
 - EXTERNAL DISK**
4. Press **SAVE RECALL** **DEFINE DISK-SAVE**.
5. Define the save by selecting one of the following choices:
 - DATA ARRAY ON**
 - RAW ARRAY ON**
 - FORMAT ARRAY ON**
 - GRAPHICS ON**
 - DATA ONLY ON**

Note

If you select **DATA ONLY ON**, you cannot recall and display the file contents on the analyzer. This type of data is intended for computer manipulation.

6. Choose the type of format you want:

- Choose **SAVE USING BINARY** for all applications except CITIFILE or CAE applications.
- Choose **SAVE USING ASCII** for CITIFILE and CAE applications or when you want to import the information into a spread sheet format.

7. Press **RETURN SAVE STATE**.

Recalling an Instrument State

1. Press **SAVE RECALL SELECT DISK**.

2. Choose from the following storage devices:

- INTERNAL MEMORY**
- INTERNAL DISK**
- EXTERNAL DISK**

3. Press the **↓** repeatedly until the name of the file that you want to recall is high-lighted.

4. Press **RETURN RECALL STATE**.

Optimizing Measurement Results

Increasing Measurement Accuracy

Connector Repeatability

- inspect the connectors
- clean the connectors
- gauge the connectors
- use correct connection techniques. See chapter 2, Table 2-1.

Interconnecting Cables

- inspect for lossy cables
- inspect for damaged cable connectors
- practice good connector care techniques
- minimize cable position changes between error-correction and measurements

Temperature Drift

- use a temperature-controlled environment
- ensure the temperature stability of the calibration devices
- avoid handling the calibration devices unnecessarily during calibration
- ensure the ambient temperature is $\pm 1^\circ$ of measurement calibration temperature

Frequency Drift

- override the internal crystal with a high-stability external source, frequency standard, or use the internal frequency standard.

Performance Verification

- perform a measurement verification at least once per year

Reference Plane and Port Extensions

Use the port extension feature to compensate for the phase shift of an extended measurement reference plane, due to such additions as cables, adapters, and fixtures, after completing an error-correction procedure (or when there is no active correction).

Press **CAL** **MORE PORT EXTENSIONS** **EXTENSIONS ON**. Then enter the delay to the reference plane.

Table 5-1.
Differences between PORT EXTENSIONS and
ELECTRICAL DELAY

| | PORT EXTENSIONS | ELECTRICAL DELAY |
|--------------------------------|--|--|
| Main Effect | The end of a cable becomes the test port plane for all S-parameter measurements. | Compensates for the electrical length of a cable.

Set the cable's electrical length x 1 for transmission.

Set the cable's electrical length x 2 for reflection |
| Measurements Affected | All S-parameters. | Only the currently selected S-parameter. |
| Electrical Compensation | Intelligently compensates for 1 times or 2 times the cable's electrical delay, depending on which S-parameter is computed. | Only compensates as necessary for the currently selected S-parameter. |

Measurement Error-Correction

Conditions Where Error-Correction is Suggested

- You are adapting to a different connector type or impedance.
- You are connecting a cable between the test device and an analyzer test port.
- You are connecting any attenuator or other such device on the input or output of the test device.

Table 5-2.
Purpose and Use of Different Error Correction Procedures

| Correction Procedure | Corresponding Measurement | Errors Corrected | Standard Devices |
|--------------------------|--|--|---|
| Response | Transmission or reflection measurement when the highest accuracy is not required. | Frequency response | Thru for transmission, open or short for reflection |
| Response & isolation | Transmission of high insertion loss devices or reflection of high return loss devices. Not as accurate as 1-port or 2-port correction. | Frequency response plus isolation in transmission or directivity in reflection | Same as response plus isolation standard (load) |
| S_{11} 1-port | Reflection of any one-port device or well terminated two-port device. | Directivity, source match, frequency response. | Short and open and load |
| S_{22} 1-port | Reflection of any one-port device or well terminated two-port device. | Directivity, source match, frequency response. | Short and open and load |
| Full 2-port ¹ | Transmission or reflection of highest accuracy for two-port devices. | Directivity, source match, load match, isolation, frequency response, forward and reverse. | Short and open and load and thru (2 loads for isolation) |
| TRL* /LRM* | Transmission or reflection when highest accuracy is not required. | Directivity, isolation, frequency response (forward and reverse) | Thru, reflect, line, or line, reflect, match, or thru, reflect, match |

¹ One-path, 2-port error correction is a variation of full 2-port that requires reversing the test device between forward and reverse measurements. Since the standard instrument does this with its internal switch, full 2-port is recommended because it is more convenient and more accurate. If the instrument should be used in a configuration where the incident/reflected signal separation device is external to it, then one-path 2-port would be useful.

Power Meter Measurement Calibration

Table 5-3.
Typical Power Meter Calibration Sweep Speed and Accuracy

| Power Desired at Test Port (dBm) | Number of Readings | Sweep Time (seconds) ¹ | Typical Accuracy (dB) ² |
|----------------------------------|--------------------|-----------------------------------|------------------------------------|
| +5 | 1 | 33 | ±0.7 |
| | 2 | 64 | ±0.2 |
| | 3 | 95 | ±0.1 |
| -15 | 1 | 48 | ±0.7 |
| | 2 | 92 | ±0.2 |
| | 3 | 123 | ±0.1 |
| -30 | 1 | 194 | ±0.7 |
| | 2 | 360 | ±0.2 |
| | 3 | 447 | ±0.1 |

1 Sweep speed applies to every sweep in continuous correction mode, and to the first sweep in sample-and-sweep mode. Subsequent sweeps in sample-and-sweep mode will be much faster.

2 The accuracy values were derived by combining the accuracy of the power meter and linearity of the analyzer's internal source, as well as the mismatch uncertainty associated with the power sensor.

Note

Loss of Power Calibration Data

The power correction data will be lost if any of the following circumstances exists.

- If you switch off the analyzer ac power and you haven't saved the correction in an internal register.
- If you change the sweep type (linear, log, list, CW, power) when the power meter correction is activated.
- If you change the frequency when the sweep type is in log or list mode.
- If you press **PRESET** and you haven't saved the correction in an internal register.

Increasing Sweep Speed

Decrease the Frequency Span

1. To see the band switch points (steps), press:

```
(SYSTEM) SERVICE MENU ANALOG BUS ON
(MEAS) ANALOG IN (29) (x1)
(FORMAT) MORE REAL
(SCALE REF) AUTO SCALE
```

2. Enter the measurement frequency span of the device under test.
Autoscale and modify the frequency span as appropriate.

Set the Auto Sweep Time Mode

- Press (MENU) SWEEP TIME (0) (x1).

Widen the System Bandwidth

1. Press **AVG** **IF BW**.
2. Set the IF bandwidth to change the sweep time.

| IF BW | Sweep Time (Seconds) ¹ | |
|---------|-----------------------------------|--------------|
| | Full Span | Narrow Sweep |
| 3000 Hz | 0.44 | 0.18 |
| 1000 Hz | 0.5 | 0.33 |
| 300 Hz | 0.95 | 0.76 |
| 100 Hz | 2.24 | 2.07 |
| 30 Hz | 7.75 | 7.14 |
| 10 Hz | 21.93 | 21.52 |

¹ The listed sweep times correspond to the analyzer being set to a preset state for the full span, and 900 MHz to 1 GHz for the narrow span.

Reduce the Averaging Factor

1. Press **AVG** **AVG FACTOR**.
2. Enter an averaging factor that is less than the value displayed on the analyzer screen and press **x1**.

Reduce the Number of Measurement Points

1. Press **MENU** **NUMBER OF POINTS**.
2. Enter a number of points that is less than the value displayed on the analyzer screen and press **x1**.

| Number of Points | Sweep Time (Seconds) ¹ | | | |
|------------------|-----------------------------------|----------|-------------|------|
| | Full Span | | Narrow Span | |
| | LIN | LIST/LOG | LIN | LIST |
| 51 | 0.35 | 0.57 | 0.09 | 0.25 |
| 101 | 0.39 | 0.77 | 0.12 | 0.43 |
| 201 | 0.43 | 1.11 | 0.17 | 0.78 |
| 401 | 0.49 | 1.73 | 0.27 | 1.33 |
| 801 | 0.69 | 3.04 | 0.47 | 2.64 |
| 1601 | 1.09 | 5.7 | 0.87 | 5.3 |

¹ The listed sweep times correspond to the analyzer being set to a preset state, with a 6 GHz span. A 3 GHz span would have faster sweep times.

Set the Sweep Type

1. Press **MENU** **SWEEP TYPE MENU**.
2. Select the sweep type:
 - LIN FREQ**
 - LIST FREQ**
 - LOG FREQ**

View a Single Measurement Channel

1. Press **DISPLAY** **DUAL CHAN OFF**.
2. Press **CHAN 1** and **CHAN 2** to alternately view the two measurement channels.

Activate Chop Sweep Mode

- Press **CAL** **MORE CHOP A** and **B**.

Increasing Dynamic Range

Increase the Test Port Input Power

Press **MENU** **POWER** and enter the new source power level, followed by **(x1)**.

Caution **TEST PORT INPUT DAMAGE LEVEL: +26 dBm**

Reduce the Receiver Noise Floor

Change System Bandwidth

Each tenfold reduction in IF (receiver) bandwidth lowers the noise floor by 10 dB.

1. Press **(AVG)** **IF BW**.
2. Enter the bandwidth value that you want, followed by **(x1)**.

Change Measurement Averaging

1. Press **(AVG)** **AVERAGING FACTOR**.
2. Enter a value followed by **(x1)**.
3. Press **AVERAGING ON**.

Reducing Trace Noise

Activate Averaging

1. Press **(AVG)** **AVERAGING FACTOR**.
2. Enter a value followed by **(x1)**.
3. Press **AVERAGING ON**.

Change System Bandwidth

1. Press **AVG** **IF BW**.
2. Enter the IF bandwidth value that you want, followed by **x1**.

Reducing Receiver Crosstalk


Set the alternate sweep, press **CAL** **MORE** **ALTERNATE A AND B**.

Application and Operation Concepts

How the HP 8753D Works

Network analyzers measure the reflection and transmission characteristics of devices and networks. A network analyzer test system consists of the following:

- source
- signal-separation devices
- receiver
- display



pg636d

Figure 6-1. Simplified Block Diagram of the Network Analyzer System

Understanding the power ranges

The built-in synthesized source contains a programmable step attenuator that allows you to directly and accurately set power levels in eight different power ranges. Each range has a total span of 25 dB. The eight ranges cover the instrument's full operating range from +10 dBm to -85 dBm (see Figure 6-2). A power range can be selected either manually or automatically.

Automatic mode

If you select **POWER RANGE AUTO**, you can enter any power level within the total operating range of the instrument and the source attenuator will automatically switch to the corresponding range.

Manual mode

If you select **POWER RANGE MAN**, you must first manually select the power range that corresponds to the power level you want to use. Then press the **POWER RANGES** softkey and select one of the eight available ranges.


When a calibration is completed and turned on, the power range selection is switched from auto to manual mode, and **PERM** appears on the display.

Note

A measurement calibration is valid *only* for the power level at which it was performed; but you can change the power within a range and still maintain nearly full accuracy.

If you decide to switch power ranges, the calibration is no longer valid and specified accuracy is forfeited. However, the analyzer leaves the correction *on* even though it's invalid.

The annotation **C?** will be displayed whenever you change the power after calibration.



pg6154d

Figure 6-2. Power Range Transitions in the Automatic Mode

Power coupling options

Channel coupling

CHAN POWER [COUPLED] toggles between coupled and uncoupled channel power. With the channel power coupled, the power level is the same on each channel. With the channel power uncoupled, you can set different power levels for each channel.

Test port coupling

PORT POWER [COUPLED] toggles between coupled and uncoupled test ports. With the test ports coupled, the power level is the same at

each port. With the ports uncoupled, you can set a different power level at each port.

Channel stimulus coupling

COUPLED CH on OFF toggles the channel coupling of stimulus values.

In the stimulus coupled mode, both channels have the following parameters coupled:

- frequency
- number of points
- source power
- number of groups
- power slope
- IF bandwidth
- sweep time
- trigger type
- gating parameters
- sweep type
- harmonic measurement
- power meter calibration

Minimum sweep time

The minimum sweep time is dependent on several factors.

- the number of points selected
- IF bandwidth
- sweep-to-sweep averaging in dual channel display mode
- smoothing
- limit test
- error correction
- trace math
- marker statistics
- time domain
- type of sweep

Table 6-1. Minimum Sweep Time (in seconds)

| Number of Points | IF Bandwidth | | | |
|------------------|--------------|------------|------------|------------|
| | 3000 Hz | 1000 Hz | 300 Hz | 10 Hz |
| 11 | 0.0055 sec. | 0.012 sec. | 0.037 sec. | 1.14 sec. |
| 51 | 0.0255 sec. | 0.060 sec. | 0.172 sec. | 5.30 sec. |
| 101 | 0.0505 sec. | 0.120 sec. | 0.341 sec. | 10.5 sec. |
| 201 | 0.1005 sec. | 0.239 sec. | 0.679 sec. | 20.9 sec. |
| 401 | 0.2005 sec. | 0.476 sec. | 1.355 sec. | 41.7 sec. |
| 801 | 0.4005 sec. | 0.951 sec. | 2.701 sec. | 83.3 sec. |
| 1601 | 0.8005 sec. | 1.901 sec. | 5.411 sec. | 166.5 sec. |

Alternate and Chop Sweep Modes

ALTERNATE A and B measures only one input per frequency sweep, in order to reduce spurious signals. Thus, this mode optimizes the dynamic range.

CHOP A and B measures both inputs A and B during each sweep.

To access the **ALTERNATE A and B** and **CHOP A and B** softkeys press **CAL MORE**. Figure 6-3 shows the *alternate* sweep mode (bold trace) overlaying the *chop* sweep mode in a band-pass filter measurement. Note the difference in the noise levels between the two modes.




Figure 6-3. Alternate and Chop Sweeps Overlaid



Understanding S-parameters

S-parameters (scattering parameters) are a convention used to characterize the way a device modifies signal flow.

S-parameters are always a ratio of two complex (magnitude and phase) quantities. S-parameter notation identifies these quantities using the numbering convention:

S out in

where the first number (out) refers to the test-device port where the signal is emerging and the second number (in) is the test-device port where the signal is incident. For example, the S-parameter S_{21} identifies the measurement as the complex ratio of the signal emerging at the test device's port 2 to the signal incident at the test device's port 1.



pg639d

Figure 6-4. S-Parameters of a Two-Port Device

S-parameters are exactly equivalent to the more common description terms below, requiring only that the measurements be taken with all test device ports properly terminated.

| S-Parameter | Definition | Test Set Description | Direction |
|-------------|---------------------------------|-------------------------------|-----------|
| S_{11} | $\frac{b_1}{a_1} \quad a_2 = 0$ | Input reflection coefficient | FWD |
| S_{21} | $\frac{b_2}{a_1} \quad a_2 = 0$ | Forward gain | FWD |
| S_{12} | $\frac{b_1}{a_2} \quad a_1 = 0$ | Reverse gain | REV |
| S_{22} | $\frac{b_2}{a_2} \quad a_1 = 0$ | Output reflection coefficient | REV |

What is Measurement Calibration?

Measurement calibration is an accuracy enhancement procedure that effectively removes the system errors that cause uncertainty in measuring a test device. It measures known standard devices, and uses the results of these measurements to characterize the system.

What is accuracy enhancement?

A perfect measurement system would have infinite dynamic range, isolation, and directivity characteristics, no impedance mismatches in any part of the test setup, and flat frequency response. In any high frequency measurement there are measurement errors associated with the system that contribute uncertainty to the results. Parts of the measurement setup such as interconnecting cables and signal-separation devices (as well as the analyzer itself) all introduce variations in magnitude and phase that can mask the actual performance of the test device. Vector accuracy enhancement, also known as measurement calibration or error correction, provides the means to simulate a nearly perfect measurement system.

What causes measurement errors?

Network analysis measurement errors can be separated into systematic, random, and drift errors.

Correctable systematic errors are the repeatable errors that the system can measure. These are errors due to mismatch and leakage in the test setup, isolation between the reference and test signal paths, and system frequency response.

The system cannot measure and correct for the non-repeatable random and drift errors. These errors affect both reflection and transmission measurements. Random errors are measurement variations due to noise and connector repeatability. Drift errors include frequency drift, temperature drift, and other physical changes in the test setup between calibration and measurement.

The resulting measurement is the vector sum of the test device response plus all error terms.

Understanding and Using Time Domain (option 010 only)

With option 010, the analyzer can transform frequency domain data to the time domain or time domain data to the frequency domain.

The analyzer has three frequency-to-time transform modes:

Time domain bandpass mode is designed to measure band-limited devices and is the easiest mode to use. This mode simulates the time domain response to an impulse input.

Time domain low pass step mode simulates the time domain response to a step input. As in a traditional TDR measurement, the distance to the discontinuity in the test device, and the type of discontinuity (resistive, capacitive, inductive) can be determined.

Time domain low pass impulse mode simulates the time domain response to an impulse input (like the bandpass mode). Both low pass modes yield better time domain resolution for a given frequency span than does the bandpass mode. In addition, using the low pass modes you can determine the type of discontinuity.

Time domain low pass

This mode is used to simulate a traditional time domain reflectometry (TDR) measurement. It provides information to determine the type of discontinuity (resistive, capacitive, or inductive) that is present.


Table 6-2.
Minimum Frequency Ranges for Time Domain Low Pass

| Number of Points | Minimum Frequency Range |
|------------------|-------------------------|
| 3 | 30 kHz to 0.09 MHz |
| 11 | 30 kHz to 0.33 MHz |
| 26 | 30 kHz to 0.78 MHz |
| 51 | 30 kHz to 1.53 MHz |
| 101 | 30 kHz to 3.03 MHz |
| 201 | 30 kHz to 6.03 MHz |
| 401 | 30 kHz to 12.03 MHz |
| 801 | 30 kHz to 24.03 MHz |
| 1601 | 30 kHz to 48.03 MHz |

Time domain concepts

Windowing

- **Finite impulse width (or rise time).** Finite impulse width limits the ability to resolve between two closely spaced responses. The effects of the finite impulse width cannot be improved without increasing the frequency span of the measurement (see Table 6-3).



pg665d

Figure 6-5. Impulse Width, Sidelobes, and Windowing

- **Sidelobes.** The impulse sidelobes limit the dynamic range of the time domain measurement by hiding low-level responses within the sidelobes of higher level responses. The effects of sidelobes can be improved by windowing (see Table 6-3).


To select a window, press **(SYSTEM) TRANSFORM MENU WINDOW**. A menu is presented that allows the selection of three window types (see Table 6-3).

6-10 Application and Operation Concepts

Table 6-3.
Impulse Width, Sidelobe Level, and Windowing Values

| Window Type | Impulse Sidelobe Level | Low Pass Impulse Width (50%) | Step Sidelobe Level | Step Rise Time (10 - 90%) |
|-------------|------------------------|------------------------------|---------------------|---------------------------|
| Minimum | -13 dB | 0.60/Freq Span | -21 dB | 0.45/Freq Span |
| Normal | -44 dB | 0.98/Freq Span | -60 dB | 0.99/Freq Span |
| Maximum | -75 dB | 1.39/Freq Span | -70 dB | 1.48/Freq Span |

NOTE: The bandpass mode simulates an impulse stimulus. Bandpass impulse width is twice that of low pass impulse width. The bandpass impulse sidelobe levels are the same as low pass impulse sidelobe levels.




pg666d

Figure 6-6.
The Effects of Windowing on the Time Domain Responses of a Short Circuit

Gating

Gating provides the flexibility of selectively removing time domain responses. The remaining time domain responses can then be transformed back to the frequency domain.



pg692d

Figure 6-7. Sequence of Steps in Gating Operation

Selecting gate shape. Each gate has a different passband flatness, cutoff rate, and sidelobe levels.


Table 6-4. Gate Characteristics

| Gate Shape | Passband Ripple | Sidelobe Levels | Cutoff Time | Minimum Gate Span |
|-------------------|-----------------|-----------------|----------------|-------------------|
| Gate Span Minimum | ± 0.10 dB | -48 dB | 1.4/Freq Span | 2.8/Freq Span |
| Normal | ± 0.01 dB | -68 dB | 2.8/Freq Span | 5.6/Freq Span |
| Wide | ± 0.01 dB | -57 dB | 4.4/Freq Span | 8.8/Freq Span |
| Maximum | ± 0.01 dB | -70 dB | 12.7/Freq Span | 25.4/Freq Span |

Amplifier Testing

Amplifier parameters

The HP 8753D allows you to measure the transmission and reflection characteristics of many amplifiers and active devices. You can measure scalar




pg6137d

Figure 6-8. Amplifier Parameters

Mixer Testing

Mixer parameters that you can measure




pg6140d

Figure 6-9. Mixer Parameters


- Transmission characteristics include conversion loss, conversion compression, RF desensitization, group delay, and RF feedthru.
- Reflection characteristics include return loss, SWR and complex impedance.
- Characteristics of the signal at the output port include the output power, the spurious or harmonic content of the signal, and intermodulation distortion.
- Other parameters of concern are isolation terms, including LO to RF isolation and LO to IF isolation.

Up-conversion and down-conversion definition


When you choose between $RF < LO$ and $RF > LO$ in the frequency offset menus, the analyzer determines which direction the internal source must sweep in order to achieve the requested IF frequency.




Example of an Upconverter with $RF > LO$



Example of an Upconverter with $RF < LO$



Example of a Downconverter with $RF > LO$



Example of a Downconverter with $RF < LO$

pg621d

Figure 6-10. Examples of Up Converters and Down Converters

Specifications and Measurement Uncertainties

Dynamic Range

The specifications described in the table below apply to transmission measurements using 10 Hz IF BW and full 2-port correction. Dynamic range is limited by the maximum test port power and the receiver's noise floor.

Table 7-1.

| DYNAMIC RANGE | |
|--------------------|---------------|
| Frequency Range | Dynamic Range |
| 30 kHz to 300 kHz | 100 dB* |
| 300 kHz to 1.3 GHz | 110 dB† ‡ |
| 1.3 GHz to 3 GHz | 110 dB‡ |
| 3 GHz to 6 GHz | 105 dB |

* 90 dB, 30 kHz to 50 kHz
 † 100 dB, 300 kHz to 16 MHz, due to fixed spurs
 ‡ 105 dB, option 075

HP 8753D Network Analyzer Specifications

HP 8753D (50Ω) with 7 mm Test Ports

The following specifications describe the system performance of the HP 8753D network analyzer. The system hardware includes the following:

- Options:006
- Calibration kit:HP 85031B
- Cables:HP 11857D

Measurement Port Characteristics

The following tables describe the measurement port characteristics for both corrected and uncorrected HP 8753D network analyzers.

Table 7-2.

| MEASUREMENT PORT CHARACTERISTICS (CORRECTED)* | | | | |
|---|--------------------------------------|--------------------------|------------------------|----------------------|
| | Frequency Range | | | |
| | 30 kHz
to
300 kHz [†] | 300 kHz
to
1.3 GHz | 1.3 GHz
to
3 GHz | 3 GHz
to
8 GHz |
| Directivity | 55 dB | 55 dB | 51 dB | 46 dB |
| Source match | 55 dB | 51 dB | 49 dB | 43 dB |
| Load match | 55 dB | 55 dB | 51 dB | 46 dB |
| Reflection tracking | ±0.001 dB | ±0.001 dB | ±0.005 dB | ±0.020 dB |
| Transmission tracking | ±0.008 dB | ±0.006 dB | ±0.009 dB | ±0.021 dB |

* These characteristics apply for an environmental temperature of 25 ± 5 °C, with less than 1 °C deviation from the calibration temperature.

[†] Typical Performance

Table 7-3.


| MEASUREMENT PORT CHARACTERISTICS
(UNCORRECTED)* | | | | |
|--|--------------------------|--------------------------|------------------------|--------------------|
| | Frequency Range | | | |
| | 30 kHz
to
300 kHz† | 300 kHz
to
1.3 GHz | 1.3 GHz
to
3 GHz | 3 GHz
to
GHz |
| Directivity | 20 dB‡ | 35 dB | 30 dB | 25 dB |
| Source match | 18 dB§ | 16 dB | 16 dB | 14 dB |
| Load match | 20 dB§ | 18 dB | 16 dB | 14 dB |
| Reflection tracking | ±2.0 dB | ±1.5 dB | ±1.5 dB | ±2.5 dB |
| Transmission tracking | ±2.0 dB | ±1.5 dB | ±1.5 dB | ±2.5 dB |
| Crosstalk | 100 dB | 100 dB | 100 dB | 90 dB |
| * Applies at 25 ±5 °C
† Typical
§ 15 dB, 30 kHz to 50 kHz
‡ 10 dB, 30 kHz to 50 kHz | | | | |

Transmission Measurement Uncertainties

S21 MAGNITUDE UNCERTAINTY

HP8753D HP85031B Test Port Power = -2 dBm


0.3 to 1300 MHz 1.3 to 3 GHz 3 to 6 GHz





S21 PHASE UNCERTAINTY

HP8753D HP85031B Test Port Power = -2 dBm

0.3 to 1300 MHz 1.3 to 3 GHz 3 to 6 GHz



Reflection Measurement Uncertainties



Front Panel Connectors

| | |
|---------------------------------|--------------------|
| Connector Type | 7 mm precision |
| Impedance | 50 ohms (nominal) |
| Connector Conductor Depth | 0.000 to 0.003 in. |

Environmental Characteristics


Operating Conditions


| | |
|---|---------------------------------------|
| Operating Temperature | 0 ° to 55 °C |
| Error-Corrected Temperature Range | ± 1 °C of calibration temperature |
| Humidity | 5% to 95% at 40 °C (non-condensing) |
| Altitude | 0 to 4500 meters (15,000 feet) |



Non-Operating Storage Conditions


| | |
|-------------------|--|
| Temperature | -40 °C to +70 °C |
| Humidity | 0 to 90% relative at +65 °C (non-condensing) |
| Altitude | 0 to 15,240 meters (50,000 feet) |

Menu Maps
















pg630d









Key Definitions

Softkey Locations

The following table lists the softkey functions alphabetically, and the corresponding front-panel access key.

Table 9-1. Softkey Locations

| Softkey | Front-Panel Access Key |
|----------------------|------------------------|
| Δ MODE MENU | MARKER |
| Δ MODE OFF | MARKER |
| Δ REF = 1 | MARKER |
| Δ REF = 2 | MARKER |
| Δ REF = 3 | MARKER |
| Δ REF = 4 | MARKER |
| Δ REF = Δ FIXED MKR | MARKER |
| 1/5 | MEAS |
| 3.5mmC | CAL |
| 3.5mmD | CAL |
| A | MEAS |
| A/B | MEAS |
| A/R | MEAS |
| ACTIVE ENTRY | DISPLAY |
| ACTIVE MKR MAGNITUDE | DISPLAY |
| ADDRESS: 8753 | LOCAL |
| ADDRESS: CONTROLLER | LOCAL |
| ADDRESS: DISK | LOCAL |
| ADDRESS: DISK | SAVE/RECALL |
| ADDRESS: P MTR/HPIB | LOCAL |
| ADJUST DISPLAY | DISPLAY |
| ALL OFF | MARKER |
| ALL SEGS SWEEP | MENU |
| ALTERNATE A and B | CAL |
| AMPLITUDE | SYSTEM |
| AMPLITUDE OFFSET | SYSTEM |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|----------------------|------------------------|
| ANALOG IN Aux Input | MEAS |
| ARBITRARY IMPEDANCE | CAL |
| ASCII | SAVE RECALL |
| ASSERT SRQ | SEQ |
| AUTO FEED on OFF | COPY |
| AUTO SCALE | SCALE REF |
| AVERAGING FACTOR | AVG |
| AVERAGING on OFF | AVG |
| AVERAGING RESTART | AVG |
| B | MEAS |
| B/R | MEAS |
| BACKGROUND INTENSITY | DISPLAY |
| BANDPASS | SYSTEM |
| BEEP DONE ON off | DISPLAY |
| BEEP FAIL on OFF | SYSTEM |
| BEEP WARN on OFF | DISPLAY |
| BRIGHTNESS | DISPLAY |
| C0 | CAL |
| C1 | CAL |
| C2 | CAL |
| C3 | CAL |
| CAL FACTOR | CAL |
| CAL FACTOR SENSOR A | CAL |
| CAL FACTOR SENSOR B | CAL |
| CAL KIT C I | CAL |
| CAL KIT: 2.5mmC | CAL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|-------------------------|------------------------|
| CAL KIT: 3.5mmD | CAL |
| CAL KIT: 7mm | CAL |
| CAL KIT: N 50Ω | CAL |
| CAL KIT: N 75Ω | CAL |
| CALIBRATE MENU | CAL |
| CALIBRATE: NONE | CAL |
| CENTER | MENU |
| CENTER | SYSTEM |
| CH1 DATA [] | COPY |
| CH1 DATA LIMIT LN | DISPLAY |
| CH1 MEM | DISPLAY |
| CH1 MEM [] | COPY |
| CH2 DATA [] | COPY |
| CH2 DATA LIMIT LN | DISPLAY |
| CH2 MEM [] | COPY |
| CH2 MEM REF LINE | DISPLAY |
| CHAN FWR [COUPLED] | MENU |
| CHAN FWR [UNCOUPLD] | MENU |
| CHOP A and B | CAL |
| CLEAR BIT | SEQ |
| CLEAR SEQUENCE | SEQ |
| COAX | CAL |
| COLOR | DISPLAY |
| CONFIGURE EXTERNAL DISK | SAVE/RECALL |
| CONTINUE SEQUENCE | SEQ |
| CONTINUOUS | MENU |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|---------------------|---------------------------|
| CONVERSION [] | MEAS |
| CORRECTION on OFF | CAL |
| COUPLED CH on OFF | MENU |
| CW FREQ | MENU |
| CW TIME | MENU |
| D2/D1 to D2 on OFF | DISPLAY |
| DATA and MEMORY | DISPLAY |
| DATA ARRAY on OFF | SAVE RECALL |
| DATA/MEM | DISPLAY |
| DATA - MEM | DISPLAY |
| DATA → MEMORY | DISPLAY |
| DATA ONLY on OFF | SAVE RECALL |
| DECISION MAKING | SEQ |
| DECR LOOP COUNTER | SEQ |
| DEFAULT COLORS | DISPLAY |
| DEFAULT PLOT SETUP | COPY |
| DEFAULT PRINT SETUP | COPY |
| DEFINE DISK-SAVE | SAVE RECALL |
| DEFINE PLOT | COPY |
| DEFINE PRINT | COPY |
| DEFINE STANDARD | CAL |
| DELAY | FORMAT |
| DELAY/THRU | CAL |
| DELETE FILE | SAVE/RECALL |
| DELTA LIMITS | SYSTEM |
| DEMOD: OFF | SYSTEM |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|----------------------|------------------------|
| DIRECTORY SIZE (LIF) | SAVE RECALL |
| DISK UNIT NUMBER | LOCAL |
| DISK UNIT NUMBER | SAVE/RECALL |
| DISPLAY: DATA | DISPLAY |
| DISP MKRS ON OFF | MARKER |
| DO SEQUENCE | SEQ |
| DONE 1-PORT CAL | CAL |
| DONE 2-PORT CAL | CAL |
| DONE RESPONSE | CAL |
| DONE RESP ISOL'N CAL | CAL |
| DONE SEQ MODIFY | SEQ |
| DONE TRL 2-PORT | CAL |
| DOWN CONVERTER | SYSTEM |
| DUAL CHAN on OFF | DISPLAY |
| DUPLICATE SEQUENCE | SEQ |
| EACH SWEEP | CAL |
| EDIT LIMIT LINE | SYSTEM |
| EDIT LIST | MENU |
| ELECTRICAL DELAY | SCALE REF |
| EMIT BEEP | SEQ |
| END OF LABEL | DISPLAY |
| END SWEEP HIGH PULSE | SEQ |
| END SWEEP LOW PULSE | SEQ |
| ERASE TITLE | CAL |
| ERASE TITLE | DISPLAY |
| ERASE TITLE | SAVE RECALL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|---------------------|---------------------------|
| EXT SOURCE AUTO | SYSTEM |
| EXT SOURCE MANUAL | SYSTEM |
| EXT TRIG ON POINT | MENU |
| EXT TRIG ON SWEEP | MENU |
| EXTENSION INPUT A | CAL |
| EXTENSION INPUT B | CAL |
| EXTENSION PORT 1 | CAL |
| EXTENSION PORT 2 | CAL |
| EXTENSIONS on OFF | CAL |
| EXTERNAL DISK | SAVE/RECALL |
| FILETITLE FILE0 | SAVE/RECALL |
| FIXED | CAL |
| FIXED MKR AUX VALUE | MARKER |
| FIXED MKR POSITION | MARKER |
| FIXED MKR STIMULUS | MARKER |
| FIXED MKR VALUE | MARKER |
| FLAT LINE | SYSTEM |
| FORM FEED | DISPLAY |
| FORMAT ARY on OFF | SAVE/RECALL |
| FORMAT DISK | SAVE/RECALL |
| FORMAT: DOS | SAVE/RECALL |
| FORMAT EXT DISK | SAVE/RECALL |
| FORMAT INT DISK | SAVE/RECALL |
| FORMAT INT MEMORY | SAVE/RECALL |
| FORMAT: LIF | SAVE/RECALL |
| FREE OFF'S MENU | SYSTEM |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|-----------------------|------------------------|
| FREQ OFFS on OFF | SYSTEM |
| FREQUENCY | CAL |
| FREQUENCY BLANK | DISPLAY |
| FREQUENCY: CW | SYSTEM |
| FREQUENCY: SWEEP | SYSTEM |
| FULL 2-PORT | CAL |
| FULL PAGE | COPY |
| FWD ISOL'N ISOL'N STD | CAL |
| FWD MATCH | CAL |
| FWD MATCH THRU | CAL |
| FWD TRANS | CAL |
| FWD TRANS THRU | CAL |
| GSB MKR | MARKER |
| GATE: CENTER | SYSTEM |
| GATE on OFF | SYSTEM |
| GATE SHAPE | SYSTEM |
| GATE SHAPE MAXIMUM | SYSTEM |
| GATE SHAPE MINIMUM | SYSTEM |
| GATE SHAPE NORMAL | SYSTEM |
| GATE: SPAN | SYSTEM |
| GATE: START | SYSTEM |
| GATE: STOP | SYSTEM |
| GOSUB SEQUENCE | SEQ |
| GRAPHICS on OFF | SAVE RECALL |
| GRATICULE [] | COPY |
| GRATICULE TEXT | DISPLAY |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|-----------------------|------------------------|
| HARMONIC MEAS | SYSTEM |
| HARMONIC OFF | SYSTEM |
| HARMONIC SECOND | SYSTEM |
| HARMONIC THIRD | SYSTEM |
| HOLD | MENU |
| HF-IB DIAG on/off | LOCAL |
| IF BW [] | AVG |
| IF LIMIT TEST FAIL | SEQ |
| IF LIMIT TEST PASS | SEQ |
| IF LOOP COUNTER = 0 | SEQ |
| IF LOOP < > COUNTER 0 | SEQ |
| IMAGINARY | FORMAT |
| INCR LOOP COUNTER | SEQ |
| INIT DISK? YES | SAVE RECALL |
| INITIALIZE DISK | SAVE RECALL |
| INPUT PORTS | MEAS |
| INSTRUMENT MODE | SYSTEM |
| INTENSITY | DISPLAY |
| INTERNAL DISK | SAVE/RECALL |
| INTERNAL MEMORY | SAVE/RECALL |
| INTERPOL on/off | CAL |
| ISOLATION | CAL |
| ISOLATION DONE | CAL |
| ISOL'N STD | CAL |
| ISTATE CONTENTS | SAVE/RECALL |
| KIT DONE (MODIFIED) | CAL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|--------------------|---------------------------|
| LABEL CLASS | CAL |
| LABEL CLASS DONE | CAL |
| LABEL KIT | CAL |
| LABEL STD | CAL |
| LEFT LOWER | COPY |
| LEFT UPPER | COPY |
| LIMIT LINE OFFSETS | SYSTEM |
| LIMIT LINE on OFF | SYSTEM |
| LIMIT MENU | SYSTEM |
| LIMIT TEST on OFF | SYSTEM |
| LIMIT TEST RESULT | DISPLAY |
| LIMIT TYPE | SYSTEM |
| LIN FREQ | MENU |
| LIN MAG | FORMAT |
| LIST FREQ | MENU |
| LIN MKR | MARKER |
| LINE TYPE DATA | COPY |
| LINE TYPE MEMORY | COPY |
| LIST | COPY |
| LO CONTROL on OFF | SYSTEM |
| LO MENU | SYSTEM |
| LO SOURCE ADDRESS | SYSTEM |
| LOAD | CAL |
| LOAD SEQ FROM DISK | SEQ |
| LOG FREQ | MENU |
| LOG MAG | FORMAT |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|---------------------|------------------------|
| LOG MKR | MARKER |
| LOOP COUNTER | SEQ |
| LOOP COUNTER | DISPLAY |
| LOSS | CAL |
| LOSS/SENSR LISTS | CAL |
| LOWER LIMIT | SYSTEM |
| LOW PASS IMPULSE | SYSTEM |
| LOW PASS STEP | SYSTEM |
| MANUAL TRG ON POINT | MENU |
| MARKER -> AMP. DFS. | SYSTEM |
| MARKER -> CENTER | MARKER FCTN |
| MARKER -> CW | SEQ |
| MARKER -> DELAY | MARKER FCTN |
| MARKER -> DELAY | SCALE REF |
| MARKER -> MIDDLE | SYSTEM |
| MARKER -> REFERENCE | MARKER FCTN |
| MARKER -> REFERENCE | SCALE REF |
| MARKER -> SPAN | MARKER FCTN |
| MARKER -> START | MARKER FCTN |
| MARKER -> STIMULUS | SYSTEM |
| MARKER -> STOP | MARKER FCTN |
| MARKER 1 | MARKER |
| MARKER 2 | MARKER |
| MARKER 3 | MARKER |
| MARKER 4 | MARKER |
| MARKER MODE MENU | MARKER |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|---------------------|---------------------------|
| MARKERS: CONTINUOUS | MARKER |
| MARKERS: COUPLED | MARKER |
| MARKERS: DISCRETE | MARKER |
| MARKERS: UNCOUPLED | MARKER |
| MAX | MARKER FCTN |
| MAXIMUM FREQUENCY | CAL |
| MEASURE RESTART | MENU |
| MEMORY | DISPLAY |
| MIDDLE VALUE | SYSTEM |
| MIN | MARKER FCTN |
| MINIMUM | SYSTEM |
| MINIMUM FREQUENCY | CAL |
| MKR SEARCH [I] | MARKER FCTN |
| MKR ZERO | MARKER |
| MODIFY [I] | CAL |
| MODIFY COLORS | DISPLAY |
| N 50Ω | CAL |
| N 75Ω | CAL |
| NETWORK ANALYZER | SYSTEM |
| NEW SEQ/MODIFY SEQ | SEQ |
| NEWLINE | DISPLAY |
| NORMAL | SYSTEM |
| NUMBER OF GROUPS | MENU |
| NUMBER OF POINTS | MENU |
| NUMBER OF READINGS | CAL |
| OFFSET DELAY | CAL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|----------------------|---------------------------|
| OFFSET LOSS | CAL |
| OFFSET Z0 | CAL |
| OMIT ISOLATION | CAL |
| ONE-PATH 2-PORT | CAL |
| ONE SWEEP | CAL |
| OPEN | CAL |
| P MTR/HPIB TO TITLE | SEQ |
| PARALLEL | LOCAL |
| PARALLEL [] | LOCAL |
| PARALLEL OUT ALL | SEQ |
| PARALL IN BIT NUMBER | SEQ |
| PARALL IN IF BIT H | SEQ |
| PARALL IN IF BIT L | SEQ |
| PAUSE TO SELECT | SEQ |
| PEN NUM DATA | COPY |
| PEN NUM GRATICULE | COPY |
| PEN NUM MARKER | COPY |
| PEN NUM MEMORY | COPY |
| PEN NUM TEXT | COPY |
| PERIPHERAL HPIB ADDR | SEQ |
| PHASE | FORMAT |
| PHASE | SYSTEM |
| PHASE OFFSET | SCALE REF |
| PLOT | COPY |
| PLOT DATA ON off | COPY |
| PLOT GRAT ON off | COPY |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|----------------------|------------------------|
| PLOT MEM ON off | COPY |
| PLOT MKR ON off | COPY |
| PLOT SPEED [] | COPY |
| PLOT TEXT ON off | COPY |
| PLOTTER BAUD RATE | LOCAL |
| PLOTTER FORM FEED | COPY |
| PLOTTER PORT | LOCAL |
| PLTR PORT HP1B | LOCAL |
| PLTR TYPE [] | LOCAL |
| POLAR | FORMAT |
| POLAR MKR MENU | MARKER |
| PORT EXTENSIONS | CAL |
| PORT PWR [COUPLED] | MENU |
| PORT PWR [UNCOUPLED] | MENU |
| POWER | MENU |
| POWER: FIXED | SYSTEM |
| POWER LOSS | CAL |
| POWER MTR [] | LOCAL |
| POWER RANGES | MENU |
| POWER SWEEP | MENU |
| PRESET: FACTORY | PRESET |
| PRESET: USER | PRESET |
| PRINT: COLOR | COPY |
| PRINT COLORS | COPY |
| PRINT: MONOCHROME | COPY |
| PRINT MONOCHROME | COPY |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|--------------------|------------------------|
| PRINT SEQUENCE | SEQ |
| PRINTER BAUD RATE | LOCAL |
| PRINTER FORM FEED | COPY |
| PRINTER PORT | LOCAL |
| PRNTR PORT HP/IB | LOCAL |
| PRNTR TYPE [J] | LOCAL |
| PWR LOSS on OFF | CAL |
| PWR RANGE AUTO man | MENU |
| PWRMTR CAL [J] | CAL |
| PWRMTR CAL [OFF] | CAL |
| R | MEAS |
| R+j% MKR | MARKER |
| RANGE 0 -15 TO +10 | MENU |
| RANGE 1 -25 TO 0 | MENU |
| RANGE 2 -35 TO -10 | MENU |
| RANGE 3 -45 TO -20 | MENU |
| RANGE 4 -55 TO -30 | MENU |
| RANGE 5 -65 TO -40 | MENU |
| RANGE 6 -75 TO -50 | MENU |
| RANGE 7 -85 TO -60 | MENU |
| RAW ARRAY on OFF | SAVE/RECALL |
| Re/In MKR | MARKER |
| REAL | FORMAT |
| RECALL COLDRS | DISPLAY |
| RECALL KEYS on OFF | SAVE/RECALL |
| RECALL REG1 | SAVE/RECALL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|-----------------------|------------------------|
| RECALL REG2 | SAVE/RECALL |
| RECALL REG3 | SAVE/RECALL |
| RECALL REG4 | SAVE/RECALL |
| RECALL REG5 | SAVE/RECALL |
| RECALL REG6 | SAVE/RECALL |
| RECALL REG7 | SAVE/RECALL |
| RECALL STATE | SAVE/RECALL |
| REFERENCE POSITION | SCALE REF |
| REFERENCE VALUE | SCALE REF |
| Ref1: FWD S11 (A/R) | MEAS |
| Ref1: REV S22 (B/R) | MEAS |
| REFLECT AND LINE | CAL |
| REFLECTION | CAL |
| RE-SAVE STATE | SAVE/RECALL |
| RESET COLOR | DISPLAY |
| RESPONSE | CAL |
| RESPONSE & ISOL'N | CAL |
| RESUME CAL SEQUENCE | CAL |
| REV ISOL'N ISOL'N STD | CAL |
| REV MATCH | CAL |
| REV MATCH THRU | CAL |
| REV TRANS | CAL |
| REV TRANS THRU | CAL |
| RF > LO | SYSTEM |
| RF < LO | SYSTEM |
| RIGHT LOWER | COPY |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|-------------------|------------------------|
| RIGHT UPPER | COPY |
| ROUND SECONDS | SYSTEM |
| S PARAMETERS | MEAS |
| S11 I-PORT | CAL |
| S11B RE FW MICH | CAL |
| S11B LN FW MICH | CAL |
| S11C LN FW TRAN | CAL |
| S22 I-PORT | CAL |
| S22A RE RV MICH | CAL |
| S22B LN RV MICH | CAL |
| S22C LN RV TRAN | CAL |
| SAVE COLORS | DISPLAY |
| SAVE USER KIT | CAL |
| SAVE USING BINARY | SAVE/RECALL |
| SCALE/DIV | SCALE REF |
| SCALE PLOT [] | COPY |
| SEARCH LEFT | MARKER FCTN |
| SEARCH: MAX | MARKER FCTN |
| SEARCH: MIN | MARKER FCTN |
| SEARCH: OFF | MARKER FCTN |
| SEARCH RIGHT | MARKER FCTN |
| SECOND | SYSTEM |
| SEGMENT | CAL |
| SEGMENT | SYSTEM |
| SEGMENT: CENTER | MENU |
| SEGMENT: SPAN | MENU |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|-------------------|---------------------------|
| SEGMENT: START | MENU |
| SEGMENT: STOP | MENU |
| SEL QARD [] | COPY |
| SEQUENCE 1 SEQ1 | SEQ |
| SEQUENCE 2 SEQ2 | SEQ |
| SEQUENCE 3 SEQ3 | SEQ |
| SEQUENCE 4 SEQ4 | SEQ |
| SEQUENCE 5 SEQ5 | SEQ |
| SEQUENCE 6 SEQ6 | SEQ |
| SET ADDRESSES | LOCAL |
| SET BIT | SEQ |
| SET CLOCK | SYSTEM |
| SET DAY | SYSTEM |
| SET FREQ LOW PASS | SYSTEM |
| SET HOUR | SYSTEM |
| SET MINUTES | SYSTEM |
| SET MONTH | SYSTEM |
| SET YEAR | SYSTEM |
| SET Z0 | CAL |
| SHORT | CAL |
| SINGLE | MENU |
| SINGLE POINT | SYSTEM |
| SINGLE SEG SWEEP | MENU |
| SLIDING | CAL |
| SLOPE | MENU |
| SLOPE on OFF | MENU |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|---------------------|------------------------|
| SLOPING LINE | SYSTEM |
| SMITH CHART | FORMAT |
| SMITH MKR MENU | MARKER |
| SMOOTHING APERTURE | AVG |
| SMOOTHING on OFF | AVG |
| SOURCE PWR ON off | MENU |
| SPAN | MENU |
| SPAN | SYSTEM |
| SPECIAL FUNCTIONS | SEQ |
| SPECIFY CLASS | CAL |
| SPECIFY GATE | SYSTEM |
| SPECIFY OFFSET | CAL |
| SPLIT DISP on OFF | DISPLAY |
| STANDARDS DONE | CAL |
| STATS on OFF | MARKER FCTN |
| STD DONE (MODIFIED) | CAL |
| STD OFFSET DONE | CAL |
| STD TYPE: | CAL |
| STEP SIZE | MENU |
| STIMULUS VALUE | SYSTEM |
| STIMULUS OFFSET | SYSTEM |
| STORE SEQ TO DISK | SEQ |
| SWEEP | SYSTEM |
| SWEEP TIME [] | MENU |
| SWEEP TYPE MENU | MENU |
| SWR | FORMAT |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|----------------------|------------------------|
| SYSTEM CONTROLLER | LOCAL |
| TAKE CAL SWEEP | CAL |
| TALKER/LISTENER | LOCAL |
| TARGET | MARKER FCTN |
| TERMINAL IMPEDANCE | CAL |
| TEST PORT 1 2 | MEAS |
| TESTSET SWP CONT MID | CAL |
| TEXT | DISPLAY |
| TEXT [] | COPY |
| THIRD | SYSTEM |
| THRU | CAL |
| TIME STAMP ON off | SYSTEM |
| TIME | DISPLAY |
| TITLE | DISPLAY |
| TITLE SEQUENCE | SEQ |
| TITLE TO MEMORY | SEQ |
| TITLE TO P MTR/HPIB | SEQ |
| TITLE TO PERIPHERAL | SEQ |
| TITLE TO PRINTER | SEQ |
| TRACKING on OFF | MARKER FCTN |
| TRANS DONE | CAL |
| TRANS: FWD S21 (B/R) | MEAS |
| TRANS: REV S12 (B/R) | MEAS |
| TRANSFORM MENU | SYSTEM |
| TRANSFORM on OFF | SYSTEM |
| TRANSMISSION | CAL |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel Access Key |
|--------------------|------------------------|
| TRIGGER MENU | MENU |
| TRIGGER: TRIG OFF | MENU |
| TRL* / LRM* 2-PORT | CAL |
| TTL I/O | SEQ |
| TTL OUT HIGH | SEQ |
| TTL OUT LOW | SEQ |
| TUNED RECEIVER | SYSTEM |
| UNCOUPLED | MARKER |
| UP CONVERTER | SYSTEM |
| UPPER LIMIT | SYSTEM |
| USE MEMORY on OFF | SYSTEM |
| USE PASS CONTROL | LOCAL |
| USER | PRESET |
| USER KIT | CAL |
| USE SENSOR A / B | CAL |
| VELOCITY FACTOR | CAL |
| VIEW MEASURE | SYSTEM |
| VOLUME NUMBER | LOCAL |
| VOLUME NUMBER | SAVE/RECALL |
| WAIT % | SEQ |
| WARNING | DISPLAY |
| WARNING [] | COPY |
| WAVEGUIDE | CAL |
| WIDE | SYSTEM |
| WIDTH VALUE | MARKER FCTN |
| WIDTHS on OFF | MARKER FCTN |

Table 9-1. Softkey Locations (continued)

| Softkey | Front-Panel
Access Key |
|-----------------|---------------------------|
| WINDOW | SYSTEM |
| WINDOW: MAXIMUM | SYSTEM |
| WINDOW: MINIMUM | SYSTEM |
| WINDOW: NORMAL | SYSTEM |
| XMIT CTRL [] | LOCAL |
| Y: Ref1 | MEAS |
| Y: Trans | MEAS |
| Z: Ref1 | MEAS |
| Z: Trans | MEAS |

Error Messages

Error Messages in Numerical Order

Refer to the alphabetical listing for explanations and suggestions for solving the problems.

| Error Number | Error |
|--------------|--|
| 1 | OPTIONAL FUNCTION; NOT INSTALLED |
| 2 | INVALID KEY |
| 3 | CORRECTION CONSTANTS NOT STORED |
| 4 | PHASE LOCK CAL FAILED |
| 5 | NO IF FOUND: CHECK R INPUT LEVEL |
| 6 | POSSIBLE FALSE LOCK |
| 7 | NO PHASE LOCK: CHECK R INPUT LEVEL |
| 8 | PHASE LOCK LOST |
| 9 | LIST TABLE EMPTY |
| 10 | CONTINUOUS SWITCHING NOT ALLOWED |
| 11 | SWEEP TIME INCREASED |
| 12 | SWEEP TIME TOO FAST |
| 13 | AVERAGING INVALID ON NON-RATIO MEASURE |
| 14 | FUNCTION NOT VALID |
| 15 | NO MARKER DELTA - SPAN NOT SET |
| 16 | TRANSFORM, GATE NOT ALLOWED |
| 17 | DEMODULATION NOT VALID |
| 18 | LOW PASS MODE NOT ALLOWED |
| 21 | POWER SUPPLY HOT! |
| 22 | POWER SUPPLY SHUT DOWN! |
| 23 | PROBE POWER SHUT DOWN! |
| 24 | PRINTER: not on, not connect, wrong addr |
| 25 | PRINT ABORTED |
| 26 | PLOTTER: not on, not connect, wrong addr |
| 27 | PLOT ABORTED |
| 28 | PLOTTER NOT READY-PINCH WHEELS UP |
| 30 | REQUESTED DATA NOT CURRENTLY AVAILABLE |
| 31 | ADDRESSED TO TALK WITH NOTHING TO SAY |

| Error Number | Error |
|--------------|--|
| 32 | WRITE ATTEMPTED WITHOUT SELECTING INPUT TYPE |
| 33 | SYNTAX ERROR |
| 34 | BLOCK INPUT ERROR |
| 35 | BLOCK INPUT LENGTH ERROR |
| 36 | SYST CTRL OR PASS CTRL IN LOCAL MENU |
| 37 | CAN'T CHANGE-ANOTHER CONTROLLER ON BUS |
| 38 | DISK: not on, not connected, wrong addr |
| 39 | DISK HARDWARE PROBLEM |
| 40 | DISK MEDIUM NOT INITIALIZED |
| 41 | NO DISK MEDIUM IN DRIVE |
| 42 | FIRST CHARACTER MUST BE A LETTER |
| 43 | ONLY LETTERS AND NUMBERS ARE ALLOWED |
| 44 | NOT ENOUGH SPACE ON DISK FOR STORE |
| 45 | NO FILE(S) FOUND ON DISK |
| 46 | ILLEGAL UNIT OR VOLUME NUMBER |
| 47 | INITIALIZATION FAILED |
| 48 | DISK IS WRITE PROTECTED |
| 49 | DISK WEAR-REPLACE DISK SOON |
| 50 | TOO MANY SEGMENTS OR POINTS |
| 51 | INSUFFICIENT MEMORY |
| 52 | SYSTEM IS NOT IN REMOTE |
| 54 | NO VALID MEMORY TRACE |
| 55 | NO VALID STATE IN REGISTER |
| 56 | INSTRUMENT STATE MEMORY CLEARED |
| 57 | OVERLOAD ON INPUT R, POWER REDUCED |
| 58 | OVERLOAD ON INPUT A, POWER REDUCED |
| 59 | OVERLOAD ON INPUT B, POWER REDUCED |
| 61 | SOURCE PARAMETERS CHANGED |

| Error Number | Error |
|--------------|--|
| 63 | CALIBRATION REQUIRED |
| 64 | CURRENT PARAMETER NOT IN CAL SET |
| 65 | CORRECTION AND DOMAIN RESET |
| 66 | CORRECTION TURNED OFF |
| 67 | DOMAIN RESET |
| 68 | ADDITIONAL STANDARDS NEEDED |
| 69 | NO CALIBRATION CURRENTLY IN PROGRESS |
| 70 | NO SPACE FOR NEW CAL \ CLEAR REGISTERS |
| 71 | MORE SLIDES NEEDED |
| 72 | EXCEEDED 7 STANDARDS PER CLASS |
| 73 | SLIDES ABORTED (MEMORY REALLOCATION) |
| 74 | CALIBRATION ABORTED |
| 75 | FORMAT NOT VALID FOR MEASUREMENT |
| 77 | WRONG DISK FORMAT, INITIALIZE DISK |
| 111 | DEADLOCK |
| 112 | SELF TEST #n FAILED |
| 113 | TEST ABORTED |
| 114 | NO FAIL FOUND |
| 115 | TROUBLE! CHECK SETUP AND START OVER |
| 116 | POW MET INVALID |
| 117 | POW MET: not on, not connected, wrong addr |
| 118 | POW MET NOT SETTLED |
| 119 | DEVICE: not on, not connect, wrong addr |
| 123 | NO MEMORY AVAILABLE FOR INTERPOLATION |
| 124 | SELECTED SEQUENCE IS EMPTY |
| 125 | DUPLICATING TO THIS SEQUENCE NOT ALLOWED |
| 126 | NO MEMORY AVAILABLE FOR SEQUENCING |
| 127 | CAN'T STORE/LOAD SEQUENCE, INSUFFICIENT MEMORY |

| Error Number | Error |
|--------------|--|
| 130 | D2/D1 INVALID WITH SINGLE CHANNEL |
| 131 | FUNCTION NOT VALID DURING MOD SEQUENCE |
| 132 | MEMORY FOR CURRENT SEQUENCE IS FULL |
| 133 | THIS LIST FREQ INVALID IN HARM/3 GHZ RNG |
| 140 | FREQ OFFSET ONLY VALID IN NETWORK ANALYZER MODE |
| 141 | STOP/CW FREQ + OFFSET MUST BE < 3 GHz |
| 144 | NO LIMIT LINES DISPLAYED |
| 145 | SWEEP TYPE CHANGED TO LINEAR SWEEP |
| 148 | EXTERNAL SOURCE MODE REQUIRES CW TIME |
| 150 | LOG SWEEP REQUIRES 2 OCTAVE MINIMUM SPAN |
| 151 | SAVE FAILED \ INSUFFICIENT MEMORY |
| 152 | D2/D1 INVALID \ CH1 CH2 NUM PTS DIFFERENT |
| 153 | SEQUENCE MAY HAVE CHANGED, CAN'T CONTINUE |
| 154 | INSUFFICIENT MEMORY, PWR MTR CAL OFF |
| 157 | SEQUENCE ABORTED |
| 159 | CH1 (CH2) TARGET VALUE NOT FOUND |
| 161 | PRESS [MENU], SELECT CW (IF) FREQ, THEN SWEPT LO |
| 162 | EXT SRC: NOT ON/CONNECTED OR WRONG ADDR |
| 163 | FUNCTION ONLY VALID DURING MOD SEQUENCE |
| 164 | TOO MANY NESTED SEQUENCES |
| 165 | PARALLEL PORT NOT AVAILABLE FOR GPIO |
| 166 | PRINT/PLOT IN PROGRESS, ABORT WITH LOCAL |
| 167 | PARALLEL PORT NOT AVAILABLE FOR COPY |
| 168 | INSUFFICIENT MEMORY FOR PRINT/PLOT |
| 169 | HPIB COPY IN PROGRESS, ABORT WITH LOCAL |
| 170 | COPY:device not responding; copy aborted |
| 171 | PRINTER: paper error |
| 172 | PRINTER: not on line |

| Error Number | Error |
|--------------|--|
| 173 | PRINTER: not connected |
| 174 | PRINTER: power off |
| 175 | PRINTER: error |
| 176 | PRINTER: busy |
| 177 | PRINTER: not handshaking |
| 178 | print color not supported with EPSON |
| 179 | POWER UNLEVELED |
| 180 | DOS NAME LIMITED TO 8 CHARS + 3 CHAR EXTENSION |
| 181 | BAD FREQ FOR HARMONIC OR FREQ OFFSET |
| 182 | LIST MODE OFF: INVALID WITH LO FREQ |
| 183 | BATTERY FAILED. STATE MEMORY CLEARED |
| 184 | BATTERY LOW! STORE SAVE REGS TO DISK |
| 185 | CANNOT FORMAT DOS DISKS ON THIS DRIVE |
| 187 | SWEEP MODE CHANGED TO CW TIME SWEEP |
| 188 | DIRECTORY FULL |
| 189 | DISK READ/WRITE ERROR |
| 190 | DISK MESSAGE LENGTH ERROR |
| 191 | EXT SOURCE NOT READY FOR TRIGGER |
| 192 | FILE NOT FOUND |
| 193 | ASCII: MISSING 'BEGIN' statement |
| 194 | ASCII: MISSING 'CITIFILE' statement |
| 195 | ASCII: MISSING 'DATA' statement |
| 196 | ASCII: MISSING 'VAR' statement |
| 197 | FILE NOT FOUND OR WRONG TYPE |
| 198 | NOT ALLOWED DURING POWER METER CAL |
| 199 | CANNOT MODIFY FACTORY PRESET |
| 200 | ALL REGISTERS HAVE BEEN USED |
| 201 | FUNCTION NOT VALID FOR INTERNAL MEMORY |

Compatible Peripherals

Measurement Accessories Available

Calibration Kits

- HP 85031B 7 mm Calibration Kit
- HP 85032B 50 Ohm Type-N Calibration Kit
- HP 85033D 3.5 mm Calibration Kit
- HP 85033C 3.5 mm Calibration Kit
- HP 85036B 75 Ohm Type-N Calibration Kit
- HP 85039A 75 Ohm Type-F Calibration Kit

Verification Kit

HP 85029B 7 mm Verification Kit

Test Port Return Cables

- HP 11857D 7 mm Test Port Return Cable Set
- HP 11857B 75 Ohm Type-N Test Port Return Cable Set

Adapter Kits

- HP 11852B 50 to 75 Ohm Minimum Loss Pad.
- HP 11853A 50 Ohm Type-N Adapter Kit
- HP 11854A 50 Ohm BNC Adapter Kit
- HP 11855A 75 Ohm Type-N Adapter Kit
- HP 11856A 75 Ohm BNC Adapter Kit

System Accessories Available

Plotters and Printers

- HP 7440A ColorPro Eight-Pen Color Graphics Plotter
- HP 7470A Two-Pen Graphics Plotter
- HP 7475A Six-Pen Graphics Plotter
- HP 7550A/B High-Speed Eight-Pen Graphics Plotter
- HP Deskjet 1200C (can also be used to plot)
- HP Deskjet 500
- HP Deskjet 520
- HP Deskjet 500C
- HP Deskjet 550C
- HP Deskjet 560C
- All LaserJets (LaserJet III and IV can also be used to plot)
- HP DeskJet Portable/310
- PaintJet 3630A

HP-IB Cables

- HP 10833A HP-IB Cable, 1.0 m (3.3 ft.)
- HP 10833B HP-IB Cable, 2.0 m (6.6 ft.)
- HP 10833D HP-IB Cable, 0.5 m (1.6 ft.)

Interface Cables

- HP C2912B Centronics (Parallel) Interface Cable, 3.0 m (9.9 ft.)
- HP C2913A RS-232C Interface Cable, 1.2 m (3.9 ft.)
- HP C2914A Serial Interface Cable, 1.2 m (3.9 ft.)
- HP 24542G Serial Interface Cable, 3 m (9.9 ft.)
- HP 24542D Parallel Interface Cable, 2 m (6 ft.)
- HP 92284A Parallel Interface Cable, 2 m (6 ft.)

Keyboards

HP C1405A Option ABA keyboard

Connecting and Configuring Peripherals





Figure 11-1. Printer Connections to the Analyzer

Configuring Peripherals with HP-IB Interface

Table 11-1. Default Addresses for HP-IB Peripherals

| Peripheral | Default HP-IB Address |
|---------------------|-----------------------|
| Printer | 01 |
| Plotter | 05 |
| Power Meter | 13 |
| Disk Drive | 00 |
| Computer Controller | 21 |

HP-IB Structure



pg635d

Figure 11-2. HP-IB Structure

HP-IB Requirements

| | |
|--|---|
| Number of Interconnected Devices: | 15 maximum. |
| Interconnection Path/Maximum Cable Length: | 20 meters maximum or 2 meters per device whichever is less. |
| Message Transfer Scheme: | Byte serial/bit parallel asynchronous data transfer using a 3-line handshake system. |
| Data Rate: | Maximum of 1 megabyte per second over limited distances with tri-state drivers. Actual data rate depends on the transfer rate of the slowest device involved. |
| Address Capability: | Primary addresses: 31 talk, 31 listen. A maximum of 1 talker and 14 listeners at one time. |
| Multiple Controller Capability: | In systems with more than one controller (like the analyzer system), only one can be active at a time. |

Analyzer HP-IB Capabilities

As defined by the IEEE 488.1 standard, the analyzer has the following capabilities:

| | |
|-----|---|
| SH1 | Full source handshake capability. |
| AH1 | Full acceptor handshake capability. |
| T6 | Can be a basic talker, answers serial poll, unaddresses if MLA is issued. |
| TE0 | No extended talker capabilities. |
| L4 | Acts as a basic listener and unaddresses if MTA is issued. |
| SR1 | Can issue service requests. |

- RL1 Will do remote, local, and local lockout.
- PP0 Does not respond to parallel poll.
- DC1 Device clear capability.
- DT1 Will respond to device trigger in hold mode.
- C1, C2, C3 No controller capabilities in talker/listener mode. System controller mode can be selected under the LOCAL menu.
- C10 Pass control capability in pass control mode.
- E2 Tri-state drivers.

Preset State and Memory Allocation

Types of Memory

The analyzer utilizes three types of memory:

- volatile
- non-volatile
- external

Volatile Memory

This is dynamic read/write memory, of approximately 2 M bytes, that contains all of the parameters that make up the *current* instrument state.

Volatile memory is cleared upon a power cycle of the instrument and, except as noted, upon instrument preset.

Non-Volatile Memory

This is CMOS read/write memory that is protected by a battery to provide short term storage of data when line power to the instrument is turned off.

Non-volatile memory consists of a block of user-allocated memory and a block of fixed memory.

Table 12-1.
Memory Requirements of Calibration and Memory Arrays

| Variable | Data Length
(Bytes) | Approximate Totals
(Bytes) | | | |
|--|--|-------------------------------|------------|-----------|------------|
| | | 401
pts | 801
pts | 1601 pts | |
| | | 1 chan | | 1
chan | 2
chans |
| Calibration Arrays | | | | | |
| Response | $N \times 6 + 52$ | 2.5 k | 5 k | 10 k | 19 k |
| Response and
Isolation | $N \times 6 \times 2 + 52$ | 5 k | 10 k | 19 k | 38 k |
| 1-Port | $N \times 6 \times 3 + 52$ | 7 k | 14 k | 29 k | 58 k |
| 2-Port | $N \times 6 \times 12 + 52$ | 29 k | 58 k | 115 k | 230 k |
| Interpolated Cal | Same as above in
addition to
regular cal | | | | |
| Power Meter Cal* | $(N^\dagger \times 2 \times$
number of
channels $^\ddagger) + 208$ | 1 k | 1.8 k | 3.4 k | 6.6 k |
| Measurement Data | | | | | |
| Memory Array* | $N \times 6 + 52$ | 2.5 k | 4.9 k | 9.7 k | 19 k |
| Instrument State# | | 3 k | 3 k | 3 k | 3 k |
| <p>N = number of points
 * This variable is allocated once per active channel.
 \dagger The number of points that was set at the time the cal was turned on.
 \ddagger If the channels are coupled, this number is always 1. If the channels are uncoupled, this number refers to the number of channels that have power meter cal on.
 # This value may change with different firmware revisions.</p> | | | | | |

External Memory

External memory is defined as either the internal floppy disk or an external disk.

Preset State

Table 12-2. Preset Conditions (1 of 10)

| Preset Conditions | Preset Value |
|----------------------------|-----------------------|
| Analyzer Mode | |
| Analyzer Mode | Network Analyzer Mode |
| Frequency Offset | Off |
| Operation | |
| Offset Value | 0 |
| Harmonic Operation | Off |
| Stimulus Conditions | |
| Sweep Type | Linear Frequency |
| Display Mode | Start/Stop |
| Trigger Type | Continuous |
| External Trigger | Off |
| Sweep Time | 100 ms, Auto Mode |
| Start Frequency | 30 kHz |
| Frequency Span (std.) | 2999.97 MHz |
| Frequency Span (Opt. 006) | 5999.97 MHz |
| Start Time | 0 |
| Time Span | 100 ms |
| CW Frequency | 1000 MHz |
| Source Power | 0 dBm |
| Power Slope | 0 dB/GHz; Off |
| Start Power | -15.0 dBm |
| Power Span | 25 dB |
| Coupled Power | On |
| Source Power | On |
| Coupled Channels | On |
| Coupled Port Power | On |

Preset Conditions (2 of 10)

| Preset Conditions | Preset Value |
|----------------------------|---|
| Power Range | Auto; Range 0 |
| Number of Points | 201 |
| Frequency List | |
| Frequency List | Empty |
| Edit Mode | Start/Stop, Number of Points |
| Response Conditions | |
| Parameter | Channel 1: S11;
Channel 2: S21 |
| Conversion | Off |
| Format | Log Magnitude (all inputs) |
| Display | Data |
| Color Selections | Same as before PRESET |
| Dual Channel | Off |
| Active Channel | Channel 1 |
| Frequency Blank | Disabled |
| Split Display | On |
| Intensity | If set to $\geq 15\%$, PRESET has no effect. If set to $< 15\%$ PRESET increases intensity to 15%. |
| Beeper: Done | On |
| Beeper: Warning | Off |
| D2/D1 to D2 | Off |
| Title | Channel 1 = [hp] |

Preset Conditions (3 of 10)

| Preset Conditions | Preset Value |
|-------------------------|-------------------|
| | Channel 2 = Empty |
| IF Bandwidth | 3000 Hz |
| IF Averaging Factor | 16; Off |
| Smoothing Aperture | 1% SPAN; Off |
| Phase Offset | 0 Degrees |
| Electrical Delay | 0 ns |
| Scale/Division | 10 dB/Division |
| Calibration | |
| Correction | Off |
| Calibration Type | None |
| Calibration Kit | 7 mm |
| System Z0 | 50 Ohms |
| Velocity Factor | 1 |
| Extensions | Off |
| Port 1 | 0 s |
| Port 2 | 0 s |
| Input A | 0 s |
| Input B | 0 s |
| Chop A and B | On |
| Power Meter Calibration | Off |
| Number of Readings | 1 |
| Power Loss Correction | Off |
| Sensor A/B | A |

Preset Conditions (4 of 10)

| Preset Conditions | Preset Value |
|-------------------------------|------------------------|
| Interpolated Error Correction | Off |
| Markers (coupled) | |
| Markers 1, 2, 3, 4 | 1 GHz; All Markers Off |
| Last Active Marker | 1 |
| Reference Marker | None |
| Marker Mode | Continuous |
| Display Markers | On |
| Delta Marker Mode | Off |
| Coupling | On |
| Marker Search | Off |
| Marker Target Value | -3 dB |
| Marker Width Value | -3 dB; Off |
| Marker Tracking | Off |
| Marker Stimulus Offset | 0 Hz |
| Marker Value Offset | 0 dB |
| Marker Aux Offset (Phase) | 0 Degrees |
| Marker Statistics | Off |
| Polar Marker | Lin Mkr |
| Smith Marker | R+jX Mkr |
| Limit Lines | |
| Limit Lines | Off |
| Limit Testing | Off |

Preset Conditions (5 of 10)

| Preset Conditions | Preset Value |
|--------------------------|---------------------|
| Limit List | Empty |
| Edit Mode | Upper/Lower Limits |
| Stimulus Offset | 0 Hz |
| Amplitude Offset | 0 dB |
| Limit Type | Sloping Line |
| Beep Fail | Off |
| Time Domain | |
| Transform | Off |
| Transform Type | Bandpass |
| Start Transform | -20 nanoseconds |
| Transform Span | 40 nanoseconds |
| Gating | Off |
| Gate Shape | Normal |
| Gate Start | -10 nanoseconds |
| Gate Span | 20 nanoseconds |
| Demodulation | Off |
| Window | Normal |
| Use Memory | Off |
| System Parameters | |
| HP-IB Addresses | Last Active State |
| HP-IB Mode | Last Active State |
| Focus | Last Active State |
| Clock Time Stamp | On |
| Preset: Factory/User | Last Selected State |

Preset Conditions (6 of 10)

| Preset Conditions | Preset Value |
|---|----------------------|
| Copy Configuration | |
| Parallel Port | Copy |
| Plotter Type | Plotter |
| Plotter Port | Serial |
| Plotter Baud Rate | 9600 |
| Plotter Handshake | Xon-Xoff |
| HP-IB Address | 5 |
| Printer Type | DeskJet |
| Printer Port | Parallel |
| Printer Baud Rate | 19200 |
| Printer Handshake | Xon-Xoff |
| Printer HP-IB Address | 1 |
| Disk Save Configuration
(Define Store) | |
| Data Array | Off |
| Raw Data Array | Off |
| Formatted Data Array | Off |
| Graphics | Off |
| Data Only | Off |
| Directory Size | Default ¹ |
| Save Using | Binary |

¹ The directory size is calculated as 0.013% of the floppy disk size (which is ≈ 256) or 0.005% of the hard disk size.

Preset Conditions (7 of 10)

| Preset Conditions | Preset Value |
|-------------------------------|-----------------|
| Select Disk | Internal Memory |
| Disk Format | LIF |
| Sequencing¹ | |
| Loop Counter | 0 |
| TTL OUT | High |
| Service Modes | |
| HP-IB Diagnostic | Off |
| Source Phase Lock | Loop On |
| Sampler Correction | On |
| Spur Avoidance | On |
| Aux Input Resolution | High |
| Analog Bus Node | 11 (Aux Input) |
| Plot | |
| Plot Data | On |
| Plot Memory | On |
| Plot Graticule | On |
| Plot Text | On |
| Plot Marker | On |
| Autofeed | On |
| Plot Quadrant | Full Page |
| Scale Plot | Full |

1 Pressing preset turns off sequencing modify (edit) mode and stops any running sequence.

Preset Conditions (8 of 10)

| Preset Conditions | Preset Value |
|-------------------|-------------------|
| Plot Speed | Fast |
| Pen Number: | |
| Ch1 Data | 2 |
| Ch2 Data | 3 |
| Ch1 Memory | 5 |
| Ch2 Memory | 6 |
| Ch1 Graticule | 1 |
| Ch2 Graticule | 1 |
| Ch1 Text | 7 |
| Ch2 Text | 7 |
| Ch1 Marker | 7 |
| Ch2 Marker | 7 |
| Line Type: | |
| Ch1 Data | 7 |
| Ch2 Data | 7 |
| Ch1 Memory | 7 |
| Ch2 Memory | 7 |
| Print | |
| Printer Mode | Last Active State |
| Auto-Feed | On |

Preset Conditions (9 of 10)

| Preset Conditions | Preset Value |
|-------------------|--------------|
| Printer Colors | |
| CH1 Data | Magenta |
| CH1 Mem | Green |
| CH2 Data | Blue |
| CH2 Mem | Red |
| Graticule | Cyan |
| Warning | Black |
| Text | Black |

Preset Conditions (10 of 10)

| Format Table | Scale | Reference | | Marker Offset |
|--------------------|-------|-----------|-------|---------------|
| | | Position | Value | |
| Log Magnitude (dB) | 10.0 | 5.0 | 0.0 | 0.0 |
| Phase (degree) | 90.0 | 5.0 | 0.0 | 0.0 |
| Group Delay (ns) | 10.0 | 5.0 | 0.0 | 0.0 |
| Smith Chart | 1.00 | - | 1.0 | 0.0 |
| Polar | 1.00 | - | 1.0 | 0.0 |
| Linear Magnitude | 0.1 | 0.0 | 0.0 | 0.0 |
| Real | 0.2 | 5.0 | 0.0 | 0.0 |
| Imaginary | 0.2 | 5.0 | 0.0 | 0.0 |
| SWR | 1.00 | 0.0 | 1.0 | 0.0 |