

TPS65981, TPS65982, and TPS65986 Power and Data Role Swaps

ABSTRACT

Power and data role swaps allow individual devices to change their roles under certain conditions. This ability allows a power source to become a sink, a data DFP to become a data UFP, or both. The roles are negotiated using USB Power Delivery (PD) messaging according to the USB PD specification. This application report explains the standard implementation of data and power role swaps as well as assigning data and power preferences to individual USB Type-C ports. This application report is to be used with Texas Instruments TPS65981/2/6 family of USB Type-C and USB PD controllers and associated software tools.

Contents

1	Introduction	2
2	Role Swap Configuration in Host Interface Registers.....	2
3	Data and Power Role Swap Examples	3
4	Requirements for Data and Power Role Swaps	7
5	Verification of Data-Role and Power-Role Swaps	8
5.1	Example 1: Debugging Power Role Swap Exiting Dead Battery Mode Operation	8
5.2	Example 2: Debugging Swap Reversal from non-Persistent Swap Conditions	12

List of Figures

1	Control Configuration Settings Tab <i>TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl</i>	3
2	Control Configuration Settings Tab <i>TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl</i>	4
3	System Configuration Settings Tab <i>TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl</i>	5
4	HD3SS460 DRP Host Connected to HD3SS460 DRP Source PD Trace (Excerpt).....	6
5	Control Configuration Register <i>TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl</i>	8
6	PD Flow With DRP Source Unpowered	9
7	Failed SWSr When Dead Battery flag is Set to 1 (True).....	10
8	Successful DBfg Command to Clear Dead Battery Flag.....	10
9	Verified Dead Battery flag Cleared to 0 (False)	11
10	Successful Swap to Source.....	11
11	SWSk Command Page Before Execution	12
12	SWSk Power-Role Swap to Sink Attempt (Inconclusive Result).....	13
13	PD Trace of Manual Power-Role Swap Followed by Automatic Power-Role Swap.....	14
14	<i>TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl</i> With <i>InitSwapToSource</i> Disabled	15
15	Manual Swap to Sink (Successful and Persistent)	15

List of Tables

1	Data-Role and Power-Role Swap Requirements.....	7
---	---	---

Trademarks

All trademarks are the property of their respective owners.

1 Introduction

The Power Delivery specification allows two connected dual-role ports to optionally switch their data role, their power role, or both roles using the power-role swap and data-role swap mechanisms.

Texas Instruments TPS65981, TPS65982, and TPS65986 families of USB Type-C and USB PD controllers can be configured to automatically initiate data or power role swaps to a desired state, or the same role swaps may be initiated by an external microcontroller through host interface commands. The control configuration (0x29) register is used to specify automatically initiated role swaps. You can specify a preferred data role by using the *Initiate Swap to DFP* command instead of the *Initiate Swap to UFP* command, and can configure the device to either allow or disallow swaps through the *Process Swap to DFP* and *Process Swap to UFP* bits. The power roles have similar settings.

Using an external microcontroller to modify data and power roles using host interface commands provides an additional level of functionality. Whereas the control configuration register provides a simple preference towards one setting or the other setting, an external microcontroller can use information gathered from the TPS65981, TPS65982, and TPS65986 host interface status registers to make more advanced power and data role decisions. For instance, a microcontroller could use the externally powered bit of the connection partner as stored in the Rx Source Capabilities (0x30) register to make a more informed decision when setting power role orientation.

2 Role Swap Configuration in Host Interface Registers

The TPS65982 registers include the following:

- Configuration registers:
 - 0x28, System Configuration register, *Port Info* field
 - 0x29, Control Configuration register, ALL fields
- Status registers:
 - 0x1A, Status register, *Port Role* and *Data Role* fields
 - 0x3F Power status register, Source or Sink field
 - 0x2D, Boot Status register, *Dead Battery* field
- Run-Time Host-Interface Commands:
 - SWSr, swap to source (power)
 - SWSk, swap to sink (power)
 - SWDF, swap to DFP (data)
 - SWUF, swap to UFP (data)

The Control Configuration register (0x29) is the primary register used to control role swap behavior. This register allows you to configure the initiation of role swaps, which causes the TPS6598x PD controller to automatically initiate the given role swap, and it allows you to configure the processing of role swaps, which controls whether the TPS65981/2/6 USB PD controller accepts or does not accept various role swap requests initiated by the port partner.

In addition to configuring system behavior in the Control Configuration register, you should be aware that the setting of the *Port Info* field of the System Configuration register also affects both the initiation and processing of role swaps.

The Status register (0x1a) reports the current data and power role of the system. The Boot Status register (0x2d) is also important as it reports whether or not the system is currently in Dead Battery Mode, and a system that is in Dead Battery Mode does not support power role swaps. Power status register (0x3F) can be used to look at power role easily.

Finally, four host interface commands can be used to manually initiate a data or power role swap using an external controller. As discussed in this application report, certain system conditions must still be met in order for a role swap to occur. If these conditions are not met, the host interface swap command is rejected.

3 Data and Power Role Swap Examples

The [TPS6598x Configuration Tool](#) contains multiple dual-role port configurations, all of which use one of two data and power role swap settings. Refer to the [TPS6598x Application-Customization Tool User Guide](#) to select the appropriate template that best represents your project configuration. Broadly speaking, there are two types of templates: "simplified" and "advanced". This document limits discussion to advanced templates to illustrate detailed functionality of power and data role swaps.

Note that the names of templates discussed below starts with the last portion of the file name that points to the version of the Configuration tool being used, which gets updated whenever a newer version of configuration tool is used. For example, template `TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl` is for the TPS65982 device and was done based on configuration tool version 2.9.

The `TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl` and `TPS65982_AlpineRidge_DRP_Host_Full_2_9.tpl` variants attempt a data role swap if necessary to become a data DFP (essentially a host). These projects do not initiate a power role swap, but accept any power swap request from a connected device.

The `TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl` and `TPS65982_AlpineRidge_DRP_Source_Full_2_9.tpl` variants attempt a power role swap if necessary to become a power DFP (essentially a source). These projects does not initiate a data role swap, but accept any data swap request from a connected device.

Testing these two projects together always generates an automatic data role swap as the source variants have the try.SRC feature enabled, which ensures that when connected to a device that does not have try (SRC enabled), they always connect as a DFP.

The `TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl` and `TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl` can be accessed using the *New Project* option from the *Project* drop-down menu in the configuration GUI.




Figure 1. Control Configuration Settings Tab `TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl`

Figure 1 shows the Control Configuration register (0x29) settings for the `TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl` project. For this project, *Process Swap to Sink*, and *Process Swap to Source* are both enabled, but *Initiate Swap to Sink* and *Initiate Swap to Source* are both disabled. This indicates that the system accepts either power role swap request from a connected device but does not (automatically) initiate a power swap request of either type. This is an agnostic configuration since it supports both power roles without driving a preference towards one or the other.

By contrast, the data role swap settings are as follows: *Initiate Swap to DFP* and *Process Swap to DFP* are both enabled, but *Initiate Swap to UFP* and *Process Swap to UFP* are both disabled. This combination indicates that the device always attempts to become the data DFP (host) in the connection.

NOTE: The *Swap to DFP* setting indicates that the device being configured swaps to become the DFP for both the *Initiate* and *Process* settings. This setting is a preferred data configuration because it drives the system towards a configuration in which the device is data DFP if possible.

When setting the initiate and process bits in the Control Configuration register, avoiding a configuration that could potentially lead to an infinite sequence of data or power role swaps is important. Firstly, a system should never be configured to initiate swaps in both directions (such as selecting *Initiate Swap to UFP* and *Initiate Swap to DFP* in the same configuration). Firstly, this would be a meaningless configuration because it provides no preference to data or power role and therefore is swapping seemingly for the sake of swapping, but secondly, if the port partner accepts swaps in both directions, this configuration would lead to an infinite series of swaps.

Likewise, any configuration that initiates a data or power role swap should not process swaps in the reverse direction. Two systems that are both configured to *Initiate Swap to DFP* and *Process Swap to UFP* toggle infinitely back and forth as each system continually initiates swaps to attempt to become DFP. In any event, a system that prefers to be configured as DFP would have no reason to accept swaps to UFP since this would require relinquishing the preferred role.

Comparing the settings of [Figure 1](#) to those of the *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* project as shown in [Figure 2](#), it is seen that the latter project is configured to drive towards a power source role by selecting *Process Swap to Source* and *Initiate Swap to Source*, and deselecting *Process Swap to Sink* and *Initiate Swap to Sink*. The data role is left agnostic by enabling the *Process* settings in both directions but disabling the *Initiate* settings.




Figure 2. Control Configuration Settings Tab *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*

Verifying that the *Port Information* field in the System Configuration register (0x28) is configured with a port behavior that supports data-role or power-role swaps as needed is required. [Figure 3](#) shows the System Configuration settings used in this template project that prefers to be a power source.




Figure 3. System Configuration Settings Tab *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*

The following PD message trace was taken with a Teledyne LeCroy PD analyzer between two TPS65982 EVMs, one loaded with the *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* example and the other with *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl*. Because *TPS65982_HD3SS460_DRP_Host_Source_2_9.tpl* has the try.SRC feature enabled, the trace always follows this structure so long as either both boards are powered before connection or the board containing the source settings is powered with the host board in Dead Battery Mode. This trace was taken with both boards powered. This example also uses a non-e-marked cable, which leads to the cable resets and VConn Swap, which is discussed.

PD	4 Packets 38-41	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	Time	Time Stamp						
				Vendor Defined	DFP or UFP	0	1	Discover Identity	Initiator	0	PD SID		638.442 us	7.201 ms	1.584.508 000						
PD	Packet 42	Left "Left"	SRC →	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role
					Source Cap	DFP	SRC	0	3		3.00 A	5.00 V	0		3.00 A	12.00 V	0		3.00 A	20.00 V	0
PD	Packet 44	Right "Right"	← SNK	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos	Duration	Time	Time Stamp				
					Request	UFP	SNK	0	1		3.00A / 75.00W	3.00A / 75.00W	0	3	632.016 us	1.337 ms	1.584.508 000				
PD	Packet 46	Left "Left"	SRC →	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					Accept	DFP	SRC	1	0	501.683 us	32.019 ms	1.594.990 000									
PD	Packet 49	Left "Left"	SRC →	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					PS Ready	DFP	SRC	2	0	501.683 us	1.466 ms	1.627.009 000									
PD	Packet 51	Right "Right"	← SNK	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					DR Swap	UFP	SNK	1	0	498.256 us	1.206 ms	1.625.475 000									
PD	Packet 53	Left "Left"	SRC →	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					Accept	DFP	SRC	3	0	501.683 us	1.389 ms	1.629.681 000									
PD	Packet 55	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.135 ms	1.631.070 000										
PD	Packet 56	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.132 ms	1.632.703 000										
PD	Packet 57	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.132 ms	1.634.333 000										
PD	Packet 58	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.209 ms	1.635.963 000										
PD	Packet 59	Right "Right"	← SNK	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					VConn Swap	DFP	SNK	2	0	498.256 us	1.195 ms	1.637.670 000									
PD	Packet 61	Left "Left"	SRC →	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					Accept	UFP	SRC	4	0	501.683 us	2.329 ms	1.638.865 000									
PD	Packet 63	Right "Right"	← SNK	PD Msg	Mag Type	DR	PR	Mag ID	Obj Cnt	Duration	Time	Time Stamp									
					PS Ready	DFP	SNK	3	0	498.256 us	50.399 ms	1.641.194 000									
PD	Packet 65	→ CBL	Cable Reset	Duration	Idle	Time Stamp															
				279.972 us	155.028 us	1.691.593 000															
PD	Packet 66	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.132 ms	1.692.028 000										
PD	Packet 67	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.131 ms	1.693.658 000										
PD	Packet 68	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.132 ms	1.695.287 000										
PD	Packet 69	→ CBL	PD Msg	Mag Type	Cable Plug	Mag ID	Obj Cnt	Duration	Idle	Time Stamp											
					Soft Reset	DFP or UFP	0	0	498.256 us	1.213 ms	1.696.917 000										
PD	Packet 70	→ CBL	Cable Reset	Duration	Idle	Time Stamp															
				279.972 us	10.243 ms	1.698.628 000															

Figure 4. HD3SS460 DRP Host Connected to HD3SS460 DRP Source PD Trace (Excerpt)

Figure 4 shows the expected sequence of PD operations for this example. This sequence is only a partial trace. The system continues with a Discover Identity, Discover SVIDs/Modes, and mode entry.

1. Packets 01 through 37 (not displayed in Figure 4) — The EVM loaded with FW from *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* connects as the DFP and *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* connects as the UFP. This will always happen, so long as the EVM programmed with the source settings is powered, because these settings enable try.SRC and the host settings do not.
2. Packets 38 through 41 — A Discover Identity request and three retries are sent to the cable. Because it is a non-e-marked cable, there is no response.
3. Packets 42 through 49 — The PD power contract is negotiated. See Section 3 of this document for an explanation of the configuration of this stage of PD negotiation.
4. Packet 51 — The EVM configured with *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* makes a data role swap request. This occurs because *Initiate Swap to DFP* is enabled in the Control Configuration register of this project and it is currently the UFP. Additional conditions are required for this to occur, as shown in .
5. Packet 53 — The EVM configured with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* accepts the data role swap request. This occurs because *Process Swap to UFP* is enabled in the Control Configuration register of this project and it is currently the DFP. Additional conditions are required for this to occur, as listed in Table 1.
6. Packets 55 through 58 — The EVM configured with *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* issues a soft reset command to the cable with three retries. The new DFP always attempts a soft reset to the cable following a data-role swap to reset the message ID to 0. The cable used in this example does not respond because it is not e-marked.
7. Packet 59 — the EVM configured with *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* issues a

VConn swap. The PD spec requires that a PD port must provide power to the connection cable in order to issue a cable reset. This VConn swap request is preliminary to the cable reset of packet 65.

8. Packets 61 and 63 — The VConn swap is accepted and then the EVM configured with *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* issues a *PS Ready* command when it is providing power to the cable.
9. Packets 65 through 70 — The host-configured port issues a *Cable Reset* command. Because the cable is not e-marked, it does not return a *Good CRC* message to this *Cable Reset* (all *Good CRC* messages have been removed from this trace to reduce its size). When no *Good CRC* message is received from the cable, the DFP (host) issues one soft reset and three retries to the cable as a result of not receiving *Good CRC* for the soft reset request. After four *Soft Reset* requests with no *Good CRC*, the port issues one final *Cable Reset* and then continues with the rest of its PD negotiation (not shown).

4 Requirements for Data and Power Role Swaps

A number of conditions must be met for the TPS6598x USB PD controller to issue or accept a power or data role swap. If a swap request is not issued or accepted as you expects, these conditions should be checked.

[Table 1](#) summarizes the requirements for each type of swap to be issued or accepted. The combination of conditions in the *Required Conditions* column must be met as specified in the table for the swap to occur. If any of the conditions in the *Blocking Conditions* column are met, the swap does not occur.

Table 1. Data-Role and Power-Role Swap Requirements

ACTION	TYPE	REQUIRED CONDITIONS	BLOCKING CONDITIONS
Issue swap to source	Power	Port is currently a Sink AND Initiate Swap to Source == 1 OR SWSr 4CC command issued	A previous swap-to-source request was NAK'd by the far-end PD port controller. Dead Battery flag is set in the Boot Status register (0x2D). The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Accept swap to source	Power	Port is currently a Sink AND Process Swap to Source == 1	The <i>Port Information</i> field in the System Configuration register does not support PR swap. Dead Battery flag is set in Boot Status register (0x2D).
Issue swap to sink	Power	Port is currently a Source AND Initiate Swap to Sink == 1 OR SWSk 4CC command issued	A previous swap-to-sink request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Accept swap to sink	Power	Port is currently a Source AND Process Swap to Sink == 1	The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Issue swap to DFP	Data	Port is currently a UFP (Device) AND Issue Swap to DFP == 1 OR SWDF 4CC command issued	A previous swap-to-DFP request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support DR swap. An Alternate Mode is Active (has been entered and not exited). A Source or Sink Capabilities message has been received from port partner that does not have Dual Role Data bit set.
Accept swap to DFP	Data	Port is currently a UFP (device) AND Process Swap to DFP == 1	The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is Active (has been entered and not exited).
Issue swap to UFP	Data	Port is currently a DFP (Host) AND Initiate Swap to UFP == 1 OR SWUF 4CC command issued	A previous Swap to UFP request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is active (has been entered and not exited). A source or sink capabilities message has been received from port partner that does not have Dual Role Data bit set.
Accept swap to UFP	Data	Port is currently a DFP (Host) AND Process Swap to UFP == 1	The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is Active (has been entered and not exited).

5 Verification of Data-Role and Power-Role Swaps

The first step in verification of the data-role and power-role swaps is to verify that the settings read from the device match those that were input into the configuration tool. The relevant settings are stored in the Control Configuration register (0x29) and the System Configuration register (0x28). These settings can be modified at runtime by an external microcontroller and therefore ensuring that the settings read as expected is useful.




Figure 5. Control Configuration Register *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*

The settings shown in Figure 5 are verified to match those of the configuration tool as shown in Figure 2. Even when this is the case, you may find cases where swaps do not occur as expected. This section provides two common examples (see Section 5.1 for example 1 and Section 5.2 for example 2) and a walkthrough of a typical debug procedure for these scenarios using the *TPS6598x Configuration Tool*.

5.1 Example 1: Debugging Power Role Swap Exiting Dead Battery Mode Operation

For the first experiment, use the two TPS65982 EVMs programmed with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* and *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* settings from the earlier example. The *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* EVM is left unpowered, while the *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* EVM is powered.

As shown in Figure 6, no power-role swap is initiated by the *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* system, even though it is a sink and has *Initiate Swap to Source* enabled.

Packet 32	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role	Duration
32	"Right"	SRC	PD Msg	Source Cap	DFP	SRC	0	2		3.00 A	5.00 V	1		3.00 A	12.00 V	0	765.775
Packet 34	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos				Duration
34	"Left"	SNK	PD Msg	Request	UFP	SNK	0	1		3.00A / 75.00W	3.00A / 75.00W	0	1				636.363 us
Packet 36	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt		Duration	Time	Time Stamp					
36	"Right"	SRC	PD Msg	Accept	DFP	SRC	1	0		498.256 us	30.947 ms	3 . 001 526 000					
Packet 38	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt		Duration	Time	Time Stamp					
38	"Right"	SRC	PD Msg	PS Ready	DFP	SRC	2	0		498.256 us	11.433 ms	3 . 032 473 000					
Packet 40	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
40	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	3	1		Discover Identity	Initiator	0	PD SID				632.016 us
Packet 42	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	ID Header			
42	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	1	4		Discover Identity	Resp ACK	0	PD SID				Texas
Packet 44	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
44	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	4	1		Discover SVIDs	Initiator	0	PD SID				632.016 us
Packet 46	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	SVIDs	SVID 0		
46	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	2	3		Discover SVIDs	Resp ACK	0	PD SID				Display P
Packet 48	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
48	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	5	1		Discover Modes	Initiator	0	Display Port				632.016 us
Packet 50	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Cap	Port C		
50	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	3	2		Discover Modes	Resp ACK	0	Display Port				UFP
Packet 52	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
52	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	6	1		Discover Modes	Initiator	0	Texas Instruments				632.016
Packet 54	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
54	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	4	2		Discover Modes	Resp ACK	0	Texas Instruments				Modes 0
64 Packets 56-119	Right	SRC	PD Msg	Msg Type	Cable Plug	Msg ID	Obj Cnt		VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
56-119	"Right"	SRC	PD Msg	Vendor Defined	DFP or UFP	0	1			Discover Identity	Initiator	0	PD SID				113.876
Packet 120	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
120	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	7	1		Enter Mode	Initiator	1	Display Port				632.016 us
Packet 122	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
122	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	5	1		Enter Mode	Resp ACK	1	Display Port				636.363 us
Packet 124	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Status	DP		
124	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	0	2		DP Status (0x10)	Initiator	1	Display Port				DF
Packet 126	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Status	DP		
126	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	6	2		DP Status (0x10)	Resp ACK	1	Display Port				UFP
Packet 128	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Config			
128	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	1	2		DP Configure (0x11)	Initiator	1	Display Port				DP Config
Packet 130	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
130	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	7	1		DP Configure (0x11)	Resp ACK	1	Display Port				632.016 u
Packet 132	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
132	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	2	2		Enter Mode	Initiator	1	Texas Instruments				Undefined 0x
Packet 134	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				Duration
134	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	0	1		Enter Mode	Resp ACK	1	Texas Instruments				636.363 us
Packet 136	Right	SRC	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				
136	"Right"	SRC	PD Msg	Vendor Defined	DFP	SRC	3	2		SVID Specific Cmd (0x14)	Initiator	1	Texas Instruments				
Packet 138	Left	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID				
138	"Left"	SNK	PD Msg	Vendor Defined	UFP	SNK	1	2		SVID Specific Cmd (0x14)	Resp ACK	1	Texas Instruments				

Figure 6. PD Flow With DRP Source Unpowered

If the system settings have been verified, but a data-role or power-role swap is not occurring as expected, initiate the role swap manually through the [TPS6598x Configuration Tool](#).

Because the *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* EVM is not issuing the expected swap request, attach the HW adapter (USB-to-I2C) for the [TPS6598x configuration tool](#) to this EVM and issue the SWSr command.




Figure 7. Failed SWSr When Dead Battery flag is Set to 1 (True)

Figure 7 shows the feedback from the host interface tools. The tool reports that the SWSr command was aborted. You can read Boot flags register (0x2D) to check if the Dead Battery Flag is set.

To correct this, you can power the board and then issue the DBfg command from the host interface which clears the Dead Battery flag as shown in Figure 8. Clearing of the Dead Battery flag should also be verified by reading the Boot Status register (0x2D) as shown in Figure 9.

The board must be powered before clearing the Dead Battery flag otherwise the device resets and reboots again in Dead Battery Mode operation.




Figure 8. Successful DBfg Command to Clear Dead Battery Flag




Figure 9. Verified Dead Battery flag Cleared to 0 (False)

When the Dead Battery flag has been cleared, the EVM programmed with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* can be swapped to the power source by issuing the SWSr host interface command as shown in Figure 10.




Figure 10. Successful Swap to Source

5.2 Example 2: Debugging Swap Reversal from non-Persistent Swap Conditions

Using the TPS65982 EVMs programmed with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* and *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* settings from the earlier example, the host interface tools may be used to issue a power-role swap.

Taking the lesson learned from [Section 5.1](#), power both EVMs and then connect. The PD flow should be as was already shown in [Figure 4](#). The end state of this system is that the *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl* EVM is the power source and the *TPS65982_HD3SS460_DRP_Host_Full_2_9.tpl* EVM is the data host.

As a next step, use the host interface tool to issue a *Swap to Sink* PD message to the port partner.




Figure 11. SWSk Command Page Before Execution

[Figure 11](#) shows the command page for the SWSk (swap to sink) host interface command. The tools are attached to the EVM that has been configured with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*, which always comes up as the power source in this example because it has the *try.SRC* feature enabled.

Before issuing SWSk, the PD Status register, displayed at the bottom of the command page, shows that the system is currently the power source (*Source-Sink* field).

After pressing the *Execute Function* button, the tool indicates a successful execution as shown in [Figure 12](#); however, the PD Status register still indicates that the device is the power source, just as it was before issuing the SWSk command. This scenario is referred to as a *swap reversal* which is an accidental scenario that arises from configuring the TPS65982 device with non-persistent swap conditions.




Figure 12. SWSk Power-Role Swap to Sink Attempt (Inconclusive Result)

As shown in [Figure 12](#), the host interface tool reports a successful completion of the *Swap to Source* command, but the Power Status register reports that the device is still a source. The reason that the device is still a source after a *Swap to Sink* command that is reported as successful is shown in [Figure 13](#). This PD capture is started at the point in which the SWSk command is issued from the host interface tool. The trace shows that, in fact, a successful *Swap to Sink* PD message sequence operation does occur (packets 1 through 15); however, the system immediately issues another swap request. The reason is shown by revisiting the Control Configuration register on the device programmed as *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*.




Figure 13. PD Trace of Manual Power-Role Swap Followed by Automatic Power-Role Swap

Referring back to Figure 5, recall that the source device has the *Initiate Swap to Source* setting enabled. The behavior of this setting is that it initiates a *Swap to Source* request at any time that the device is a sink and none of the blocking conditions of Table 1 are present. So, in this system, when the manual swap requests swaps power roles, the *Initiate Swap to Source* setting immediately swaps the power role back. In fact, any number of *Swap to Sink* requests are immediately swapped back as long as this setting is enabled.




Figure 14. TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl With InitSwapToSource Disabled

A simple means of completing this test is to use the host interface tools to disable *Initiate Swap to Sink* in the Control Configuration register (0x29) of the EVM that has been configured with *TPS65982_HD3SS460_DRP_Source_Full_2_9.tpl*.

NOTE: Register changes made with the host interface tools are made only in the device RAM, not the system FLASH, and will therefore be reset back to their default values if there is a device reset or power cycle.

Do not forget to click the *Write Register* button after making this change.

The *Process Swap to Sink* field does not need to be enabled for the SWSk command to work properly. This field is only used to evaluate swap requests that are initiated by the port partner.




Figure 15. Manual Swap to Sink (Successful and Persistent)

Figure 15 shows the successful completion of the SWSk host interface command after disabling *Initiate Swap to Source* field in Control Configuration register (0x29). The Power Status register now shows the device is the power sink in the connection.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2019, Texas Instruments Incorporated