

BENCH BRIEFS

SERVICE INFORMATION FROM HEWLETT-PACKARD

3rd Quarter 1987

A Few Fundamentals About Semiconductors

The diode, one of the simplest of semiconductor devices, functions as a low-resistance conductor to current flowing in one direction and as a virtually "open" conductor for current flowing in the opposite direction.

Diodes are most commonly made by growing materials with p-type impurities on materials with n-type impurities to form what is known as a pn junction.


These devices are said to be forward-biased when conventional current flows from the anode, or p-type material, across the junction to the cathode, or n-type material, with a positive-voltage connected to the p-side and a negative voltage connected to the n-side. (This is the same as saying that forward-biased electrons flow easily from the cathode to the anode.)

In the reverse- or backward-bias condition with a positive voltage on the n-type material (cathode), diodes become good insulators and their resistance may be $1M\Omega$ or more. In this instance, electrons can't flow easily across the junction, because a high potential barrier or depletion region exists. The diode is the same as a check valve in a waterline, allowing water (or current) to flow in only one direction.

Diodes may be made of germanium, silicon or gallium arsenide, and the electrical characteristics of the diode depend on the physical properties of these materials.

The most useful property of the diode is its ability to convert alternating current to direct current by a process called rectification. It is also used to demodulate or detect radio-frequency signals, clamp or limit signal levels and bypass current to ground.

Signal-level diodes are those capable of handling up to 1 watt of power, but there are also many specialized diodes, such as those listed below.



Rectifiers—power diodes used primarily for power rectification in half-wave and full-wave bridge configurations. High-power rectifiers are usually packaged in metal cases to permit the rapid dissipation of heat.

Zener Diodes—designed for normal reverse-bias operation. This diode is made so that when the voltage applied reaches a specified value, the device breaks down in a nondestructive manner.

Thus, after achieving the breakdown voltage, the voltage across the zener remains essentially constant for any further increase of reverse current up to a preset limit.

Zener diodes are used for voltage regulation, overvoltage protection and voltage reference. Two "back to back" zeners may be used to limit alternating-current voltage levels or suppress voltage transients on an ac line.

Commercial zener diodes are available across the power range of .25 to 50 watts. Breakdown voltages may be between 1.8 and 200 volts. Thus, there are both signal-level and power zeners.

Varactors—the voltage-variable capacitor diode, or varactor, is intended for tuning applications in radio and TV circuits. When the diode is reverse-biased, its barrier width, or depletion region, at the pn junction can be controlled by varying the bias.

Since the depletion region acts as a dielectric between two conducting plates, the varactor acts as a capacitor whose capacitance value depends on the applied reverse voltage.

TVs or radios may be tuned to channels or stations manually by turning a knob that changes the position of capacitor plates with respect to one another. They use a manually altered air variable tuner. The same result may be obtained by changing the voltage on a varactor, perhaps with the use of a pushbutton panel or remote control.

PIN Diodes—are specialized microwave diodes and are called PIN diodes with reference to their layers of p-type, intrinsic-type and n-type silicon. When the PIN diode is reversed-biased, it has a high impedance at microwave frequencies. However, when it is forward-biased, it has a very low impedance at these frequencies. The impedance can be varied continuously by gradually changing the dc bias. We can also vary the bias with an audio or video frequency signal to modulate a microwave carrier.

A switching PIN diode acts like a capacitor paralleled by a variable resistor. The capacitance value remains relatively constant with changes in the applied voltage, while the ability of the resistor to conduct current is proportional to the charge.

stored in the diode.


Therefore, by changing the bias on the PIN diode from reverse to forward, usually by high-speed digital signals, the PIN diode is able to act as a high-speed switch.

These diodes are rated for use at different frequency ranges such as VHF, UHF and SHF (superhigh frequency). VHF PIN diodes are used for general-purpose switching, but UHF and SHF PIN diodes are used in attenuators and modulators as well as switches.

Bipolar Transistors—three-terminal devices that have the ability to control current. There are two common bipolar transistors: npn and pnp, with p representing p-type semiconductor material and n representing n-type. The area where the p-type and n-type materials join is called the pn junction, as in a diode.

Conventional current flows into the base and collector of an npn transistor and out of the emitter. Current flow in a pnp transistor is opposite to the npn: current flows into the emitter and out of the base and collector (note that it is in the direction of the arrows on the transistor symbols). Although they have differences in current and electron flow, both npn and pnp bipolar transistors can function as amplifiers and switches.

The base-emitter junction of a transistor acts like a diode. Under normal operation of an npn transistor, for example, current flows forward into the base and out of the emitter, but does not flow in the reverse direction from emitter to base. At the same time, the collector-base junction also acts as a diode, but supply voltage is always applied to it in the reverse direction. Although it is very small, some reverse current flows from this junction.



The term bipolar refers to conduction through both n- and p-type materials. There are many characteristics that define a bipolar transistor including current gain, noise figure, maximum power dissipation, conductivity, leakage current and breakdown voltage.

Another characteristic, operating speed, indicates the switching speed or operating frequency of the transistor. The transition frequency or f_T is the highest frequency at which the transistor can operate and still provide effective amplification. This is especially important in radio-frequency amplifiers.

Field-Effect Transistors—or FETs, depend on majority carrier current for their operation; that is, the carriers stay in the same kind of material when passing from source to drain. A FET has a conductive channel of either n- or p-type semiconductor material whose conductivity is controlled by the application of a voltage to a gate terminal.

There are two kinds of FETs—the junction-gate FET, or JFET, and the insulated-gate FET, or MOSFET. Both are considered unipolar devices.

JFETs are further classified as either p- or n-channel-depletion types,

while MOSFETs may be either p- or n-channel-depletion or p- or n-channel-enhancement types.

Current carriers are injected at one terminal (the source) and pass to the other (the drain).

The ability of this channel to conduct the carriers depends on the condition of the depletion region. The external bias signal applied to the gate alters the conductivity of the channel, making it either more or less difficult for current to pass. Like the conventional vacuum tube, the junction-gate FET is basically an on device and must be biased part-way off to set the operating point in a position for amplification.


The source (terminal) of the FET corresponds to the emitter, the drain corresponds to the plate and the gate corresponds to the base of the bipolar transistor. When no control signal is applied to the gate, current cannot flow from source to drain.

This is similar to the situation that occurs in a bipolar transistor when no signal is applied to the base.


A significant difference between the bipolar transistor and the FET, however, is that current applied to the transistor base controls the transistor, but voltage applied to the gate controls the FET.

Thus, the term "field effect" refers to the effect of an electric field within the device created by the gate voltage. The term "metal-oxide semiconductor" describes the construction of the device—a metal gate, an oxide layer and a semiconductor channel. □


THREE DIFFERENT VIEWS OF BIPOLAR NPN TRANSISTORS



Functional Diagram



Schematic Diagram



Replacement Part Cross Reference

When selecting replacement parts for your HP products, you may notice that many manuals list only an HP part number for the part, even though it appears that this part is manufactured by one of the large semiconductor manufacturers. Service personnel often ask why only HP part numbers are listed.

It is recommended that HP replacement parts be used to ensure that original performance of the product will be retained. While some parts used in HP instruments are identical to those that can be purchased at a local electronics distributor, many times parts will be selected for certain characteristics,

such as gain, bandwidth, capacitance, etc. There may also be slight mechanical differences, such as the shaping or length of leads. In some cases special quality checks are used to ensure that high reliability parts are used at the factory and at HP field offices.

Therefore, we suggest obtaining replacement parts from HP to maintain the quality that you have paid for in your instrument. There may be situations however, where HP replacement parts are not in stock and substituting parts will allow you to return the product to service immediately. In these cases it may be worthwhile to see if a substitute part

will work in the circuit. Perhaps an HP part could be ordered and installed at some later date.

To help you in these situations, here is a cross-reference of HP part numbers to JEDEC numbers for transistors and diodes.

NOTE

This is not a comprehensive list. Many semiconductors are made exclusively for Hewlett-Packard and there are no substitutes. If the part number you are looking for is not listed here, it does not have a JDEC number and must be replaced with the same HP part number. □

Manufacturers Code Number Cross Reference

No. Manufacturer

| | |
|-------|---|
| 00039 | NEC ELECTRONICS INC |
| 00046 | UNITRODE CORP |
| 00746 | ROHM CORP |
| 01250 | GTE SYLVANIA ELEK COMPONENTS GROUP |
| 01590 | PLESSY SEMICONDUCTORS |
| 01691 | TRW INC SEMICONDUCTOR DIV |
| 01698 | TEXAS INSTRUMENTS INC |
| 01921 | RCA CORP |
| 01973 | GE CO SEMICONDUCTOR PROD DEPT |
| 01979 | LANSDALE TRANSISTOR & ELEK INC |
| 01991 | TRANSITRON ELECTRONIC CORP |
| 02037 | MOTOROLA INC |
| 02062 | HP DIV 05 MSD |
| 02086 | WESTINGHOUSE ELEC CORP SEMICON DEPT/OUNGWOD |
| 02158 | EDAL INDUSTRIES INC |
| 02180 | PRECISION MONOLITHICS INC |
| 02237 | FAIRCHILD SEMICONDUCTOR CORP |
| 02526 | SEMICON INC |
| 02569 | CRYSTALONICS, DIV TELEDYNE |
| 02619 | SOLIDTRON DEVICES INC (DIODES) |
| 02634 | SPRAGUE ELECTRIC SEMICON DIV |
| 02661 | SEMTECH CORP |
| 02682 | ITT SEMICONDUCTORS DIV |
| 02684 | MICROSEMI CORP |
| 02713 | GENERAL INSTRUMENT CORP (DIODE) |
| 02763 | TELEDYNE SEMICONDUCTOR |
| 02783 | INT'L DIODE CORP |
| 02788 | M/A-COM INC |
| 02803 | CODI SEMICONDUCTOR |
| 02865 | ALPHA INDUSTRIES INC |
| 02883 | SILICONIX INC |
| 02910 | SIGNETICS CORP |
| 03038 | INT'L RECTIFIER CORP |
| 03171 | SOLIDTRON DEVICES INC |
| 03191 | SOLIDTRON DEVICES INC (FETS, DIODES) |
| 03285 | ANALOG DEVICES INC |
| 03287 | GENERAL SEMICONDUCTOR IND INC |
| 03291 | AVANTEK INC |
| 03334 | NV PHILIPS ELCOMA |
| 03406 | NATIONAL SEMICONDUCTOR CORP |
| 03447 | HUGHES AIRCRAFT CO NEW BEACH DIV |
| 03571 | LANSDALE XSTR ELEK CO ADVANCE LINE COLMAR |

No. Manufacturer

| | |
|-------|---|
| 00039 | NEC ELECTRONICS INC |
| 00046 | UNITRODE CORP |
| 00746 | ROHM CORP |
| 01250 | GTE SYLVANIA ELEK COMPONENTS GROUP |
| 01590 | PLESSY SEMICONDUCTORS |
| 01691 | TRW INC SEMICONDUCTOR DIV |
| 01698 | TEXAS INSTRUMENTS INC |
| 01921 | RCA CORP |
| 01973 | GE CO SEMICONDUCTOR PROD DEPT |
| 01979 | LANSDALE TRANSISTOR & ELEK INC |
| 01991 | TRANSITRON ELECTRONIC CORP |
| 02037 | MOTOROLA INC |
| 02062 | HP DIV 05 MSD |
| 02086 | WESTINGHOUSE ELEC CORP SEMICON DEPT/OUNGWOD |
| 02158 | EDAL INDUSTRIES INC |
| 02180 | PRECISION MONOLITHICS INC |
| 02237 | FAIRCHILD SEMICONDUCTOR CORP |
| 02526 | SEMICON INC |
| 02569 | CRYSTALONICS, DIV TELEDYNE |
| 02619 | SOLIDTRON DEVICES INC (DIODES) |
| 02634 | SPRAGUE ELECTRIC SEMICON DIV |
| 02661 | SEMTECH CORP |
| 02682 | ITT SEMICONDUCTORS DIV |
| 02684 | MICROSEMI CORP |
| 02713 | GENERAL INSTRUMENT CORP (DIODE) |
| 02763 | TELEDYNE SEMICONDUCTOR |
| 02783 | INT'L DIODE CORP |
| 02788 | M/A-COM INC |
| 02803 | CODI SEMICONDUCTOR |
| 02865 | ALPHA INDUSTRIES INC |
| 02883 | SILICONIX INC |
| 02910 | SIGNETICS CORP |
| 03038 | INT'L RECTIFIER CORP |
| 03171 | SOLIDTRON DEVICES INC |
| 03191 | SOLIDTRON DEVICES INC (FETS, DIODES) |
| 03285 | ANALOG DEVICES INC |
| 03287 | GENERAL SEMICONDUCTOR IND INC |
| 03291 | AVANTEK INC |
| 03334 | NV PHILIPS ELCOMA |
| 03406 | NATIONAL SEMICONDUCTOR CORP |
| 03447 | HUGHES AIRCRAFT CO NEW BEACH DIV |
| 03571 | LANSDALE XSTR ELEK CO ADVANCE LINE COLMAR |

| | |
|-------|---|
| 00039 | NEC ELECTRONICS INC |
| 00046 | UNITRODE CORP |
| 00746 | ROHM CORP |
| 01250 | GTE SYLVANIA ELEK COMPONENTS GROUP |
| 01590 | PLESSY SEMICONDUCTORS |
| 01691 | TRW INC SEMICONDUCTOR DIV |
| 01698 | TEXAS INSTRUMENTS INC |
| 01921 | RCA CORP |
| 01973 | GE CO SEMICONDUCTOR PROD DEPT |
| 01979 | LANSDALE TRANSISTOR & ELEK INC |
| 01991 | TRANSITRON ELECTRONIC CORP |
| 02037 | MOTOROLA INC |
| 02062 | HP DIV 05 MSD |
| 02086 | WESTINGHOUSE ELEC CORP SEMICON DEPT/OUNGWOD |
| 02158 | EDAL INDUSTRIES INC |
| 02180 | PRECISION MONOLITHICS INC |
| 02237 | FAIRCHILD SEMICONDUCTOR CORP |
| 02526 | SEMICON INC |
| 02569 | CRYSTALONICS, DIV TELEDYNE |
| 02619 | SOLIDTRON DEVICES INC (DIODES) |
| 02634 | SPRAGUE ELECTRIC SEMICON DIV |
| 02661 | SEMTECH CORP |
| 02682 | ITT SEMICONDUCTORS DIV |
| 02684 | MICROSEMI CORP |
| 02713 | GENERAL INSTRUMENT CORP (DIODE) |
| 02763 | TELEDYNE SEMICONDUCTOR |
| 02783 | INT'L DIODE CORP |
| 02788 | M/A-COM INC |
| 02803 | CODI SEMICONDUCTOR |
| 02865 | ALPHA INDUSTRIES INC |
| 02883 | SILICONIX INC |
| 02910 | SIGNETICS CORP |
| 03038 | INT'L RECTIFIER CORP |
| 03171 | SOLIDTRON DEVICES INC |
| 03191 | SOLIDTRON DEVICES INC (FETS, DIODES) |
| 03285 | ANALOG DEVICES INC |
| 03287 | GENERAL SEMICONDUCTOR IND INC |
| 03291 | AVANTEK INC |
| 03334 | NV PHILIPS ELCOMA |
| 03406 | NATIONAL SEMICONDUCTOR CORP |
| 03447 | HUGHES AIRCRAFT CO NEW BEACH DIV |
| 03571 | LANSDALE XSTR ELEK CO ADVANCE LINE COLMAR |

HP P/N Mfr. Desc.

| | | |
|-----------|-------|-----------|
| 1820-0225 | 03406 | LM103-2.4 |
| 1820-0240 | 01921 | CA3026 |
| 1820-0352 | 01921 | CA3018 |
| 1820-1804 | 02037 | MPQ684#2 |
| 1821-0001 | 01921 | CA3046 |
| 1821-0021 | 01921 | CA3045 |
| 1821-0006 | 02237 | SH6501PC |
| 1850-0033 | 01921 | 2N1516 |
| 1850-0018 | 01921 | 2N384 |
| 1850-0021 | 01921 | 2N1143 |
| 1850-0031 | 01921 | 2N526 |
| 1850-0032 | 01921 | 2N404 |
| 1850-0044 | 01921 | 2N384 |
| 1850-0043 | 01921 | 2N1516 |
| 1850-0051 | 02634 | 2N1500 |
| 1850-0052 | 02713 | 2N506 |
| 1850-0055 | 04200 | 2N2360 |
| 1850-0056 | 02037 | 2N174 |
| 1850-0059 | 02037 | 2N174 |
| 1850-0061 | 01698 | 2N2561 |
| 1850-0062 | 06632 | 2N404A |
| 1850-0064 | 01921 | 2N1183 |

| | | |
|-----------|-------|---------|
| 1850-0065 | 01921 | 2N1370 |
| 1850-0074 | 01921 | 2N1366 |
| 1850-0075 | 01921 | 2N779A |
| 1850-0076 | 01698 | 2N2556 |
| 1850-0078 | 02037 | 2N398B |
| 1850-0085 | 02037 | 2N64 |
| 1850-0093 | 03571 | 2N1499A |
| 1850-0096 | 01698 | 2N2189 |
| 1850-0099 | 06362 | 2N961 |
| 1850-0103 | 01698 | 2N2190 |
| 1850-0105 | 01979 | 2N2048 |
| 1850-0110 | 02713 | 2N604 |
| 1850-0111 | 01698 | 2N404A |
| 1850-0112 | 01698 | 2N2001 |
| 1850-0113 | 01698 | 2N1997 |
| 1850-0114 | 01921 | 2N1905 |
| 1850-0119 | 02037 | 2N963 |
| 1850-0126 | 01921 | 2N2869 |
| 1850-0127 | 02713 | 2N159A |
| 1850-0130 | 02037 | 2N1193 |
| 1850-0131 | 02037 | 2N1192 |

| | | |
|-----------|-------|--------|
| 1850-0137 | 01979 | 2N976 |
| 1850-0146 | 02619 | 2N1501 |
| 1850-0150 | 05840 | 2N1358 |
| 1850-0151 | 01698 | 2N1309 |
| 1850-0154 | 01979 | 2N508A |
| 1850-0156 | 01979 | S4617 |
| 1850-0160 | 01921 | 2N2147 |
| 1850-0163 | 02037 | 2N2635 |
| 1850-0166 | 01698 | 2N2188 |
| 1850-0170 | 01698 | 2N1377 |
| 1850-0172 | 01698 | 2N2996 |
| 1850-0173 | 01698 | 2N1307 |
| 1850-0178 | 01698 | 2N1038 |
| 1850-0179 | 02037 | 2N3232 |
| 1850-0180 | 01698 | 2N1374 |
| 1850-0181 | 01698 | 2N2552 |
| 1850-0182 | 01698 | 2N1378 |
| 1850-0194 | 05840 | 2N1523 |
| 1850-0404 | 01698 | 2N1305 |
| 1850-0406 | 02783 | 2N1760 |
| 1850-0409 | 01698 | 2N2664 |
| 1850-0417 | 02713 | 2N597 |

HP P/N Mfr. Desc.

| | | | | | | | | | | | |
|-----------|-------|----------|-----------|-------|--------------------|-----------|-------|---------------|-----------|-------|----------|
| 1853-0012 | 02037 | 2N2904A | 1853-0437 | 02037 | 2N6520 | 1853-0645 | 02037 | NMBT4126 | 1854-0399 | 02037 | 2N4912 |
| 1853-0013 | 01698 | 2N2904 | 1853-0439 | 01921 | 2N6248 | 1853-0650 | 02037 | 2N4405 | 1854-0409 | 02037 | 2N5210 |
| 1853-0014 | 02237 | 2N3304 | 1853-0440 | 02037 | MME018 | 1853-0652 | 02037 | MJE15031 | 1854-0411 | 02037 | 2N2972 |
| 1853-0015 | 01698 | 2N1131 | 1853-0441 | 02037 | MJE2955T | 1853-0654 | 01698 | TIP32F | 1854-0416 | 02237 | 2N3426 |
| 1853-0023 | 01698 | 2N3703 | 1853-0442 | 02037 | 2N367 | 1853-0657 | 02037 | MJE5852 | 1854-0418 | 02237 | 2N3563 |
| 1853-0028 | 02037 | 2N3634 | 1853-0447 | 02037 | MJE253 | 1853-0659 | 02037 | 2N3905 (SEL) | 1854-0431 | 01921 | 2N5179 |
| 1853-0031 | 02037 | 2N3789 | 1853-0448 | 02037 | MPSH81 | 1853-0660 | 02037 | MPSW51 | 1854-0432 | 02237 | 2N3646 |
| 1853-0033 | 04200 | 2N3318 | 1853-0449 | 02037 | MPS-U95 | 1853-0661 | 02037 | 2N6124 | 1854-0435 | 03334 | A211 |
| 1853-0036 | 03406 | 2N3906 | 1853-0450 | 02037 | MJE371K (SELECTED) | 1853-0662 | 02037 | MPSH54 | 1854-0453 | 02037 | 2N5192 |
| 1853-0043 | 02037 | MPS 623 | 1853-0451 | 01698 | 2N3799 | 1853-0663 | 02037 | MD6002 | 1854-0453 | 01921 | 2N5406 |
| 1853-0045 | 01921 | 2N4036 | 1853-0452 | 02037 | 2N6594 | 1853-0664 | 02237 | FW4250 | 1854-0456 | 01698 | TIP41A |
| 1853-0046 | 02037 | 2N3250 | 1853-0453 | 01698 | TIP336 | 1853-0665 | 02037 | 2N3640RLRA1 | 1854-0467 | 02037 | 2N4401 |
| 1853-0051 | 01921 | 2N4037 | 1853-0454 | 01698 | TIP106 | 1853-0666 | 02037 | 2N6667 | 1854-0472 | 02037 | MPS-A14 |
| 1853-0052 | 02037 | 2N3740 | 1853-0455 | 02037 | MJE6400 | 1853-0667 | 02037 | 2N6107 (SEL) | 1854-0474 | 02037 | 2N5551 |
| 1853-0057 | 0263h | 3N91 | 1853-0457 | 02037 | 2N5400 | 1853-0668 | 01698 | TIP115 | 1854-0476 | 01921 | 2N3879 |
| 1853-0058 | 02237 | S32248 | 1853-0458 | 02037 | MJE251 | 1853-0670 | 02037 | 2N6213 | 1854-0477 | 02237 | 2N2222A |
| 1853-0059 | 02037 | 2N3791 | 1853-0461 | 02037 | 2N6318 | 1853-0672 | 05946 | BPFQ23C | 1854-0478 | 02237 | 2N4046 |
| 1853-0071 | 02037 | 2N3494 | 1853-0462 | 02037 | 2N3635 | 1853-0673 | 02037 | 2N3811 | 1854-0492 | 02037 | MPS3643 |
| 1853-0072 | 02237 | 2N4034 | 1853-0463 | 02037 | TIP105 | 1853-0674 | 00746 | 2SBL007 | 1854-0511 | 02037 | MPS-U02 |
| 1853-0081 | 02237 | 2N4258 | 1853-0464 | 01698 | TIS-119 | 1854-0004 | 01698 | 2N743 | 1854-0518 | 02037 | 2N5877 |
| 1853-0084 | 02037 | 2N4918 | 1853-0467 | 02037 | MPS-D54 | 1854-0005 | 02237 | 2N708 | 1854-0519 | 01921 | 2N3772 |
| 1853-0086 | 03406 | 2N5087 | 1853-0468 | 01698 | TIP-127 | 1854-0009 | 02037 | 2N709 | 1854-0527 | 02037 | 2N2895 |
| 1853-0087 | 01921 | 40394 | 1853-0469 | 02037 | 2N6109 | 1854-0010 | 02037 | 2N834 | 1854-0534 | 01921 | 2N5838 |
| 1853-0089 | 02237 | 2N4917 | 1853-0470 | 02037 | JAN TXV 2N2907A | 1854-0011 | 02037 | 2N835 | 1854-0540 | 02037 | MMW006 |
| 1853-0091 | 02237 | 2N4917 | 1853-0471 | 02037 | MD-982 | 1854-0013 | 02037 | 2N2218A | 1854-0547 | 01698 | 2N3725 |
| 1853-0097 | 02237 | BSX29 | 1853-0472 | 04550 | D45H2 | 1854-0014 | 02037 | 2N2720 | 1854-0548 | 02237 | 2N5963 |
| 1853-0204 | 02037 | 2N4920 | 1853-0476 | 02037 | MPS-U52 | 1854-0017 | 02237 | 2N706A | 1854-0555 | 02037 | MMT3960 |
| 1853-0205 | 02037 | 2N2907 | 1853-0477 | 02037 | JANTV2N3251A | 1854-0022 | 02237 | 2N918 | 1854-0556 | 02037 | 2N2427 |
| 1853-0206 | 02237 | .2N4028 | 1853-0478 | 02037 | 2N6490 | 1854-0022 | 02237 | S17843 | 1854-0557 | 01698 | 2N2432A |
| 1853-0212 | 02037 | 2N5194 | 1853-0479 | 04550 | 72006 | 1854-0028 | 01973 | 2N335 | 1854-0560 | 02037 | MPS-A12 |
| 1853-0213 | 02037 | 2N4236 | 1853-0483 | 02037 | MPS-A66 | 1854-0029 | 01973 | 2N2712 | 1854-0566 | 01921 | 2N3771 |
| 1853-0217 | 02037 | MPS-404A | 1853-0484 | 02037 | MDE2905A | 1854-0032 | 02237 | 2N2369 | 1854-0570 | 01921 | 2N5189 |
| 1853-0221 | 01921 | 2N5416 | 1853-0487 | 02037 | 2N6609 | 1854-0031 | 01698 | 2N865 | 1854-0572 | 01921 | 2N5805 |
| 1853-0222 | 02037 | 2N4919 | 1853-0488 | 0237 | MPS4356 | 1854-0032 | 02037 | 2N2221 | 1854-0575 | 02037 | MPS-A42 |
| 1853-0223 | 02037 | 2N4902 | 1853-0489 | 02037 | MME4032 | 1854-0033 | 01973 | 2N3391 | 1854-0576 | 01921 | 2N6258 |
| 1853-0224 | 01921 | 2N5415 | 1853-0490 | 02037 | TIP107 | 1854-0036 | 02037 | 2N2958 | 1854-0577 | 01921 | 2N6259 |
| 1853-0231 | 01698 | TIP42A | 1853-0492 | 02037 | MJE2955 | 1854-0039 | 01921 | 2N3053 | 1854-0580 | 02037 | MMB801 |
| 1853-0236 | 02037 | 2N5102 | 1853-0493 | 03334 | 2N5415 | 1854-0044 | 01698 | 2N2716 | 1854-0581 | 02037 | MJE800 |
| 1853-0244 | 02037 | MPS3640 | 1853-0494 | 04550 | D45H5 | 1854-0045 | 01921 | 2N887 | 1854-0583 | 02037 | MPS-A18 |
| 1853-0258 | 02237 | 2N4035 | 1853-0496 | 02037 | MPS-U57 | 1854-0050 | 02237 | 2N916 | 1854-0585 | 02037 | MJE182 |
| 1853-0261 | 02037 | 2N5401 | 1853-0497 | 04550 | D45H11 | 1854-0053 | 02037 | 2N2218 | 1854-0586 | 02037 | 2N5429 |
| 1853-0269 | 02037 | 2N3809 | 1853-0498 | 02037 | TIP145 | 1854-0054 | 01921 | 2N3119 | 1854-0587 | 02037 | MMT3960A |
| 1853-0271 | 02037 | 2N4403 | 1853-0501 | 02037 | MJ11015 | 1854-0057 | 01973 | 2N3855A | 1854-0589 | 02037 | MJ3772 |
| 1853-0272 | 02037 | MPS4007 | 1853-0502 | 02037 | MMBT81 | 1854-0060 | 02237 | 2N3656 | 1854-0590 | 01921 | 2N3054 |
| 1853-0277 | 01921 | 2N5954 | 1853-0503 | 02037 | 2C4403 | 1854-0062 | 01921 | 2N701 | 1854-0591 | 03334 | BFR90 |
| 1853-0280 | 02037 | 2N5195 | 1853-0504 | 02037 | MJ11021 | 1854-0063 | 01921 | 2N3055 | 1854-0592 | 01698 | TIP-35A |
| 1853-0281 | 02682 | 2N2907A | 1853-0505 | 02037 | 2N3256 | 1854-0064 | 01698 | 2N3710 | 1854-0594 | 01698 | TIP-33 |
| 1853-0287 | 02037 | 2N3252 | 1853-0506 | 02037 | 2N6437 | 1854-0065 | 01973 | 2N2925 | 1854-0596 | 02037 | 2N5427 |
| 1853-0290 | 02037 | JTM2907A | 1853-0507 | 03334 | BFQ-32 | 1854-0067 | 01921 | 2N2102 | 1854-0597 | 02037 | 2N5943 |
| 1853-0292 | 02037 | 2N3905 | 1853-0509 | 02037 | MD1130 | 1854-0071 | 00746 | CP4071 | 1854-0598 | 01921 | 2N6249 |
| 1853-0293 | 02037 | 2N5583 | 1853-0510 | 02037 | MPS6534 | 1854-0072 | 01921 | 2N3054 | 1854-0599 | 01921 | 2N6078 |
| 1853-0303 | 02037 | 2N5956 | 1853-0512 | 02037 | MME2955 | 1854-0073 | 01921 | 2N3119 | 1854-0600 | 02037 | 2N4233A |
| 1853-0305 | 02037 | 2N5875 | 1853-0513 | 02037 | MD3680 | 1854-0076 | 01921 | 2N3139 | 1854-0611 | 02037 | 2N6055 |
| 1853-0308 | 02037 | MME405 | 1853-0514 | 02037 | 2N7571 | 1854-0078 | 01698 | 2N3711 | 1854-0612 | 01921 | 40608 |
| 1853-0310 | 02037 | 2N4398 | 1853-0540 | 02037 | 2N6491 | 1854-0084 | 02037 | 2N3232 | 1854-0613 | 01921 | 2N1701 |
| 1853-0311 | 02037 | 2N3792 | 1853-0542 | 02037 | 2N6492 | 1854-0086 | 05840 | DTSL13 | 1854-0615 | 01921 | 40854 |
| 1853-0314 | 02037 | 2N2905A | 1853-0543 | 01698 | TIP647 | 1854-0089 | 03334 | 2N3053LV 2449 | 1854-0617 | 01921 | 40852 |
| 1853-0318 | 02037 | MPS6562 | 1853-0544 | 03334 | BFQ51 | 1854-0093 | 04550 | 2N3145 | 1854-0618 | 02037 | MJ3000 |
| 1853-0320 | 02237 | 2N4032 | 1853-0545 | 01698 | BCX18 | 1854-0095 | 01921 | 40346 | 1854-0619 | 03285 | AD814 |
| 1853-0322 | 01698 | 2N2946A | 1853-0546 | 02037 | 2N3765 | 1854-0096 | 04550 | 2N3392 | 1854-0621 | 01698 | BF258 |
| 1853-0323 | 02037 | 2N4000 | 1853-0547 | 02037 | MJE2901T | 1854-0203 | 02237 | 2N3694 | 1854-0622 | 02037 | MJE340 |
| 1853-0326 | 02037 | MPS-U51 | 1853-0548 | 02037 | 2N6420 | 1854-0209 | 02237 | 2N910 | 1854-0623 | 02037 | 2N6306 |
| 1853-0327 | 01698 | 40831 | 1853-0550 | 00744 | 2SBP73 | 1854-0210 | 02037 | 2N2222 | 1854-0624 | 02037 | 2N6308 |
| 1853-0328 | 01921 | 2N6211 | 1853-0551 | 03404 | TN4030-D742 | 1854-0211 | 02037 | 2N2501 | 1854-0625 | 01698 | TIP-11 |
| 1853-0337 | 02037 | MJE1091 | 1853-0552 | 02037 | MPSW56 | 1854-0213 | 01698 | 2N2538 | 1854-0626 | 02037 | MJE802 |
| 1853-0341 | 02037 | MJE1090 | 1853-0553 | 03334 | A440 | 1854-0215 | 01921 | 2N1482 | 1854-0628 | 02037 | MPS-H17 |
| 1853-0349 | 01698 | 2N5333 | 1853-0555 | 02037 | MPS404A | 1854-0215 | 02037 | 2N3904 | 1854-0632 | 02037 | MJE891 |
| 1853-0350 | 01698 | TIP-34 | 1853-0557 | 02037 | MME2906 | 1854-0216 | 02037 | 2N3441 | 1854-0633 | 02037 | MJE800 |
| 1853-0351 | 02037 | 2N6053 | 1853-0571 | 02037 | 2N2905A (SEL) | 1854-0233 | 01921 | 2N3866 | 1854-0634 | 02037 | MPS-U01 |
| 1853-0353 | 02037 | MPS-U55 | 1853-0572 | 02037 | MPSAT6 | 1854-0234 | 01921 | 2N3440 | 1854-0635 | 04550 | D44H5 |
| 1853-0355 | 01698 | TIP42 | 1853-0573 | 02037 | 2N6709 | 1854-0235 | 01921 | 2N1484 | 1854-0637 | 02037 | 2N219A |
| 1853-0356 | 02037 | 2N3799 | 1853-0574 | 02037 | 2N3468 | 1854-0236 | 02037 | 2N3953 | 1854-0639 | 01921 | RCP-703C |
| 1853-0362 | 02037 | 2N6053 | 1853-0576 | 02037 | 2N5416 (SEL) | 1854-0242 | 01921 | 2N3262 | 1854-0640 | 02037 | MJE2801K |
| 1853-0363 | 02037 | X4550 | 1853-0577 | 02037 | 2N3065RLRA2 | 1854-0242 | 01921 | 40250 | 1854-0642 | 02037 | MPS-A17 |
| 1853-0365 | 02037 | MJE2918 | 1853-0578 | 00309 | NE90115 | 1854-0244 | 02037 | SPS 233 | 1854-0654 | 02037 | 2N3484 |
| 1853-0366 | 02037 | MJE2910 | 1853-0579 | 02037 | 2SA1226 | 1854-0246 | 02037 | 2N3013 | 1854-0656 | 02037 | 2N3484 |
| 1853-0371 | 01921 | 2N6107 | 1853-0580 | 02037 | MDE2903 | 1854-0268 | 01698 | 2N4044 | 1854-0659 | 02037 | MJE180 |
| 1853-0372 | 02037 | MJE5195 | | | | | | | | | |

HP P/N Mfr. Desc.

| | | | | | | | | | | | |
|-----------|-------|-----------------|-----------|-------|-------------|-----------|-------|--------------|-----------|-------|-------------|
| 1854-0752 | 02037 | MMCS2369 | 1854-1004 | 02037 | BD415 | 1855-0020 | 02037 | SFE793 | 1855-0521 | 03038 | IRFF210 |
| 1854-0754 | 02037 | MJE244 | 1854-1005 | 02037 | BUS08A | 1855-0021 | 01973 | 2N1671B | 1855-0522 | 03038 | IRFD9120 |
| 1854-0755 | 01921 | 2N6254 | 1854-1006 | 02037 | BU406 | 1855-0027 | 04550 | 2N2647 | 1855-0523 | 06121 | BUZ 15 |
| 1854-0756 | 02037 | 2N6315 | 1854-1007 | 02037 | 2N5943(SEL) | 1855-0038 | 02763 | 2N3922 | 1855-0524 | 03038 | IRF640 |
| 1854-0758 | 02037 | 2N5427 | 1854-1008 | 00339 | NE-41635 | 1855-0040 | 01698 | 2N3819 | 1855-0525 | 02883 | VNO300M |
| 1854-0760 | 02037 | 2N2060 | 1854-1009 | 00339 | NE21935 | 1855-0052 | 02237 | 2N4360 | 1855-0526 | 02883 | VP0300M |
| 1854-0762 | 01921 | 2N5039 | 1854-1010 | 02037 | MD918A | 1855-0055 | 02883 | 2N4339 | 1855-0527 | 02037 | MTM2P45 |
| 1854-0763 | 01698 | TIP 141 | 1854-1014 | 02037 | MBT6429 | 1855-0056 | 02237 | 2N4342 | 1855-0528 | 03406 | PF5101(SEL) |
| 1854-0764 | 02037 | MPS U-10 | 1854-1015 | 02037 | MJ16012 | 1855-0065 | 01698 | 2N4391 | 1855-0530 | 02883 | U310 |
| 1854-0765 | 01921 | 2N6292 | 1854-1016 | 02037 | M2369A | 1855-0071 | 02569 | 2N5544 | 1855-0531 | 03038 | IRF120 |
| 1854-0766 | 02037 | 2N5428 | 1854-1018 | 02037 | 2N3714 | 1855-0077 | 01973 | 2N1671C | 1855-0531 | 01921 | 40673 |
| 1854-0767 | 01921 | 2N6306 | 1854-1019 | 03334 | BUM12A | 1855-0095 | 01921 | W0468 | 1855-0533 | 03714 | IT7150 |
| 1854-0768 | 02037 | MJE1661 | 1854-1020 | 02037 | MMCB132Q5 | 1855-0096 | 02037 | 2N5485(SEL) | 1855-0538 | 03038 | IRFD120 |
| 1854-0769 | 02062 | 358218 | 1854-1022 | 02037 | MRF561 | 1855-0098 | 03714 | TT1700 | 1855-0537 | 03714 | IVN5000TNE |
| 1854-0770 | 02037 | 2N3904 CHIP | 1854-1023 | 02037 | TIP112 | 1855-0099 | 02037 | 2N4563 | 1855-0539 | 06121 | BUZ24 |
| 1854-0771 | 03406 | 2N4384 CHIP | 1854-1027 | 02037 | MMBR931 | 1855-0204 | 02037 | 2N4852 | 1855-0540 | 03406 | 2N5115(SEL) |
| 1854-0774 | 01921 | 2N6056 | 1854-1028 | 02037 | 2N3904 | 1855-0205 | 02883 | VCR3P | 1855-0542 | 02037 | MTP12N06 |
| 1854-0775 | 03334 | BUX-80 | 1854-1029 | 04507 | LT1839-1 | 1855-0206 | 02883 | E111 | 1855-0545 | 02883 | VN10KE |
| 1854-0777 | 02237 | FT570 | 1854-1032 | 02037 | MRF581 | 1855-0207 | 03406 | 2N3955 | 1855-0546 | 07221 | VN0104N3 |
| 1854-0780 | 03334 | BUX-83 | 1854-1033 | 02062 | HXTR-3675 | 1855-0208 | 02883 | 2N4117 | 1855-0548 | 06121 | BUZ71A |
| 1854-0784 | 02037 | 2N3866A | 1854-1035 | 02037 | MID132 | 1855-0213 | 03406 | 2N5912 | 1855-0549 | 03038 | IRFS12 |
| 1854-0785 | 02037 | 2N6305 | 1854-1036 | 03334 | BFR94 | 1855-0215 | 02883 | SD211E(SEL) | 1855-0550 | 02883 | VPO300L |
| 1854-0786 | 02037 | 2N2540 | 1854-1037 | 02037 | MMBT3904 | 1855-0221 | 01698 | 2N3824 | 1855-0551 | 03038 | IRFD420 |
| 1854-0787 | 02037 | 2N6545 | 1854-1039 | 02037 | 2N4401 | 1855-0226 | 02037 | 2N4560 | 1855-0553 | 06121 | BZL20 |
| 1854-0792 | 02237 | 2N2920 | 1854-1041 | 06354 | 2SC2878 | 1855-0232 | 02883 | 2N5565 | 1855-0554 | 03406 | J304(SEL) |
| 1854-0793 | 01921 | 2N5671 | 1854-1042 | 02037 | MRF571(SEL) | 1855-0235 | 02037 | U310(SEL) | 1855-0555 | 02883 | VN300L |
| 1854-0794 | 02037 | MJE243 | 1854-1043 | 02037 | 2N5179(SEL) | 1855-0241 | 02910 | SD215 | 1855-0556 | 02883 | VN222L |
| 1854-0795 | 02037 | MPSH10 | 1854-1044 | 00339 | NE21935 | 1855-0242 | 03406 | 2N4857 | 1855-0557 | 09283 | SD306(SEL) |
| 1854-0797 | 01698 | B105 | 1854-1045 | 03334 | BFR92(SEL) | 1855-0250 | 01698 | 3N215 | 1855-0560 | 02883 | VN105 |
| 1854-0798 | 02037 | MPS-U5 | 1854-1046 | 07050 | MPM12-78-69 | 1855-0251 | 02037 | 2N6659 | 1855-0561 | 03038 | IRF510 |
| 1854-0799 | 02037 | TIP41C | 1854-1047 | 02037 | MRF587 | 1855-0256 | 02037 | 2N4416A CHIP | 1855-0562 | 03038 | IRF523 |
| 1854-0802 | 02037 | MMS262 | 1854-1048 | 02037 | 2N3904RLRA2 | 1855-0257 | 03406 | 2N5247 | 1855-0563 | 02037 | MTP12N18 |
| 1854-0803 | 01698 | TIP75B | 1854-1049 | 02037 | BFR96 | 1855-0258 | 03406 | 2N5914 | 1855-0565 | 01921 | RFP10N12 |
| 1854-0804 | 03038 | IR5062 | 1854-1050 | 03334 | BFR91A | 1855-0263 | 02883 | VMP-1 | 1855-0567 | 03038 | IRFD9123 |
| 1854-0805 | 02037 | BD139 | 1854-1051 | 02037 | 2N3772(SEL) | 1855-0265 | 02883 | WC2R2N | 1855-0568 | 06121 | BUZ71A |
| 1854-0806 | 01698 | TIP51 | 1854-1052 | 02037 | MPSR550 | 1855-0268 | 02883 | J309 | 1855-0569 | 00309 | NET1000 |
| 1854-0809 | 02037 | 2N3694A | 1854-1054 | 03334 | BF619 | 1855-0272 | 02037 | MPS3004 | 1855-0571 | 00309 | ZSS533 |
| 1854-0810 | 02037 | C10-1558 | 1854-1055 | 03334 | BFR93 | 1855-0274 | 02883 | E232 | 1855-0572 | 03038 | IRF523 |
| 1854-0813 | 02037 | 2N35015 | 1854-1056 | 02037 | MJ14000 | 1855-0275 | 02883 | VN66AF | 1855-0573 | 02883 | U440 |
| 1854-0817 | 02037 | MPS-U5 | 1854-1058 | 02037 | MJ13091 | 1855-0276 | 02037 | 2N4416A | 1855-0574 | 02883 | J175 |
| 1854-0819 | 02037 | MJE2801T | 1854-1059 | 02037 | 2N3904 | 1855-0277 | 02037 | 2N5268 | 1855-0575 | 02883 | 2N6660 |
| 1854-0825 | 02062 | HXTR-5002 | 1854-1060 | 02037 | MJH16018 | 1855-0278 | 01698 | 3N5198 | 1855-0576 | 00309 | 2SK105F,H |
| 1854-0826 | 03406 | LM-394B | 1854-1061 | 02037 | 2N59179 | 1855-0282 | 02037 | SD214 | 1855-0580 | 02883 | IRF123 |
| 1854-0827 | 02037 | MJE-13009 | 1854-1062 | 02037 | MKT2222A | 1855-0286 | 02910 | SD214 | 1855-0581 | 03038 | IRF521 |
| 1854-0828 | 01698 | TIP-122 | 1854-1064 | 02037 | MPSW01 | 1855-0288 | 02883 | E107 | 1855-0582 | 02883 | VN0300M |
| 1854-0829 | 02037 | JAN TXV 2N2222A | 1854-1066 | 00339 | NET316D | 1855-0289 | 02763 | 2N5396 | 1855-0583 | 02883 | VQ1001P |
| 1854-0830 | 03406 | LM394 | 1854-1067 | 03291 | AT-41435-5 | 1855-0289 | 01698 | 2N5246 | 1855-0585 | 02883 | IRF523 |
| 1854-0831 | 02037 | 2N6429A | 1854-1069 | 02037 | TIP50 | 1855-0295 | 02883 | VN3636 | 1855-0586 | 03038 | IRF523 |
| 1854-0834 | 01921 | 2N6033 | 1854-1071 | 02037 | MJ16018 | 1855-0296 | 02037 | 2N4416A | 1855-0587 | 03038 | IRF9521 |
| 1854-0836 | 02037 | MPS-U2 | 1854-1072 | 02037 | MJH16018 | 1855-0297 | 02037 | 2N5268 | 1855-0588 | 03038 | IRF9513 |
| 1854-0837 | 01921 | 2N6289 | 1854-1073 | 02037 | MKT2222A | 1855-0298 | 02037 | SD214 | 1855-0589 | 03038 | IRF513 |
| 1854-0838 | 02037 | TIP41C | 1854-1074 | 01698 | 2N5239 | 1855-0299 | 02883 | 2N3631 | 1855-0590 | 02037 | IRF540(SEL) |
| 1854-0839 | 02037 | 2N6407 | 1854-1075 | 02037 | D404D | 1855-0299 | 03406 | 2N5432 | 1855-0591 | 02883 | VQ1000J |
| 1854-0840 | 02037 | TIP100 | 1854-1076 | 00339 | NE55633 | 1855-0299 | 02883 | 2N6565 | 1855-0592 | 03038 | IRF523 |
| 1854-0842 | 02037 | 2N3014 | 1854-1079 | 02037 | TIP50 | 1855-0299 | 03038 | IRF300 | 1855-0593 | 02037 | MTM12N06 |
| 1854-0845 | 02037 | MJ11012 | 1854-1080 | 02037 | MRF962 | 1855-0299 | 02037 | 2N2608 | 1855-0594 | 02037 | MF960 |
| 1854-0847 | 02037 | MJE12007 | 1854-1082 | 02037 | 2N3771 | 1855-0299 | 02883 | J177 | 1855-0595 | 01921 | RFL1N08L |
| 1854-0848 | 01698 | 2N6584 | 1854-1084 | 02037 | MKT2222A | 1855-0301 | 02883 | 2N5198 | 1855-0596 | 02883 | VN222L |
| 1854-0849 | 02037 | MFR515 | 1854-1085 | 02037 | MKT2369 | 1855-0303 | 02883 | SD214 | 1855-0606 | 02037 | MTP5N40 |
| 1854-0851 | 02037 | 2N4428 | 1854-1089 | 01698 | TIP162A | 1855-0307 | 01921 | SD214 | 1855-0607 | 02037 | MTP4N50 |
| 1854-0860 | 02039 | 2S23234 | 1854-1090 | 02037 | MKT2369 | 1855-0307 | 02037 | 2N4352 | 1855-0616 | 02883 | 2N6659 |
| 1854-0861 | 02062 | HXTR-6001 | 1854-1091 | 02037 | MKT3904 | 1855-0311 | 04550 | 2N6027 | 1855-0617 | 01921 | RFP8P08 |
| 1854-0862 | 02062 | HXTR-5002 | 1854-1092 | 02037 | MKTB24 | 1855-0312 | 03334 | 2N5105 | 1855-0618 | 02037 | IRF140 |
| 1854-0863 | 02062 | HXTR-2101 | 1854-1094 | 02062 | HXTR-3002 | 1855-0313 | 02883 | SD214 | 1855-0619 | 01921 | RFL1N08L |
| 1854-0864 | 02062 | HXTR-6105 | 1854-1095 | 02037 | MKT6965 | 1855-0317 | 02883 | 2N4416 | 1855-0620 | 02883 | VQ1006P |
| 1854-0865 | 03038 | IR6062 | 1854-1096 | 02037 | MKT901 | 1855-0318 | 02883 | SD214 | 1855-0621 | 01921 | RFP6P08 |
| 1854-0867 | 02037 | PN3568 | 1854-1097 | 02037 | MKT2275 | 1855-0319 | 02883 | 2N6028 | 1855-0622 | 03038 | IRF521 |
| 1854-0868 | 02037 | TIP140 | 1854-1098 | 02037 | MKTB142T1 | 1855-0319 | 02883 | 2N4254 | 1855-0623 | 01921 | RFP512 |
| 1854-0881 | 01921 | 2N6488 | 1854-1099 | 02037 | BD435 | 1855-0321 | 02037 | 2N4092 | 1855-0624 | 02037 | IRF150N5L |
| 1854-0886 | 02037 | MJE3302 | 1854-1102 | 02037 | 2N6587 | 1855-0324 | 02883 | 2N5114 | 1855-0629 | 01921 | RFP15N05L |
| 1854-0887 | 02037 | MJE1016 | 1854-1123 | 02062 | HXTR-5102 | 1855-0325 | 02883 | 2N5519 | 1855-0630 | 02883 | 2N391(CHIP) |
| 1854-0889 | 02037 | MJE1499 | 1854-1124 | 02037 | 2N3771 | 1855-0326 | 02883 | SD21451 | 1855-0631 | 03038 | IRF740 |
| 1854-0890 | 02037 | MJE904 | 1854-1125 | 02037 | MKT5711 | 1855-0327 | 02883 | 2N5115 | 1855-0632 | 02037 | 2N4860 |
| 1854-0891 | 06023 | BU82 | 1854-1126 | 02037 | MKT512 | 1855-0328 | 02883 | J110 | 1855-0635 | 02883 | U401 |
| 1854-0906 | 02037 | MJE2010 | 1854-1127 | 02037 | MKT2369 | 1855-0329 | 02883 | 2N5116 | 1855-0636 | 00039 | NET1084-06 |
| 1854-0914 | 02037 | MJE1002 | 1854-1128 | 02037 | MKT2369 | 1855-0331 | 02883 | 2N3685 | 1855-0637 | 00039 | NE00199 |
| 1854-0918 | 02037 | MJE1006 | 1854-1129 | 02037 | MKT3904 | 1855-0343 | 02883 | SD214T1 | 1855-0639 | 02883 | U443 |
| 1854-0927 | 01698 | TIP102 | 1854-1130 | 02037 | MKTB10 | | | | | | |

| HP P/N | Mfr. | Desc. | 1900-0065 | 02062 | HSC-H-6332 | 1901-0490 | 02713 | GI250-3 | 1901-0912 | 02037 | MBR3545 |
|-----------|-------|------------------|-----------|-------|------------------------|-----------|-------|------------|-----------|-------|------------------|
| 1855-0714 | 03799 | HMP-0620 | 1900-0066 | 02062 | HSC-H-6332 | 1901-0491 | 02037 | IN4724 | 1901-0917 | 03287 | 1.5KE15A |
| 1855-0715 | 02037 | MMF#193 | 1900-0068 | 02865 | CSE#201-01 | 1901-0492 | 02037 | IN5002 | 1901-0920 | 02062 | 5082-2755 |
| 1855-0719 | 03799 | HMP-0310-100 | 1900-0070 | 02062 | HSC-H-5512 | 1901-0493 | 02037 | IN4725 | 1901-0921 | 03038 | 80SQ030 |
| 1855-0720 | 02391 | AT-8160 | 1900-0071 | 02062 | HSC-H-5312 | 1901-0494 | 02037 | IN5003 | 1901-0952 | 00046 | IN5802 |
| 1855-0721 | 02037 | 2NS266 | 1900-0072 | 02062 | HSC-H-5280 | 1901-0495 | 02037 | MR1120 | 1901-0953 | 00046 | UESS601R |
| 1855-0722 | 02883 | VPI108B | 1900-0074 | 02062 | HSC-H-5210 | 1901-0496 | 02037 | MR1121 | 1901-0954 | 02037 | IN5285 |
| 1855-0723 | 02883 | SD214DE | 1900-0075 | 08852 | MSS-30,254-B20 | 1901-0497 | 02037 | MR1122 | 1901-0960 | 05088 | VSK71 |
| 1855-0724 | 02883 | VNC66AD | 1900-0084 | 08852 | MSS-30,254-B20 | 1901-0498 | 02037 | MR1123 | 1901-0961 | 00046 | UES083R |
| 1855-0725 | 02037 | MP#3055A | 1900-0076 | 02062 | HSC-H-5336 (SELECTED) | 1901-0499 | 02037 | MR1124 | 1901-0970 | 02037 | MUR115 |
| 1855-0726 | 03038 | IRP9220 | 1900-0077 | 02062 | HSC-H-6330 | 1901-0500 | 02037 | MR1125 | 1901-0974 | 05088 | H2745-9 |
| 1855-0727 | 02037 | 2NT000 | 1900-0078 | 02062 | HSC-H-2800 | 1901-0511 | 06563 | IN3889R | 1901-0975 | 02037 | MPN3500 |
| 1855-0729 | 02883 | IRPD123 | 1900-0079 | 02062 | 5082-2830 | 1901-0518 | 04501 | 5082-2800 | 1901-0976 | 05088 | VSK540 |
| 1855-0004 | 01921 | CA3049 | 1900-0080 | 08852 | MM#830-E20 SELECTED | 1901-0519 | 00046 | IN3070 | 1901-0977 | 08852 | MX1098 |
| 1855-0008 | 02037 | SPQ526K | 1900-0082 | 08852 | MX-2844 | 1901-0519 | 00046 | IN3070 | 1901-0978 | 02037 | MR2100 |
| 1855-0009 | 02037 | MHQ2221 | 1900-0083 | 02062 | 5082-2831 | 1901-0526 | 02664 | SCA1 | 1901-0979 | 00046 | TID778 |
| 1855-0010 | 02037 | MPQ2906 | 1900-0084 | 08852 | MX-2860 | 1901-0531 | 04501 | AZ5097 | 1901-0981 | 02526 | IN5653A |
| 1855-0020 | 02237 | SH#4101PC | 1900-0085 | 08852 | MSS#4,141-B10 SELECTED | 1901-0532 | 01973 | A14P | 1901-0982 | 02526 | IN5651A |
| 1855-0021 | 01921 | CA3083 | 1900-0086 | 08852 | MX2946 | 1901-0537 | 00046 | IN645 | 1901-0983 | 02526 | IN5641A |
| 1855-0022 | 02873 | SG38E1N | 1900-0087 | 02062 | 5082-2831 | 1901-0545 | 02062 | 5082-2805 | 1901-0984 | 00046 | VX30 |
| 1855-0023 | 01921 | CA3081E | 1900-0088 | 02062 | 5082-2794 | 1901-0551 | 02037 | MR1126 | 1901-0985 | 02865 | DDC 4565-96 |
| 1855-0024 | 01921 | CA3146E | 1900-0089 | 02062 | 5082-2800 SELECTED | 1901-0552 | 02037 | MR1128 | 1901-0986 | 02037 | MBR1060 |
| 1855-0034 | 02037 | MPQ3725 | 1900-0091 | 02062 | HSC-H-2812 | 1901-0553 | 02037 | MR1130 | 1901-0987 | 01921 | RUR810 |
| 1855-0036 | 03285 | AD21 (SPEC) | 1900-0092 | 04507 | A25832 | 1901-0557 | 01921 | CA3019 | 1901-0988 | 02664 | 3SF2 |
| 1855-0037 | 04208 | JLN#2082A | 1900-0093 | 02062 | 5082-0001 | 1901-0558 | 02037 | IN1184R | 1901-0999 | 06078 | 16M#40 (SEL) |
| 1855-0040 | 01921 | CA3127E | 1900-0094 | 02062 | HSC-H-0012 | 1901-0565 | 02037 | MR1120R | 1901-0995 | 05088 | TG-10 |
| 1855-0045 | 03404 | LM3018AH | 1900-0095 | 08852 | MX3141 | 1901-0591 | 05131 | ED6240 | 1901-0997 | 02713 | RGP15M |
| 1855-0046 | 01921 | CA3097E | 1900-0096 | 02062 | HSC-H-380-T30 | 1901-0592 | 02037 | MR1121R | 1901-0998 | 02664 | SFR0 |
| 1855-0047 | 04200 | JLN#-2003A | 1900-0099 | 02062 | 5082-3140 | 1901-0600 | 00046 | IN6607 | 1901-0999 | 04486 | SD103C |
| 1855-0048 | 01921 | CA3082E | 1900-0100 | 02062 | HM#830-1800 | 1901-0630 | 02037 | MR1123R | 1901-1000 | 02037 | MR504 |
| 1855-0052 | 02037 | SPQ1678 | 1900-0201 | 02788 | MA#P550 | 1901-0638 | 02037 | MD#970A2 | 1901-1015 | 01698 | IN4531 |
| 1855-0055 | 02037 | MPQ2369 | 1900-0202 | 02062 | HSC-H-2825 | 1901-0639 | 02062 | 5082-3080 | 1901-1061 | 02037 | MR810 |
| 1855-0057 | 01921 | CA3082F | 1900-0001 | 03171 | H13-0302-5 | 1901-0646 | 02664 | S2F | 1901-1063 | 01973 | MPD400 |
| 1855-0058 | 02037 | MPQ3906 | 1901-0002 | 01921 | IN1200A | 1901-0661 | 02037 | MB#5550A | 1901-1068 | 02037 | MR881R |
| 1855-0061 | 04200 | JLN#-2004A | 1901-0004 | 03038 | IN1084 | 1901-0662 | 02037 | MR751 | 1901-1073 | 02037 | MR891R |
| 1855-0062 | 02037 | MPQ3762 | 1901-0005 | 01991 | IN603A | 1901-0663 | 02619 | NS3000 | 1901-1072 | 04550 | IN4154 |
| 1855-0063 | 01921 | CA3102E | 1901-0006 | 02037 | IN1566A | 1901-0669 | 02664 | S4F | 1901-1075 | 02037 | IN1186 |
| 1855-0064 | 01921 | CA3051H | 1901-0010 | 04550 | IN540 | 1901-0671 | 02037 | IN3900 | 1901-1065 | 02713 | IN4936 |
| 1855-0065 | 04200 | JLN#-2815A-2 | 1901-0013 | 01991 | IN253 | 1901-0672 | 02037 | IN3890 | 1901-1067 | 02237 | FHD444 |
| 1855-0066 | 03714 | IHM41A | 1901-0016 | 02037 | IN1566 | 1901-0673 | 01973 | A15A | 1901-1078 | 02037 | MBD5300 |
| 1855-0067 | 04200 | ULN#-2033A | 1901-0017 | 04550 | IN1118 | 1901-0674 | 02664 | S3F1 | 1901-1081 | 02037 | IN5817 (RELAXED) |
| 1855-0069 | 04200 | ULN#-2803A | 1901-0019 | 02080 | IN1344 | 1901-0678 | 02037 | IN3899R | 1901-1085 | 02062 | 5082-2835 |
| 1855-0071 | 02037 | MPQ3798 | 1901-0021 | 04550 | IN538 | 1901-0684 | 02037 | IN3890R | 1901-1087 | 02037 | MR856 |
| 1855-0072 | 04200 | JLN#-2813A | 1901-0022 | 03334 | BA220 | 1901-0685 | 02037 | MR822RL | 1901-1091 | 04550 | A115F |
| 1855-0073 | 04200 | JLN#-2805A | 1901-0025 | 00046 | IN645 | 1901-0690 | 01973 | A114 | 1901-1092 | 04550 | A114A |
| 1855-0074 | 02037 | MPQ6100 | 1901-0032 | 02037 | IN3209 | 1901-0691 | 02037 | IN1566A | 1901-1093 | 02037 | IN5204 |
| 1855-0075 | 02037 | MPQ3546 | 1901-0033 | 00046 | IN645 | 1901-0692 | 02037 | MR852 | 1901-1095 | 02037 | MBR1540 |
| 1855-0076 | 02037 | MPQ2907P | 1901-0038 | 0237 | IN3064 | 1901-0693 | 02037 | IN1934 | 1901-1098 | 02763 | IN4150 |
| 1855-0077 | 02037 | MPQ2222P | 1901-0040 | 00046 | IN418 | 1901-0696 | 01450 | A114D | 1901-1100 | 02237 | JANTXV IN4148-1 |
| 1855-0081 | 03811 | C7254 | 1901-0041 | 00046 | IN4607 | 1901-0699 | 02664 | 3L05 | 1901-1101 | 01691 | SD-41 |
| 1855-0082 | 04200 | JLN#-2804A | 1901-0044 | 00046 | IN418 | 1901-0701 | 00046 | STB567 | 1901-1102 | 02037 | IN5816 |
| 1855-0083 | 04200 | TPQ#002 | 1901-0048 | 02037 | IN3210 | 1901-0703 | 04486 | IT#600 | 1901-1103 | 02664 | IN5623 |
| 1855-0084 | 04200 | JLN#-2804A | 1901-0050 | 00046 | IN4150 | 1901-0704 | 02084 | IN4002 | 1901-1105 | 05088 | VBI0X |
| 1855-0085 | 04200 | JDN#2580A | 1901-0051 | 02037 | IN1566A | 1901-0710 | 01698 | IN914 | 1901-1106 | 09914 | UES-1106 |
| 1855-0086 | 02037 | MPQ6700 | 1901-0053 | 00046 | IN5395 | 1901-0719 | 02037 | MR854 | 1901-1107 | 04507 | AZ1501 |
| 1855-0087 | 02037 | MPQ3904 | 1901-0057 | 02037 | IN2525 | 1901-0726 | 02037 | IN5823 | 1901-1108 | 09914 | UES1305 |
| 1855-0088 | 02037 | MPQ7091 | 1901-0058 | 01991 | IN628 | 1901-0727 | 02037 | IN5823 | 1901-1109 | 02237 | JANTXV IN4148-1 |
| 1855-0089 | 02037 | MC1411 | 1901-0059 | 01991 | IN629 | 1901-0731 | 04486 | IN4004G | 1901-1110 | 09914 | UES1306 |
| 1855-0090 | 02037 | MPQ6002 | 1901-0060 | 02037 | IN1116 | 1901-0732 | 02037 | IN4007 | 1901-1111 | 09914 | UES1105 |
| 1855-0091 | 02037 | MPQ2484 | 1901-0061 | 01991 | IN816 | 1901-0734 | 02037 | IN5818 | 1901-1112 | 03334 | BV#27-150 |
| 1855-0092 | 02037 | MPQ3799 | 1901-0062 | 02037 | IN1563A | 1901-0735 | 02158 | 066110H | 1901-1113 | 02037 | RUR810 |
| 1855-0093 | 02037 | MPQ6700 | 1901-0071 | 02763 | IN625 | 1901-0741 | 02037 | IN1563 | 1901-1114 | 10881 | BAL 74 |
| 1855-0094 | 02037 | MPQ918 | 1901-0081 | 00046 | IN418 | 1901-0743 | 01698 | IN4004 | 1901-1115 | 04507 | DSR3800X |
| 1855-0095 | 00046 | PIC900C | 1901-0096 | 02237 | FDR-400 | 1901-0750 | 02664 | IN5553 | 1901-1116 | 04507 | DSR3700X |
| 1855-0096 | 01921 | CA3183E | 1901-0126 | 01921 | IN1763 | 1901-0765 | 03627 | IN5812 | 1901-1122 | 02713 | IN5408 |
| 1855-0097 | 04200 | JLN#-2023A | 1901-0129 | 01698 | IN647 | 1901-0767 | 02037 | MR754 | 1901-1126 | 10881 | BW#80-100 |
| 1855-0098 | 04200 | JLN#-2023A (SEL) | 1901-0131 | 01921 | IN1764 | 1901-0768 | 02037 | MR752 | 1901-1127 | 00046 | UES803 |
| 1855-0100 | 02037 | MPQ7051 | 1901-0132 | 02037 | IN4721 | 1901-0769 | 01687 | IN617 | 1901-1128 | 02037 | IN5819 |
| 1855-0101 | 02037 | MPQ7051 | 1901-0133 | 02037 | IN4722 | 1901-0774 | 02037 | IN3801R | 1901-1129 | 02037 | MUR105 |
| 1855-0102 | 02037 | MPQ7051 | 1901-0134 | 02037 | IN4723 | 1901-0775 | 02037 | IN5000 | 1901-1130 | 02037 | MUR860A |
| 1855-0103 | 02037 | MPQ7051 | 1901-0135 | 02037 | IN183A | 1901-0782 | 02037 | IN5821 | 1901-1132 | 02865 | AWS021 SELECTED |
| 1855-0122 | 02037 | MPQ#2222A | 1901-0316 | 02086 | IN183AR | 1901-0826 | 02062 | 5082-3900 | 1901-1133 | 04550 | IN5626 |
| 1855-0118 | 02037 | MPHQ-3906 | 1901-0319 | 01973 | IN347A | 1901-0787 | 02037 | MR756 | 1901-1134 | 03334 | BA483 |
| 1855-0119 | 02037 | MPHQ-3906 | 1901-0319 | 01973 | IN347A | 1901-0788 | 02037 | MR752 | 1901-1135 | 02713 | GP30B |
| 1855-0116 | 02037 | MPQ2484 | 1901-0319 | 02086 | IN1864AR | 1901-0789 | 02037 | MR850 | 1901-1136 | 03038 | 10TQ045 |
| 1855-0016 | 02037 | MPQ603 | 1901-0319 | 02086 | IN1864AR | 1901-0833 | 01691 | IN6056 | 1901-1137 | 02037 | MR2406F |
| 1855-0017 | 02037 | MPQ612 | 1901-0320 | 02086 | IN187A | 1901-0835 | 01698 | BY#205-400 | 1901-1138 | 00046 | EDGP30B |
| 1855-0018 | 02037 | MPQ265P | 190 | | | | | | | | |

| HP P/N | Mfr. | Desc. | HP P/N | Mfr. | Desc. | HP P/N | Mfr. | Desc. |
|------------|-------|-----------------|-----------|-------|-------------------|-----------|-------|-------------|
| 1901-1205 | 03287 | 1.5KE39 | 1902-0973 | 02037 | JAN TXV 1N825 | 1902-1454 | 02037 | MLL5237 |
| 1901-1206 | 03287 | 1.5KE39C | 1902-0976 | 02526 | 1.5SE18C | 1902-1455 | 02037 | MLL5239B |
| 1901-1207 | 03287 | 1.5KE120C | 1902-0977 | 02037 | IN5352 | 1902-1456 | 02037 | MLL5240 |
| 1901-1208 | 03287 | MPT6-15 | 1902-0978 | 02037 | IN5346 | 1902-1457 | 02037 | MLL5241 |
| 1901-1209 | 03287 | MPT6-15C | 1902-0980 | 02037 | IN5302S2 | 1902-1458 | 02037 | MLL5242 |
| 1901-1210 | 03287 | LCE7 .0 | 1902-0981 | 02037 | IN5232S2 | 1902-1459 | 02037 | MLL5243 |
| 1901-1211 | 03287 | 5KPS .0A | 1902-0982 | 02037 | IN5282S2 | 1902-1460 | 02037 | MLL5245 |
| 1901-1213 | 02037 | MBD501 | 1902-0983 | 01691 | 1N4621 | 1902-1461 | 02037 | MLL5246 |
| 1901-1214 | 02037 | MUR160 | 1902-0986 | 02037 | IN6270A | 1902-1462 | 02037 | MLL5248 |
| 1901-1216 | 02037 | MUR415 | 1902-0987 | 02037 | IN2991 | 1902-1463 | 02037 | MLL5250 |
| 1901-1218 | 02064 | USD840 | 1902-0988 | 02037 | IN5272S2 | 1902-1464 | 02037 | MLL5251 |
| 1901-1220 | 05088 | VSKR530 | 1902-0989 | 02037 | IN5202S2 | 1902-1465 | 02037 | MLL5252 |
| 1901-1222 | 03334 | BYV36C | 1902-0990 | 02037 | IN5236B | 1902-1466 | 02037 | MLL5254 |
| 1901-1224 | 03334 | BAV74 SELECTED | 1902-0991 | 02803 | IN4577 | 1902-1467 | 02037 | MLL5256 |
| 1901-1225 | 02037 | MMB9194 | 1902-0993 | 03287 | 1.5KE7 .5C | 1902-1468 | 02037 | MLL5257 |
| 1901-1227 | 02337 | BAS16 | 1902-0994 | 02037 | 1.4M8 .221 | 1902-1469 | 02037 | MLL5258 |
| 1901-1228 | 02337 | MMB914XT1 | 1902-0995 | 02037 | IN5373B | 1902-1470 | 02037 | MLL5259 |
| 1901-1230 | 03334 | BYV264 SELECTED | 1902-0996 | 02037 | IN5336B | 1902-1471 | 02037 | MLL5260 |
| 1901-1231 | 02064 | 5082-1006 | 1902-0997 | 02037 | JANTX1N3020B | 1902-1472 | 02037 | MLL5261 |
| 1901-1233 | 02037 | MUR4100 | 1902-0998 | 02037 | IN3001B | 1902-1473 | 02037 | MLL5262 |
| 1901-1237 | 02713 | RGP15-15 | 1902-0999 | 02037 | IN3993A | 1902-1474 | 02037 | MLL5263 |
| 1901-1239 | 02037 | MUR410 | 1902-1000 | 02037 | IN5366B | 1902-1475 | 02037 | MLL5265 |
| 1901-1244 | 02037 | MUR140 | 1902-1170 | 02037 | IN4101 | 1902-1476 | 02037 | MLL5266 |
| 1901-1246 | 03334 | BYD33M | 1902-1171 | 02037 | IN4102 | 1902-1477 | 02037 | MLL5267 |
| 1901-1247 | 02062 | HSM5-0002 | 1902-1172 | 02037 | IN4103 | 1902-1478 | 02037 | MLL5268 |
| 1901-1248 | 02037 | IN4937 SELECTED | 1902-1195 | 06563 | IN1362 | 1902-1479 | 02037 | MLL5270 |
| 1901-1249 | 03334 | BYV36C | 1902-1199 | 06563 | IN1604A | 1902-1480 | 02037 | IN524 .7A10 |
| 1901-1251 | 05088 | H1601-1 .5 | 1902-1205 | 02037 | IN2979RB | 1902-1481 | 02713 | IN5953B |
| 1901-1252 | 04200 | TMPI4150 | 1902-1217 | 02037 | IN3998RA | 1902-1482 | 02713 | IN5954B |
| 1901-1253 | 03334 | BA482 | 1902-1226 | 02037 | IN1996A | 1902-1486 | 02037 | IN5388B |
| 1901-1254 | 02713 | BAR42 | 1902-1228 | 02037 | IN2988RB | 1902-1487 | 03334 | BZ284-c12 |
| 1901-1255 | 04550 | DE131 | 1902-1232 | 02037 | IN3997RA | 1902-1488 | 04486 | LL474T |
| 1902-0003 | 02037 | IN754 | 1902-1234 | 02037 | IN4000A | 1902-1489 | 04486 | LL474U |
| 1902-0018 | 02037 | IN941 | 1902-1259 | 02037 | IN5357B | 1902-1490 | 04486 | LL474O |
| 1902-0021 | 02037 | IN2992RB | 1902-1260 | 02037 | IN5525C | 1902-1491 | 04486 | LL473A |
| 1902-0027 | 02037 | SZ1521-250 | 1902-1276 | 02037 | IN2809B | 1902-1492 | 04486 | LL474Z |
| 1902-0028 | 02037 | IN2999A | 1902-1278 | 02037 | IN5348B | 1902-1493 | 02037 | IN5919B |
| 1902-0030 | 02037 | IN3028B | 1902-1286 | 02037 | IN5342B | 1902-1494 | 02037 | IN5252B |
| 1902-0033 | 01991 | IN823 | 1902-1288 | 02037 | IN5358B | 1902-1495 | 02688 | IN5987D |
| 1902-0035 | 02037 | IN3008B | 1902-1291 | 02037 | IN5338B | 1902-1498 | 02037 | IN5362B |
| 1902-0039 | 06563 | IN1597A | 1902-1292 | 02037 | IN5372B | 1902-1500 | 02037 | MCZ6 .8A3 |
| 1902-0041 | 02237 | IN751A | 1902-1294 | 02037 | IN5388A | 1902-1501 | 02037 | MBB5231 |
| 1902-0042 | 02037 | IN1608 | 1902-1295 | 02883 | CL4-720 | 1902-1502 | 02037 | IN5939B |
| 1902-0082 | 02037 | IN1596A | 1902-1297 | 02037 | IN4561 | 1902-1505 | 02037 | MDT454B |
| 1902-0086 | 02684 | IN1513 | 1902-1298 | 02037 | IN820 | 1902-1506 | 02037 | IN5993B |
| 1902-0088 | 02037 | IN3003B | 1902-1303 | 02037 | IN587F | 1902-1507 | 02037 | IN6021B |
| 1902-0089 | 02037 | IN3004B | 1902-1332 | 02634 | IN5851B | 1902-1509 | 02037 | IN5333BR |
| 1902-0094 | 02037 | IN705A | 1902-1336 | 02037 | IN6001B | 1902-1510 | 02037 | IN5367B |
| 1902-0095 | 02037 | IN716 | 1902-1338 | 02037 | IN4557A | 1902-1512 | 02037 | BZ284c7V5 |
| 1902-0121 | 02763 | CD36191 | 1902-1340 | 02037 | IN5355B | 1902-1513 | 02037 | IN5334BR |
| 1902-0156 | 02037 | IN2986B | 1902-1342 | 02037 | IN4742A | 1902-1516 | 02037 | IN6377 |
| 1902-0157 | 02037 | IN2620 | 1902-1343 | 02037 | IN5365B | 1902-1518 | 02037 | IN5334D |
| 1902-0178 | 02037 | IN3004RA | 1902-1345 | 02037 | IN5821D | 1902-1519 | 03334 | BZ284-c3V9 |
| 1902-0183 | 02037 | IN0993 | 1902-1346 | 02037 | IN5358B | 1902-1520 | 02037 | SA100CA |
| 1902-0184 | 02037 | IN4095B | 1902-1347 | 02037 | IN2222S | 1902-1523 | 11708 | BZ2050 .56B |
| 1902-0186 | 02037 | IN4105 | 1902-1352 | 04507 | IN456A | 1902-1524 | 02037 | MBB5230 |
| 1902-01517 | 02037 | SZ11213-48 | 1902-1356 | 02037 | IN753A | 1902-1529 | 11708 | 1.5KE250CA |
| 1902-01522 | 02037 | IN5340B | 1902-1374 | 02037 | IN753A | 1902-1534 | 02037 | SA11A |
| 1902-01526 | 02037 | IN5305 | 1902-1380 | 11708 | IN531A | 1902-1535 | 02037 | MBB5257B |
| 1902-01528 | 02037 | IN5524D | 1902-1384 | 02037 | IN525C | 1902-1536 | 02037 | IN5368B |
| 1902-01549 | 02037 | IN5365A | 1902-1385 | 02661 | SX43 | 1902-1537 | 02037 | 1.5KE91C |
| 1902-0570 | 02688 | DZ703028 | 1902-1387 | 02037 | IN524C | 1902-1539 | 02037 | IN5987D |
| 1902-0584 | 02037 | SZG30590 | 1902-1388 | 02037 | IN4697 | 1906-0006 | 05080 | VE48 |
| 1902-0625 | 02037 | IN829 | 1902-1391 | 02037 | IN4683 | 1906-0007 | 02037 | MDA2502 |
| 1902-0627 | 02037 | IN5312 | 1902-1392 | 02037 | IN5256 (SELECTED) | 1906-0008 | 02037 | MDA2500 |
| 1902-0630 | 02037 | IN5236B | 1902-1394 | 02037 | IN5378B | 1906-0016 | 02037 | MDA2506 |
| 1902-0631 | 02037 | IN5351B | 1902-1396 | 02037 | IN5335B | 1906-0017 | 02037 | MDA990 .93 |
| 1902-0632 | 02037 | IN5354B | 1902-1397 | 02037 | IN6273A | 1906-0023 | 02037 | MDA922-4 |
| 1902-0640 | 02037 | IN5847A | 1902-1398 | 02037 | IN821D | 1906-0024 | 02037 | MDM6150 |
| 1902-0643 | 02037 | IN2979B | 1902-1399 | 02037 | IN5248 SELECTED | 1906-0025 | 02037 | MDM6100 |
| 1902-0645 | 02037 | IN2997RB | 1902-1400 | 02037 | IN5244 SELECTED | 1906-0026 | 02037 | MDM7000 |
| 1902-0680 | 02037 | IN827 | 1902-1401 | 02037 | IN2835A | 1906-0027 | 02037 | MDA922-6 |
| 1902-0686 | 02037 | IN825 | 1902-1402 | 02037 | IN5373A | 1906-0028 | 02037 | MDA922-3 |
| 1902-0687 | 02037 | IN937 | 1902-1411 | 02037 | IN574A | 1906-0052 | 05080 | VH148 |
| 1902-0786 | 02037 | IN938 | 1902-1423 | 02037 | IN5338A | 1906-0056 | 02037 | MSD 7000 |
| 1902-0788 | 02037 | IN31514 | 1902-1424 | 10881 | BZ284c5V6 | 1906-0058 | 02037 | MDA900-2 |
| 1902-0789 | 02037 | IN31515 | 1902-1425 | 02037 | IN5359B | 1906-0067 | 05080 | R714 |
| 1902-0791 | 02037 | IN942 | 1902-1426 | 02037 | IN5230 (SELECTED) | 1906-0071 | 02664 | SCPA05F |
| 1902-0793 | 02037 | IN944 | 1902-1427 | 02037 | IN2805A | 1906-0072 | 02664 | SCBA2F |
| 1902-0777 | 02037 | IN825 | 1902-1409 | 02037 | IN2989B | 1906-0074 | 02237 | IN5335P |
| 1902-0785 | 02037 | IN936 | 1902-1410 | 02037 | IN6283A | 1906-0049 | 02037 | SCDA2 |
| 1902-0786 | 02037 | IN937 | 1902-1411 | 02037 | IN574A | 1906-0079 | 05080 | VJ148X |
| 1902-0787 | 02037 | IN938 | 1902-1423 | 02037 | IN5338A | 1906-0082 | 02062 | 5082-2826 |
| 1902-0788 | 02037 | IN2934 | 1902-1434 | 02037 | IN1998RA | 1906-0085 | 05080 | VJ848TT |
| 1902-0907 | 04507 | LV41A3 | 1902-1436 | 02037 | MBB5232 | 1906-0088 | 05080 | R7128 |
| 1902-0909 | 02037 | LV46A8 | 1902-1437 | 02037 | MBB5241 | 1906-0088 | 05080 | MDA900-6 |
| 1902-0909 | 02037 | IN2972A | 1902-1438 | 02037 | IN594B | 1906-0090 | 00046 | 698-1 |
| 1902-0910 | 02037 | IN2984RB | 1902-1439 | 02037 | IN2835RA | 1906-0093 | 04200 | ND946 |
| 1902-0916 | 02037 | MZ5556 | 1902-1440 | 02037 | MLL5221 | 1906-0094 | 02037 | MDA3501 |
| 1902-0918 | 02037 | IN5172S2 | 1902-1441 | 02037 | MLL5221 | 1906-0096 | 02037 | MDA202 |
| 1902-0919 | 02037 | M1B12S2 | 1902-1442 | 02037 | MLL5223 | 1906-0100 | 02883 | DPAD 100 |
| 1902-0920 | 02037 | IN5345B | 1902-1443 | 02037 | MLL5225 | 1906-0201 | 02713 | KBU4G |
| 1902-0923 | 02037 | IN5337A | 1902-1444 | 02037 | MLL5226 | 1906-0202 | 01694 | TID130 |
| 1902-0924 | 02037 | IN5952T | 1902-1445 | 02037 | MLL5227 | 1906-0203 | 01531 | PK10 |
| 1902-0925 | 02037 | INCH740A | 1902-1446 | 02037 | MLL5228 | 1906-0204 | 02062 | 5082-2804 |
| 1902-0927 | 02037 | IN5349 | 1902-1447 | 02037 | MLL5229 | 1906-0205 | 05080 | VK148 |
| 1902-0931 | 02037 | IN120Z5 | 1902-1448 | 02037 | MLL5230 | 1906-0210 | 02062 | 5082-2830 |
| 1902-0933 | 02037 | IN5370B | 1902-1449 | 02037 | MLL5231 | 1906-0212 | 02037 | MDA3504 |
| 1902-0934 | 02037 | IN5380B | 1902-1450 | 02037 | MLL5232 | 1906-0213 | 01698 | TIR101B |
| 1902-0939 | 02037 | IN526 | 1902-1451 | 02037 | MLL5234 | 1906-0214 | 01698 | TIR12018 |
| 1902-0941 | 03287 | ICTE-12 | 1902-1452 | 02037 | MLL5235 | 1906-0216 | 05080 | VL447 |
| 1902-0942 | 03046 | IM103H-5.1 | 1902-1453 | 02037 | MLL5236 | 1906-0217 | 02037 | |

| | | | | | |
|----------|-----------------|------------------|-----------------|------------------|-----------------|
| 1N1566A | 02037 1901-0051 | 1N4150 | 00046 1901-0050 | 1N5944B | 02037 1902-1438 |
| 1N1581 | 01991 1901-0138 | 1N4150 | 02763 1901-1098 | 1N5949B | 02037 1902-1493 |
| 1N1596A | 02037 1902-0082 | 1N4154 | 04550 1901-1052 | 1N5953B | 02713 1902-1481 |
| 1N1597A | 05653 1902-0039 | 1N4156 | 01973 1901-0463 | 1N5954B | 02713 1902-1482 |
| 1N1604A | 05653 1902-1199 | 1N4158 | 01250 1900-0009 | 1N5987D | 02688 1902-1495 |
| 1N1608 | 02037 1902-0042 | 1N415C | 02788 1900-0015 | 1N5993B | 02037 1902-1506 |
| 1N1763 | 01921 1901-0126 | 1N4168 | 02788 1900-0006 | 1N6001B | 02037 1902-1336 |
| 1N1764 | 01921 1901-0131 | 1N4168M | 02788 1900-0011 | 1N6021B | 02037 1902-1507 |
| 1N191 | 02682 1910-0021 | 1N4189 | 03447 1901-0465 | 1N603A | 01991 1901-0005 |
| 1N2148 | 04583 1901-0394 | 1N4148 | 02237 1901-1200 | 1N6074 | 02664 1901-0786 |
| 1N2158 | 01973 1901-0305 | 1N4530 | 01973 1901-0370 | 1N6096 | 01691 1901-0833 |
| 1N2158R | 01973 1901-0306 | 1N4531 | 01598 1901-1015 | 1N625 | 02763 1901-0071 |
| 1N218 | 02788 1900-0001 | 1N4557A | 02037 1902-1338 | 1N6270A | 02037 1902-0986 |
| 1N218MR | 01250 1900-0010 | 1N4561 | 02037 1902-1297 | 1N6273A | 02037 1902-1397 |
| 1N218 | 02865 1900-0017 | 1N4574 | 02037 1902-1411 | 1N628 | 01991 1901-0058 |
| 1N2242 | 05111 1901-0151 | 1N4577 | 02803 1902-0991 | 1N6283A | 02037 1902-1410 |
| 1N2326 | 01921 1910-0041 | 1N4603 | 02865 1900-0016 | 1N629 | 01991 1901-0059 |
| 1N23B | 01250 1900-0012 | 1N4607 | 00046 1901-0041 | 1N6377 | 02037 1902-1516 |
| 1N23C | 02788 1900-0018 | 1N4607 | 00046 1901-0620 | 1N645 | 00046 1901-0025 |
| 1N250C | 01973 1901-0310 | 1N4608 | 01973 1901-0894 | 1N645 | 00046 1901-0033 |
| 1N2525 | 02037 1901-0057 | 1N4621 | 01691 1902-0983 | 1N645 | 00046 1901-0537 |
| 1N253 | 01991 1901-0013 | 1N4626 | 04507 1902-1407 | 1N647 | 01698 1901-0129 |
| 1N2565 | 04583 1901-0383 | 1N4683 | 02037 1902-1391 | 1N647 | 00046 1901-0356 |
| 1N2620 | 02037 1902-0157 | 1N4697 | 02037 1902-1388 | 1N660 | 01698 1901-0132 |
| 1N265P | 02788 1900-0007 | 1N4719 | 02037 1901-0409 | 1N662 | 03447 1901-014 |
| 1N270 | 02682 1910-0023 | 1N4720 | 02037 1901-0410 | 1N705A | 02037 1902-0094 |
| 1N276 | 03447 1910-0013 | 1N4721 | 02037 1901-0164 | 1N746 | 02037 1902-0095 |
| 1N277 | 02682 1910-0014 | 1N4722 | 02037 1901-0412 | 1N751A | 02237 1902-0041 |
| 1N279 | 02682 1910-0033 | 1N4723 | 02037 1901-0414 | 1N751A(SELECTED) | 02037 1902-1405 |
| 1N2805A | 02037 1902-1427 | 1N4724 | 02037 1901-0491 | 1N754 | 02037 1902-0003 |
| 1N2809B | 02037 1902-1276 | 1N4725 | 02037 1901-0493 | 1N76 | 02865 1900-0004 |
| 1N281 | 03447 1910-0007 | 1N4742A | 02037 1902-1342 | 1N76A | 01250 1900-0020 |
| 1N2820 | 02037 1902-1298 | 1N4753ARL | 02037 1902-1356 | 1N816 | 01991 1901-0061 |
| 1N2835A | 02037 1902-1407 | 1N4934 | 02037 1901-0693 | 1N82 | 02788 1900-0005 |
| 1N2835RA | 02037 1902-1439 | 1N4936 | 02713 1901-1065 | 1N821 | 02037 1902-0761 |
| 1N2972A | 02037 1902-0909 | 1N4937 | 02037 1901-0831 | 1N821D | 02037 1902-1398 |
| 1N2979B | 02037 1902-0643 | 1N4937 SELECTED | 02037 1901-1248 | 1N823 | 01991 1902-0033 |
| 1N2979RB | 02037 1902-1205 | 1N5000 | 02037 1901-0775 | 1N825 | 02037 1902-0686 |
| 1N2983B | 02037 1902-0759 | 1N5002 | 02037 1901-0492 | 1N825 | 02037 1902-0777 |
| 1N2984B | 02037 1902-0910 | 1N5002R | 02037 1901-0843 | 1N827 | 02037 1902-0680 |
| 1N2986B | 02037 1902-0151 | 1N5003 | 02037 1901-0494 | 1N829 | 02037 1902-0625 |
| 1N2988B | 02037 1902-1228 | 1N5061 | 04550 1901-1172 | 1N831 | 02788 1900-0019 |
| 1N2989B | 02037 1902-1409 | 1N5230(Selected) | 02037 1902-1426 | 1N90 | 06418 1910-0004 |
| 1N2991 | 02037 1902-0987 | 1N5236B | 02037 1902-0630 | 1N91 | 01973 1911-0001 |
| 1N2992B | 02037 1902-0021 | 1N5244 SELECTED | 02037 1902-1408 | 1N914 | 01698 1901-0710 |
| 1N2995B | 02037 1902-0183 | 1N5245 | 02037 1902-1400 | 1N935 | 02037 1902-0772 |
| 1N2997B | 02037 1902-1205 | 1N5248 SELECTED | 02037 1902-1399 | 1N936 | 02037 1902-0785 |
| 1N2999A | 02037 1902-0028 | 1N5252B | 02037 1902-1494 | 1N937 | 02037 1902-0786 |
| 1N3001B | 02037 1902-0998 | 1N5256(Selected) | 02037 1902-1392 | 1N938 | 02037 1902-0787 |
| 1N3003B | 02037 1902-0088 | 1N5271 | 02037 1902-1509 | 1N941 | 02037 1902-0018 |
| 1N3004B | 02037 1902-0089 | 1N5283 | 02037 1902-1515 | 1N942 | 02037 1902-0791 |
| 1N3004RA | 02037 1902-0178 | 1N5284 | 02037 1902-1518 | 1N944 | 02037 1902-0793 |
| 1N3008B | 02037 1902-0035 | 1N5285 | 02037 1901-0954 | 1N963B | 11708 1902-0960 |
| 1N3028B | 02037 1902-0030 | 1N5297 | 02037 1901-0869 | 1N989B | 02037 1902-0793 |
| 1N3064 | 02237 1901-0038 | 1N5305 | 02037 1902-0526 | 1N992B | 02037 1902-0795 |
| 1N3070 | 00046 1901-0519 | 1N5312 | 02037 1902-0627 | 1N995 | 02682 1910-0025 |
| 1N3154 | 02037 1902-0788 | 1N5333BRL | 02037 1902-1509 | 1NC4740A | 02037 1902-0925 |
| 1N3155 | 02037 1902-0789 | 1N5334BRL | 02037 1902-1515 | 1SS135 | 00746 1901-1117 |
| 1N3208 | 02037 1901-0421 | 1N5334D | 02037 1902-1518 | 1SS153 | 00339 1901-1166 |
| 1N3209 | 02037 1901-0032 | 1N5335B | 02037 1902-1396 | 20FQ040 | 03038 1901-0892 |
| 1N3210 | 02037 1901-0346 | 1N5336B | 02037 1902-0996 | 25D786 | 00746 1854-0991 |
| 1N3211 | 02037 1901-0422 | 1N5337A | 02037 1902-0923 | 29C | 01921 1854-0644 |
| 1N3212 | 02037 1901-0423 | 1N5338A | 02037 1902-1343 | 2C3906 | 02037 1853-0614 |
| 1N3260R | 01973 1901-0311 | 1N5338B | 02037 1902-1423 | 2C4403 | 02037 1853-0523 |
| 1N3262 | 01973 1901-0312 | 1N5338B | 02037 1902-1291 | 2N1027 | 02619 1853-0002 |
| 1N3262R | 01973 1901-0313 | 1N5340B | 02037 1902-0522 | 2N1038 | 01698 1850-0178 |
| 1N3289 | 01973 1901-0307 | 1N5341B | 11708 1902-1380 | 2N1121 | 01973 1851-0038 |
| 1N3289R | 01973 1901-0308 | 1N5342B | 02037 1902-1286 | 2N1131 | 01698 1853-0019 |
| 1N3491 | 02037 1901-0404 | 1N5345B | 02037 1902-0920 | 2N1143 | 01698 1850-0020 |
| 1N3491R | 02037 1901-0343 | 1N5348B | 02037 1902-1278 | 2N1183 | 01921 1850-0025 |
| 1N3492 | 02037 1901-0424 | 1N5349 | 02037 1902-0927 | 2N1192 | 02037 1850-0131 |
| 1N3493 | 02037 1901-0425 | 1N5351B | 02037 1902-0631 | 2N1193 | 02037 1850-0130 |
| 1N3494 | 02037 1901-0426 | 1N5352 | 02037 1902-0977 | 2N1305 | 01698 1850-0404 |
| 1N3495 | 02037 1901-0427 | 1N5354B | 02037 1902-0632 | 2N1306 | 01698 1851-0011 |
| 1N349A | 02682 1910-0031 | 1N5355B | 02037 1902-1340 | 2N1306 | 01698 1851-0025 |
| 1N3560 | 05644 1912-0022 | 1N5358B | 02037 1902-1466 | 2N1307 | 01698 1850-0173 |
| 1N3563 | 01921 1901-0742 | 1N5359B | 02037 1902-1288 | 2N1183 | 01921 1850-0064 |
| 1N3570 | 01973 1901-0304 | 1N5359B | 02037 1902-1425 | 2N1192 | 02037 1850-0151 |
| 1N3595 | 00046 1901-0373 | 1N5362B | 02037 1902-1291 | 2N1358 | 05840 1850-0150 |
| 1N3595 | 00046 1901-1195 | 1N5365A | 02037 1902-0522 | 2N1370 | 01921 1850-0065 |
| 1N3644 | 02682 1910-0752 | 1N5365A | 02037 1902-0549 | 2N1374 | 01698 1850-0180 |
| 1N3650 | 02037 1901-0428 | 1N5366B | 02037 1902-1000 | 2N1377 | 01698 1850-0170 |
| 1N3661 | 02037 1901-0430 | 1N5367B | 02037 1902-1510 | 2N1378 | 01698 1850-0182 |
| 1N3662 | 02037 1901-0431 | 1N5370B | 02037 1902-1536 | 2N1396 | 01921 1850-0074 |
| 1N3663 | 02037 1901-0432 | 1N5372B | 02037 1902-0933 | 2N1482 | 01921 1854-0214 |
| 1N3712 | 01973 1912-0009 | 1N5373A | 02037 1902-1292 | 2N1484 | 01921 1854-0235 |
| 1N3714 | 01973 1912-0007 | 1N5373B | 02037 1902-1402 | 2N1499A | 03571 1850-0093 |
| 1N3716 | 01973 1912-0008 | 1N5378B | 02037 1902-0995 | 2N1500 | 02634 1850-0051 |
| 1N3717 | 01973 1912-0015 | 1N538B | 02037 1902-1394 | 2N1501 | 02619 1850-0146 |
| 1N3718 | 01973 1912-0006 | 1N5380B | 02037 1902-0934 | 2N1516 | 03334 1850-0003 |
| 1N3719 | 01973 1912-0017 | 1N5381B | 02037 1902-1432 | 2N1523 | 05840 1850-0194 |
| 1N3720 | 01973 1912-0014 | 1N5388A | 02037 1902-1294 | 2N1605 | 01698 1851-0031 |
| 1N3721 | 01973 1912-0019 | 1N5388B | 02037 1902-1486 | 2N1605A | 01698 1851-0034 |
| 1N3881 | 02037 1901-0756 | 1N5393 | 01921 1901-0838 | 2N1671A | 01973 1855-0001 |
| 1N3889 | 02037 1901-0791 | 1N5395 | 00046 1901-0053 | 2N1671B | 01973 1855-0021 |
| 1N3889R | 00653 1901-0511 | 1N540 | 04550 1901-0010 | 2N1671C | 01973 1855-0077 |
| 1N3890 | 02037 1901-0672 | 1N5406 | 02713 1901-0759 | 2N169A | 01973 1851-0006 |
| 1N3890R | 02037 1901-0684 | 1N5408 | 02713 1901-1123 | 2N169A | 01973 1851-0007 |
| 1N3891 | 02037 1901-0717 | 1N5418 | 00046 1901-0790 | 2N1701 | 01921 1854-0062 |
| 1N3891R | 02037 1901-0774 | 1N5524C | 02037 1902-1387 | 2N1701 | 01921 1854-0613 |
| 1N3893 | 02037 1901-0890 | 1N5524D | 02037 1902-0528 | 2N174 | 02037 1850-0058 |
| 1N3899R | 02037 1901-0678 | 1N5525C | 02037 1902-1260 | 2N174 | 02037 1850-0059 |
| 1N38B | 02682 1910-0002 | 1N5525C | 02037 1902-1384 | 2N1760 | 02783 1850-0406 |
| 1N3900 | 02037 1901-0671 | 1N5553 | 02664 1901-0750 | 2N1905 | 01921 1850-0114 |
| 1N3912 | 00046 1901-0888 | 1N5554 | 02664 1901-0751 | 2N1973 | 01698 1850-0076 |
| 1N3935B | 01973 1901-0478 | 1N55A | 01250 1910-0039 | 2N2001 | 01698 1850-0112 |
| 1N3996A | 02037 1902-1226 | 1N5623 | 02664 1901-1103 | 2N2048 | 01979 1850-0105 |
| 1N3997RA | 02037 1902-1232 | 1N5626 | 04550 1901-1133 | 2N2060 | 02037 1851-0761 |
| 1N3998RA | 02037 1902-1217 | 1N5641A | 02526 1901-0983 | 2N2102 | 01921 1854-0067 |
| 1N3998RA | 02037 1902-1434 | 1N5651A | 02526 1901-0982 | 2N2147 | 01921 1850-0160 |
| 1N4000A | 02037 1902-1234 | 1N5653A | 02526 1901-0981 | 2N2148 | 01698 1850-0166 |
| 1N4002 | 02086 1901-0704 | 1N5758 | 02037 1901-1120 | 2N2188 | 01698 1850-0096 |
| 1N4003 | 02037 1901-1203 | 1N5802 | 00046 1901-0952 | 2N2190 | 01698 1850-01 |

JDEC

Mfr. HP P/N

| | | | | | |
|---------------|-----------------|--------------|-----------------|-------------|-----------------|
| 2N2483 | 02237 1854-0304 | 2N3824 | 01698 1855-0224 | 2N5192 | 02037 1854-0453 |
| 2N2501 | 02037 1854-0211 | 2N384 | 01921 1850-0018 | 2N5193 | 02037 1853-0236 |
| 2N2538 | 01698 1854-0213 | 2N384 | 01921 1850-0041 | 2N5194 | 02037 1853-0212 |
| 2N2540 | 02037 1854-0786 | 2N385A | 01973 1854-0057 | 2N5195 | 02037 1853-0280 |
| 2N2552 | 01698 1850-0181 | 2N386 | 01921 1854-0233 | 2N5196 | 02883 1855-0301 |
| 2N2556 | 01698 1850-0076 | 2N386A | 02037 1854-0784 | 2N519A | 02713 1850-0127 |
| 2N2561 | 01698 1850-0065 | 2N386T | 02037 1854-0412 | 2N5210 | 02037 1854-0409 |
| 2N2608 | 03406 1855-0297 | 2N387 | 01921 1854-0176 | 2N5217 | 03776 1854-0286 |
| 2N2635 | 02037 1850-0163 | 2N388A | 01698 1851-0002 | 2N5239 | 01921 1854-1085 |
| 2N2646 | 04550 1855-0010 | 2N388A | 01698 1851-0003 | 2N5245 | 02037 1855-0688 |
| 2N2647 | 04550 1855-0027 | 2N388A | 01698 1851-0009 | 2N5245(SEL) | 02037 1855-0690 |
| 2N2664 | 01698 1850-0409 | 2N3904 | 01698 1851-0021 | 2N5246 | 01698 1855-0285 |
| 2N2712 | 01973 1854-0029 | 2N3904 | 01698 1851-0024 | 2N5247 | 03406 1855-0257 |
| 2N2716 | 04550 1854-0044 | 2N3904 | 02037 1854-0215 | 2N5256 | 01698 1850-0031 |
| 2N2720 | 02037 1854-0014 | 2N3904 | 02037 1854-1028 | 2N5262 | 01921 1854-0363 |
| 2N2857 | 01921 1854-0048 | 2N3904 | 02037 1854-1061 | 2N5266 | 02037 1855-0721 |
| 2N2857 | 01921 1854-0323 | 2N3904 | 02037 1854-1084 | 2N5268 | 02037 1855-0277 |
| 2N2865 | 01698 1854-0031 | 2N3904 | 03406 1854-1110 | 2N5294 | 01921 1854-0370 |
| 2N2869 | 01921 1850-0128 | 2N3904 CHIP | 02037 1854-0770 | 2N5301 | 02037 1854-0398 |
| 2N2895 | 02037 1854-0527 | 2N3904(SEL) | 02037 1854-1177 | 2N5320 | 01921 1854-0999 |
| 2N2896 | 02037 1854-0748 | 2N3904RLRA2 | 02037 1854-1048 | 2N5333 | 01698 1853-0349 |
| 2N2904 | 01698 1853-0013 | 2N3905 | 02037 1853-0292 | 2N5396 | 02763 1855-0283 |
| 2N2904A | 02037 1853-0012 | 2N3906 | 03406 1853-0036 | 2N5397 | 03406 1855-0498 |
| 2N2905A | 02037 1853-0314 | 2N3906(SEL) | 02037 1853-0563 | 2N5400 | 02037 1853-0457 |
| 2N2905A(SEL) | 02037 1853-0571 | 2N3906(SEL) | 02037 1853-0659 | 2N5401 | 02037 1853-0264 |
| 2N2907 | 02037 1853-0205 | 2N3906RLRA2 | 02037 1853-0577 | 2N5401(SEL) | 02037 1853-0570 |
| 2N2907A | 02682 1853-0281 | 2N3922 | 02763 1853-0038 | 2N5415 | 01921 1853-0224 |
| 2N2913 | 02037 1854-0349 | 2N3933 | 03406 1854-0238 | 2N5415 | 03334 1853-0493 |
| 2N2920 | 02237 1854-0792 | 2N3955 | 03406 1855-0207 | 2N5416 | 01921 1853-0221 |
| 2N2925 | 01973 1854-0066 | 2N3959 | 02037 1854-0220 | 2N5416(SEL) | 02037 1853-0576 |
| 2N2944A | 01698 1853-0327 | 2N3966 | 02883 1855-0286 | 2N5417 | 02037 1854-0596 |
| 2N2946A | 01698 1853-0322 | 2N398B | 02037 1850-0078 | 2N5417 | 02037 1854-0758 |
| 2N2958 | 02037 1854-0036 | 2N3993 | 02037 1855-0387 | 2N5418 | 02037 1854-0766 |
| 2N2972 | 02037 1854-0411 | 2N4028 | 02237 1853-0206 | 2N5419 | 02037 1854-0586 |
| 2N2996 | 01698 1850-0172 | 2N4032 | 02237 1853-0320 | 2N5432 | 03406 1855-0292 |
| 2N3013 | 06338 1854-0267 | 2N4033 | 01698 1853-0422 | 2N5460 | 02037 1855-0226 |
| 2N3014 | 02037 1854-0842 | 2N4034 | 02237 1853-0072 | 2N5461 | 02037 1855-0659 |
| 2N3019 | 02037 1854-0263 | 2N4035 | 02237 1853-0258 | 2N5461 | 02037 1855-0379 |
| 2N3053 | 01921 1854-0667 | 2N4036 | 01921 1853-0045 | 2N5476 | 02037 1855-0290 |
| 2N3053LV 2449 | 03334 1854-0090 | 2N4037 | 02037 1853-0591 | 2N5485(SEL) | 02037 1855-0096 |
| 2N3053S | 01921 1854-0039 | 2N4041 | 01921 1853-0051 | 2N5496 | 01921 1854-0454 |
| 2N3054 | 01921 1854-0072 | 2N4041 | 01698 1850-0032 | 2N5519 | 02883 1855-0398 |
| 2N3054 | 01921 1854-0590 | 2N4046 | 03191 1854-0248 | 2N5544 | 02569 1855-0071 |
| 2N3055 | 01921 1854-0063 | 2N404A | 02237 1854-0478 | 2N5551 | 02037 1854-0474 |
| 2N3119 | 01921 1854-0056 | 2N404A | 06632 1850-0062 | 2N5556 | 02883 1855-0288 |
| 2N3134 | 02037 1853-0006 | 2N404A | 01698 1850-0111 | 2N5565 | 02883 1855-0232 |
| 2N3227 | 02037 1854-0260 | 2N4092 | 02037 1855-0371 | 2N5575 | 01921 1854-0709 |
| 2N3232 | 02037 1854-0084 | 2N4117 | 02883 1855-0208 | 2N5578 | 01921 1854-0708 |
| 2N3244 | 02037 1853-0384 | 2N4117A | 02883 1855-0305 | 2N5582 | 02037 1853-0293 |
| 2N3250 | 02037 1853-0008 | 2N4209 | 02037 1853-0405 | 2N5671 | 01921 1854-0793 |
| 2N3250 | 02037 1853-0046 | 2N423A | 02037 1854-0600 | 2N5679 | 02037 1853-0585 |
| 2N3250 | 02037 1853-0287 | 2N4236 | 02037 1853-0213 | 2N5681 | 02037 1854-1062 |
| 2N3251 | 02037 1853-0007 | 2N4237 | 02037 1854-0556 | 2N5684 | 02037 1853-0428 |
| 2N3261 | 01921 1854-0301 | 2N4239 | 02037 1854-0361 | 2N5771 | 02037 1853-0540 |
| 2N3262 | 01921 1854-0242 | 2N4240 | 01921 1854-0311 | 2N5782 | 01921 1853-0370 |
| 2N3302 | 02237 1854-0278 | 2N4258 | 02237 1853-0081 | 2N5805 | 01921 1854-0572 |
| 2N3304 | 02237 1853-0014 | 2N4264 | 02037 1854-1186 | 2N5806 | 02037 1854-1129 |
| 2N3318 | 04200 1853-0033 | 2N4298 | 01921 1854-0379 | 2N5838 | 01921 1854-0534 |
| 2N3323 | 02037 1850-0179 | 2N4338 | 02883 1855-0341 | 2N5840 | 02237 1854-0751 |
| 2N3330 | 01698 1855-0393 | 2N4339 | 02883 1855-0055 | 2N5875 | 02037 1853-0305 |
| 2N3355 | 01973 1854-0026 | 2N4342 | 02237 1855-0056 | 2N5876 | 02037 1853-0344 |
| 2N3382 | 03714 1855-0390 | 2N4348 | 01921 1854-0382 | 2N5877 | 02037 1854-0518 |
| 2N3391 | 01973 1854-0033 | 2N4351 | 02037 1855-0380 | 2N5878 | 02037 1854-0743 |
| 2N3392 | 04550 1854-0098 | 2N4352 | 02037 1855-0309 | 2N5880 | 02037 1853-0407 |
| 2N3393 | 01973 1854-0218 | 2N4393 | 02237 1855-0052 | 2N5883 | 02037 1853-0425 |
| 2N3414 | 04200 1854-0216 | 2N4398 | 02037 1853-0310 | 2N5912CHP | 02037 1854-0534 |
| 2N3414 | 03171 1854-1147 | 2N4398 | 02037 1853-0421 | 2N5943 | 02037 1854-0597 |
| 2N3442 | 01921 1854-0217 | 2N4401 | 02037 1854-0467 | 2N5943(SEL) | 02037 1854-1007 |
| 2N3467 | 03406 1853-0399 | 2N4401 | 02037 1854-1039 | 2N5949 | 03406 1855-0258 |
| 2N3468 | 02037 1854-0416 | 2N4401 | 02037 1854-1126 | 2N5954 | 01921 1853-0277 |
| 2N3436 | 02763 1855-0005 | 2N4403 | 02037 1853-0271 | 2N5956 | 02037 1853-0303 |
| 2N3439 | 01921 1854-0079 | 2N4403 | 02037 1853-0419 | 2N5957 | 02713 1850-0052 |
| 2N3440 | 01921 1854-0234 | 2N4403 | 02037 1853-0565 | 2N5962 | 03285 1855-0507 |
| 2N3441 | 01921 1854-0216 | 2N4403 | 02037 1853-0600 | 2N5963 | 02883 1855-0669 |
| 2N3441 | 03171 1854-1147 | 2N4405 | 02037 1853-0650 | 2N597 | 02713 1850-0417 |
| 2N3442 | 01921 1854-0217 | 2N4410 | 02037 1854-0365 | 2N5987 | 02037 1853-0378 |
| 2N3467 | 03406 1853-0399 | 2N4416 | 01698 1855-0327 | 2N600 | 02713 1850-0418 |
| 2N3478 | 02037 1854-0325 | 2N4416A | 02037 1855-0276 | 2N6027 | 04550 1855-0314 |
| 2N3494 | 02037 1853-0071 | 2N4403 | 02037 1853-0419 | 2N6028 | 03714 1855-0661 |
| 2N3501S | 02037 1854-0813 | 2N4403 | 02037 1853-0565 | 2N6033 | 03406 1855-0213 |
| 2N3553 | 01921 1854-0308 | 2N4403 | 02037 1853-0600 | 2N604 | 03285 1855-0507 |
| 2N3563 | 02237 1854-0148 | 2N4405 | 02037 1853-0650 | 2N6049 | 02037 1853-0391 |
| 2N3565 | 02237 1854-0060 | 2N4410 | 02037 1854-0635 | 2N6053 | 02037 1853-0351 |
| 2N3583 | 01921 1854-0282 | 2N4416 | 01698 1855-0327 | 2N6053 | 02037 1853-0362 |
| 2N3585 | 01921 1854-0643 | 2N4416A | 02037 1855-0276 | 2N6055 | 02037 1854-0611 |
| 2N3631 | 02883 1855-0291 | 2N4416A CHIP | 02037 1855-0256 | 2N6056 | 01921 1854-0774 |
| 2N3633 | 01991 1854-0315 | 2N4428 | 02037 1854-0851 | 2N6057 | 02713 1850-0110 |
| 2N3634 | 02037 1853-0028 | 2N4852 | 02037 1855-0204 | 2N6058 | 02037 1853-0413 |
| 2N3635 | 02037 1853-0462 | 2N4853 | 02037 1855-0099 | 2N6059 | 02037 1854-0548 |
| 2N3638 | 02037 1853-0638 | 2N4857 | 03406 1855-0244 | 2N6061 | 02037 1853-0391 |
| 2N3640RLLRA1 | 02037 1853-0665 | 2N4860 | 02037 1855-0632 | 2N6063 | 02037 1853-0351 |
| 2N3642 | 02237 1854-0255 | 2N4891 | 02037 1855-0665 | 2N6065 | 02037 1853-0362 |
| 2N3663 | 01973 1854-0219 | 2N4902 | 02037 1853-0223 | 2N6066 | 02037 1854-0223 |
| 2N3685 | 03714 1855-0430 | 2N4904 | 02037 1853-0426 | 2N6067 | 02037 1854-0669 |
| 2N3688 | 02237 1854-0231 | 2N4912 | 02037 1854-0399 | 2N6078 | 01921 1854-0599 |
| 2N3694 | 02237 1854-0203 | 2N4917 | 02237 1853-0089 | 2N6107 | 01921 1853-0371 |
| 2N3703 | 01698 1853-0023 | 2N4917 | 02237 1853-0091 | 2N6107 | 01921 1853-0538 |
| 2N3710 | 01698 1854-0064 | 2N4917 | 02237 1853-0597 | 2N6107(SEL) | 02037 1853-0667 |
| 2N3711 | 01698 1854-0081 | 2N4917 | 02237 1853-0610 | 2N6109 | 02037 1853-0469 |
| 2N3713 | 02037 1854-0252 | 2N4918 | 02037 1853-0084 | 2N6124 | 02037 1853-0661 |
| 2N3714 | 02037 1854-1018 | 2N4919 | 02037 1854-0222 | 2N6211 | 01921 1853-0328 |
| 2N3715 | 02037 1854-0264 | 2N4920 | 02037 1853-0204 | 2N6213 | 02037 1853-0670 |
| 2N3724A | 01698 1854-0350 | 2N4922 | 02037 1851-0389 | 2N6248 | 01921 1853-0139 |
| 2N3725 | 01698 1854-0547 | 2N4923 | 02037 1851-0347 | 2N6249 | 01921 1854-0598 |
| 2N3725A | 01698 1854-0687 | 2N4959 | 02037 1853-0430 | 2N6254 | 01921 1854-0755 |
| 2N3737 | 02037 1854-0988 | 2N4966 | 01698 1854-0397 | 2N6256 | 01921 1854-0576 |
| 2N3739 | 02037 1854-0324 | 2N5022 | 02237 1853-0373 | 2N6259 | 01921 1854-0577 |
| 2N3740 | 02037 1853-0052 | 2N5039 | 01921 1854-0762 | 2N6260 | 02037 1854-1133 |
| 2N3741 | 02037 1853-0392 | 2N5067 | 02037 1854-0695 | 2N6261 | 01921 1854-0738 |
| 2N3762 | 02037 1853-0429 | 2N5070 | 01921 1854-0386 | 2N6262 | 02037 1854-0671 |
| 2N3765 | 02037 1853-0546 | 2N5087 | 03406 1853-0086 | 2N6289 | 01921 1854-0837 |
| 2N3766 | 02037 1854-0259 | 2N5088 | 02037 1854-0392 | 2N6292 | 01921 1854-0765 |
| 2N3771 | 01921 1854-0313 | 2N5089 | 02237 1854-0731 | 2N6292 | 01921 1854-0917 |
| 2N37 | | | | | |

| Mfr. | HP P/N | 5082-3140 | 02062 1900-0099 | BYD33M | 03334 1901-1246 |
|---------------|-----------------|-----------------|-----------------|----------------------|-------------------|
| 2N6340 | 02037 1854-1145 | 5082-3900 | 02062 1901-0826 | BYP50-300 | 03334 1901-0887 |
| 2N6354 | 01921 1854-0715 | 5082-3900 | 02062 1901-0875 | BYV26C SELECTED | 03334 1901-1230 |
| 2N6420 | 02037 1853-0548 | 50L200 | 02158 1901-0738 | BYV27-100 | 06002 1901-1118 |
| 2N6423 | 02037 1853-0414 | KXP5_0A | 03287 1901-1211 | BYV27-150 | 03334 1901-1112 |
| 2N6429A | 02037 1854-0831 | 5M172S2 | 02037 1902-0918 | BYV27-200 | 03334 1901-1141 |
| 2N6437 | 02037 1853-0526 | 5M182S2 | 02037 1902-0919 | BYV27-310 | 03334 1906-0296 |
| 2N6474 | 01921 1854-0727 | 5M202S2 | 02037 1902-0989 | BYV36C | 03334 1901-1223 |
| 2N6476 | 01921 1853-0406 | 5M222S2 | 02037 1902-1347 | BYV36E | 03334 1901-1249 |
| 2N6477 | 01921 1854-0737 | 5M232S2 | 02037 1902-0981 | BYV95C | 07766 1901-1138 |
| 2N6488 | 01921 1854-0884 | 5M272S2 | 02037 1902-0988 | BYV29-50 | 03334 1901-0858 |
| 2N6490 | 02037 1853-0478 | M268ZS2 | 02037 1902-0982 | BYW80-100 | 10881 1901-1126 |
| 2N6491 | 02037 1853-0542 | M309S2 | 02037 1902-0980 | B24M5-568 | 11708 1902-1523 |
| 2N6497 | 02037 1854-0839 | 6T-2 | 00046 1906-0035 | BZT75-C2V1 | 03334 1901-1160 |
| 2N6499 | 02037 1854-0889 | 698_1 | 00046 1906-0090 | BZK8-3A5V1 | 02037 1902-1374 |
| 2N6520 | 02037 1853-0427 | 805Q030 | 04550 1853-0479 | BZK8L-C12 | 03334 1902-1487 |
| 2N6545 | 02037 1854-0787 | A114A | 03038 1901-0921 | BZK8L-C3V9 | 03334 1902-1519 |
| 2N6554 | 02037 1853-0558 | A114A | 01973 1901-0690 | BZK8AC5V6 | 10881 1902-1424 |
| 2N6584 | 01691 1854-0848 | A114D | 04550 1901-1092 | BZK84CTV5 | 02037 1902-1512 |
| 2N6594 | 02037 1853-0452 | A115A | 04550 1901-0696 | BZK8L7V5 | 10818 1902-3129 |
| 2N6609 | 02037 1853-0487 | A115F | 01973 1901-0691 | CT754 | 03811 1858-0081 |
| 2N6658 | 02883 1855-0293 | A115M | 04550 1901-1091 | CA3018 | 01921 1820-0352 |
| 2N6659 | 02037 1855-0251 | A115M | 01973 1901-0879 | CA3019 | 01921 1901-0557 |
| 2N6660 | 02883 1855-0614 | A14B | 01973 1901-0327 | CA3026 | 01921 1820-0240 |
| 2N6667 | 02037 1853-0666 | A14D | 01973 1901-0328 | CA3045 | 01921 1821-0002 |
| 2N6678 | 01921 1854-0871 | A14M | 04550 1901-0329 | CA3045H | 01921 1858-0064 |
| 2N6709 | 10881 1853-0573 | A14W | 01973 1901-0330 | CA3046 | 01921 1821-0001 |
| 2N6741 | 02062 1854-0971 | A14P | 01973 1901-0532 | CA3049 | 01921 1858-0004 |
| 2N6837 | 02037 1854-1122 | A15A | 01973 1901-0673 | CA3081E | 01921 1858-0023 |
| 2N7000 | 02883 1855-0667 | A15F | 04550 1901-0754 | CA3082E | 01921 1858-0048 |
| 2N7000 | 02037 1855-0727 | A211 | 03334 1854-0435 | CA3082F | 01921 1858-0057 |
| 2N706A | 02237 1854-0017 | A25097 | 04507 1901-0531 | CA3083 | 01921 1858-0021 |
| 2N708 | 02237 1854-0005 | A25832 | 04507 1900-0092 | CA3096E | 01921 1858-0118 |
| 2N709 | 02037 1854-0009 | A2X1501 | 04507 1901-1107 | CA3097E | 01921 1858-0046 |
| 2N720A | 02237 1854-0750 | A2X2118 | 04507 1900-0043 | CA3102E | 01921 1858-0063 |
| 2N730 | 10698 1854-0289 | A3604 | 03334 1854-1164 | CA3127E | 01921 1858-0040 |
| 2N743 | 10698 1854-0004 | A400(SEL) | 03334 1854-1120 | CA3146E | 01921 1858-0032 |
| 2N779A | 01979 1850-0075 | A440 | 03334 1853-0553 | CA3183E | 01921 1858-0096 |
| 2N779A | 06632 1850-0411 | A4S021 SELECTED | 02865 1901-1132 | CD36191 | 02763 1902-0121 |
| 2N834 | 02037 1854-0010 | A4X665 | 04507 1900-0034 | CL4720 | 02883 1902-1295 |
| 2N835 | 02037 1854-0011 | A5S092 SELECTED | 04507 1900-0036 | CLA3132-86 | 02865 1900-0046 |
| 2N910 | 02237 1854-0209 | A574260 | 01698 1853-0404 | CP4071 | 00746 1854-0071 |
| 2N915 | 02237 1854-0287 | A5X1046 | 04507 1900-0042 | CSB7201-01 | 02865 1900-0068 |
| 2N916 | 02237 1854-0050 | AD814 | 03285 1854-0619 | CT-1058 | 04200 1854-0810 |
| 2N918 | 02237 1854-0021 | AD821 (SPEC) | 03285 1858-0036 | D404d | 02037 1854-1086 |
| 2N963 | 02037 1850-0119 | AT-41400 | 03291 1854-1144 | D41D4 | 02037 1853-0595 |
| 2N964 | 02037 1850-0085 | AT-41435-5 | 03291 1854-1067 | D42C11N | 04550 1854-0998 |
| 2N964 | 06632 1850-0099 | AT-8160 | 03291 1855-0720 | D44H11 | 04550 1854-0872 |
| 2N976 | 01979 1850-0137 | BA220 | 03334 1901-0022 | D44H5 | 04550 1854-0635 |
| 2SA1151 | 00039 1853-0624 | BA482 | 03334 1901-1253 | D45H11 | 04550 1853-0497 |
| 2SA1220 | 00039 1853-0629 | BA483 | 03334 1901-1134 | D45H2 | 04550 1853-0472 |
| 2SA1226 | 00039 1853-0588 | BAL 74 | 10881 1901-1114 | D45H5 | 04550 1853-0494 |
| 2SA1227 | 00039 1853-0632 | BAR42 | 11708 1901-1254 | D5848 | 02865 1906-0244 |
| 2SA1227A | 00039 1853-0622 | BAS 40-04 | 06122 1906-0320 | DAW601 | 00746 1906-0293 |
| 2SA1302 | 06351 1853-0621 | BAS16 | 02237 1901-1227 | DDC4565-96 | 02865 1901-0985 |
| 2SA812 | 03334 1853-0636 | BAS19 | 03334 1901-1150 | DDC4565D | 02865 1900-0053 |
| 2SA985 | 00039 1853-0633 | BAS10-06 | 06121 1906-0332 | DDC4582D | 02865 1900-0056 |
| 2SB1007 | 00746 1854-0674 | BAS56 | 03334 1906-0337 | DE111 | 04550 1901-0905 |
| 2SB737 | 00746 1854-0550 | BAS70-04 | 06121 1906-0331 | DE131 | 04550 1901-1255 |
| 2SB965 | 00039 1853-0531 | BAT17 | 03334 1901-1151 | DF01 | 02713 1906-0284 |
| 2SC1623 | 03334 1854-1132 | BAT85 | 03334 1901-1183 | DF04 | 02713 1906-0283 |
| 2SC2275 | 00039 1854-1119 | BAV10 SELECTED | 03334 1901-1164 | DF06M | 02713 1906-0306 |
| 2SC2314 | 00039 1854-0860 | BAV70 | 02037 1901-1144 | DM6553 | 02865 1900-0062 |
| 2SC2429 (SEL) | 06344 1854-0940 | BAV74 SELECTED | 03334 1901-1224 | DM6556 | 02865 1900-0039 |
| 2SC2690 | 00039 1854-1115 | BAV99 | 03334 1906-0303 | DMF5835A | 02865 1900-0061 |
| 2SC2718 | 00039 1854-1112 | BAW56 | 02037 1901-1145 | DMF5848 | 02865 1906-0294 |
| 2SC2876 | 06354 1854-1003 | BC321C-18 | 02327 1853-0366 | DMU4705 SELECTED | 02865 1900-0031 |
| 2SC2878 | 06354 1854-1041 | BCF70 | 03334 1853-0599 | DMU4708 | 02865 1906-0279 |
| 2SC2987 | 00039 1854-1118 | BCW65C | 02037 1854-1150 | DMU4768 | 02865 1900-0059 |
| 2SC2987A | 00039 1854-1113 | BCX18 | 10881 1853-0545 | DN2094 | 02883 1855-0659 |
| 2SC3281 | 06354 1854-1117 | BCX20 | 10881 1854-0987 | DPAD 100 | 02883 1906-0100 |
| 2SD1288 | 00039 1853-0630 | BCY 57/LV2345 | 03334 1854-0307 | DPAD10 | 02883 1906-0325 |
| 2SD1378 | 00746 1854-1187 | BD139 | 02037 1854-0805 | DPA10 | 02883 1906-0325 |
| 2SD786 | 00746 1854-1136 | BD415 | 02037 1854-1004 | DQA05050505 | 03287 1906-0297 |
| 2SK105F, H | 00039 1855-0576 | BD416 | 02037 1853-0557 | DSG 6474-44 | 02865 1900-0032 |
| 2SK523 | 00039 1855-0570 | BD435 | 02037 1854-1121 | DSR3700X | 04507 1901-1116 |
| 35821E | 02062 1854-0769 | BF258 | 01698 1854-0621 | DSR3800X | 04507 1901-1115 |
| 3L05 | 02661 1901-0699 | BF398 | 01698 1853-0355 | DSR5500X | 04507 1901-0893 |
| 3N128 | 01921 1855-0306 | BF569 | 03334 1853-0611 | DTS-802 | 02865 1906-0705 |
| 3N138 | 01921 1855-0332 | BF980 | 03334 1855-0666 | DT413 | 05840 1854-0886 |
| 3N142 | 01921 1855-0357 | BFQ-32 | 03334 1853-0527 | DZ70302N | 02688 1902-0570 |
| 3N153 | 01921 1855-0307 | BFQ19 | 03334 1854-1054 | E107 | 02883 1855-0280 |
| 3N163 | 02883 1855-0432 | BFQ23C | 05946 1853-0672 | E111 | 02883 1855-0206 |
| 3N172 | 03714 1855-0323 | BFQ34 | 03334 1854-0942 | E232 | 02883 1855-0274 |
| 3N190 | 03714 1855-0279 | BFQ51 | 03334 1853-0544 | ED6240 | 05131 1901-0591 |
| 3N215 | 03714 1855-0396 | BFR36 | 06592 1854-0868 | EGP10B | 02713 1901-1147 |
| 3N91 | 02634 1853-0057 | BFR90 | 03334 1854-0591 | F54011A | 03406 1855-0693 |
| 3SF1 | 02661 1901-0674 | BFR91 | 03334 1854-0632 | FD777 | 02237 1901-0179 |
| 3SF2 | 02661 1901-0988 | BFR91A | 03334 1854-1050 | FDH-400 | 02237 1901-0096 |
| 40250 | 01921 1854-0224 | BFR92 | 10881 1854-0986 | FDW444 | 02237 1901-1067 |
| 40313 | 01921 1854-0383 | BFR92(SEL) | 03334 1854-1045 | FDS01503 | 02237 1906-0334 |
| 40316 | 01921 1854-0095 | BFR93 | 03334 1854-1055 | FE16F | 02713 1901-1143 |
| 40394 | 01921 1853-0087 | BFR94 | 03334 1854-1036 | FEN16CT7 | 02713 1906-0308 |
| 40468 | 01921 1855-0095 | BFR95 | 03334 1854-0721 | FPF16GT ³ | 02713 1906-0295 |
| 40608 | 01921 1854-0612 | BFR96 | 03334 1854-0722 | FES8GT | 02713 1901-1140 |
| 40673 | 01921 1855-0344 | BFRC90 | 02037 1854-1049 | FM2645 | 02883 1855-0395 |
| 40831 | 01921 1853-0342 | BFT46 | 02037 1854-0972 | FMSA2509P | 02237 1906-0339 |
| 40852 | 01921 1854-0617 | BFT92 | 03334 1855-0640 | FMSA2565P | 02237 1906-0324 |
| 40854 | 01921 1854-0615 | BFT93 | 03334 1853-0616 | FMSA619P | 02237 1906-0257 |
| 4089030 | 03038 1801-0859 | BFT99 | 03334 1853-0612 | FSA157P | 02237 1906-0074 |
| 5082-0001 | 02062 1901-0881 | BFT90 | 02037 1854-1063 | FSA237P | 02237 1906-0335 |
| 5082-0001 | 02062 1900-0093 | BS170 | 02037 1855-0696 | FT50 | 02237 1854-0777 |
| 5082-0001 | 02062 1900-0057 | BS170 | 02037 1855-0696 | FT5754M | 12010 1858-0115 |
| 5082-0008 | 02062 1900-0033 | BSX29 | 02237 1853-0097 | FT5755M | 12010 1858-0109 |
| 5082-0009 | 02062 1900-0060 | BU105 | 01698 1854-0797 | G6R110H | 02158 1901-0739 |
| 5082-0012 | 02062 1901-1176 | BU406 | 02037 1854-1006 | GES3416 | 04550 1854-0978 |
| 5082-0023 | 02062 1901-1194 | BU426 | 02037 1854-1157 | GI250-3 | 00713 1901-0490 |
| 5082-0030 | 02062 1900-0066 | BU508A | 02037 1854-1005 | GP30B | 02713 1901-1135 |
| 5082-0049 | 02062 1900-0025 | BU807 | 02037 1854-1165 | GX55220A | 03287 1854-0869 |
| 5082-0830 | 02062 1901-1193 | BUS11 | 06023 1854-0665 | H1601-1.5 | 05088 1901-1251 |
| 5082-1006 | 02062 1901-1232 | BUS11A | 03334 1854-1183 | H1651-12 | 05088 1901-1197 |
| 5082-2272 | 02062 1905-0252 | BUS12 | 03334 1854-1182 | H2745-9 | 05088 1901-0974 |
| 5082-2370 | 02062 1906-0234 | BUS11A | 02037 1854-1166 | H617 | 05088 1901-0768 |
| 5082-2755 | 02062 1901-0920 | BUS12A | 03334 1854-1019 | HMF-0310-100 | 03799 1855-0719 |
| 5082-2794 | 02062 1900-0088 | BUX-80 | 03334 1854-0775 | HMF-0620 | 03799 1855-0714 |
| 5082-2800 | 04507 1901-0518 | BUX-83 | 03334 1854-0780 | HP-3 | 05176 1854-0664</ |

JDEC

Mfr. HP P/N

| | | | | | | | | |
|-----------------|-------|-----------|--------------------|-------|-----------|-------------------|-------|-----------|
| HSMS-0002 | 02062 | 1901-0094 | LM3018AH | 03406 | 1858-0045 | MJE200 | 02037 | 1854-0739 |
| HSMS-2800 | 02062 | 1900-0078 | LM394 | 03406 | 1854-0830 | MJE2100 | 02037 | 1854-0701 |
| HSMS-2812 | 02062 | 1900-0091 | LT1839-1 | 04507 | 1854-1029 | MJE2102 | 02037 | 1854-0647 |
| HSMS-2825 | 02062 | 1900-0202 | LT5239 | 04507 | 1853-0583 | MJE220 | 02037 | 1854-0735 |
| HSMS2810 | 02062 | 1900-0074 | LVA 456A | 04507 | 1902-1352 | MJE223 | 02037 | 1854-0692 |
| HSMS2820 | 02062 | 1900-0072 | LVA43A | 04507 | 1902-0906 | MJE233 | 02037 | 1853-0367 |
| HXTR-2101 | 02062 | 1854-0863 | LVA56A | 04507 | 1902-0905 | MJE2361 | 02037 | 1854-0749 |
| HXTR-3002 | 02062 | 1854-1104 | LVA68A | 04507 | 1902-0907 | MJE241 | 02037 | 1854-0808 |
| HXTR-3101 | 02062 | 1854-0944 | M100 | 02883 | 1855-0427 | MJE243 | 02037 | 1854-0794 |
| HXTR-3102 | 02062 | 1854-1093 | MA-40035 | 02788 | 1900-0041 | MJE244 | 02037 | 1854-0754 |
| HXTR-3675 | 02062 | 1854-1033 | MA-4P402L | 02788 | 1900-0040 | MJE251 | 02037 | 1853-0458 |
| HXTR-5002 | 02062 | 1854-0825 | MA-4P203-287 | 05695 | 1900-0047 | MJE253 | 02037 | 1853-0447 |
| HXTR-5002 | 02062 | 1854-0862 | MA4004A | 02037 | 1850-0439 | MJE2801K | 02037 | 1854-0640 |
| HXTR-5102 | 02062 | 1854-1123 | MABE202L | 02788 | 1906-0285 | MJE2801T | 02037 | 1854-0819 |
| HXTR-5104 | 02062 | 1854-0878 | MAPW85 | 02788 | 1900-0045 | MJE2901K | 02037 | 1853-0365 |
| HXTR-6001 | 02062 | 1854-0861 | MAPW50 | 02788 | 1900-0201 | MJE2901T | 02037 | 1853-0547 |
| HXTR-6105 | 02062 | 1854-0864 | MAD130P | 02037 | 1906-0312 | MJE2955T | 02037 | 1853-0441 |
| ICTE-12 | 03287 | 1902-0941 | MAT-01GH | 02180 | 1854-0712 | MJE3302 | 02037 | 1854-0886 |
| ID101 | 03714 | 1906-0268 | MAT-02-0098 | 02180 | 1854-1181 | MJE340 | 02037 | 1854-0622 |
| IRH01A | 03714 | 1858-0066 | MAT-02FH | 02180 | 1854-1109 | MJE371K | 02037 | 1853-0369 |
| IRH6490 | 02037 | 1902-1431 | MATO4FV | 02180 | 1858-0110 | MJE371K | 02037 | 1853-0634 |
| IR5365B | 02037 | 1902-1345 | MBAV70 | 02037 | 1906-0336 | MJE371K(Selected) | 02037 | 1853-0450 |
| IR5062 | 03038 | 1854-0804 | MBAV74 | 02037 | 1906-0335 | MJE5191 | 02037 | 1854-0682 |
| IR6062 | 03038 | 1854-0865 | MBAV99 | 02037 | 1906-0291 | MJE5192 | 02037 | 1854-0654 |
| IRF120 | 03038 | 1855-0511 | MBAW56 | 02037 | 1906-0290 | MJE5194 | 02037 | 1853-0385 |
| IRF130 | 03038 | 1855-0494 | MBD501 | 02037 | 1901-1213 | MJE5195 | 02037 | 1853-0372 |
| IRF140 | 02037 | 1855-0618 | MBD5300 | 02037 | 1901-1078 | MJE521K | 02037 | 1854-0653 |
| IRF150 | 03038 | 1855-0508 | MBD5550A | 02037 | 1901-0661 | MJE5657 | 02037 | 1854-1127 |
| IRF250 | 03038 | 1855-0562 | MBCD101 | 02037 | 1901-0861 | MJE5657 | 02037 | 1854-0736 |
| IRF300 | 03038 | 1855-0296 | MBI-101 | 02037 | 1901-0760 | MJE5659 | 02037 | 1853-0584 |
| IRF431 | 03038 | 1855-0454 | MBR-3535 | 02037 | 1901-0860 | MJE5652 | 02037 | 1853-0657 |
| IRF440 | 03038 | 1855-0536 | MBR030 | 02037 | 1901-1158 | MJE6040 | 02037 | 1853-0455 |
| IRF510 | 03038 | 1855-0561 | MBR1060 | 02037 | 1901-0986 | MJE6043 | 02037 | 1854-0879 |
| IRF512 | 03038 | 1855-0549 | MBR1535CT | 02037 | 1906-0276 | MJE700 | 02037 | 1853-0347 |
| IRF513 | 03038 | 1855-0589 | MBR1540 | 02037 | 1901-1095 | MJE701 | 02037 | 1853-0364 |
| IRF520 | 03038 | 1855-0461 | MBR1645 | 02037 | 1901-1152 | MJE800 | 02037 | 1854-0581 |
| IRF521 | 03038 | 1855-0581 | MBR20045CT | 02037 | 1906-0307 | MJE800 | 02037 | 1854-0633 |
| IRF521 | 03038 | 1855-0622 | MBR2035CT | 02037 | 1906-0286 | MJE802 | 02037 | 1854-0626 |
| IRF523 | 03038 | 1855-0572 | MBR2545CT | 02037 | 1906-0292 | MJE16018 | 02037 | 1854-1072 |
| IRF523 | 03038 | 1855-0586 | MBR3035CT | 02037 | 1906-0267 | MJJ40037T1 | 02037 | 1901-1161 |
| IRF530 | 03038 | 1855-0492 | MBR340P | 02037 | 1901-0877 | MLL5221 | 02037 | 1902-1441 |
| IRF533 | 03038 | 1855-0592 | MBR3545 | 02037 | 1901-0912 | MLL5223 | 02037 | 1902-1442 |
| IRF540 | 02037 | 1855-0670 | MBR745 | 02037 | 1901-1173 | MLL5225 | 02037 | 1902-1443 |
| IRF540(SEL) | 02037 | 1855-0590 | MBRL030-T1 | 02037 | 1901-1204 | MLL5226 | 02037 | 1902-1444 |
| IRF610 | 03038 | 1855-0488 | MC1107P | 02037 | 1906-0229 | MLL5227 | 02037 | 1902-1445 |
| IRF612 | 03038 | 1855-0641 | MC1111 | 02037 | 1858-0089 | MLL5228 | 02037 | 1902-1446 |
| IRF630 | 03038 | 1855-0504 | MD-982 | 02037 | 1853-0471 | MLL5229 | 02037 | 1902-1447 |
| IRF640 | 03038 | 1855-0524 | MD1130 | 02037 | 1853-0529 | MLL5230 | 02037 | 1902-1448 |
| IRF740 | 03038 | 1855-0631 | MD1132 | 02037 | 1854-1035 | MLL5231 | 02037 | 1902-1449 |
| IRF830 | 03038 | 1855-0510 | MD2252 | 02037 | 1854-0222 | MLL5232 | 02037 | 1902-1450 |
| IRF9130 | 03038 | 1855-0484 | MD2369A | 02037 | 1854-1016 | MLL5234 | 02037 | 1902-1451 |
| IRF9513 | 03038 | 1855-0588 | MD2905A | 02037 | 1853-0484 | MLL5235 | 02037 | 1902-1452 |
| IRF9520 | 03038 | 1855-0509 | MD4260 | 02037 | 1853-0589 | MLL5236 | 02037 | 1902-1453 |
| IRF9521 | 03038 | 1855-0587 | MD6002 | 02037 | 1853-0663 | MLL5237 | 02037 | 1902-1454 |
| IRF9530 | 03038 | 1855-0493 | MD918A | 02037 | 1854-1010 | MLL5239B | 02037 | 1902-1455 |
| IRF9531 | 03038 | 1855-0499 | MDA 990-3 | 02037 | 1906-0017 | MLL5240 | 02037 | 1902-1456 |
| IRF9532 | 03038 | 1855-0517 | MDA-104 | 02037 | 1906-0094 | MLL5241 | 02037 | 1902-1457 |
| IRF9220 | 03038 | 1855-0726 | MDA1201 | 02037 | 1901-0161 | MLL5242 | 02037 | 1902-1458 |
| IRFD110 | 03038 | 1855-0502 | MDA202 | 02037 | 1906-0096 | MLL5243 | 02037 | 1902-1459 |
| IRFD110 | 03038 | 1855-0518 | MDA208 | 02037 | 1906-0219 | MLL5245 | 02037 | 1902-1460 |
| IRFD113 | 03038 | 1855-0520 | MDA2500 | 02037 | 1906-0008 | MLL5246 | 02037 | 1902-1461 |
| IRFD120 | 02883 | 1855-0709 | MDA2504 | 02037 | 1906-0007 | MLL5250 | 02037 | 1902-1463 |
| IRFD123 | 02883 | 1855-0729 | MDA2504 | 02037 | 1906-0222 | MLL5251 | 02037 | 1902-1464 |
| IRFD210 | 03038 | 1855-0712 | MDA2506 | 02037 | 1906-0016 | MLL5252 | 02037 | 1902-1465 |
| IRFD420 | 03038 | 1855-0551 | MDA2506 | 02037 | 1906-0224 | MLL5254 | 02037 | 1902-1466 |
| IRFD9120 | 03038 | 1855-0500 | MDA3500 | 02037 | 1906-0221 | MLL5256 | 02037 | 1902-1467 |
| IRFD9123 | 03038 | 1855-0567 | MDA3502 | 02037 | 1906-0266 | MLL5258 | 02037 | 1902-1469 |
| IRFD9210 | 03038 | 1855-0711 | MDA3504 | 02037 | 1906-0212 | MLL5259 | 02037 | 1902-1470 |
| IRFF123 | 02883 | 1855-0580 | MDA3506 | 02037 | 1906-0217 | MLL5260 | 02037 | 1902-1471 |
| IRFF131 | 03038 | 1855-0646 | MDA9205 | 02037 | 1901-0365 | MLL5261 | 02037 | 1902-1472 |
| IRFF210 | 03038 | 1855-0521 | MDA922-3 | 02037 | 1906-0028 | MLL5262 | 02037 | 1902-1473 |
| IRFP250 | 04550 | 1855-0691 | MDA922-4 | 02037 | 1906-0023 | MLL5263 | 02037 | 1902-1474 |
| IRFP450 | 03038 | 1855-0682 | MDA922-6 | 02037 | 1906-0027 | MLL5265 | 02037 | 1902-1475 |
| IRF222 | 03038 | 1855-0683 | MDA970A2 | 02037 | 1901-0638 | MLL5266 | 02037 | 1902-1476 |
| IRF240 | 03038 | 1855-0694 | MDA970A2 | 02037 | 1906-0258 | MLL5267 | 02037 | 1902-1477 |
| IT1110 | 03714 | 1855-0406 | MDA980-3 | 02037 | 1906-0032 | MLL5268 | 02037 | 1902-1478 |
| IT1110 | 03714 | 1855-0625 | MDA980-6 | 02037 | 1906-0049 | MLL5270 | 02037 | 1902-1479 |
| IT120A-T071 | 03714 | 1854-0957 | MDA990-1 | 02037 | 1906-0337 | MM1904 | 02037 | 1854-0883 |
| IT130-T071 | 03714 | 1853-0635 | MDA990-2 | 02037 | 1906-0058 | MM1906 | 02037 | 1853-0276 |
| IT17400 | 03714 | 1855-0998 | MDS60 | 02037 | 1853-0539 | MM4018 | 02037 | 1853-0440 |
| IT17500 | 03714 | 1855-0535 | MFE3004 | 02037 | 1855-0272 | MM4032 | 02037 | 1853-0489 |
| IT500 | 03714 | 1855-0434 | MFE5521 | 02037 | 1855-0652 | MM4645 | 02037 | 1853-0308 |
| ITS1015(SEL) | 03714 | 1855-0992 | MFQ960C | 02037 | 1855-0651 | MMS262 | 02037 | 1854-0802 |
| ITS4066 | 01973 | 1855-0442 | MFR515 | 02037 | 1854-0849 | MMS001 | 02037 | 1854-0580 |
| ITT600 | 04486 | 1901-0703 | MFR961 | 02037 | 1854-0980 | MMS006 | 02037 | 1854-0540 |
| IVN50001TNE | 03714 | 1855-0537 | MHQ2221 | 02037 | 1858-0009 | MMB1321Q5 | 02037 | 1854-1020 |
| IVN5001ANF | 03714 | 1855-0431 | MJ10006 | 02037 | 1854-0948 | MMBD101 | 02037 | 1900-0037 |
| IVN5201TNF | 03714 | 1855-0489 | MJ11012 | 02037 | 1854-0845 | MMBD352 | 02037 | 1900-0039 |
| J107 | 02883 | 1855-0445 | MJ11015 | 02037 | 1853-0501 | MMBD6050 | 02037 | 1901-1142 |
| J108 | 03406 | 1855-0424 | MJ11016 | 02037 | 1854-0887 | MMBD7000 | 02037 | 1906-0298 |
| J112 | 02883 | 1855-0446 | MJ11021 | 02037 | 1853-0524 | MMBD914XT1 | 02037 | 1901-1228 |
| J175 | 02883 | 1855-0574 | MJ12003 | 02037 | 1854-0941 | MMBDB222A | 02037 | 1854-1053 |
| J177 | 02883 | 1855-0289 | MJ12004 | 02037 | 1854-0964 | MMBT2369 | 02037 | 1854-1095 |
| J2472 | 02883 | 1855-0298 | MJ12005 | 02037 | 1854-0969 | MMBT2907A | 02037 | 1853-0525 |
| J270 | 03406 | 1855-0437 | MJ12005(Selected) | 02037 | 1854-0983 | MMBT3904 | 02037 | 1854-1037 |
| J304 | 03406 | 1855-0425 | MJ12010 | 02037 | 1854-0906 | MMBT3906 | 02037 | 1853-0567 |
| J304(SEL) | 03406 | 1855-0554 | MJ13091 | 02037 | 1854-1060 | MMBT4124T1 | 02037 | 1854-1138 |
| J309 | 02883 | 1855-0268 | MJ13099 | 02037 | 1854-1056 | MMBT4126 | 02037 | 1853-0645 |
| JAN TXV 1N825 | 02037 | 1854-0829 | MJ16002 (Selected) | 02037 | 1854-0984 | MMBT4260 | 02037 | 1854-1027 |
| JAN TXV 2N2222A | 02037 | 1853-0470 | MJ16012 | 02037 | 1854-1015 | MMBT4403 | 02037 | 1853-0580 |
| JANTXLN750A | 02237 | 1902-0697 | MJ16018 | 02037 | 1854-1071 | MMBT4493 | 02037 | 1853-0695 |
| JANTXV 1N1418-1 | 02237 | 1901-1101 | MJ2500 | 02037 | 1853-0387 | MMBT4493 | 02037 | 1853-0715 |
| JANTXV1N3020B | 02037 | 1902-0997 | | | | | | |

| | | | | | |
|---------------------|-----------------|--------------------------|-----------------|--------------------|-----------------|
| MMD6100 | 02037 1906-0025 | MR2406 | 02037 1901-1121 | RFL1N08L | 01921 1855-0619 |
| MMD6150 | 02037 1906-0024 | MR2406F | 02037 1901-1137 | RFL1N012 | 01921 1855-0672 |
| MMD7000 | 02037 1906-0026 | MR501 | 02037 1901-1081 | RFP1N012 | 01921 1855-0565 |
| MHD830-E20 | 08852 1900-0050 | MR502 | 02037 1901-0870 | RFP1N015 | 01921 1855-0676 |
| MHD830-E20 SELECTED | 08852 1900-0080 | MR504 | 02037 1901-1000 | RFP1OF15 | 01921 1855-0674 |
| MDC6050 | 02037 1901-0829 | MR508 | 02037 1901-0889 | RFP1P2N08 | 01921 1855-0677 |
| MMPQ-3906 | 02037 1858-0114 | MR510 | 02037 1901-0839 | RFP1N05L | 01921 1855-0629 |
| MMPQ2222A | 02037 1858-0112 | MR751 | 02037 1901-0662 | RFP2N08L | 01921 1855-0678 |
| MMPQ2907A | 02037 1858-0113 | MR752 | 02037 1901-0788 | RFP2N12L | 01921 1855-0665 |
| MMPQ3799 | 02037 1858-0122 | MR754 | 02037 1901-0767 | RFP4N06L | 01921 1855-0708 |
| MMPQ3904 | 02037 1858-0120 | MR756 | 02037 1901-0781 | RFP5P12 | 01921 1855-0623 |
| MRT3960 | 02037 1854-0555 | MR758 | 02037 1901-0787 | RFP6P08 | 01921 1855-0621 |
| MRT3960A | 02037 1854-0587 | MR818 | 02037 1901-1188 | RFP8P08 | 01921 1855-0617 |
| MKL1735 | 08852 1900-0048 | MR820 | 02037 1901-1148 | RGP-10M | 02713 1901-0847 |
| MPL312-78-69 | 07050 1854-1046 | MR822RL | 02037 1901-1086 | RGP1P15-15 | 02713 1901-1237 |
| MP358 | 07050 1853-0619 | MR850 | 02037 1901-0685 | RGP15M | 02713 1901-0997 |
| MP603 | 02037 1850-0440 | MR852 | 02037 1901-0789 | RKBU4K | 02713 1906-0333 |
| MP833-1004 | 07050 1855-0515 | MR854 | 02037 1901-0692 | RUR810 | 01921 1901-0987 |
| MP200 | 02073 1901-0866 | MR854 | 02037 1901-0719 | RUR810 | 01921 1901-1113 |
| MPD100 | 02073 1901-1034 | MR856 | 02037 1901-1087 | S10925 | 02526 1901-1154 |
| MPF6660 | 02037 1855-0675 | MR862R | 02037 1901-1122 | S17843 | 02237 1854-0022 |
| MPF960 | 02037 1855-0594 | MR881R | 02037 1901-1035 | S2F | 02664 1901-0646 |
| MPF3401 | 02037 1901-0844 | MR891R | 02037 1901-1037 | S12248 | 02237 1853-0058 |
| MPN3500 | 02037 1901-0975 | MRF531 (SEL) | 02037 1854-1168 | S4F | 02664 1901-0669 |
| MPQ2222P | 02037 1858-0077 | MRF544 | 02037 1854-1114 | SA100CA | 03287 1902-1522 |
| MPQ2369 | 02037 1858-0055 | MRF545 | 02037 1853-0625 | SA11A | 03287 1902-1534 |
| MPQ2369 | 02037 1858-0100 | MRF571 (SEL) | 02037 1854-1042 | SA617 | 01799 1850-0156 |
| MPQ2484 | 02037 1858-0091 | MRF5711L | 02037 1854-1125 | SB160 | 02713 1901-1165 |
| MPQ2906 | 02037 1858-0010 | MRF580A | 02037 1854-1143 | SB1660 | 02713 1906-0300 |
| MPQ2907P | 02037 1858-0076 | MRF581 | 02037 1854-1022 | SB560 | 02713 1901-1163 |
| MP43546 | 02037 1858-0075 | MRF581 | 02037 1854-1032 | SCA1J | 02664 1901-0526 |
| MP43725 | 02037 1858-0034 | MRF581 (MOD) | 02037 1854-1184 | SCBA2F | 02664 1906-0072 |
| MP43762 | 02037 1858-0062 | MRF586 | 02037 1854-1175 | SCDA2 | 02664 1906-0040 |
| MP43798 | 02037 1858-0071 | MRF587 | 02037 1854-1047 | SCPA05F | 02664 1906-0071 |
| MP43799 | 02037 1858-0092 | MRF604 | 02037 1854-1159 | SCPA2 | 02664 1906-0039 |
| MP43799-2 | 02037 1858-0111 | MRF630 | 02037 1854-0990 | SD-241 | 01691 1906-0239 |
| MP43904 | 02037 1858-0087 | MRF870 | 02037 1854-1149 | SD-1 | 01691 1901-1100 |
| MP43906 | 02037 1858-0058 | MRF904 | 02037 1854-0890 | SD103C | 04486 1901-0999 |
| MP46002 | 02037 1858-0090 | MRF911 | 02037 1854-1178 | SD210DE | 02883 1855-0647 |
| MP46100 | 02037 1858-0074 | MRF962 | 02037 1854-1092 | SD211DE (SELECTED) | 09283 1855-0215 |
| MP46426 | 02037 1858-0102 | MRF965 | 02037 1854-1107 | SD213 | 09283 1855-0404 |
| MP46700 | 02037 1858-0086 | MSD 7000 | 02037 1906-0056 | SD214 | 02910 1855-0269 |
| MP46700 | 02037 1858-0093 | MSD6101 | 02037 1901-0358 | SD214DE | 02883 1855-0723 |
| MP46842 | 02037 1820-1804 | MSS-30_254-B20 | 08852 1900-0075 | SD215 | 02910 1855-0241 |
| MP47041 | 02037 1858-0107 | MSS-40_155-E20 | 08852 1900-0054 | SD306 (SEL) | 09283 1855-0557 |
| MP47051 | 02037 1858-0106 | MSS4_141-B10 SELECTED | 08852 1900-0085 | SE5055 | 02237 1854-0388 |
| MP47091 | 02037 1858-0088 | MTM10N10 SELECTED | 02037 1855-0490 | SES5603CR | 00046 1906-0259 |
| MP4918 | 02037 1858-0091 | MTM10N15 | 02037 1855-0495 | SPF793 | 02037 1855-0020 |
| MP5 6523 | 02037 1853-0043 | MTM12N06 | 02037 1855-0593 | SPR0 | 02664 1901-0998 |
| MP5 A12 | 02037 1854-0560 | MTM12N10 | 02037 1855-0506 | SG3R21N | 03793 1858-0022 |
| MP5 A18 | 02037 1854-0691 | MTM12N18 | 02037 1855-0478 | SGS126 | 06338 1853-0642 |
| MP5 U-10 | 02037 1854-0764 | MTP12P45 | 02037 1855-0527 | SGS126 | 06338 1854-1158 |
| MP5 U-60 | 02037 1853-0423 | MTP1W05A | 02037 1855-0664 | SH6401PC | 02237 1858-0020 |
| MP5-404 | 02037 1853-0217 | MTP1W05A | 02037 1855-0673 | SH6501PC | 02237 1821-0006 |
| MP5-A14 | 02037 1854-0472 | MTP12N06 | 02037 1855-0542 | SJ7076 | 02037 1854-0968 |
| MP5-A14 | 02037 1854-0977 | MTP12N10 | 02037 1855-0506 | SL2364C | 01590 1858-0101 |
| MP5-A17 | 02037 1854-0628 | MTP12N18 | 02037 1855-0563 | SMF230K | 02664 1901-0878 |
| MP5-A18 | 02037 1854-0583 | MTP1W05A | 02037 1855-0660 | SPF938 | 02037 1855-0687 |
| MP5-A42 | 02037 1854-0575 | MTP1W100 | 02037 1855-0664 | SPQ1678 | 02037 1858-0052 |
| MP5-A64 | 02037 1853-0416 | MTP2N90 | 02037 1855-0497 | SPQ526K | 02037 1858-0008 |
| MP5-A66 | 02037 1853-0483 | MTP305A | 02037 1855-0725 | SFS 233 | 02037 1854-0246 |
| MP5-A70 | 02037 1853-0395 | MTP3M60 | 02037 1855-0608 | SPS 3627 | 02037 1854-0270 |
| MP5-D54 | 02037 1853-0667 | MTP4N50 | 02037 1855-0607 | ST3011 | 06632 1854-0690 |
| MP5-H17 | 02037 1854-0628 | MTP5N40 | 02037 1855-0606 | STB523-A | 01973 1901-0460 |
| MP5-U01 | 02037 1854-0634 | MUR105 | 02037 1901-1129 | STB567 | 00046 1901-0701 |
| MP5-U02 | 02037 1854-0514 | MUR115 | 02037 1901-0970 | TG4 | 02664 1902-1385 |
| MP5-U02 | 02037 1854-0836 | MUR140 | 02037 1901-1244 | TID130 | 01598 1901-0995 |
| MP5-U05 | 02037 1854-0817 | MUR150 | 02037 1901-1189 | TIP 115 | 01598 1853-0377 |
| MP5-U07 | 02037 1854-0877 | MUR160 | 02037 1901-1214 | TIP 141 | 01598 1854-0763 |
| MP5-U45 | 02037 1854-0796 | MUR1620CT | 02037 1906-0321 | TID778 | 00046 1901-0979 |
| MP5-U51 | 02037 1853-0326 | MUR1620CT OPTION T0220-C | 02037 1906-0338 | TIP-33 | 01698 1854-0594 |
| MP5-U52 | 02037 1853-0476 | MUR3020PT | 02037 1906-0329 | TIP140 | 01698 1854-0663 |
| MP5-U55 | 02037 1853-0353 | MUR410 | 02037 1901-1239 | TG-10 | 05088 1901-0995 |
| MP5-U57 | 02037 1853-0496 | MUR4100 | 02037 1901-1233 | TID130 | 01598 1906-0202 |
| MP5-U95 | 02037 1853-0449 | MUR415 | 02037 1901-1216 | TIP100 | 02037 1854-0840 |
| MP52369 | 02037 1854-0979 | MUR460 | 02037 1901-1199 | TIP102 | 01598 1854-0970 |
| MP52907A | 02037 1853-0626 | MUR860A | 02037 1901-1130 | TIP105 | 02037 1854-0663 |
| MP53640 | 02037 1853-0244 | MURC115 | 02037 1901-1169 | TIP126 | 01598 1853-0424 |
| MP53643 | 02037 1854-0492 | MX-284 | 08852 1900-0082 | TIP127 | 01598 1853-0468 |
| MP53646 | 02037 1854-1141 | MX-2860 | 08852 1900-0084 | TIP3-4 | 01598 1853-0350 |
| MP54250A | 02037 1853-0587 | MX1098 | 08852 1901-0977 | TIP3-35A | 01598 1854-0593 |
| MP54356 | 02237 1853-0488 | MX2946 | 08852 1900-0086 | TIP4-1 | 01598 1854-0625 |
| MP55179 | 02037 1854-0981 | MX31141 | 08852 1900-0095 | TIP100 | 02037 1854-0840 |
| MP5571 | 02037 1854-1142 | MXR5583 | 02037 1853-0610 | TIP104 | 01598 1854-0970 |
| MP56531 | 02037 1854-0730 | MXR5943 | 02037 1854-1100 | TIP105 | 02037 1854-0985 |
| MP56534 | 02037 1853-0536 | MXT2222A | 02037 1854-1094 | TIP106 | 01598 1853-0454 |
| MP56543 | 02037 1854-1140 | MXT2907A | 02037 1853-0609 | TIP107 | 02037 1853-0490 |
| MP56543 SELECTED | 02037 1854-0296 | MXT3040 | 02037 1854-1101 | TIP110 | 01598 1854-0670 |
| MP56562 | 02037 1853-0318 | MXT3906 | 02037 1853-0613 | TIP112 | 02037 1854-1023 |
| MP56746 | 02037 1853-0572 | ND946 | 04200 1906-0092 | TIP122 | 02337 1854-1128 |
| MP58492 | 02037 1853-0336 | NE-41635 | 00039 1854-1008 | TIP124 | 02037 1854-0700 |
| MP58C404A | 02037 1853-0555 | NE02133L | 00039 1854-1091 | TIP140 | 02037 1854-0880 |
| MP58H10 | 02037 1854-0795 | NE02135 | 00039 1854-0946 | TIP141 | 02037 1854-0985 |
| MP58H10 | 02037 1854-0993 | NE21935 | 00039 1854-1009 | TIP141C | 02037 1854-0799 |
| MP58H10 | 02037 1854-1139 | NE64533 | 00039 1854-1044 | TIP141C (SELECTED) | 02037 1854-0967 |
| MP58H54 | 02037 1853-0662 | NE64533 | 00039 1854-1002 | TIP142 | 01698 1853-0356 |
| MP58H81 | 02037 1853-0444 | NE68135 | 00039 1854-1111 | TIP42A | 01698 1853-0234 |
| MP58H81 | 02037 1853-0639 | NET1000 | 00039 1855-0569 | TIP42C | 02037 1853-0431 |
| MP58H81 | 02037 1854-1064 | NET1084-06 | 00039 1855-0636 | TIP47 | 02037 1854-0838 |
| MP58H86 | 02037 1854-0997 | NET3416D | 00039 1854-1066 | TIP50 | 02037 1854-1069 |
| MP58H96 | 02037 1853-0660 | NE800199 | 00039 1855-0637 | TIP51 | 01698 1854-0806 |
| MP58H51 | 02037 1853-0559 | NE85633 | 00039 1854-1089 | TIP642 | 01698 1854-0982 |
| MP58H56 | 02037 1853-0552 | NE90115 | 00039 1853-0578 | TIP647 | 01698 1853-0543 |
| MP58H75 | 03287 1901-1208 | NEL2301-53 | 00039 1854-1170 | TIP75B | 01698 1854-0803 |
| MP58H75 | 03287 1901-1209 | NS3000 | 02619 1901-0663 | TIP75D | 01698 1854-0960 |
| MR1-1400 | 02037 1901-0885 | PAD5 | 02883 1901-0842 | TIP762A | 01698 1854-1099 |
| MR1033A | 02037 1901-0411 | PF5101 (SELECTED) | 03406 1855-0529 | TIP115 | 01698 1853-0668 |
| MR1035A | 02037 1901-0413 | PIC900C | 00046 1858-0095 | TIR101B | 01698 1906-0213 |
| MR1120 | 02037 1901-0495 | PK10 | 05131 1906-0203 | TIR201B | 01698 1906-0214 |
| MR1120R | 02037 1901-0585 | PN3568 | 02237 1854-0867 | TIS-149 | 01698 1853-0464 |
| MR1121 | 02037 1901-0494 | PN4250 | 02237 1853-0664 | TMP04150 | 04200 1901-1252 |
| MR1121R | 02037 1901-0592 | PN4250 | 02237 1853-0664 | TM4030-D74Z | 03406 1853-0551 |
| MR1122 | 02037 1901-0497 | PU4220 | 08709 1858-0117 | TND908 | 04200 1906-0275 |
| MR1123 | 02037 1901-0499 | R711XE | 05088 1906-0242 | TPQ6002 | 04200 1858-0083 |
| MR1123R | 02037 1901-0630 | R712 | 05088 1906-0231 | U1897E | 03406 1855-0436 |
| MR1124 | 02037 1901-0499 | R712A | 05088 1906-0236 | U310 | 02883 1855-0530 |

| | | | | | | | | |
|----------------|-------|-----------|----------|-------|-----------|---------|-------|-----------|
| UES-1106 | 09914 | 1901-1106 | USD 745C | 00046 | 1906-0265 | VN10KE | 02883 | 1855-0545 |
| UES1105 | 09914 | 1901-1110 | USD840 | 00046 | 1901-1218 | VN10KM | 02883 | 1855-0423 |
| UES1303 | 09914 | 1901-1111 | USD945 | 00046 | 1901-1156 | VN10LE | 02883 | 1855-0560 |
| UES1305 | 09914 | 1901-1108 | V334X | 05088 | 1901-0848 | VN2222L | 02883 | 1855-0556 |
| UES1306 | 09914 | 1901-1109 | V336X | 05088 | 1901-0882 | VN2222L | 02883 | 1855-0598 |
| UES2602R | 00046 | 1906-0254 | VB10X | 05088 | 1901-1105 | VN66AD | 02883 | 1855-0724 |
| UES2603 | 00046 | 1906-0304 | VCR2N | 02883 | 1855-0265 | VN66AF | 02883 | 1855-0275 |
| UES2605 | 00046 | 1906-0277 | VCR3P | 02883 | 1855-0205 | VP0300L | 02883 | 1855-0550 |
| UES601R | 00046 | 1901-0953 | VE48 | 05088 | 1906-0006 | VP0300L | 02883 | 1855-0686 |
| UES803 | 00046 | 1901-1127 | VG-2X | 05088 | 1901-0845 | VP0300M | 02883 | 1855-0526 |
| UES803R | 00046 | 1901-0961 | VH148 | 05088 | 1906-0052 | VP1008B | 02883 | 1855-0722 |
| UES804 | 00046 | 1901-0904 | VHE1404 | 05088 | 1901-1157 | VP1204W | 07221 | 1855-0649 |
| UF4004 | 02713 | 1901-1149 | VHE2402A | 05088 | 1906-0270 | VQ1000J | 02883 | 1855-0591 |
| ULN-2003A | 04200 | 1858-0047 | VHE2404 | 05088 | 1906-0301 | VQ1001J | 02883 | 1858-0116 |
| ULN-2003A(SEL) | 04200 | 1858-0099 | VJ148X | 05088 | 1906-0079 | VQ1001P | 02883 | 1858-0585 |
| ULN-2004A | 04200 | 1858-0061 | VJ848 | 05088 | 1906-0309 | VQ1006P | 02883 | 1855-0620 |
| ULN-2023A | 04200 | 1858-0097 | VJ848PTT | 05088 | 1906-0085 | VQ2001P | 02883 | 1855-0650 |
| ULN-2033A | 04200 | 1858-0067 | VK248 | 05088 | 1906-0205 | VS148 | 05088 | 1906-0240 |
| ULN-2803A | 04200 | 1858-0069 | VKP 248 | 05088 | 1906-0264 | VSK12 | 05088 | 1906-0263 |
| ULN-2804A | 04200 | 1858-0082 | VL447 | 05088 | 1906-0216 | VSK231 | 05088 | 1906-0278 |
| ULN-2804A | 04200 | 1858-0084 | VM28X | 05088 | 1906-0289 | VSK304T | 05088 | 1906-0238 |
| ULN-2805A | 04200 | 1858-0073 | VMP-1 | 02883 | 1855-0263 | VSK530 | 05088 | 1901-1220 |
| ULN-2813A | 04200 | 1858-0072 | VN0104N3 | 07221 | 1855-0546 | VSK540 | 05088 | 1901-0976 |
| ULN-2815A-2 | 04200 | 1858-0065 | VN0106N6 | 07221 | 1858-0105 | VSK71 | 05088 | 1901-0960 |
| ULN2003D | 02910 | 1858-0104 | VN0300L | 02883 | 1855-0555 | VX30 | 00046 | 1901-0984 |
| ULN2082A | 04200 | 1858-0037 | VN0300M | 02883 | 1855-0525 | W02M | 02713 | 1906-0256 |
| ULQ-2823A | 04200 | 1858-0121 | VN0300M | 02883 | 1855-0582 | X45H281 | 04550 | 1853-0363 |
| ULQ2804A | 04200 | 1858-0108 | VN0610L | 02883 | 1855-0684 | ZSK533 | 00039 | 1855-0571 |

Reader's Comment

Irv Barditch, of Baltimore Maryland, requested clarification on how the Rotary Pulse Generator, described in the previous 2nd Quarter issue of *Bench Briefs*, actually determined rotational direction. Figure 1 and the timing diagram did not clearly show how the RPG determined direction, and the text stated only that, "The shaft encoder was designed such that A and B transitions were always shifted by 90 degrees."

The fundamental Rotary Pulse Generator I described is shown in Figure 2 as an artist's conception. It contains a light source, a light shield with two windows a precise distance apart, a round disc with slots of equal size and spacing (sometimes called a shutter), and two phototransistors. The shield is in a fixed position between the light source and rotating disc, which is attached to the knob. The phototransistors are lined up behind the shutter and in line with their respective windows in the shield. (We'll call them windows A and B.) The windows are offset so that as the disc rotates between the shield and phototransistors, light shines directly through one window first, through the disc and onto one phototransistor. So, as an example, when you rotate the shaft counterclockwise, light shines through window B, the shutter and onto phototransistor Q1. Q1 conducts and turns on Q2, which causes the Schmitt trigger output B to go high. A moment later the shutter's rotation allows light to pass through from window A and shine on phototransistor Q3, which causes output A to go high. As the shutter continues CCW, the light is cut off first from

Q1 causing output B to go low, then Q3 causing output A to go low.

Therefore, as the shaft is rotated CCW, Q1 conducts first, then Q3 conducts. Then Q1 turns off followed by Q3. When you rotate the shaft

clockwise, Q3 conducts first followed by Q1 and so on. The spacing between the windows in the light shield and the alignment of the shutter to these windows determines the 90 degrees difference in output transitions. □




Figure 1




Figure 2

Safety-Related Service Notes

Service notes from HP relating to personal safety and possible equipment damage are of vital importance to our customers. To make you more aware of these important notes, they are printed on paper with a red border, and the service note number has a "S" suffix. In order to make you immediately aware of any potential safety problems, we are highlighting safety-related service notes here with a brief description of each problem. Also, in order to draw your attention to safety-related service notes on the service note order form at the back of Bench Briefs, each appropriate number is highlighted by being printed in color.

HP 3552A Transmission Test Set

Product Safety Service Note 3552A-

15-S describes a possible safety hazard that may exist if an incorrectly rated fuse has been installed because of incorrect information on the power module information label.

Check the information label on the power module of HP 3552s with serial numbers 2615U06154 to 2615U06443 to ensure that it shows the correct fuse ratings as follows:

110/120V — 250mA
220/240V — 125mA

If a unit has an incorrect label, replace it with HP P/N 7124-2372. Also make sure the correctly rated fuse is installed for the selected line voltage. Replacement fuses are:

250mA slow blow 250V
HP P/N 2110-0201
125mA slow blow 250V
HP P/N 2110-0318

HP 3709A Constellation Display

A situation may occur on HP 3709As with serial numbers

HP 1631A/D LOGIC ANALYZERS

1630/31A/D/G-12. All serials. New ROM release and update on ROM replacement policy. Supersedes 1630G-5, 1630G-5A, 1630A/D-6, 1630A/D/G-11, 1631A/D-1, 1631A/D-1A, 1631A/D-2, 1631A/D-3, 1631A-4, 1631A/D-11.

1630/31A/D/G-13, 54200A/D-7, 54201A/D-7. Serial prefixes 2645A and below. Modification to CRT PA lead to prevent intermittent power supply shutdown.

HP 3061A BOARD TEST SYSTEM

3061A/3062A-18. All serials. Modifications to the HP 3253A ASRU calibration program to improve performance.

HP 3062A BOARD TEST SYSTEM

3061A/3062A-18. All serials. Modifications to the HP 3253 ASRU calibration program to improve performance.

HP 3235A/E SWITCH/TEST UNIT

3235A/E-2. Serials: 34520A DMM-s/n 2628A00223 and below. 34520B DMM-s/n 2628A00228 and below. Modification to prevent random power-on failures of 34520 DMM modules.

3235A/E-3. Serials: 34520A DMM-s/n 2628A00223 and below. 34520B DMM-s/n 2628A00228 and below. Modification to prevent backplane relays closing after short power loss.

3235A/E-4. All serials. Part number change of test/calibration software from 03235-10002 to 03235-10100.

HP 3400A RMS VOLTMETER

3400A-13B. All serials. Replacement of photocopper amplifier assembly to improve performance.

3400A-16. Serials below 2415A33728. Preferred replacement of input attenuator assembly to improve performance.

HP 3466A DIGITAL MULTIMETER

3466A-17. Serials 2549A26100 to 2549A26637. List of failures related to the switch assembly.

HP 3488A SWITCH/CONTROL UNIT

3488A-11. Serials 2719A10500 to 2719A10580. Incorrect line fuse installed.

2722U00260 and below where the POWER on/off switch contacts could weld together.

Note that this hazard applies only to service personnel when the instrument's protective covers are removed. There is no hazard to the operator.

For more information, please order Product Safety Service Note 3709A-4-S from this issue of Bench Briefs.

HP 61001A DC Power Supply Unit

Some power supplies from serial numbers 2504A00101 through 250400900 may have the line or neutral conductors and the earth conductor reversed on one or more of the internal power output cables. This may cause accessible parts on the connected PC Instruments modules to be at line potential.

If you wish to inspect the System Power Unit yourself, order Product

continued on page 16

HP 3552A TRANSMISSION TEST SET

3552A-14. All serials. Preferred replacement for resistor A3R113.

3552A-15-S. Serials 2615U06154 to 2615U06443. Possible incorrect fuse ratings. Elimination of potential safety hazard.

HP 3577A NETWORK ANALYZER

3577A-13. All serials. Mixers on all receivers in instrument must be of same type to meet the ratio phase specification.

HP 3582A SPECTRUM ANALYZER

3582A-6A. Serials 1809A04380 and below. Updating the ROM assembly.

HP 3709A CONSTELLATION DISPLAY

3709A-4-S. Serials 2722U00260 and below. On/off switch may cause potential safety hazard.

HP 3746A SELECTIVE LEVEL MEASURING SET

3746A-23. All serials. Modification to correct false readings when used in the SCAN mode with AVE 0 selected.

HP 3764A DIGITAL TRANSMISSION ANALYZER

3764A-19B. Serials between 2615U01162 and 2719U01637. Retrofit kit to upgrade the auxiliary analog input.

3764A-22. Serials 2712U01594 and below. Preferred replacement of A3 or A3 (option 001) assemblies.

HP 3789B DS3 TRANSMISSION TEST SET

3789B-2. All serials. Retrofit procedure for Opt. 003 — 2nd measurement.

HP 4936A TRANSMISSION IMPAIRMENT MEASURING SET

4936A-8. All serials. Preferred replacement capacitors on transmitter assembly.

HP 4948A IN-SERVICE TRANSMISSION IMPAIRMENT MEASURING SET

4948A-4. Serials 2615U00247 and below (excluding 159, 167, 190, 192, 193, 204, 206, 207, 218, 219, 227, 229-238, 243-245). Firmware upgrade to improve performance.

HP 4951C PROTOCOL ANALYZER

4951C-4. All serials. Instructions on replacing damaged rear panel studs.

4951C-5. Serials 2631A00851 and below, and 2631F50306 and below. Recommended line voltage rectifier diode replacement where the line voltage exceeds 210 volts.

HP 5335A UNIVERSAL FREQUENCY COUNTER

5335A-11A. Series prefixes below 2548A. Cycle power off then on if front panel exhibits lockup problem.
5335A-22. Serials 2510A07735 through 2510A07831, and 2510A07731 and below. Simple modification to increase the reliability of the power supplies.

HP 5384A/85A FREQUENCY COUNTER

5384A/85A-3. Series prefixes 2436A and below. Modification to prevent power supply fuses from prematurely blowing.

HP 6010A DC POWER SUPPLY

6010A-2. Serials 2707A00255 to 2707A00284. Modification to prevent output voltage being present after power off.

6010A-3. All serials. Modification to prevent transient response during auto-parallel operation.

HP 6011A AUTORANGING POWER SUPPLY

6011A-4. All serials. Modification to prevent transient response during auto-parallel operation.

HP 6012B AUTORANGING POWER SUPPLY

6012B-3. All serials. Modification to prevent transient response during auto-parallel operation.

HP 6030A SYSTEM DC POWER SUPPLY

6030A-5. Serials 2641A00465 to 2641A00494. Modification to prevent output voltage being present after power off.

6030A-6. All serials. Modification to prevent transient response during auto-parallel operation.

HP 6031A AUTORANGING POWER SUPPLY

6031A-8. All serials. Modification to prevent transient response during auto-parallel operation.

HP 6032A AUTORANGING POWER SUPPLY

6032A-7. All serials. Modification to prevent transient response during auto-parallel operation.

HP 8672A SYNTHESIZED SIGNAL GENERATOR

8672A-15A. All serials. Retrofit kit to modify 8672A for compatibility with 86720A. Supersedes 8672A-11, 8672A-13, 8672A-15.

HP 8673B SYNTHESIZED SIGNAL GENERATOR

8673B-2B. Serial prefixes 2629A and below. Firmware history and upgrade kit.

8673B-3. Serial prefixes 2629A and below. Millimetre-wave source modules compatibility kit.

8673B-5A. All serials. Procedure for troubleshooting the option switch.

8673B-8. Serial prefixes 2552A, 2634A and above. Recommended replacement for calibration EPROM A1A8U13.

8673B-9. Serial prefixes 2629A and below. Recommended insulators for transistors A3Q1 through A3Q4 mounted on the anodized heat sink A3MP54.

HP 8673C SYNTHESIZED SIGNAL GENERATOR

8673C-2B. Serial prefixes 2626A and below. Firmware history and upgrade kit.

8673C-5A. All serials. Procedure for troubleshooting the option switch.

8673C-7. Serial prefixes 2626A and below. Procedure for retrofitting the 8673C to form a millimetre-wave source system.

8673C-9. Serial prefixes 2552A, 2634A and above. Recommended replacement for calibration EPROM A1A8U13.

8673C-10. Serial prefixes 2629A and below. Recommended insulators for transistors A3Q1 through A3Q4 mounted on the anodized heat sink A3MP54.

HP 8673D SYNTHESIZED SIGNAL GENERATOR

8673D-2B. Serial prefixes 2626A and below. Firmware history and upgrade kit.

8673D-5A. All Serials. Procedure for troubleshooting the option switch.

8673D-7. Serial prefixes 2626A and below. Procedure for retrofitting the 8673D to form a millimetre-wave source system.

8673D-9. All Serials. Recommended YTM A1A10 replacement.

8673D-10. Serial prefixes 2552A, 2634A and above. Recommended replacement for calibration EPROM A1A8U13.

8673D-11. 2629A and below. Recommended insulators for transistor A3Q1 through A3Q4 mounted on the anodized heat sink A3MP54.

HP 8673E SYNTHESIZED SIGNAL GENERATOR

8673E-2. All serials. Firmware history and update kit.

HP 8770A ARBITRARY WAVEFORM SYNTHESIZER

8770A-6B. All serials. Firmware history and upgrade procedures.

8770A-12. Serial prefixes 2626A and below. Procedure for testing A10R8 current limiting resistor.

8770A-14. Serial prefixes 2710A and below. 16K RAM assembly replaced by 64K RAM assembly to expand memory.

8770A-15. Serial prefixes 2710A and below. Procedure for installing 512K memory retrofit kit, K51.

HP 8970B NOISE FIGURE METER

8970B-1. Serial prefix 2645A. Firmware update to improve performance.

HP 10312B/C 80286 PROCESSOR INTERFACE

10312B/C-2. All serials. New flexible cable assembly that offers improved electrical and mechanical characteristics.

HP 37212A MODEM

37212A-1A. All serials. Procedure to clear invalid initiation of remote digital loopback (RDL).

HP 51089A DISPLAY UNIT

51089A-4A. Serial prefixes 2510A and below. Recommended replacement of older jumper-wired boards.

HP 54111D DIGITIZING OSCILLOSCOPES

54111D-1. Serial prefix 2701A and below. New ADC control assembly to improve performance.

HP 54200A/D OSCILLOSCOPE

1630/31A/D/G-13, 54200A/D-7, 54201A/D-7. Serial prefixes 2645A and below. Modification to CRT PA lead to prevent intermittent power supply shutdown.

HP 54201A/D DIGITIZING OSCILLOSCOPES

54201A/D-3. Serial prefix 2602A. Firmware update to improve EOI compatibility with fast controller.

54201A/D-4. Serial prefixes 2625A and below. Recommended A4 analog board assembly.

54201A/D-5. Serial prefixes 2632A and below. Firmware update corrects erroneous Vmin clipped message.

54201A/D-6. Serial prefixes 2625A, 2632A and 2638A. Incorrectly calculated negative slope trigger level causes failure to meet trigger sensitivity specification in some instruments.

HP 54201A/D OSCILLOSCOPE

1630/31A/D/G-13, 54200A/D-7, 54201A/D-7. Serial prefixes 2645A and below. Modification to CRT PA lead to prevent intermittent power supply shutdown.

HP 61001A DC POWER SUPPLY UNIT

61001A-2A-S. Serials 2504A00101 through 2504A00900. Possible shock hazard due to miswired input power.

HP 64220C 80C86 EMULATOR POD

64220C-2. Pod repair number 2549A00225 and below. Recommended replacement for processor chip mask set #1598.

HP 64253A Z80 EMULATOR SUBSYSTEM

64253A-3. Z80 emulator pod, all serials. Modification to correct peripheral interrupt routine execution of RETI instruction. Supersedes 64253A-2.

HP 64286 F9450 EMULATOR

64286A-3. Serial prefix 2713A and below. Modification to improve bus cycle timing.

HP 64416A/B 68020 EMULATION SUBSYSTEM

64416A-2. Emulation pod suffix number 00211 and below. Recommended label on the emulation control board's CPU socket to aid in cable connection.

64416A-3. Emulation pod suffix number 00186 and below. Grabber probe assembly may be missing from shipments—order HP P/N 1400-1422.

64416AB-1. Emulation pod serial prefix number 2650A and below. Test procedure for emulation break, emulation memory write, and coordinated emulation start.

64416B-2. Emulation pod suffix number 00274 and below. Recommended label on the emulation control board's CPU socket to aid in cable connection.

64416B-3. Emulation pod suffix number 00234 and below. Grabber probe assembly may be missing from shipments—order HP P/N 1400-1422.

HP 64657A 80286 PROCESSOR INTERFACE

64657A-2. All serials. Upgrade to 64657B cable technology.

HP 70001A MODULAR MEASUREMENT SYSTEM MAINFRAME

70001A-7-S. Serials 2704A01437 and below. Modification to prevent possible shock hazard if safety earth ground is defeated and there is a short on the +5 volt supply.

HP 70205A GRAPHICS DISPLAY

70205A-3. Serial prefix 2629A and below. New dot generator board assembly update kit.

HP 70206A SYSTEM GRAPHICS DISPLAY

70206A-6. Serial prefix 2629A and below. New dot generator board assembly update kit.

HP 70591A MODULE DEVELOPMENT KIT

70591A-1. All serials. Assembly instructions for 1/8 module kit.

HP 70592A MODULE DEVELOPMENT KIT

70592A-1. All serials. Assembly instructions for 2/8 module kit.

HP 70593A MODULE DEVELOPMENT KIT

70593A-1. All serials. Assembly instructions for 3/8 module kit.

HP 70900A LOCAL OSCILLATOR

70900A-14A. All serials. New firmware for increased system compatibility.

HP 71000 SPECTRUM ANALYZER SYSTEMS

71000A-3. All serials. Recommended system re-configuration cable kit.

Service Note Order Form

If you want service notes, please check the appropriate boxes below and return this form separately to one of the following addresses.

Hewlett-Packard
1820 Embarcadero Road
Palo Alto, California 94303

continued from page 14

Safety Service Note 61001A-2A-S. The test will take approximately 15 minutes to perform.

If you choose to have Hewlett-Packard inspect the unit, return it to a Customer Service Center and reference the Product Safety Service Note.

HP 70001A Modular Measurement System Mainframe

Mainframes with serial number 2704A001437 and below may not have enough space between a circuit trace and a solder pad. In these instances, if the safety earth ground is defeated and there is a short on the +5V power supply, a possible shock hazard may exist.

The modification procedure is detailed in Product Safety Service Note 790001A-7-S. A kit (70001-60076) is available that supplies all the necessary material to make the modification. No adjustment is needed after the modification. □

For European customers (ONLY)

Hewlett-Packard
Nederland BV
Central Mailing Dept.
P.O.Box 529
1180 AM Amstelveen
The Netherlands

Name _____
Firm _____
Address _____
City _____
State _____ Zip _____

- | | | | | |
|---|--------------------------------------|--------------------------------------|---------------------------------------|-------------------------------------|
| <input type="checkbox"/> 1349A/D-04 | <input type="checkbox"/> 4936A-08 | <input type="checkbox"/> 8673B-09 | <input type="checkbox"/> 51089A-04A | <input type="checkbox"/> 70592A-01 |
| <input type="checkbox"/> 1630/31A/D/G-12 | <input type="checkbox"/> 4948A-04 | <input type="checkbox"/> 8673C-02B | <input type="checkbox"/> 54111D-01 | <input type="checkbox"/> 70593A-01 |
| <input type="checkbox"/> 1630/31A/D/G-13, | <input type="checkbox"/> 4951C-04 | <input type="checkbox"/> 8673C-05A | <input type="checkbox"/> 54201A/D-03 | <input type="checkbox"/> 70900A-14A |
| 54200A/D-7, | <input type="checkbox"/> 4951C-05 | <input type="checkbox"/> 8673C-07 | <input type="checkbox"/> 54201A/D-04 | <input type="checkbox"/> 71000A-03 |
| 54201A/D-7 | <input type="checkbox"/> 5335A-11A | <input type="checkbox"/> 8673C-09 | <input type="checkbox"/> 54201A/D-05 | |
| | | | | |
| <input type="checkbox"/> 3061A/3062A-18 | | | | |
| <input type="checkbox"/> 3235A/E-02 | <input type="checkbox"/> 5335A-22 | <input type="checkbox"/> 8673C-10 | <input type="checkbox"/> 54201A/D-06 | |
| <input type="checkbox"/> 3235A/E-03 | <input type="checkbox"/> 5384A/85A-3 | <input type="checkbox"/> 8673D-02B | <input type="checkbox"/> 61001A-02A-S | |
| <input type="checkbox"/> 3235A/E-04 | <input type="checkbox"/> 6010A-02 | <input type="checkbox"/> 8673D-05A | <input type="checkbox"/> 64220C-02 | |
| <input type="checkbox"/> 3400A-13B | <input type="checkbox"/> 6010A-03 | <input type="checkbox"/> 8673D-07 | <input type="checkbox"/> 64253A-03 | |
| <input type="checkbox"/> 3400A-16 | <input type="checkbox"/> 6011A-04 | <input type="checkbox"/> 8673D-09 | <input type="checkbox"/> 64286A-03 | |
| <input type="checkbox"/> 3466A-17 | | | | |
| <input type="checkbox"/> 3488A-11 | <input type="checkbox"/> 6012B-03 | <input type="checkbox"/> 8673D-10 | <input type="checkbox"/> 64416A-02 | |
| <input type="checkbox"/> 3552A-14 | <input type="checkbox"/> 6030A-05 | <input type="checkbox"/> 8673D-11 | <input type="checkbox"/> 64416A-03 | |
| <input type="checkbox"/> 3552A-15-S | <input type="checkbox"/> 6030A-06 | <input type="checkbox"/> 8673E-02 | <input type="checkbox"/> 64416AB-01 | |
| <input type="checkbox"/> 3577A-13 | <input type="checkbox"/> 6031A-08 | <input type="checkbox"/> 8770A-06B | <input type="checkbox"/> 64416B-02 | |
| <input type="checkbox"/> 3582A-06A | <input type="checkbox"/> 6032A-07 | <input type="checkbox"/> 8770A-12 | <input type="checkbox"/> 64416B-03 | |
| <input type="checkbox"/> 3709A-04-S | <input type="checkbox"/> 8672A-15A | <input type="checkbox"/> 8770A-14 | <input type="checkbox"/> 64657A-02 | |
| <input type="checkbox"/> 3746A-23 | <input type="checkbox"/> 8673B-02B | <input type="checkbox"/> 8770A-15 | <input type="checkbox"/> 70001A-07-S | |
| <input type="checkbox"/> 3764A-19B | <input type="checkbox"/> 8673B-03 | <input type="checkbox"/> 8970B-01 | <input type="checkbox"/> 70205A-03 | |
| <input type="checkbox"/> 3764A-22 | <input type="checkbox"/> 8673B-05A | <input type="checkbox"/> 10312B/C-02 | <input type="checkbox"/> 70206A-06 | |
| <input type="checkbox"/> 3789B-02 | <input type="checkbox"/> 8673B-08 | <input type="checkbox"/> 37212A-01A | <input type="checkbox"/> 70591A-01 | |

Please photocopy this order form if you do not want to cut off the page.

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
Mississauga, Ontario L4V 1M8

BENCH BRIEFS 3RD QUARTER 1987

Volume 27 Number 3


Service information from
Hewlett-Packard Company

To obtain a qualification form for a free subscription, send your request to the above address.

Reader comments or technical article contributions are welcomed.

Please send them to the
Bench Briefs Editor.

Editor: Jim Bechtold
Hewlett-Packard



All rights reserved. Permission to reprint Bench Briefs granted upon written request to the Editor.

Printed in U.S.A.