


Because of multiple footprint in this design.  
Place a piece of kapton tape on board as shown  
to insulate T1 and L1 from open copper. No solder  
under kapton tape area (tape off the stencil opening  
for not used pads under T1 and L1).



T1 PIN 1

ASSY TOP