



NOTES: UNLESS OTHERWISE SPECIFIED

1. WORKMANSHIP SHALL BE IN ACCORDANCE WITH IPC-A-610.
2. INSERT SMA CONNECTORS FLUSH AGAINST BOARD EDGE.
3. ASSY PROCESSES SHALL INCLUDE: REFLOW SOLDER TOP SIDE SMD.
HAND SOLDER BOTTOM SIDE SMD.
HAND SOLDER BOTTOM THRU-HOLE COMPONENTS.
4. PARTS TO OMIT WILL BE SPECIFIED ON THE PARTS LIST.
LOCATIONS OF OMITTED PARTS SHALL BE FREE FO SOLDER.
MASK THE SOLDER STENCIL WHERE SMT PARTS ARE OMITTED.
5. SHORTAGES SHALL EXIST ON THE MINIMUM NUMBER OF BOARDS.
6. DO NOT OTHERWISE MARK BOARDS (e.g. NO QA-STAMP).
7. DEPANELIZE BOARDS AFTER ASSEMBLY. DO NOT BEND.
USE DIAGONAL CUTTERS TO SEPARATE PCB'S.