



Silkscreen bottom

ASSY BOTTOM

Linear Tech. Corp.
Demo Circuit 1538A

NOTES: C8 NEEDS TO BE INSTALLED.

ALL OPTIONAL COMPONENTS EXCEPT C8 ARE UNSTUFFED AND
SHOULD BE FREE OF SOLDER AFTER ASSEMBLY.