


REVISIONS		
REV	DESCRIPTION	APPR



Silkscreen Top

### NOTES :

1. Unused SMD components should be free of Solder.
  2. Fill up all vias with solder.
- Install Shunts: JP1 = ON  
JP2 = FIXED FREQ.

## Assembly Top Drawing

APPROVALS		INIT		DATE	
DRAWN		KL			
CHECK					
DESIGN					
ENGR					
SCALE = NONE		SHT 1 of 1			



LTC3534EDHC

1MHz, 500mA, Synchronous Buck-Boost Converter

SIZE	Demo Circuit 1227A	REV.	A
------	--------------------	------	---