

#### 4. INSTALL SHUNTS AS SHOWN.

5. INSTALL THE QRS CABLES AFTER DEPANELIZE BOARDS AFTER ASSEMBLY AND ROUTE-OUT THE BREAKOUT TABS ON FOUR SIDES OF THE BOARD EDGE.
6. DO NOT APPLY ANY KIND OF ASSEMBLY STAMP OR QA STAMP
7. TURRETS AND BANANA JACKS, INSTALL FROM THE TOP OF THE

