


# Keysight Technologies

## RF PA/FEM Characterization & Test, Reference Solution

9 kHz to 27 GHz

### Configuration Guide



# Overview

This configuration guide contains information to help you configure your RF PA/FEM characterization & test, Reference Solution and tailor the system to meet your requirements.

Table of Contents	Page Number
<b>Hardware</b>	
A: Select Options for M9381A PXIe VSG	3
B: Select PXIe Vector Signal Analyzer (either M9391A or M9393A)	4
C: Add M9300A PXIe Frequency Reference(s)	5
D: Select PXI Vector Network Analyzer	6
E: Select Hardware for Envelope Tracking and DUT Control	6
F. Select Controller (either PXI embedded controller or external PC controller)	7
G. Select a Chassis and Accessories	9
<b>Reference solution</b>	
H: Select Solution Start-up Kit (optional)	9
<b>Physical Connection Diagram for Controllers, Chassis &amp; Accessories</b>	10
<b>Software</b>	
I: Select Software for M9381A PXIe VSG	11
J: Select Software for PXIe VSA (M9391A or M9393A)	12
<b>Services</b>	
K: Select Software for M937xA PXIe VNA	13
L. Measurement Accessories	13
M. Select Services: Warranty, Calibration, Start-up Assistance	14
<b>Configurations</b>	
RF PA/FEM Characterization & Test, Reference Solution with single 2-port M937XA PXIe VNA	16
<b>Other</b>	
Upgrading Your System	17
Using a Non-Keysight Chassis	17
PC Requirements for M9381A PXIe VSG, M9391A/M9393A PXIe VSA and M937XA PXIe VNA Control	18
Related Literature	18

Recommended options for RF PA/FEM characterization & test, Reference Solution indicated by ■ below.

## A. Select Options for M9381A PXIe VSG

<b>Step 1. Start with M9381A PXIe VSG base configuration</b>			
■	The M9381A PXIe VSG (occupies 4 slots) includes:		
	M9301A	PXIe Synthesizer	– Frequency range 1 MHz - 3 GHz
	M9310A	PXIe Source Output	– Modulation bandwidth 40 MHz
	M9311A	PXIe Digital Vector Modulator	– Memory 32 MSa
			– One day start up assistance
			– Modular interconnect cables
			– Software, example programs and product information on CD
			– Return to Keysight Technologies, Inc. warranty - 3 years
<b>Step 2. Choose recommended frequency range</b>			
<input type="checkbox"/>	M9381A-F03	1 MHz - 3 GHz	Included in base configuration of M9381A
■	M9381A-F06	1 MHz - 6 GHz	
<b>Step 3. Choose recommended modulation bandwidth</b>			
<input type="checkbox"/>	M9381A-B04	40 MHz	Included in base configuration of M9381A
■	M9381A-B10	100 MHz	
<input type="checkbox"/>	M9381A-B16	160 MHz	
<b>Step 4. Choose recommended memory size</b>			
■	M9381A-M01	32 MSa	Included in base configuration of M9381A
<input type="checkbox"/>	M9381A-M05	512 MSa	
<input type="checkbox"/>	M9381A-M10	1024 MSa	
<b>Step 5. Add high output power (optional)</b>			
Minimizes need for external amplification to overcome power loss			
<input type="checkbox"/>	M9381A-1EA	High output power	Max output power +18 dBm across the frequency range
<b>Step 6. Add recommended fast switching speed</b>			
Accelerates test throughput			
■	M9381A-UNZ	Fast switching	240 μs RF tuning and 10 μs baseband tuning in list mode
<b>Step 7. Add analog modulation (optional)</b>			
<input type="checkbox"/>	M9381A-UNT	Analog modulation	AM, FM, phase, pulse & multitone modulation

## B. Select PXI Vector Signal Analyzer (either M9391A or M9393A)

### B1. For M9391A PXIe VSA

<b>Step 1. Start with M9391A PXIe VSA base configuration</b>			
<input type="checkbox"/>	The M9391A PXIe VSA base configuration (occupies 3 slots) includes:		
	M9301A	PXIe synthesizer	– Frequency range 1 MHz - 3 GHz
	M9350A	PXIe downconverter	– Analysis bandwidth 40 MHz
	M9214A	PXIe IF digitizer	– Memory 128 MSa (512 MB)
			– One day start up assistance
			– Modular interconnect cables
			– Software, example programs and product information on CD
			– Return to Keysight warranty - 3 years
<b>Step 2. Choose recommended frequency range</b>			
<input type="checkbox"/>	M9391A-F03	1 MHz - 3 GHz	Included in base configuration of M9391A
<input type="checkbox"/>	M9391A-F06	1 MHz - 6 GHz	
<b>Step 3. Choose recommended analysis bandwidth</b>			
<input type="checkbox"/>	M9391A-B04	40 MHz	Included in base configuration of M9391A
<input type="checkbox"/>	M9391A-B10	100 MHz	
<input type="checkbox"/>	M9391A-B16	160 MHz	
<b>Step 4. Choose recommended memory size</b>			
<input type="checkbox"/>	M9391A-M01	128 MSa	Included in base configuration of M9391A
<input type="checkbox"/>	M9391A-M05	512 MSa	
<input type="checkbox"/>	M9391A-M10	1024 MSa	
<b>Step 5. Add recommended fast switching speed</b>			
Accelerates test throughput			
<input type="checkbox"/>	M9391A-UNZ	Fast switching	

### B2. M9393A PXIe Performance VSA

Recommended when harmonics measurements > 6 GHz are required

<b>Step 1. Start with M9393A PXIe Performance VSA base configuration</b>			
<input checked="" type="checkbox"/>	The M9393A PXIe performance VSA base configuration (occupies 4 slots) includes:		
	M9308A	PXIe synthesizer	– Frequency range 9 kHz - 8.4 GHz
	M9365A	PXIe downconverter	– Analysis bandwidth 40 MHz
	M9214A	PXIe IF digitizer	– Memory 128 MSa (512 MB)
			– One day start up assistance
			– Modular interconnect cables
			– Software, example programs and product information on CD
			– Return to Keysight warranty - 3 years
<b>Step 2. Choose a frequency range</b>			
<input checked="" type="checkbox"/>	M9393A-F08	9 kHz – 8.4 GHz	Included in base configuration
<input type="checkbox"/>	M9393A-F14	9 kHz – 14 GHz	
<input type="checkbox"/>	M9393A-F18	9 kHz – 18 GHz	
<input type="checkbox"/>	M9393A-F27	9 kHz – 27 GHz	

## B2. M9393A PXIe Performance VSA (continued)

<b>Step 3. Choose an analysis bandwidth</b>			
<input type="checkbox"/>	M9393A-B04	40 MHz	Included in base configuration
<input checked="" type="checkbox"/>	M9393A-B10	100 MHz	
<input type="checkbox"/>	M9393A-B16	160 MHz	
<b>Step 4. Choose memory size</b>			
<input checked="" type="checkbox"/>	M9393A-M01	128 MSa	Included in base configuration
<input type="checkbox"/>	M9393A-M05	512 MSa	
<input type="checkbox"/>	M9393A-M10	1024 MSa	
<b>Step 5. Add fast switching speed (optional)</b>			
Accelerates test throughput and stepped spectrum analysis			
<input checked="" type="checkbox"/>	M9393A-UNZ	Fast tuning	
<b>Step 6. Add pre-amplifier (optional)</b>			
Enhances sensitivity to detect low-level signals			
<input type="checkbox"/>	M9393A-P08	9 kHz – 8.4 GHz	
<input type="checkbox"/>	M9393A-P14	9 kHz – 14 GHz	
<input type="checkbox"/>	M9393A-P18	9 kHz – 18 GHz	
<input type="checkbox"/>	M9393A-P27	9 kHz – 27 GHz	

## C. Add M9300A PXIe Frequency Reference(s)

Required to meet data sheet specifications for M9381A, M9391A, and M9393A

<b>Step 1. Add a M9300A PXIe frequency reference (occupies 1 slot)</b>			
One frequency reference required per chassis. It can support up to five VSGs or VSAs			
<input checked="" type="checkbox"/>	M9300A	PXIe Frequency Reference	Five 100 MHz outputs One 10 MHz output Internal 10 MHz OCXO timebase output

## D. Select PXI Vector Network Analyzer

Step 1. Start by choosing the frequency range of the M937xA PXIe VNA		
<input type="checkbox"/>	M9370A	300 kHz to 4 GHz
<input checked="" type="checkbox"/>	M9371A	300 kHz to 6.5 GHz
<input type="checkbox"/>	M9372A	300 kHz to 9 GHz
<input type="checkbox"/>	M9373A	300 kHz to 14 GHz
<input type="checkbox"/>	M9374A	300 kHz to 20 GHz
<input type="checkbox"/>	M9375A	300 kHz to 26.5 GHz
Step 2. Add time domain capability (optional)		
<input type="checkbox"/>	M937xA-010	Time domain
Step 3. Add full N-port correction capability (optional)		
<input type="checkbox"/>	M937xA-551	N-port calibrated measurement <sup>1</sup>
Step 4. Add additional VNA features and capabilities (optional)		
<input type="checkbox"/>	M937xA-102	Advanced VNA features and capabilities
		Fixture simulator including:
		– Port Z (impedance) conversion
		– 4-port embed/de-embed
		– Differential impedance conversion
		– Common mode impedance conversion
		– Differential port matching
		– Source power compensation
		Port extend
		– Manual and automated
		Equation editor
Step 5. Add multiport cable kit (optional)		
<input type="checkbox"/>	Y1242A	Multiport cable kit
		– Includes 2 SMB cables and 1 SMA cables for connecting 2 modules together.
		– Add one multiport cable kit for each additional 2-port VNA
Step 6. Add multiport accessory and tool kit (optional)		
<input type="checkbox"/>	Y1281A	Accessory and tool kit, including:
		– 5002-3361 Pull tool for SMB connectors
		– 5023-1450 Custom long deep socket for 3.5/SMA connector nuts

1. When ordering multiple VNA modules Option Y1242A is recommended for multiport interconnections.

## E. Select Hardware for Envelope Tracking and DUT Control

Step 1. Select waveform generator		
Plays envelope waveform for envelope tracking measurement		
<input checked="" type="checkbox"/>	SD AOU-H3353	Signadyne 200 MHz, 2-channel, AWG Contact Signadyne @ <a href="http://www.signadyne.com/en/products/hardware/high-speed/analog-out--awgs--signal-generators/sd-aou-h3353--analog-out--avg--signal-generator">http://www.signadyne.com/en/products/hardware/high-speed/analog-out--awgs--signal-generators/sd-aou-h3353--analog-out--avg--signal-generator</a>
Step 2. Select SMU		
		For DUT control
<input checked="" type="checkbox"/>	N6700B	Low profile modular power system mainframe
<input checked="" type="checkbox"/>	Qty 2 N6782A	2-quadrant source/measure unit (SMU) for functional test
<input type="checkbox"/>	N6784A	4-quadrant source/measure unit (SMU) for functional test
Step 3. Select power sensor		
		For calibration
<input checked="" type="checkbox"/>	U2004A	USB power sensor 9 kHz to 6 GHz

## F. Select Controller (either PXI embedded controller or external PC controller)<sup>1</sup>

### F1. For PXI embedded controller, select either M9036A or M9037A

#### Step 1. Select either M9036A or M9037A<sup>2</sup>

- M9036A-M04 Mid-performance embedded controller  
Intel i5-520E dual-core, 2.4 GHz, 4 thread, 4GB RAM

Select the M9036A for mid-performance, lower cost or, if your application requires XP operating system



- M9037A-M04 High-performance embedded controller  
Intel i7-4700EQ quad-core processor, 2.4 GHz, 8 thread, 4GB RAM

Select M9037A for the best performance if you have memory intensive applications, multiple applications running in parallel or if a lot of data is sent to the PC from the PXIe chassis. Features removable SSD drive for security and x8 connector from front for connection to second chassis



#### Step 2. Upgrade from standard memory size (optional)

##### For M9036A

- M9036A-M08 Memory upgrade from 4 GB to 8 GB RAM

##### For M9037A

- M9037A-M08 Memory upgrade from 4 GB to 8 GB RAM
- M9037A-M16 Memory upgrade from 4 GB to 16 GB RAM

#### Step 3. Select an operating system

##### For M9036A

- M9036A-WE3 Microsoft Windows Embedded Standard 7 (32-bit)
- M9036A-WE6 Microsoft Windows Embedded Standard 7 (64-bit)
- M9036A-WXP Downgrade to Microsoft Windows XP (32-bit)

##### For M9037A







- M9037A-WE3 Microsoft Windows Embedded Standard 7 (32-bit)
- M9037A-WE6 Microsoft Windows Embedded Standard 7 (64-bit)

1. For list of qualified external controllers, please see Tested Computer List Technical Note literature no. 5990-7632EN.  
The M9021A is used for both PC controllers and can only be used in the M9018A chassis.

2. The M9018A 18-slot chassis includes empty space to the left of the 1st functional slot.  
The embedded controller occupies that empty space and the 1st functional slot.

## F. Select Controller (either PXI embedded controller or external PC controller)<sup>1</sup>

F2. For external PC controller, select options for laptop or desktop PC, below<sup>1</sup>

To use your laptop PC as a controller:			
<input type="checkbox"/>	M9045B	PCIe ExpressCard adapter	
<input type="checkbox"/>	Y1200B	PCIe cable	
<input type="checkbox"/>	M9021A	PCIe cable interface <sup>2</sup> : 1 slot	
To use your desktop PC as a controller:			
<input type="checkbox"/>	M9048A	PCIe desktop adapter	
<input type="checkbox"/>	Y1202A	PCIe cable	
<input type="checkbox"/>	M9021A	PCIe cable interface <sup>2</sup> : 1 slot	

1. For list of qualified external controllers, please see *Tested Computer List Technical Note literature no. 5990-7632EN*. See physical connections diagram on page 10.


2. The M9021A is used for either PC control option and can only be used with the Keysight M9018A 18-slot chassis.



## G. Select a Chassis and Accessories

### Step 1. Select a chassis

- M9018A PXIe 18-slot chassis



### Step 2. Choose enough slot blocker kits and EMC filler panels to fill every open slot

Recommended to achieve data sheet specifications

- Y1212A Qty 2 Slot blocker kit: 5 slots




- Y1213A Qty 2 PXI EMC filler panel kit: 5 slots



### Step 3. Choose a rack mount kit (optional)

- Y1215A Rack mount kit for M9018A PXIe 18-slot chassis



### Step 4. Choose an air inlet kit<sup>1</sup> (optional)

Recommended for rack mounted systems with less than 1U space below chassis

- Y1214A Air inlet kit: M9018A PXIe 18-slot chassis<sup>1</sup>



## H. Select a Solution Start-up Kit

### Choose a solution level start-up kit (optional)


Includes documentation, configuration software and example programs

- Y1299A-004 RF PA/FEM Characterization & Test, Reference Solution

1. Available in 1-slot, 2-slot or 3-slot options depending on the chassis configuration.  
For more information, please visit [www.keysight.com/find/m9018a](http://www.keysight.com/find/m9018a)

## Physical Connections

### Physical Connection Diagram for Controllers



## I. Select Software for M9381A PXIe VSG

### Step 1. Start with M9381A base configuration

The M9381A comes standard with the following software:

- Keysight IO Libraries Suite including Connection Expert <sup>1</sup>
- Instrument software, soft front panel, drivers for use with MATLAB, LabVIEW, Visual Studio (including VB Net, C#, C/C++), Keysight VEE <sup>2</sup>
- Sample waveforms and programming examples

### Step 2. Download free Keysight Command Expert software <sup>4</sup> (optional)

FREE software that provides fast and easy instrument control for the PC. Command Expert combines instrument command sets, command sequences, documentation, syntax checking and command execution in one simple interface. Command Expert helps you to:

- Find instrument commands
- Access command documentation
- Verify command syntax
- Build instrument command sequences
- Execute instrument command sequences
- Integrate sequences in MATLAB, Visual Studio, Excel, LabVIEW, Keysight VEE or Keysight SystemVue PC application environment
- Generate code for command sequences in MATLAB, Visual C#, Visual Basic.NET and Visual C/C++
- Profile command execution time
- Debug command sequences using breakpoints and single stepping

### Step 3. Add Signal Studio software <sup>3,5</sup> (optional)

Provides performance optimized referenced signals validated by Keysight

#### Cellular Communications

<input type="checkbox"/>	N7600B	Signal Studio for W-CDMA / HSPA+
<input type="checkbox"/>	N7601B	Signal Studio for cdma2000® / 1xEV-DO
<input type="checkbox"/>	N7602B	Signal Studio for GSM / EDGE / EVO
<input type="checkbox"/>	N7612B	Signal Studio for TD-SCDMA / HSDPA
<input checked="" type="checkbox"/>	N7624B	Signal Studio for LTE / LTE-Advanced FDD
<input type="checkbox"/>	N7625B	Signal Studio for LTE / LTE-Advanced TDD

To use Signal Studio with modular instruments, you must purchase a "connect to" license for each Signal Studio license used (see list at left).

- 9FP Connect to M9381A/M9252A fixed perpetual license (recommended)
- 9TP Connect to M9381A/M9252A transportable perpetual license

For LTE (N7624B or N7625B), the following licensing option is recommended:

- HFP Basic LTE FDD Rel 9 fixed perpetual license

#### Wireless Connectivity

<input type="checkbox"/>	N7617B	Signal Studio for WLAN 802.11a/b/g/n/ac
--------------------------	--------	---

#### Power Amplifier

<input checked="" type="checkbox"/>	N7614B	Signal Studio for PA test
-------------------------------------	--------	---------------------------

For PA test (N7614B), the following licensing options are recommended:

- EFP - Envelope tracking
- FFP - Digital pre-distortion

### Step 4. Add MATLAB software <sup>6</sup> (optional)

Create arbitrary waveforms, customize measurement and data analysis routines, create your own instruments applications and test systems, automate measurements, signal generation, and report generation

<input type="checkbox"/>	N6171A-M01	MATLAB Basic Package
<input type="checkbox"/>	N6171A-M02	MATLAB Standard Package
<input type="checkbox"/>	N6171A-M03	MATLAB Advanced Package

1. Both IO library (version 16.3 or newer) and Connection Expert software need to be installed on the PC controlling the equipment.  
To download, visit [www.keysight.com/find/iosuite](http://www.keysight.com/find/iosuite)
2. Find latest versions of this software at [www.keysight.com/find/m9381a](http://www.keysight.com/find/m9381a)
3. For more information, see Signal Studio brochure, literature number 5989-6448EN.
4. To download or get more information on Command Expert, visit [www.keysight.com/find/commandexpert](http://www.keysight.com/find/commandexpert)
5. To generate an envelope, Signal Studio for LTE must be purchased.
6. For more information on MATLAB software, visit [www.keysight.com/find/n6171a](http://www.keysight.com/find/n6171a)

## J. Select Software for PXIe VSA (M9391A or M9393A)

### Step 1. Start with M9391A or M9393A base configuration

The M9391A and M9393A comes standard with the following software:

- Keysight IO Libraries Suite including Connection Expert <sup>1</sup>
- Instrument software, soft front panel, drivers for use with MATLAB, LabVIEW, Visual Studio (including VB Net, C#, C/C++), Keysight VEE <sup>2</sup>
- Sample waveforms and programming examples

### Step 2. Download free Keysight Command Expert software <sup>3</sup> (optional)

FREE software that provides fast and easy instrument control for the PC. Command Expert combines instrument command sets, command sequences, documentation, syntax checking and command execution in one simple interface. Command Expert helps you to:

- Find instrument commands
- Access command documentation and verify command syntax
- Build and execute instrument command sequences
- Integrate sequences in MATLAB, Visual Studio, Excel, LabVIEW, Keysight VEE or Keysight SystemVue PC application environment
- Generate code for command sequences in MATLAB, Visual C#, Visual Basic.NET and Visual C/C++
- Profile command execution time
- Debug command sequences using breakpoints and single stepping

### Step 3. Add X-Series Measurement Applications for Modular Instruments <sup>4</sup> (optional)

Provides essential RF conformance measurements and tasks for specific communications standards.

<input checked="" type="checkbox"/>	M9080B	LTE/LTE-Advanced FDD <sup>5</sup>	To use X-series measurement applications with modular instruments, you must purchase the license with product number "M90XX" and select either: – 1FP Fixed perpetual license (recommended) – 1TP Transportable perpetual license
<input type="checkbox"/>	M9082B	LTE/LTE-Advanced TDD <sup>5</sup>	
<input type="checkbox"/>	M9073A	W-CDMA/HSPA+	
<input type="checkbox"/>	M9071A	GSM/EDGE/EVO	
<input type="checkbox"/>	M9079A	TD-SCDMA/HSPA	
<input type="checkbox"/>	M9076A	1xEV-DO	
<input type="checkbox"/>	M9072A	cdma2000/cdmaOne	
<input type="checkbox"/>	M9077A	WLAN 802.11a/b/g/n/ac	

1. Both IO library (version 16.3 or newer) and Connection Expert software need to be installed on the PC controlling the equipment.

To download, visit [www.keysight.com/find/iosuite](http://www.keysight.com/find/iosuite)

2. Find latest versions of this software at [www.keysight.com/find/m9391a](http://www.keysight.com/find/m9391a)

3. To download or get more information on Command Expert, visit [www.keysight.com/find/commandexpert](http://www.keysight.com/find/commandexpert)

4. For more information, see "Accelerate PXI VSA Measurements with X-Series Measurement Applications," literature number 5991-2604EN.

5. For LTE-Advanced licenses, select options – 2FP or – 2TP. For more information, see the M9080/82B technical overview, literature number 5991-4610EN.

## K. Select Software for M937xA PXIe VNA

### Step 1. Start with M937xA base configuration

The M937xA comes standard with the following software:

- Keysight IO Libraries Suite including Connection Expert<sup>1</sup>
- Instrument software, soft front panel, drivers for use with MATLAB, LabVIEW, Visual Studio (including VB Net, C#, C/C++), Keysight VEE<sup>2</sup>
- Programming examples

### Step 2. Download free Keysight Command Expert software<sup>3</sup> (optional)

FREE software that provides fast and easy instrument control for the PC. Command Expert combines instrument command sets, command sequences, documentation, syntax checking, and command execution in one simple interface. Command Expert helps you to:

- Find instrument commands
- Access command documentation
- Verify command syntax
- Build instrument command sequences
- Execute instrument command sequences
- Integrate sequences in MATLAB, Visual Studio, Excel, LabVIEW, Keysight VEE or Keysight SystemVue PC application environment
- Generate code for command sequences in MATLAB, Visual C#, Visual Basic.NET and Visual C/C++
- Profile command execution time
- Debug command sequences using breakpoints and single stepping

1. Both IO library (version 16.3 or newer) and Connection Expert software need to be installed on the PC controlling the equipment.  
To download, visit [www.keysight.com/find/iosuite](http://www.keysight.com/find/iosuite)
2. Find latest versions of this software at [www.keysight.com/find/pxivna](http://www.keysight.com/find/pxivna)
3. To download or get more information on Command Expert, visit [www.keysight.com/find/commandexpert](http://www.keysight.com/find/commandexpert)

## L. Measurement Accessories

A complete list of RF and microwave test accessories is available at: [www.keysight.com/find/mta](http://www.keysight.com/find/mta).

Accessories are available in these connector types: 50 ohm Type-N, 3.5 mm, 7 mm, and waveguide. Test port cables and a calibration kit should be added for a complete measurement system. A verification kit is used to verify corrected system performance.

Refer to 5990-7745EN for a complete list of measurement accessories.

## M. Select Services: Warranty, Calibration, Start-up Assistance

■		One day start-up assistance	Included in base configuration
■		Return to Keysight warranty - 3 years	Included in base configuration
□	R-51B-001-5Z	Return to Keysight warranty - 5 years	
□	M9381A-UK6	Commercial calibration certificate with test data for M9381A (M9301A, M9310A, M9311A)	Calibration certificate with measurement results available only at time of purchase.
□	M9391A-UK6	Commercial calibration certificate with test data for M9391A (M9301A, M9350A, M9214A)	Calibration certificate with measurement results available only at time of purchase.
□	M9300A-UK6	Commercial calibration certificate with test data for M9300A	Calibration certificate with measurement results available only at time of purchase.
□	M937xA-UK6	Commercial calibration certification with test data	Complete set of measurements which tests unit to manufacturer's published specifications. Includes calibration label, calibration certificate, and data report. Conforms to ISO 9001.
□	M937xA -1A7	ISO 17025 compliant calibration	Complete set of measurements which tests unit to manufacturer's published specifications. Includes calibration label, ISO 17025 calibration certificate, and data report, measurement uncertainties and guardbands on all customer specifications. Conforms to ISO 17025 and ISO 9001.
□	M937xA -A6J	ANSI Z540 compliant calibration	Complete set of measurements which tests unit to manufacturer's published specifications. Includes pre- and post-adjustment data with measurement uncertainty information compliant to the ANSI/ NCSL Z540 standard.
□	M937xA -897 <sup>1</sup>	Perpetual license for built-in performance test software for Keysight inclusive cal	Adds built-in performance testing and calibration software for self-maintainers. Requires additional equipment. See the analyzer's Service Guide for more information on equipment required.
□	M937xA -898 <sup>1</sup>	Perpetual license for built-in performance test software for Standards compliant cal	Adds built-in performance testing and calibration software for self-maintainers. Requires additional equipment. See the analyzer's Service Guide for more information on equipment required.
□	R-51B-001-3X	Express warranty - 5 day turnaround For 3 years	Available in the US, Japan, China and many EU countries
□	R-51B-001-5X	Express warranty - 5 day turnaround For 5 years	Available in the US, Japan, China and many EU countries
□	N7800A	Calibration and adjustment software	To be used for on-site calibrations

1. Additional hardware required. Please refer to the analyzer's Service Guide for required service test equipment.

## Global warranty

Keysight Technologies provides the peace of mind that today's high tech industry requires. Your investment is protected by Keysight's global reach in more than 100 countries (either directly or through distributors). The warranty gives you convenient standard coverage for the country in which the product is used, eliminating the need to ship equipment back to the country of purchase. Keysight's warranty service provides:

- All parts and labor necessary to return your investment to full specified performance
- Recalibration for products supplied originally with a calibration certificate
- Return shipment

## Express warranty

Reduce downtime with the fastest repair service in the industry. The express warranty upgrades the global warranty to provide:

- 5 day typical turnaround repair service in the US, Japan, China and many EU countries or up to a 10 day improvement in turnaround time in the rest of the world
- Priority return shipment

## One day start-up assistance

A Keysight Technologies applications engineer will get you started quickly by helping you install the modules in a chassis, configure the controller, load software and start making measurements.

## Calibration services

The modular products are factory calibrated and shipped with an ISO-9002, NIST-traceable calibration certificate. A one year calibration cycle is recommended. The M9381A PXIe VSG, M9393A PXIe Performance VSA and M937XA PXIe VNA M9391A PXIe VSA are supported by the Keysight N7800A Calibration Software to perform calibrations that test all product specifications and is compliant with ISO 17025:2005, ANSI/NCSS Z540.3-2006 and Measurement Uncertainty per ISO Guide to Expression of Measurement Uncertainty 1995.

## N7800A calibration & adjustment software

The M9381A PXIe VSG, M9391A PXIe VSA, M9393A PXIe Performance VSA and M937XA PXIe VNA are supported by Keysight's calibration and adjustment software. This is the same software used at Keysight's service centers to automate calibration. The software offers compliance tests for ISO 17025:2005, ANSI/NCSS Z540.3-2006, and measurement uncertainty per ISO Guide to Expression of Measurement Uncertainty.

Product Information: [www.keysight.com/find/contactus](http://www.keysight.com/find/contactus)

Or call: 1 800 829-4444 US

Repair and Calibration: [www.keysight.com/find/infoline](http://www.keysight.com/find/infoline)

Parts and Accessories: [www.parts.keysight.com](http://www.parts.keysight.com)

Email Updates: [www.keysight.com/find/emailupdate](http://www.keysight.com/find/emailupdate)

For all modular products: [www.keysight.com/find/modular](http://www.keysight.com/find/modular)

## Configurations


In each of the configurations shown below, the M9300A PXIe frequency reference needs to be ordered separately, or as an option to the M9381A PXIe VSG or M9391A/M9393A PXIe VSA.

Cables for module to module connections are shipped with the product.

Please see the startup guides for detailed cabling diagram and parts list:

- For M9381A PXIe VSG and M9391A PXIe VSA: literature number M9300-90090
- For M9393A PXIe Performance VSA: literature number M9393-90002
- For M937XA PXIe VNA: literature number M9370-90001

### RF PA/FEM Characterization & Test, Reference Solution with single 2-port M937XA PXIe VNA




### RF PA/FEM Characterization & Test, Reference Solution with multi-site measurement capability

The Keysight M937xA multi-site capability allows for each PXI module to behave as an independent VNA. This makes it possible to run measurements of different devices at the same time or different measurement paths in a single component. In addition, segment sweep enables you to optimize measurement conditions specifically for each device under test, so you can balance speed and accuracy.

For multi-site configurations that require either Option 010 and/or 102, a valid license is required for at least one module in each independent VNA configuration.

The Y1242A multipoint cable kit only needs to be ordered when modules are used in a multipoint configuration.





## Upgrading Your System

Your product can be easily upgraded after the initial purchase. All PXIe VSA and PXIe VSG options are controlled by a licensing key and can be quickly upgraded.

### How to upgrade your M9391A/M9393A PXIe VSA or M9381A PXIe VSG:

1. Contact your Keysight representative to place an order for an option upgrade.
2. You will receive your hardware entitlement certificate via email.
3. Redeem the certificate online by following the instructions provided to receive a license key file.
4. Install the license key file using the Keysight License Manager.
5. Begin using the new capability.

### How to upgrade your M937XA PXIe VNA:

1. Contact your Keysight representative to place an order for an option upgrade.
2. Return your instrument to a Keysight service center for upgrade and calibration.

## Using a Non-Keysight Chassis

The M9381A and M9391A/M9393A (with M9300A frequency reference) and M937XA can be successfully installed in a non-Keysight PXI chassis. Please use the following guidelines.

- Ensure that the chassis has 5 consecutive PXIe or PXI-H slots which can be used by the M9381A or M9391A/M9393A and M9300A and one available PXIe or PXI-H slot which can be used by the M937XA.
- Ensure that the chassis and controller supports peer-to-peer PXI Express I/O switch topology.
- Ensure that controller selected is compatible with chassis.

Please contact your Keysight representative for more detailed information. For technical assistance with non-Keysight equipment, please refer to the equipment manufacturer's website.

## PC Requirements for M9381A PXIe VSG, M9391A/M9393A PXIe VSA and M937XA PXIe VNA Control <sup>1</sup>

Windows 7 and Vista	
Operating system	Windows 7 (32 & 64 bit) Windows Vista, SP 1 & 2 (32 & 64 bit)
Processor speed	1.5 GHz dual core (x86 or x64) minimum, 2.4 GHz recommended No support for Itanium64
Available memory	4 GB minimum 8 GB recommended
Available disk space 1	1.5 GB available hard disk space includes: 1 GB for Microsoft.NET framework 3.5 SPI <sup>2</sup> 100 MB for Keysight IO libraries suite 1.5 GB available hard disk space includes: 1 GB for Microsoft.NET framework 3.5 SPI <sup>2</sup> 100 MB for Keysight IO libraries suite
Video	Support for DirectX 9 graphics with 128 MB graphics recommended (SuperVGA supported)
Browser	Microsoft Internet Explorer 7.0 or greater

1. For a list of computers compatible with Keysight Technologies PXIe M9018A chassis, refer to Tested Computer Technical Note (literature no. 5990-7632EN).
2. NET framework runtime components are installed by default with Windows Vista and Windows 7.  
Therefore, you may not need this amount of available disk space.

## Related Literature

For more detailed product and specification information refer to the following literature and web pages:

- RF PA/FEM Characterization & Test, Reference Solution, Brochure (literature no. 5992-0071EN)
- Increase Power Amplifier Test Throughput with the M9381A PXIe VSG and M9391A PXIe VSA (literature no. 5991-0652EN)
- M9381A PXIe VSG, Data Sheet (literature no. 5991-0279EN)
- M9391A PXIe VSA, Data Sheet (literature no. 5991-2603EN)
- M9393A PXIe Performance VSA, Flyer (literature no. 5991-4035EN)
- M937XA PXIe VNA, Data Sheet (literature no. 5991-4884EN)
- M937XA PXIe VNA, Startup Guide (literature no. M9370-90001)
- M9391A PXIe VSA and M9381A PXIe VSG, Startup Guide (literature no. M9300-90090).
- M9018A PXIe 18 slot Chassis, Data Sheet (literature no. 5990-6583EN)
- M9036A PXIe Embedded Controller, Data Sheet (literature no. 5990-8465EN)
- M9037A PXIe Embedded Controller, Data Sheet (literature no. 5991-3661EN)
- N6700B Low Profile Modular Power System Mainframe, Data Sheet (literature no. 5989-1411EN)
- N6780 Series Source/Measure Units for N6700 Modular Power System, Data Sheet (literature no. 5990-5829EN)
- U2000 Series USB Power Sensors, Data Sheet (literature no. 5989-6278EN)
- X-Series Measurement Applications for Modular Instruments, Brochure (literature no. 5991-2604EN)

**myKeysight**

**myKeysight**

[www.keysight.com/find/mykeysight](http://www.keysight.com/find/mykeysight)

A personalized view into the information most relevant to you.

[www.pxisa.org](http://www.pxisa.org)



PCI eXtensions for Instrumentation (PXI) modular instrumentation delivers a rugged, PC-based high-performance measurement and automation system.

**Three-Year Warranty**

[www.keysight.com/find/ThreeYearWarranty](http://www.keysight.com/find/ThreeYearWarranty)

Keysight's commitment to superior product quality and lower total cost of ownership. The only test and measurement company with three-year warranty standard on all instruments, worldwide.



**Keysight Assurance Plans**

[www.keysight.com/find/AssurancePlans](http://www.keysight.com/find/AssurancePlans)

Up to five years of protection and no budgetary surprises to ensure your instruments are operating to specification so you can rely on accurate measurements.



[www.keysight.com/go/quality](http://www.keysight.com/go/quality)

Keysight Technologies, Inc.

DEKRA Certified ISO 9001:2008

Quality Management System



**Keysight Channel Partners**

[www.keysight.com/find/channelpartners](http://www.keysight.com/find/channelpartners)

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

PCI-SIG®, PCIe® and the PCI Express® are US registered trademarks and/or service marks of PCI-SIG.

cdma2000 is a US registered certification mark of the Telecommunications Industry Association.

Bluetooth and the Bluetooth logos are trademarks owned by Bluetooth SIG, Inc., U.S.A. and licensed to Keysight Technologies, Inc.

WiMAX, Mobile WiMAX, WiMAX Forum, the WiMAX Forum logo, WiMAX Forum Certified, and the WiMAX Forum Certified logo are US trademarks of the WiMAX Forum.

[www.keysight.com/find/modular](http://www.keysight.com/find/modular)

[www.keysight.com/find/solution-padvt](http://www.keysight.com/find/solution-padvt)

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: [www.keysight.com/find/contactus](http://www.keysight.com/find/contactus)

**Americas**

Canada	(877) 894 4414
Brazil	55 11 3351 7010
Mexico	001 800 254 2440
United States	(800) 829 4444

**Asia Pacific**

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 6375 8100

**Europe & Middle East**

Austria	0800 001122
Belgium	0800 58580
Finland	0800 523252
France	0805 980333
Germany	0800 6270999
Ireland	1800 832700
Israel	1 809 343051
Italy	800 599100
Luxembourg	+32 800 58580
Netherlands	0800 0233200
Russia	8800 5009286
Spain	0800 000154
Sweden	0200 882255
Switzerland	0800 805353
	Opt. 1 (DE)
	Opt. 2 (FR)
	Opt. 3 (IT)
United Kingdom	0800 0260637

For other unlisted countries:  
[www.keysight.com/find/contactus](http://www.keysight.com/find/contactus)  
 (BP-09-04-14)

