
TEST LEADS

16048C



HEWLETT PACKARD

WARRANTY AND ASSISTANCE

All Hewlett-Packard products are warranted against defects in materials and workmanship. This warranty applies for one year from the date of delivery, or, in the case of certain major components listed in the operating manual, for the specified period. We will repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard. No other warranty is expressed or implied. We are not liable for consequential damages.

Service contracts or customer assistance agreements are available for Hewlett-Packard products that require maintenance and repair on-site.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

1. INTRODUCTION

This operating note provides complete information on the Hewlett-Packard Model 16048C Test Lead. The 16048C is shown pictorially on the front-cover and its physical dimensions are given in Table 1. To order additional copies of this operating note, use the part number listsed on the rear cover.

Table 1. Specifications.

Function: For use with Hewlett-Packard Models 4274A, 4275A, and 4192A.

Permits connecting odd-shaped components to the UNKNOWN terminals (4-terminal pair configuration) of the 4274A, 4275A, or 4192A.

Probe: Dual alligator clip type.

DC Bias: ±35V maximum

Cable Length: Approximately 1m (39.4 inches)

Weight: 325 grams (0.717 lbs.)

Applicable Measurement Range: Capacitance > 1000pF, Inductance > 100µH

Frequency Range: 100kHz maximum

Note: Residual parameter values. C < 5pF, L < 200nH, $R < 10m\Omega$

2. DESCRIPTION

The Model 16048C Test Fixture $\,$ is designed for use $\,$ with the following instruments:

Model 4192A LF Impedance Analyzer

Model 4274A Multi-Frequency LCR Meter

Model 4275A Multi-Frequency LCR Meter

The 16048C consists of a direct attachment, 4-terminal pair type fixture which is equipped with two large, insulated alligator clips. These alligator clips make it possible to measure odd-shaped components that cannot be measured with conventional test fixtures. Maximum frequency is 100kHz. Cable length is approximately 1 meter. The 16048C is shown in Figure 1.




Figure 1. 16048C Test Leads.

3. ZERO OFFSET ADJUSTMENT

The 16048C has inherent stray capacitance, residual inductance, and residual resistance that affect the accuracy of measured values. To compensate for, or negate, these residuals to minimize measurement error, the instrument's zero offset adjustment procedure should be performed. The procedue is given in Section III of the instrument's operating manual.

Note

When performing OPEN or SHORT zero offset adjustment for the 16048C on the 4274A, the OSC LEVEL (V) of the 4274A should be set to maximum. OPEN and SHORT zero offset adjustment for the 16048C on the 4275A cannot be performed. This does not, however, mean that the 16048C cannot be used with the 4275A; it simply means that the measured value of the DUT will include the residuals of the test leads.

4. OPERATION

Setup and measurement procedure is as follows:

- a. Set the CABLE LENGTH switch (4275A and 4192A only) on the instrument's front-panel to lm.
- b. Connect the 16048C directly to the UNKNOWN terminals of the instrument.
- c. Perform ZERO OFFSET ADJUSTMENT (4274A and 4192A only) as described in section III of the instrument's operating manual.
- d. Connect the DUT to the test leads.

5. MAINTENANCE

An exploded view of the 16048C — for parts identification — is shown in Figure 2. Do not disassemble any further than shown. Maintenance consists principally of cleaning contacts and replacing worn or damaged parts. Take special care when cleaning contacts. To order parts, use the Hewlett-Packard part numbers listed in Figure 2. If a faulty part is located in an assembly that cannot be disassembled, order the next higher assembly or return the whole device to the nearest Hewlett-Packard Sales/Service Office for repair or replacement.




Figure 2. Parts Identification for 16048C (Sheet 1 of 2).

Reference	HP Part No.	Qty	Description	Note
1 2 3 4 5	0362-0007 16047-24000 2950-0043 2190-0878 3050-0789	4 4 4 4	SLEEVE NUT NUT WASHER WASHER	
6 7 8 9 10	2360-0192 16047-04002 16047-40002 16038-30021 16012-7122	2 1 4 2 2	SCREW COVER-BOTTOM INSULATOR CONNECTOR-BNC CONNECTOR-BNC	
11 12 13 14 15	16048-04002 2200-0105 3050-0229 16047-40000 2260-0009	1 1 1 1	COVER-TOP SCREW WASHER STOPPER NUT	
16 17 18 19 20	1400-0719 0400-0011 8120-0367 16048-61602 2360-0190	2 1 1 1 2	TIE RAP GROMMET CABLE ASS'Y-CABLE SCREW	
21 22 23 24 25	0400-0010 1400-0493 16048-04004 0362-0215 16034-00600	1 1 1 4 1	GROMMET CABLE TIE COVER-TOP CONTACT SHIELD PLATE	
26 27 28 29 30	0400-0009 16048-04003 2360-0190 8120-0041 4093-0120	2 1 1 4	GROMMET COVER-BOTTOM SCREW WIRE MOLD	
31 32 33 34 35	16036-8521 16036-7021 16036-8522 16036-1024 16036-1022]]]]	SPRING ASS'Y-CLIP INSULATION FILM SPRING CLIP	,
36 37 38	16036-5121 16036-7511 16048-61603 16048-61604	2 1 1 1	PROBE SHELL ASS'Y-PROBE ASS'Y-CABLE BLACK ASS'Y-CABLE RED	3) thru 35 29 and 30 29 and 30

Figure 2. Parts Identification for 16048C (Sheet 2 of 2).