


X1	
Цепь	Комп.
UDU	13
DOO	19
DO1	20
DO2	21
DO3	22
DO4	18
DO5	17
DO6	16
DO7	15
DO8	7
DO9	6
DO10	5
DO11	1
DO12	2
DO13	3
DO14	8
DO15	9
DO16	10
DO17	11
DO18	12
DO19	14
DO20	15
DO21	16
DO22	17
DO23	18
DO24	19
DO25	20
DO26	21
DO27	22
DO28	23
DO29	24
DO30	25
DO31	26
DO32	27
DO33	28
DO34	29
DO35	30
DO36	31
DO37	32
DO38	33
DO39	34
DO40	35
DO41	36
DO42	37
DO43	38
DO44	39
DO45	40
DO46	41
DO47	42
DO48	43
DO49	44
DO50	45



Позиционное обозначение микросхем	Номер вывода подключенного к цепи	
	+58	корпус
Д1, Д2, Д5... Д8, Д11, Д12	14	7
Д3	16	8
Д4	20	10

КТ - контрольная точка

Рис. 44